LAND CRUISER Station Wagon (EWD575E)

H OVERALL ELECTRICAL WIRING DIAGRAM

Power Source

Seat Belt Warning

* 1 : w/ Navigation System
* 2 : w/o Navigation System
* 3 : w/ Driving Position Memory
* 4 : w/o Driving Position Memory

1 2 3 4

ACC
IG1 4
2 AM1
W-R
7 AM2
IG2 6
ST2
I26
Ignition SW

J24
Junction
Connector

J14
Junction
Connector

10A ECU-B2
25 3B
44 3Q

C32
Center Cluster
Integration Panel
8 IG
20 S/BW
21 3N
11 3N

A57(A), A59(C)
A/C Control Assembly
22 C
IG
30 A
I-SBW

41 2E
10 2A

24 1B
9 1B
39 2E
6 2D
25 2D
65 2Q
37 2E

30A BAT
15A AM2
15A A/C
10A GAUGE1

Short Pin (A)

7.5A AM1

IG1 NO.2 Relay

1 1C
1 2C

2 A
1 B

F37(A), F38(B)
Fusible Link Block

120A J/B NO.2

120A MAIN
140A ALT

Battery
Battery

B
(Diesel)

Set Bolt of
Cowl Side
J/B LH
IF

7.5A MET
4 3E
7 3Q

C15(A), C17(C), C18(D)
Combination Meter
Seat Belt

10 A
11 D
12 D
1 D
11 C

8 IV1

41 2Q
10 2G
18 2K

(Except 1HD-FTE)
EC

(1HD-FTE)
ED

Rear Bank of
Right Cylinder
Head (2UZ-FE)
Rear Bank of
Left Cylinder
Head (1FZ-FE, 1HZ)

Rear Bank
of Left
Cylinder Head

Body ECU
<1-52>

3 Bb1
5 BS3
2

B10
Buckle SW LH
1
3

4 BS3
1 Bb1

J31
Junction
Connector
E
E

Airbag Sensor
Assembly<24-8>

BJ Under the Front Seat LH

2
B15
Buckle SW LH
1
3
4

Airbag Sensor
Assembly<24-8>

26 3D
21 3K

3 Bd1

5 BU3

S17
Seat Belt Warning
Occupant Detection
Sensor

B11
Buckle SW RH

4 BU3
1 Bd1

Front Side
Under the Front
Seat RH
BK