REASSEMBLY

BO1X4–01

Reassembly is in the reverse order of disassembly (See page BO–205).