

REASSEMBLY

1. 1FZ-FE, 2UZ-FE, 1HZ Engine: INSTALL CLUTCH ACCUMULATOR


Using SST, install the accumulator with a new gasket.

SST 09922-10010


Torque: 32 N·m (330 kgf·cm, 24 ft·lbf)

HINT:

Use a torque wrench with a fulcrum length of 345 mm (13.58 in)



- 2. COAT PARTS WITH LITHIUM SOAP BASE GLYCOL GREASE, AS SHOWN
- 3. INSERT PISTON AND SPRING INTO CYLINDER
- 4. INSTALL PUSH ROD ASSEMBLY WITH SNAP RING



5. INSTALL RESERVOIR TANK

- (a) Install the reservoir tank and a new grommet.
- (b) Using a pin punch and hammer, drive in the slotted spring pin.