19 LAND CRUISER (RHD) Stop Light Power Source 3 2 G-R ABS ECU<22-6> ABS & BA & TRC & G-W VSC ECU<21-6> Suspension Control G-W ECU<24-7> G-W 26 (2E) * 1 : Swing Type * 2 : Liftgate Type * 3 : 2UZ-FE * 4 : 1HD-FTE 71 (2Q) * 5 : w/ Navigation System * 6 : w/o Navigation System G-W G-W 5 (2M) (*3) 2 BK2 (\$2) 8 (6D) 36 (6D) 20 **3**Q STPI Engine ECU - Engine and ECT ECU <8-16><9-11><10-14> Body ECU 3 BK2 (*5) 5 BK2 (* Stop/ Stop/ Tail 6 BP2 (Diesel) W-B Battery Battery (*<u>1</u> Left Rear Side Quarter Panel Front Side Under the Front Under the BK/ Front Seat LH Seat RH

OVERALL

Ш

E

CTRICAL WIRING DIAGRAM