DIRRI I_04

6. Screen cannot be dimmed in hight time.

11	VS	PE	CT	10	N	PR	O	CE	Dl	JRI	Ε
	•		•	. •			_		_		_

1 Check[if[]the[screen[]s[dimmed[at[]night.[[With[]the[]ight[control[]switch[]ON),[do[all screens[except[]the[]navigation[screen[]appear[]n[Night[Mode?)]

NG□

Check[the[light[control[switch.

OK

2 | Check[the[multicdisplay.

CHECK:

Measure[]he[]voltage[]between[]erminals[]DR[]and[]GND1[]of[]he[]nulti-display.

OK:

DR: Above 97

NG

Replace or repair wire harness.

OK

3 Check[multi-display[power[source[circuit[see[page[DI-259].

NG

Replace or repair wire harness.

OK

Replace the multi display.