## 4 LAND CRUISER (RHD) Power Source Ignition (2UZ-FE) 2 3 J14 Junction ST2 I26 Ignition SW 8 lb5 Engine ECU Engine and ECT ECU<8-13><8-14> IGT +B +B IGT GND GND GND GND GND GND GND GND W-B B-W B-R F37 Fusible Link Block 120A MAIN 7 lh1 Engine ECU Engine and ECT ECU <8-14> Rear Bank of Right Cylinder Head