DIAS7-01

DTC C1516 / 16 VGRS Actuator Neutral Position Incomplete

CIRCUIT DESCRIPTION

This code is set when the VGRS system calibration procedure does not complete normally.

DTC[No.	DTC[Detecting[Condition	Trouble[A rea
C1516/16		

INSPECTION PROCEDURE

1 Clear DTC See page DI – 348).

NEXT

2 | Perform[VGRS[\$ystem[calibration[(See[page[DI-357).

NEXT

3 Is DTC C1516/16 output?

NO

VGRS system calibration is completed.

YES

4 Is DTC C1532/32 output?

YES

Replace VGRS ECU.

NO

Proceed to step 5.

5	Is DTC C1516/16 output after 3 or more attempts?	
	YES Replace VGRS actuator.	
NO		
Go to	step 1	