## **CIRCUIT INSPECTION**

DI88P-01

# 1. Black screen (Nothing displayed)

## **INSPECTION PROCEDURE**

1 Check the ECU-IG fuse.

NG

Replace the fuse.

OK

2 Check multi-display.

#### **PREPARATION:**

Disconnect the mult- display connector.

#### **CHECK:**

Check voltage terminals +B.

OK:

+B: 10 - 14 V

#### **CHECK:**

Check voltage terminal ACC when turn ignition switch ACC or ON position.

OK:

ACC: 10 - 14 V

**CHECK:** 

Check continuity terminal GND.

<u>OK:</u>

**GND: Continuity** 

NG

Replace or repair wire harness or connector.

OK

Replace the mult-display.