DI897-06

19. Navigation screen cannot change to the hight mode color.

INSPECTION PROCEDURE	
1[Check[the[setting.[(ls[it[set[to[Day[Mode[in[screen[adjustment?)
	Yes ☐ Normal
No	
2[]	Check[]f[]the[]screen[]s[dimmed[]at[]hight.[(With[]the[]ight[]control[]switch[]ON,[]do[]all screens[]except[]the[]havigation[]screen[]appear[]n[Night[]Mode?)
	NG Go to step 5.
ОК	
3[]	Does[the[beep[sound[by[operating[switches[on[the[havigation[screen?
	OK Replace havigation ECU.
NG	
4[]	Check[]*AVC-LAN@communication@circuit**.[(See@page@DI-275)
	NG Replace or repair AVC-LAN circuit.
ОК	
Replace the navigation ECU.	

5 Check the multi display.

CHECK:

Measure the voltage between terminal DR and GND1 of the multi-display.

<u>OK:</u>

DR: Above 9 V

OK Replace the multi display.

NG

Replace or repair wire harness.