$\textbf{DIAGNOSTICS} \square \ -$

DI6XC-02

DTC	C1289∏⊈1∏	VGRS[Malfunction
-----	-----------	------------------

CIRCUIT DESCRIPTION

DTC[No.	DTC[Detecting[Condition	Trouble[A rea
C1289 <u>∏</u> [41	VGRS@ontrol@system@s@bnormal.	VGRS@ontrolsystem

INSPECTION PROCEDURE

1[Check[the[DTC[for[the[VGRS[(See[page[DI-185).
----	---

Repair VGRS control system according to the code output.

***2**

Check for ECU connected to malfunction indicator light.

- *1: Output NG code
- *2: Malfunction indicator light remains ON