DIAZJ-01

DTC P0607/54 Control Module Performance

CIRCUIT INSPECTION

 $This \verb|[DTC]| \verb|expresses|| \verb|[]| he \verb|[]| internal \verb|[]| abnormalities \verb|[]| of \verb|[]| ECM.$

DTC[No.	Detection <u>[</u> tem	Trouble[Area
P0607/54	©ruise@ontrol@nput[signal@bnormal. Stop@ight[switch@nput[signal@bnormal.	•ECM

INSPECTION PROCEDURE

Check[and[replace[ECM[[See[page[]N-38]].