HOW[TO[TROUBLESHOOT[ECU[CONTROLLED[\$YSTEMS

GENERAL INFORMATION

IN005-05

System	Page
1. Engine	DI-1
2. Sub Fuel Tank System	DI-1 <u>B</u> 1

The troubleshooting procedure and how to make use of it are described on the following pages.