DIAGRAM

42 LAND CRUISER (LHD) * 1 : w/ Navigation System * 2 : w/o Navigation System * 3 : w/ Driving Position Memory * 4 : w/o Driving Position Memory Power Source Seat Belt Warning 2 ACC IG1 22(C) IG2 6 Passenger Passenger Seat Belt Seat Belt ST2 Warning Warning Light Light S/BW I-SBW 37 **2E** 24 (1B) 9 (1B) 6(2D) 25 (2D) 65 (2Q) I26 Ignition SW 30(A) (* 2) 10A GAUGE1 S17 Seat Belt Warning Occupant Detection Sensor IG1 NO. : 7. 5A AM1 C15(A), C17(C), C18(D) Combination Meter Bd1 1 (2C) 1**(**B) B11 Buckle SW RH 120A J/B NO. 2 (*3) ¥-E 120A MAIN 1 Bb1 4 BU3 10 (2G) 1 Bd1 (Diesel) Battery Battery Rear Bank of Right Cylinder Head (2UZ–FE) Rear Bank of Left Cylinder Head Set Bolt of Cowl Side Under the Front Seat LH Front Side Under the Front BK J/B LH Left Cylinder Seat RH Head (1FZ-FE, 1HZ)