## 9400 Obtain Firmware Versions

## **Using SCPI Test Panel:**


Using the controlling PC, start the SCPI Test Panel:

"Start->All Programs->NH Research->9400->SCPI Test Panel"

Connect to the 9400 system and then send the "DIAG:NHR:VERS?" command to capture the current firmware version.

## **Using 9400 Soft Panel**

Using the controlling PC and running the NHR 9400 Panel software, on the top right corner click the "Info" button and then expand the General Information.



Using the controlling PC and running the NHR 9400 Panel software, send the "DIAG:NHR:VERS?" command to capture the current firmware version.

