

How to interpret these values can be seen in the sheet "Meanings"

Meaning of solar status P1090

P1090	Description
0	Init
1	Wait for Init
2	Wait for grid management
10	Ready
11	Ready+warning
20	Undervoltage
30	Mains synchronization
40	MPP tracking
41	MPP Tracking+Warning
42	MPP maximum
43	MPP minimum
44	MPP+FastSearch
50	Fault
51	Fault+Warning
60	AutoAcknowledgement
100	Slave mode

Meaning of current error P259/P260

P260 decimal value	P259 Error code	Description
0	F0000	No error
256	F0100	IxT
258	F0102	long-term Ixt
259	F0103	short-term Ixt
512	F0200	Heat sink overtemperature
513	F0201	Heat sink sensor
768	F0300	Inside temperature
769	F0301	Undertemperature
770	F0302	max . Overtemperature
774	F0306	Max Temperature Gradient
784	F0310	Critical failure
785	F0311	DC circuit points interchanged
1027	F0403	Transformer overtemperature
1028	F0404	Insulation
1029	F0405	Mains monitoring
1030	F0406	Overvoltage monitoring
1031	F0407	Main contactor monitoring
1033	F0409	Transformer magnetization
1042	F0412	Mains monitoring device
1043	F0413	Fault Diagnostics S2IND or S4IND
1056	F0420	Mains overfrequency
1057	F0421	Mains underfrequency
1058	F0422	Mains synchronisation
1059	F0423	Mains Islanding
1061	F0425	Effective Power AC DC diff
1062	F0426	Left rotating field
1280	F0500	Overcurrent
1281	F0501	Uce monitoring
1282	F0502	Dynamic string current limitation
1285	F0505	Earth fault overcurrent
1286	F0506	Overcurrent
1287	F0507	Overcurrent
1328	F0530	negative I DC-link
1329	F0531	short circuit DC-link
1330	F0532	over-current DC-link
1331	F0533	Idc although Pac=0
1344	F0540	Iac although Pac = 0
1792	F0700	DC Overvoltage
1794	F0702	Mains failure
1840	F0730	DC Short Circuit
2048	F0800	Electronic voltage 15 V too low
2049	F0801	Electronic voltage 24 V too low
2052	F0804	Electronic voltage 24 V too high
2304	F0900	Precharge contactor
2305	F0901	Precharge contactor neg Current
2336	F0920	DC switch defect
2337	F0921	DC switch opened during operation
2338	F0922	Feedback motor switch
4609	F1201	Diagnosis error STO
4613	F1205	STO 5s monitoring.
4864	F1300	Earth fault
8704	F2200	Communication error system bus,

Error code = "F" & P260 as HEX value

Meaning of warnings P269/P270

P270 decimal value	P269 Warning code	Warning message text
0	A0000	"No Warning"
1	A0001	"Warning Ixt"
2	A0002	"Warning short-term Ixt"
4	A0004	"Warning long-term Ixt"
8	A0008	"Warning heat sink temperature Tk"
16	A0010	"Warning inside temperature Ti"
32	A0020	"Warning I-limit"
64	A0040	"Warning Init"
8192	A2000	"Sysbus"
16384	A4000	"Low DC Voltage"
32768	A8000	"Warning Application"(see also P273/P274)

Warning code is the hexadecimal sum of all occurred warning codes

Example:

"Warning Application" + "Warning I-limit"

A8000 + A0020 = A8020 = "Warning Application + Warning I-limit"

Warning code = "A" & P270 as HEX value

Meaning of warnings P273/P274

P274	P273	Warning message text
0	A0000	"No Warning"
1	A0001	"Light"
64	A0040	"Mains"
128	A0080	"Power reduction"
1024	A0400	"PowerRed. 0V"
2048	A0800	"P.1105on"
8192	A2000	"Check fan"
16384	A4000	"Power Limit"
32768	A8000	"DC Switch"