

D-Modem

AT Command Reference

The modem core of `dmodemd`, libdmodem and the `PBX` modules

Version 1.0.0

October 2026

Contents

1 Introduction 3
2 Common Terms 5
3 Command Summary 8
4 Command Lines 10
5 Echo and Result Code Settings 11
6 Settings and Profiles 16
7 Identification and Diagnostics 18
8 Dialling, Answering and Hanging Up 24
9 Speaker, Line and Country 30
10 Modulation 33
10.1 V.cvm . . . 39
10.2 V.92 Call Waiting and Modem-on-Hold . . . 40
11 Error Control 42
11.1 V.80 Synchronous Access . . . 45
12 Data Compression 49
13 DTE Interface and Flow Control 54
14 ISDN and Cellular 58
15 Result Codes 61
16 S-Registers 63
16.1 S-Register Definitions . . . 64
17 Fax Commands 72
17.1 Class 2 and 2.0 . . . 76
18 Text Telephone Commands 81
19 Voice Commands 85
19.1 Voice Events . . . 90
19.2 From Voice to Fax or Data . . . 91
20 Online, the Escape and Hanging Up 93
21 dmodemd on a SIP Line 94
22 Compatibility 95
22.1 Where D-Modem Differs . . . 95
22.2 Not Supported . . . 95
23 Glossary 96

Term	Meaning
PPP	Point-to-Point Protocol. How a computer carries the internet over a modem call.
PREP, ACK, TERM	Preparatory, Acknowledgement and Termination. V.54's signals to start, confirm and end a remote loop test.
PSTN	Public Switched Telephone Network. The ordinary telephone network.
Retrain, renegotiation	Modems re-measuring the line during a call (retrain), or changing only the rate (renegotiation).
Robbed-bit signalling	A digital network taking a bit of some samples for its own use, which a V.90 modem must allow for.
RTTY	Radio Teletypewriter. Baudot over radio, as radio amateurs send it.
SNR	Signal-to-Noise Ratio. How far the signal stands above the noise, in dB.
SYN	Synchronous idle. The idle octet of V.80's synchronous mode.
T.30	The fax protocol: its messages, phases and timers.
Type II caller ID	The caller ID of a waiting call, sent during a call.
Unimodem	Windows' modem driver; #UD gives its diagnostics.
V.8	The start of a modern call, where the modems tell each other what they have.
V.cvm, V.wb	D-Modem's data over mobile speech paths, and its wideband modem for a dry pair.
X.75, V.110, V.120	Protocols on an ISDN data channel (+B2).
XID	Exchange Identification. V.42's message that agrees the compression.
XON, XOFF	Transmit On and Transmit Off. The characters (DC1 and DC3) that start and stop the flow of data.
zstd	Zstandard. A modern compression D-Modem offers between two D-Modems (+DSZ).

1 Introduction

This manual specifies the AT command set of D-Modem's modem core (core/ in the source). The core takes the commands of every D-Modem program:

- dmodemd, the modem on a pseudo terminal (/dev/ttyDM0 links to it), its line a SIP call or, with -a and -usb, an analogue telephone line;
- **libdmodem** (dmodem.h), the modem as a library: the program that embeds it sends the commands;
- the **Asterisk and FreeSWITCH modules** (app_dmodem, mod_dmodem), whose profiles give the commands each call starts with.

Feature Overview

- **Data** from 300 bit/s to 56000 bit/s: V.21, V.22, V.22bis, V.23, Bell 103 and 212A, V.32, V.32bis, V.34 up to 33600 bit/s, and V.90 and V.92 as the digital modem. Automode finds the best modulation both ends have (Section 10).
- **Error correction and compression**: V.42 (LAPM) and MNP 2 to 5; V.42bis, V.44, MNP 5 and zstd (Sections 11 and 12).
- **V.92's extras**: quick connect, PCM upstream and modem-on-hold, to take a waiting call and come back to the data call.
- **Fax**: Class 1 (T.31) and Class 2 and Class 2.0 (T.32), up to 14400 bit/s with V.17, and adaptive answer, which tells a fax call from a data call (Section 17).
- **Voice** (V.253): play and record audio, send and detect DTMF and tones, use a handset, and turn a voice call into a fax or data call (Section 19).
- **Text telephones** (V.18): the 5-bit TTY of the deaf community, telex and RTTY, EDT, and automoding between them (Section 18).
- **Caller ID**, from a SIP call or a telephone line (FSK and DTMF), and a waiting call's caller in voice mode.
- **Leased lines**, 2-wire and 4-wire (V.29, V.33, V.27ter), with V.13's simulated carrier control.
- **Digital channels**: V.91 between two digital modems, the clear 64000 bit/s channel of an ISDN data call (X.75, PPP, V.110, V.120) (Section 14), and V.80's synchronous access.
- **V.cvm** for data over mobile speech paths, and **V.wb**, a wideband modem for a dry pair.
- **Diagnostics**: the last call's statistics (ATI11, AT&V1, AT#UD) and loop tests (AT&T).
- **Other modems' setup strings** work: the modem accepts the commands of V.250, Rockwell and Conexant, and USRobotics modems, most of them with no effect; their entries say so.

Every command, range, *default* and response in this manual is the core's own. A setting that is kept but changes nothing says so.

How to Read This Manual. Each command has an entry of the same form: its name and title in a strip, what it does, then where it has them its syntax, its result codes and a numbered table of its values, the *default* marked *(default)*. Table 1 lists every command and links to its entry. Commands are shown in capitals; the modem takes either case. *n* is a decimal number, *h* a hexadecimal one; [ ] marks what may be left out. A setting's *default* is the one ATZ and the start of the program give.

The text is styled by what it is:

- Red monospace is a command or part of one, as you type it (ATD, +MS=V92); where it is a link it leads to that command's entry.
- Monospace on blue is what the modem sends back: a result code or other response, as it appears on the DTE's screen (OK, CONNECT 33600, NO CARRIER).
- Plain monospace is a standard, a signal or a term from one (V.34, CNG), an acronym (DTE), or a number such as a speed (33600 bit/s).
- *Italics* stand for a value you fill in (ATS*n*).

Term	Meaning
DIL	Digital Impairment Learning. The V.90 and V.92 sequence that measures the digital network.
DIS, DTC, DCS	Digital Identification Signal, Digital Transmit Command and Digital Command Signal. The fax messages that offer (DIS), ask for polling (DTC) and choose (DCS) the session's settings.
DLE	Data Link Escape (10h). In fax and voice modes, the character that starts a code in the data, such as <DLE><ETX>.
DMT	Discrete Multitone. Many carriers side by side, as in V.wb and ADSL.
ECM	Error Correction Mode. Fax pages sent in frames, and repeated where damaged.
EDT	European Deaf Telephone. A text telephone at 110 bit/s (V.18).
ETSI	European Telecommunications Standards Institute. The European standards body.
FSK, DPSK, QAM	Frequency Shift Keying, Differential Phase Shift Keying and Quadrature Amplitude Modulation. Ways of putting data on a carrier: by its frequency, by its phase, by phase and size together.
HDLC	High-level Data Link Control. Frames with flags and an FCS, the basis of LAPM, of fax's T.30 messages and of PPP.
ISDN	Integrated Services Digital Network. Digital telephone lines with 64000 bit/s channels.
ITU-T	International Telecommunication Union, Telecommunication Standardization Sector. The standards body whose recommendations are V.... (modems), T.... (fax) and so on.
Leased line	A permanent line between two modems, with no dialing; 2-wire or 4-wire (&L).
LR, LD	Link Request and Link Disconnect. MNP's messages that start and end its link.
MDMF, SDMF	Multiple Data Message Format and Single Data Message Format. The two forms of a caller ID message.
MH	Modified Huffman. The plainest fax page coding (T.4).
Modem-on-hold	V.92's way to put a data call on hold to take another call (+PMH).
PBX	Private Branch Exchange. An office telephone system, such as Asterisk or FreeSWITCH.

23 Glossary

Term	Meaning
A-law, u-law	The two ways G.711 codes telephone audio in 8 bits: A-law in Europe, u-law in North America and Japan.
ADPCM	Adaptive Differential Pulse Code Modulation. Compressed audio, one of the voice formats of +VSM.
ADSI	Analog Display Services Interface. A telephone's screen and keys, driven by tones.
ALSA	Advanced Linux Sound Architecture. The sound system of Linux; dmodemd uses it to reach a telephone line through a sound card.
Automode	Trying modulations from the fastest down until both modems have one (N, +MS).
Baudot	The 5-bit code (ITA2) of teleprinters, of the deaf community's TTY, of telex and of RTTY.
Bell 103, Bell 212A	The North American 300 and 1200 bit/s modulations, akin to V.21 and V.22.
CAPI	Common ISDN Application Programming Interface. The programming interface of ISDN cards; +B2 uses its numbers.
CED, CNG	Called terminal identification and Calling tone. The fax answer tone (2100 Hz) and the calling fax's tone (1100 Hz).
CIG, CSI, TSI	Calling subscriber identification, Called Subscriber Identification and Transmitting Subscriber Identification. The fax identities of the poller, the answerer and the caller (+FLI).
Class 1, Class 2, Class 2.0	The fax command sets: in Class 1 (T.31) the DTE runs the fax protocol, in Class 2 and Class 2.0 (T.32) the modem does.
Clear channel	A 64000 bit/s digital channel used as it is, with no modulation, as in an ISDN data call.
CPE	Customer Premises Equipment. The equipment at the subscriber's end of a line.
CRC, FCS	Cyclic Redundancy Check and Frame Check Sequence. A checksum on a frame that shows whether it arrived damaged.
DCD, DSR, DTR, RTS, CTS	Data Carrier Detect, Data Set Ready, Data Terminal Ready, Request To Send and Clear To Send. The serial port's control signals.

2 Common Terms

A few words this manual uses throughout. The glossary (Section 23) explains the rarer ones.

AT command
AT stands for "attention". An instruction to the modem, sent as text that starts with the letters AT, such as ATZ. One line can hold several commands (ATE1Q0V1).

Basic and extended commands
Basic commands are a letter, maybe after &, \, or %, and a number (E1, &K3). Extended commands start with + or - and take values (+MS=V92).

Baud
Symbols per second: how many times a second the modem changes its signal. Each symbol can carry several bits, so a connection's bit/s is often higher than its baud: V.34 sends up to 3429 baud but 33600 bit/s. Older modems were sold by baud, which is why the two words are often mixed up.

bit/s
Bits per second, the speed of a connection; CONNECT gives it.

Carrier
The signal the far modem sends during a call. Losing it ends the call (NO CARRIER).

Command mode and online mode
In command mode the modem reads what the DTE sends as commands. Once a call is up (CONNECT) it is online: what the DTE sends goes to the far end as data. The escape sequence (+++, with a pause before and after) returns to command mode with the call kept, and ATO goes back online (Section 20).

DCE
Data Circuit-terminating Equipment. The modem: what sits between the DTE and the telephone line or call, here D-Modem itself.

Default
A setting's value after ATZ or when the program starts. The modem keeps no stored profiles.

Dial string
What follows ATD: the number and the modifiers that change how it is dialed (T, P, W, , and so on).

Dry pair
A pair of copper wires with nothing on it: no telephone exchange, no battery voltage and no dial tone, such as two modems wired to each other directly. A modem uses it as a leased line; V.wb runs only on one.

DTE
Data Terminal Equipment. The computer or program that talks to the modem: a terminal program, a fax program, `pppd`, or the program that embeds libdmodem.

DTMF
Dual Tone Multi-Frequency. The tones of a telephone keypad, two at once for each key. The modem dials with them (`T`), and hears them in voice mode and in `DTMF` caller ID.

Error correction and compression
Error correction (`V.42`, `MNP`) resends data the line damaged; compression (`V.42bis`, `V.44`) packs it to go faster. Both need the far modem to have them too.

Fax
Facsimile. Sending a page as an image over a telephone line: the fax machine scans the page and its modem sends it to another fax machine, which prints it. This modem can act as a fax machine's modem for a fax program on the `DTE` (Section 17).

ITU
International Telecommunication Union. The United Nations agency for telecommunications. Its standards sector, ITU-T, writes the recommendations modems follow: the V.... series for modems (`V.34`, `V.92`), T.... for fax (`T.30`), G.... for audio (`G.711`) and so on.

LAPM
Link Access Procedure for Modems. `V.42`'s error correction, the one most modems use: data goes in numbered frames with a checksum, and a damaged frame is sent again.

Leased line
A permanent connection between two modems, with no dialing, ringing or dial tone: each end starts at once (`&L`). A 2-wire leased line carries both directions on one pair; a 4-wire line has a pair for each direction.

MNP
Microcom Networking Protocol. An older family of error correction (classes 2 to 4) and compression (class 5), from before `V.42`; many modems still have it (`\N`).

Modem
Modulator-demodulator. A device that turns a computer's data into sound that can travel over a telephone line, and turns the sound from the far end back into data. D-Modem does this in software, with no modem hardware.

Modulation
How the modem turns data into sound on the line, and so how fast it goes: `V.34`, `V.90`, `V.92` and the rest, chosen with `+MS`.

PCM
Pulse Code Modulation. Sound as numbers: the telephone network carries a call

22 Compatibility

22.1 Where D-Modem Differs

- `&K` is the compression, as on USRobotics' modems; on Rockwell's and Conexant's it is flow control. `&K3` leaves `V.42`'s compression on (`MNP 5` off), `&K0` turns it off.
- The S-registers past `S16` are D-Modem's own: `S29` and `S30` are the speaker's (elsewhere the hook flash time and the inactivity timer), `S92` the answer's delay (elsewhere a fax transmit level). The others (`S36`, `S37`, `S91` ...) are free: kept as written. `S7` and `S11` start at 60 and 100.
- There are no stored numbers or profiles: `&Z` and `ATDS=`*n* are `ERROR`, `&W` stores nothing.
- `ATI`'s numbers are the modem's own (`I0` to `I7`), but for the call statistics: `I6` as USRobotics', `I11` as Conexant's, `&V1` as Rockwell's.
- The numeric results (`V0`) and `CONNECT`'s number for each rate are D-Modem's own; those of USRobotics' and Conexant's modems differ.
- `MNP` is classes 2 to 5 (`\N`, `%C`): there is no `MNP 10` or 10EC. A modem with `MNP 10EC` connects with `V.42` (its "EM" detection patterns are passed over). See `docs/link.md`, `MNP`.
- K56flex is not there: `+MS=56` runs `V.90`.

22.2 Not Supported

These are `ERROR`: `&V2` and up, `&Z` (no stored numbers), `&T2` and `&T9` and up, `\B` (a break), `X5` and up, `ATI8` to `ATI10` and `ATI12` and up, `-V90` (`+MS` chooses), `+MA`, `+MSC`, `+EB`, `+ESR`, `+ETBM`, `+EWIND`, `+EFRAM`, `+A8E`, `+A8T`, `+PMHF`, `+GSN` and `+GOI`; `+MS`'s names of modulations the modem has not got (`V23S`, `V26B`, `V26T`, `V27` ...).

21 dmodemd on a SIP Line

- ATD*number* calls sip:*number*@*domain* of SIP_LOGIN. A telephone number (only V.250's dial characters: digits, * # + A B C D, the modifiers T P W , @ ! ; and - ( ) . and blanks) goes as its digits and DTMF characters: ATDT555-1000 calls sip:5551000@*domain*. Anything else is a SIP user's name, as it is: ATDalice.
- The line has no dial tone: ATX3 (or X1), else NO DIALTONE.
- A dial string with a ; (ATDT5551000;) makes the SIP call and says OK at once, the modem in command state: what ATD adds then goes as DTMF on the call (a menu's choices, an extension), and ATD alone or ATA starts the modem's handshake.
- With -L dmodemd registers and takes calls: RING every 3 seconds while one waits, ATA or S0 rings (ATS0=1) answer it, and the rings stop if the caller gives up. A call that comes while the line is in use is refused (486, busy); without -L every call is (480).
- The call is G.711 at 8000 Hz, which is what V.90 and V.92 need (AT+MS=92, the *default*). Over a real PSTN gateway a lower modulation (AT+MS=132,0,4800,9600) may do better.

as 8000 8-bit samples a second (G.711). V.90 and V.92 send data as these numbers, which is how they reach 56000 bit/s.

Result code
: The modem's answer to a command line, or news of a call: OK, ERROR, CONNECT, RING, NO CARRIER and so on (Section 15).

S-register
: A numbered setting, read with ATS*n*? and set with ATS*n*=*value* (Section 16).

SIP
: Session Initiation Protocol. The protocol of internet telephony. dmodemd places and takes its calls as SIP calls (Section 21).

TTY
: Teletypewriter. A text telephone used by deaf and hard of hearing people, sending Baudot code at 45.45 or 50 bit/s (Section 18). On Linux, a tty is also a terminal device in /dev, such as a serial port (/dev/ttyS0) or a pseudo terminal (/dev/pts/3). dmodemd appears as a pseudo terminal, so terminal programs open it like a serial modem.

3 Command Summary

Table 1. AT command summary

Command	Description	Command	Description
A/	Repeat last command.	\An	MNP block size.
A	Answer.	\Gn	XON/XOFF pass through (accepted).
Bn	Communication standard.	\Jn	Rate adjust (accepted).
Cn	Carrier control (accepted).	\Kn	Break control (accepted).
Ds	Dial.	\Nn	Error control mode.
En	Command echo.	\Qn	Flow control (accepted).
Fn	On-line data echo (accepted).	\Rn	Ring indicator (accepted).
Hn	Hook control.	\Tn	Inactivity timer (accepted).
In	Identification, call statistics.	\Vn	Protocol in CONNECT.
Ln	Speaker volume.	%B, *B	Blacklisted numbers.
Mn	Speaker control.	%Cn	Data compression.
Nn	Automode.	%En	Line quality monitor (kept).
On	Return to on-line data mode.	#CID	Caller ID.
P	Pulse dialing.	#UD	Unimodem diagnostics.
Qn	Result codes on or off.	-C, -K, -Q	MNP 10 (accepted).
Sn	Read or set an S-register.	)M, @M, *H	MNP 10 (accepted).
T	Tone dialing.	+MS	Modulation.
Vn	Result code form.	+GMI, +GMM, +GMR	Identification.
Wn	Connect message (accepted).	+GCAP	Capabilities.
Xn	Result codes and call progress.	+GCI	Country.
Yn	Long space disconnect (kept).	+ES	Error control.
Zn	Reset.	+ESA	V.80 synchronous access.
&An	Connection lines before CONNECT.	+ITF	V.80 transmit buffer.
&Bn	V.32 retrain (accepted).	+DS	V.42bis.
&Cn	Data carrier detect (kept).	+DS44	V.44.
&Dn	Data terminal ready (accepted).	+DSZ	zstd compression.
&En	Rate in CONNECT (kept).	+B2, +CBST, +CRC	B-channel protocol, V.110, ring type.

20 Online, the Escape and Hanging Up

Online, what the DTE sends goes to the other modem, except the escape sequence: three S2 characters (+++), each within 0.5 s of the one before, with 0.5 s of nothing before them and after them. The modem then says OK and is in online command mode, the call still up: ATO goes back online, ATH hangs up, and on a V.92 connection AT+PMHR asks for modem-on-hold. The +++ itself is data (the modem cannot know it is the escape until the guard time after it), and what the DTE sent before the escape and the line had not taken yet is kept, not dropped: it goes to the other modem, +++ last, once ATO is back online.

The call ends with NO CARRIER when the other side hangs up or its carrier is gone for S10 tenths of a second. dmodemd hangs up as well when the DTE drops DTR (it sets the pty's speed to 0) or, with HUPCL set on the pty, closes it; it then makes a new pty (/dev/ttyDM0 follows it).

Example session: from voice to fax

```
AT+VTX                  CONNECT      the greeting's samples follow
                        <DLE>c       the caller's CNG
<DLE><ETX>              OK
AT+FCLASS=1             OK
ATA                     CONNECT      class 1, as after AT+FTH=3
```

With +FAA=1 the modem does it itself, in the voice command state (a +VTX, +VRX, +VTR or +VTS under way ends first): after <DLE>c, FAX, +FCLASS=1 and the fax answer's CONNECT; after <DLE>e, +FCLASS=0 and the adaptive data answer (DATA, then its CONNECT).

Table 1. AT command summary *(continued)*

Command	Description	Command	Description
&F*n*	Factory *defaults* (accepted).	+IFC, +ICF, +IPR	DTE interface.
&G*n*	Guard tone (accepted).	+ILRR, +IDSR, +ILSD	DTE interface (kept).
&H*n*	Flow control (kept).	+MR, +ER, +DR	Reports (kept).
&I*n*	XON/XOFF flow control (accepted).	+PCW, +PIG	V.92 options (kept).
&J*n*	Auxiliary relay (accepted).	+PMH, +PMHT	Modem-on-hold.
&K*n*	Data compression.	+PMHR	Ask for modem-on-hold.
&L*n*	Leased line.	+CVM	V.cvm.
&M*n*	Asynchronous mode (accepted).	-SEC	MNP 10EC (kept).
&N*n*	Line rate (accepted).	+FCLASS	Data, fax or voice.
&P*n*	Pulse dial ratio (kept).	+FAA	Adaptive answer.
&Q*n*	Error control mode.	+FMI, +FMM, +FMR	Fax identification.
&R*n*	RTS/CTS (accepted).	+FTS, +FRS	Fax silence.
&S*n*	Data set ready (accepted).	+FTM, +FRM	Fax data.
&T*n*	Loop tests.	+FTH, +FRH	Fax HDLC frames.
&V*n*	View active configuration, call statistics.	+FPR	Fax DTE rate (kept).
&W*n*	Store profile (accepted).	+V...	Voice (Section 19).
&Y*n*	Profile at power on (accepted).	+FLI, +FPI	Fax Class 2 identity.
		+FLP, +FSP	Fax Class 2 polling.
		+FCC, +FIS, +FCS	Fax Class 2 capabilities.
		+FBO, +FHS, ...	Fax Class 2 settings.
		+FDT, +FDR, +FET, +FKS	Fax Class 2 pages.
		+MV18S, +MV18R	V.18 text telephone.
		+MV18AM, +MV18P	V.18 answer message.
		+MBAUDOT	5-bit (TTY, telex) settings.

4 Command Lines

AT commands are issued to the modem to control its operation and its settings. The modem takes them in command mode: after it starts, when a call ends, after any command but a dial or an answer, and online after the escape sequence (Section 20), the call still up. Each command line is answered with a result code (Section 15).

- A command line begins with AT and ends with the character of S3 (carriage return) or S4 (line feed). Blanks and tabs in it are dropped before it is read.
- The character of S5 (backspace) takes back the last one typed.
- A line holds **63** characters at most; a longer one is ERROR.
- With echo on (E1), what the DTE types comes back as it is typed.
- A line that does not begin with AT is not a command: with echo on it is blanked out on the DTE's screen.

The commands of a line run in turn (ATE1Q0V1). A basic command's number left out is 0 (ATE is ATE0). An extended command (+...) takes =*values*, ? (its values) and =? (its ranges). A ; may stand between two commands, as V.250 puts one after an extended command that another follows (AT+IFC=2,2;+MS=V92); here it is not needed. A value left out of an extended command's =*values* keeps what it was.

Some extended parameters (+ILRR, +MR, +PCW, -SEC and others) are kept for other modems' setup strings, with no other effect but where an entry says so. =*values* sets them (each in its range, else ERROR), ? gives +*name*: *values*, =? the ranges, and ATZ the *defaults*.

The commands are grouped by what they do, each group a section: echo and result codes, settings and profiles, identification, dialling and answering, the speaker and the line, modulation, error control, data compression, the DTE interface, ISDN, then fax, text telephones and voice. Table 1 lists them by name.

The first command that fails ends the line with ERROR; otherwise OK follows the last one. A, D and O end the line and give their result later (CONNECT, NO CARRIER and so on), and Z ends it with OK: whatever follows them on the line is not read, but for a dial string's ;, after which the rest of the line runs once the number is dialed (ATD). A command that reports something (I, S*n*?, +MS? ...) prints it on lines of its own before the result.

A character from the DTE while a call is being set up (dialing, answering, the modems' training) hangs up. After a dial string's ; the modem is in command state, and takes commands.

Table 55. Voice Events

Report	Event
<DLE>0-9 * # A-D	A DTMF digit from the far end.
<DLE>~	The DTMF digit ended.
<DLE>r	A ring of a ringing tone (400 to 480 Hz, or 440 and 480 Hz, or 400 and 450 Hz, on for 0.6 s at least; the UK's two bursts are one ring; it ends after 0.3 s without the tone).
<DLE>b	A busy or congestion tone (four rounds of 0.2 to 0.8 s on and off).
<DLE>a	An answer tone of 2100 Hz (a fax or data answer), 0.3 s into it.
<DLE>f	An answer tone of 2225 Hz (a data answer), 0.3 s into it.
<DLE>c	A calling fax machine's CNG (1100 Hz, bursts of 0.36 to 0.8 s).
<DLE>e	A calling data modem's V.25 tone (1300 Hz).
<DLE>l	Loop current interruption: the far end ended the call.
<DLE>H, <DLE>h	The phone on the modem's own jack off hook, on hook again.
<DLE>X ...<DLE>.	Caller ID (+VCID).

When the far end ends a voice call, the modem reports <DLE>l (V.253's loop current interruption, "usually a remote hangup") and goes on hook (+VLS=0); V.253 has no NO CARRIER in voice mode. What was under way ends: +VRX's samples with <DLE><ETX>, then OK; +VTX and +VTR when the DTE ends them (its samples until then are discarded), then OK, +VTR's after <DLE><ETX>; +VTS's tones with ERROR. In the command state <DLE>l comes alone.

19.2 From Voice to Fax or Data

A voice call can become a fax or data call (V.253 5.3.2 and its example I.6). +FCLASS=1 (or 0) in the voice command state, off hook, keeps the call: the voice engine stops, the line stays off hook and silent, and A answers on it as a fax (Class 1: CED, then CONNECT for the DIS) or data modem, or D calls on it (call progress waits for the far end's answer tone). H, Z or the far end hanging up ends the held call. For example, a fax machine calls while the greeting plays:

+VTS — DTMF and Tone Generation

This command plays the elements of *string*, separated by commas, in turn, and gives OK after the last. Durations are in 10 ms, 0 to 6000. A field may be left empty: a frequency is then 0, a digit none (silence), and a duration +VTD's, so {5}, [440] and [] last +VTD and {} is silence for as long. Two digits in a row get 50 ms of silence between them: +VTS=1,2,3 dials 123. A hook flash is the line's: over SIP an RFC 4733 event (16), the audio silent meanwhile.

Syntax:

- +VTS=*string*
- +VTS? (gives the tone settings)
- +VTS=? (gives +VTS=0-4000,0-4000,0-6000)

Result code	When
OK	After the last element.
ERROR	If one element cannot be (nothing is played): a flash on a line that has none (a SIP call whose far end takes no telephone-events), a value out of range.

Table 54. +VTS Elements

Element	Plays
s	The DTMF digit *s* (0–9, *, #, A–D), or ! a hook flash, for +VTD.
{*s*,*d*}	The DTMF digit or hook flash *s* for *d*.
[*f1*,*f2*,*d*]	A tone of *f1* and *f2* Hz (0 to 4000; 0 is none) for *d*.

19.1 Voice Events

While the line is taken (+VLS=1) the modem reports what it hears, as V.253 has it, as <DLE> and a character. DTMF digits from the far end are reported 51 ms into them and again every 70 ms while they last, in the voice command state as well as among +VRX's samples, whose audio is silence from a digit's report until it ends; the modem's own +VTS tones are not reported. The calling tones are reported as a burst ends and 4 s apart at least.

5 Echo and Result Code Settings

A/ — Repeat Last Command

A/ runs the last command line again. It needs no AT before it and no line end after it: the modem runs it as the / is typed. It is mostly used to dial a busy number again.

E*n* — Command Echo

This command sets whether the modem echoes the DTE's characters in command mode (S13).

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

Table 2. E*n* Commands

Command	Function
E0	No echo.
E1	Echo (*default*).

Q*n* — Result Code Control

This command sets whether the modem gives result codes (S14).

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

Table 3. Q*n* Commands

Command	Function
Q0	Result codes are given (*default*).
Q1	Result codes are not given.

`Vn` — Result Code Form

This command sets whether result codes are words or numbers (S15). Section 15 lists both.

Result code	When
`OK`	If *n* = 0 or 1.
`ERROR`	Otherwise.

Table 4. V*n* Commands

Command	Function
`V0`	Numbers, each on a line of its own.
`V1`	Words (*default*).

`Wn` — Connect Message Control

Other modems use `W` to choose what `CONNECT` reports. The modem accepts it and changes nothing: here `&A` and `\V` choose.

Result code	When
`OK`	If *n* = 0–2.
`ERROR`	Otherwise.

`+VTX`, `+VRX`, `+VTR` — Voice Transmit, Receive, Duplex

These commands send, receive, or both at once: `CONNECT`, then samples in `+VSM`'s format and rate, `<DLE>` doubled. A gap in the `DTE`'s samples plays as silence.

Result code	When
`CONNECT`	Then `OK` when it ends.
`ERROR`	Without the line or a handset taken (`+VLS`).

Table 53. Voice Data Commands

Command	Ends at
`+VTX`	`<DLE><ETX>`, `<DLE>!` or `<DLE><CAN>` from the `DTE`; then `OK`.
`+VRX`	Any character from the `DTE`; the modem ends its samples with `<DLE><ETX>`, then `OK`.
`+VTR`	`<DLE>^` from the `DTE` only; then `<DLE><ETX>` and `OK`.

`+VTD` — Beep Tone Duration

The duration of a `+VTS` element that gives none, in 10 ms, 0 to 6000 (0: 1 s); 100 at the start.

+VEM — Event Reporting and Masking

0 or 1: V.253's event reports in the speakerphone state, which the modem has not. Kept; 0 at the start and with +VIP.

D — Voice Dial

In voice mode, ATD*number* dials and gives OK when the far end answers, BUSY, NO ANSWER after S7, or ERROR when the call fails otherwise. An answer tone is the answer and a busy tone BUSY on any line (on SIP in its early media too); on SIP the answer is otherwise the 200 OK, on a line that does not tell the ringing tone's end (+VRA), or +VRN without one. On an analogue line the modem waits 2 s for the dial tone first. With the line taken it dials the digits as DTMF, S11 ms each.

H — Voice Hang Up

In voice mode, ATH leaves the line and goes back to data mode, +FCLASS=0.

+VRA — Ringback Goes Away Timer

The far end has answered when the ringing tone has been gone this long since its last ring, in 100 ms, 0 to 255 (0: as the first ring ends); 50 at the start.

+VRN — Ringback Never Appeared Timer

The far end has answered when no ring has come in this long after dialling, in seconds, 0 to 255 (not beyond S7); 10 at the start.

X*n* — Result Code Set and Call Progress

This command sets whether CONNECT gives the rate, whether the modem waits for a dial tone before dialing, and whether it reports a busy tone (S56).

Result code	When
OK	If *n* = 0–4.
ERROR	Otherwise.

Table 5. X*n* Commands

	CONNECT	Before dialing	BUSY
X0	Without the rate.	No wait for a dial tone.	No.
X1	With the rate.	No wait for a dial tone.	No.
X2	With the rate.	Waits for a dial tone (below).	No.
X3	With the rate.	No wait for a dial tone.	Yes.
X4	With the rate.	Waits for a dial tone (below) (*default*).	Yes.

The dial tone X2 and X4 wait for is 1 s of tone, steady or in a cadence whose gaps are 1 s at most (as Italy's: its tone added up); NO DIALTONE if none comes in S6 seconds (2 s at least; 2 s more while a dial tone in a cadence is heard). A busy tone is four cycles of the country's busy or congestion tone's cadence (the ITU's list's, 15% or 80 ms either side: 0.48 s on and off or 0.24 in Germany, 0.75 s in India, 1 s on and 4 off in Egypt), not its ringing tone; a country with neither (none of the 192) its table's bounds. NO ANSWER comes with every *n*, and the dial string's W and @ wait with every *n*. A SIP call has no dial tone: dmodemd wants ATX3.

&An — Connection Lines Before CONNECT

This command adds lines on the connection before a data call's CONNECT (S70). *n* is a sum of the bits below. With V0 the first three lines are numbers and the fourth is left out.

Result code	When
OK	If *n* = 0–7.
ERROR	Otherwise.

Table 6. &A*n* Bits

Bit	Line	With V0
1	Modulation: *name*, the modulation (V92, V34, V32bis, ...).	1000 and its number (1092, 1034, 1132, ...).
2	Protocol: LAPM, MNP or NONE, the error correction (V.42's LAPM, MNP 2 to 4).	77, 78, 76.
1 and 2	Compression: V44, V42bis, MNP5, ZSTD (V.cvm's, Annex F) or NONE, what V.42 or MNP agreed.	68, 67, 66, 70, 69.
4	TxRate: *rate*, the rate the modem sends at.	None.

The *default* is 0, no lines.

&En — Rate in CONNECT

The modem keeps the value in S71. It changes nothing: CONNECT always gives the rate the modem receives at.

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

+VLS — Analog Source/Destination Selection

This command takes the line for voice or leaves it, or puts the voice engine on a handset. Moving between 1, 14 and 15 keeps the voice engine running, the line taken or left.

Result code	When
OK	Always.
ERROR	For a device the modem has not.

Table 52. +VLS Values

Value	Device
0	Leave the line, on hook (*default*).
1	Take the line for voice (on SIP: answer the call that rings).
14	A handset of the modem's own alone, the line on hook: +VRX records its microphone, +VTX plays to its earpiece, and DTMF from it is reported.
15	The line with the handset on the call: the DTE hears the line and the handset, the line gets the DTE's samples and the handset.

AT+VLS=? gives V.253's list of the devices, with the events each reports in the transmit, receive and command states as hex bit fields (bit *n* for V.253's event *n*, event 0 the leftmost of 32):

Example output: AT+VLS=?

```
0,"",00000000,00000000,90000000
1,"T",0B043060,0B043060,0B043060
```

On hook (0) that is caller ID (with +VCID) and RING; on the line (1) DTMF, the two calling tones, the loop current interruption, a ringing tone, a busy tone and the two answer tones, in every state. A line that senses the phone on the modem's own jack (a SmartUSB56 with dmodemd -usb-handset) adds event 8 to both, in every state (00800000, 0B843060, ...). A modem with a handset of its own (a SmartUSB56 with dmodemd -usb-voice-codec) lists two more:

Example output: AT+VLS=?, the handset's lines

```
14,"H",08000000,08000000,08000000
15,"HT",0B043060,0B043060,0B043060
```

+VSM — Voice Compression Method

This command sets the format of the samples +VTX, +VRX and +VTR carry: format *m* at *r* samples/s (left out: 8000, or the rate the format runs at). *s* and *e*, silence compression's, are taken (0 to 255) and kept, though the modem compresses no silence.

Syntax:

- +VSM=*m*[,*r*[,*s*[,*e*]]]
- +VSM? (gives +VSM=1,8000,0,0 at the start)
- +VSM=? (lists the formats, one a line)

Result code	When
OK	Always.
ERROR	For another format, or a rate the format does not run at; the setting is kept.

Table 51. +VSM Formats

m	Format
0, 1	8-bit linear, signed and unsigned (offset by 128), at 7200, 8000 or 11025 (V.253's numbers).
4, 5	G.711 u-law and A-law, at 8000.
128	8-bit linear unsigned, as 1 (Conexant's numbers from here on).
129	16-bit linear signed, the low octet first, at 7200, 8000 or 11025.
130, 131	A-law and u-law, as 5 and 4.
132	IMA ADPCM, 4 bits a sample, two an octet with the first in the low nibble (as in a WAV file), at 7200, 8000 or 11025; the coder starts afresh at each +VTX, +VRX, +VTR.

\V*n* — Protocol Result Code

This command sets whether a data call's CONNECT gives the error correction and the compression after its rate (S106). With V0 or X0 it changes nothing.

Result code	When
OK	If *n* = 0–2.
ERROR	Otherwise.

Table 7. \V*n* Commands

Command	Function
\V0	The rate alone: CONNECT 33600 (*default*).
\V1, \V2	The protocol too: CONNECT 33600/LAPM/V42bis, CONNECT 2400/MNP/MNP5, CONNECT 28800/NONE.

+MR, +ER, +DR — Modulation, Error Control and Compression Reports

On other modems these turn on the +MCR:, +MRR:, +ER: and +DR: reports. Kept; each 0 or 1, *default* 0.

6 Settings and Profiles

Sn — Read or Set an S-Register

ATS*n*? reads S-register *n* (0 to 255) and gives its value in decimal on a line of its own. ATS*n*=*v* sets it to *v*; the registers hold 8 bits, so *v* is taken modulo 256. Both numbers are decimal, a leading 0 too (ATS09? is S9). ATS103=*n* is \N*n*. Section 16 lists the registers.

Syntax:

- ATS*n*?
- ATS*n*=*v*

Result code	When
OK	Always.
ERROR	For a number over 255, a read-only register (S44, S45), or neither ? nor = after it.

Zn — Reset

This command hangs up and sets the modem as it was at the start: the S-registers, +MS, modem-on-hold, the data mode (+FCLASS=0), the extended parameters and the loop tests (&T5). The country stays, and so do the S-registers without a *default* of their own: S18, S28, S47 (&L), S48, S161 and the free ones. There are no stored profiles, so *n* (0 to 3) changes nothing. The rest of the line is not read.

Result code	When
OK	Always.

&Fn — Restore Factory Defaults

Accepted, with or without a digit, and nothing done; see &D. ATZ restores the *defaults*.

19 Voice Commands

With AT+FCLASS=8 the modem takes V.253's voice commands; they are ERROR in the other modes, but for +VCID. Each +V parameter takes ? (its values) and =? (their ranges).

+VIP — Initialize Voice Parameters

This command sets the voice settings as at the start.

Result code	When
OK	Always.

+VNH — Automatic Hangup Control

0 or 1. It is accepted and has no effect: a held call's failed handshake hangs up.

+VGT, +VGR — Transmit and Receive Gain

The gain sending (+VGT) and receiving (+VGR), 0 to 128.

Result code	When
OK	If *n* = 0–128.
ERROR	Otherwise.

+VIT — Inactivity Timer

The inactivity timer, 0 to 255.

+VSD — Silence Detection

Silence detection's sensitivity and period, each 0 to 255.

Syntax:

- +VSD=*s*,*t*

+MBAUDOT — 5-bit Mode

This command (D-Modem's own) sets the 5-bit mode's rate, tones and figures, for telex and RTTY: AT+MBAUDOT=50,2125,2295,1 is 50 baud ITA2 on RTTY's 170 Hz shift. The two ends must agree; automoding listens on these tones. Z sets the US TTY's 45,1400,1800,0.

Syntax:

- +MBAUDOT=[*rate*][,[*mark*][,[*space*][,[*code*]]]]
- +MBAUDOT? (gives +MBAUDOT: 45,1400,1800,0)
- +MBAUDOT=? (gives +MBAUDOT: (45,50,75,100),(300-3400),(300-3400),(0,1))

Result code	When
OK	Always.
ERROR	For a value out of range, or the same mark and space.

Table 50. +MBAUDOT Values

Value	Meaning
rate	45 (45.45), 50, 75 or 100 bit/s.
mark	The mark (1) tone, Hz.
space	The space (0) tone, Hz.
code	The figures: 0 the US TTY's ($ on D, " on Z, ; on V, unshift on space), 1 ITA2's (telex).

&V*n* — View Active Configuration

&V and &V0 show the active settings, in lines of **72** columns at most: the basic commands', the S-registers in use (S*nn*:*vvv*; not S18 or S44 to S48), +MS and the other extended settings, and the extended parameters. There are no stored profiles: the list ends with STORED PROFILES: none. &V1 gives the last call's statistics, as ATI11 (Rockwell's).

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

Example output: AT&V

```
ACTIVE PROFILE:
E1 L3 M1 N1 Q0 T V1 X4 Y0 &A0 &C0 &E0 &H0 &P0 \A3 \N3 \V0 %C3 %E0
S00:000 S01:000 S02:043 S03:013 S04:010 S05:008 S06:002 S07:060 S08:002
...
+MS=92,1,300,56000 +FCLASS=0 +GCI=b5 +PMH=0 +PMHT=5 #CID=0 +IFC=2,2
...
STORED PROFILES: none
```

&W*n* — Store Current Configuration

There are no stored profiles: &W, &W0 and &W1 answer OK and store nothing.

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

&Y*n* — Profile at Power On

Accepted, changing nothing: there are no stored profiles.

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

7 Identification and Diagnostics

In — Identification and Statistics

This command reports what the modem is, its settings and the last call's statistics.

Result code	When
OK	If *n* = 0–7 or 11.
ERROR	Otherwise.

Table 8. I*n* Commands

Command	Function
I0	The product: D-Modem.
I1, I2	The product and version (D-Modem, 1.0.0), then the maker, D-Modem project.
I3	The modem's name, then its line's kind (dmodemd: dmodem0, SIP).
I4	S0 to S23, eight a line (s00=000 s01=000 ...).
I5	Stored Profile 0: (there are none).
I6	The last call's statistics, as USRobotics' link diagnostics (the same as I11).
I7	The country: Country: USA.
I11	The last call's statistics, as Conexant's modems give them.

ATI11 lists the last call's statistics: in online command state those of the call that is up, after a call (dialed or answered, connected or not) its own, until the next one; before any, No Previous Call. ATI6 and AT&V1 give the same lines, and AT#UD the same figures in Unimodem's form. A line whose value the call does not have is left out: the rates and what follows for a call that never came up, the frame counts without error correction, the coding lines without V.34, the measurements a modulation does not make, the cause while the call is up.

Table 9. ATI11 Lines

Line	Value
Last Connection	The modulation it came up with (V34, V90, V92, V91, V32bis, ...), Fax, or None.

+MV18AM, +MV18P — Answer Message, Probe Order

+MV18AM sets the answer message, up to 63 printable characters, the blanks in its quotes kept (AT+MV18AM="GA"): sent in the probes, and on answering with +MV18S's *msg*. +MV18P (2 to 7) is kept: the probes go in the order above.

Syntax:

- +MV18AM="*text*", +MV18AM?, +MV18AM=? (gives +MV18AM: (63)(32-126))
- +MV18P=*n*, +MV18P? (gives +MV18P: 2), +MV18P=?

Result code	When
OK	Always.
ERROR	For a message too long or a value out of range.

+MV18S — V.18 Selection

This command chooses the text telephone mode (as +MS would; 0 sets +MS=92 if +MS had a text one), and whether the modem probes a silent remote and sends the answer message on answering. Z sets 0,0,0,0,1.

Syntax:

- +MV18S=[*mode*][,[*dflt*][,[*fbk*][,[*msg*][,[*probe*]]]]]
- +MV18S? (gives +MV18S: 0,0,0,0,1)
- +MV18S=? (gives +MV18S: (0-2,4-7),(0-7),(0,1),(0,1),(0-2))

Result code	When
OK	Always.
ERROR	For a value out of range, or *mode* 3 (DTMF).

Table 49. +MV18S Values

Value	Meaning
mode	0 off; 1 automoding (+MS=18); 2 5-bit (45); 4 EDT (110); 5 V.21; 6 V.23; 7 Bell 103.
dflt	The *default* answering mode: kept.
fbk	Kept.
msg	1: the answer message on answering in the 5-bit mode or EDT.
probe	0: automoding only listens; 1 or 2: it probes.

+MV18R — V.18 Report

With +MV18R=1 automoding reports the mode it found before the CONNECT, as +MV18R: *mode* with +MV18S's numbers (+MV18R: 2 for a TTY).

Syntax:

- +MV18R=*n*
- +MV18R? (gives +MV18R: 0)
- +MV18R=? (gives +MV18R: (0,1))

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

Table 9. ATI11 Lines *(continued)*

Line	Value
Initial Transmit/Receive Carrier Rate	The rates (bit/s) at CONNECT.
Final Transmit/Receive Carrier Rate	The rates now, or at the end (after renegotiations).
Symbol Rate (Tx/Rx)	Each direction's symbols a second (V.22 to V.92, the clear channel).
Carrier Frequency (Hz, Tx/Rx)	Each direction's carrier, PCM for a V.90, V.91 or V.92 PCM direction.
Protocol Negotiation Result	LAPM, MNP or NONE.
Data Compression Result	V44, V42bis, MNP5, ZSTD or NONE.
Trellis Code, Nonlinear Encoding, Precoding, Shaping (Tx/Rx)	V.34's coding each way (16S-4D, ON, OFF; - for a PCM direction).
Estimated SNR (dB)	The receiver's signal to noise ratio (V.34, V.90's upstream, V.32bis, V.29, V.33, V.27ter, V.wb).
Receive/Transmit Signal Power Level (dBm0)	The line's mean power each way while the call was up.
Round Trip Delay (ms)	As V.34's phase 2 (or V.cvm's start-up) measured it.
Near/Far Echo Level (dBm0)	The echoes of our signal the canceller takes away (V.34, V.90, V.92).
Carrier Frequency Offset (Hz)	How far the far end's carrier is from ours (V.22 to V.92).
Timing Offset (ppm)	How far the far end's clock is from ours (V.32bis to V.92).
PCM Encoding	The network's law, A-law or u-law (V.90, V.92).
Digital Loss (dB), Robbed Bit Frames	The network's pad and the frames of six whose bit it robs (None, 6, ...), as the analogue modem's DIL found them (Section 10).
Characters Sent/Received	The DTE's.
Transmit Frame Count	LAPM's or MNP's frames sent.

Table 9. ATI11 Lines *(continued)*

Line	Value
`Transmit Frame Error Count`	The information frames among them sent again.
`Receive Frame Count`	The frames received intact.
`Receive Frame Error Count`	The frames received with a bad `FCS`.
`Retrains by Local Modem, Retrains Requested by Remote Modem`	Retrains, ours and the other modem's.
`Rate Renegotiation by Local/Remote Modem`	Rate renegotiations (`V.34`, `V.90`, `V.92`).
`Call Duration`	From `CONNECT`, *h*:*mm*:*ss*.
`Call Termination Cause`	`Local hangup` (`ATH`, `ATZ`, `DTR`, a character while connecting), `Remote cleardown` (the other modem's `LAPM` `DISC` or `MNP` `LD`), `Line dropped` (the `SIP` call ended), `Carrier lost`, `No dial tone`, `Busy`, `No answer`, `Training failed`, `Protocol failure` (no error correction where it is required, `LAPM`'s errors), `No carrier`.

Example output: ATI11

```
Description                    Status
-----------                    ------
Last Connection                V34
Initial Transmit Carrier Rate  33600
...
Call Duration                  0:00:10
Call Termination Cause         Local hangup
```

The digital modem has no view of the line's digital loss or robbed-bit signalling, so on `dmodemd`'s `SIP` line those two lines are not there; the analogue modem (`dmodemd -a`, `-usb`) measures them.

18 Text Telephone Commands

The modem is a text telephone in `V.18`'s modes (`+MS` or `+MV18S` chooses one): the 5-bit (Baudot) mode of the `TTYs`, at `45.45` bit/s on 1400 and 1800 Hz (TIA-825-A), and with `+MBAUDOT` the telex and `RTTY` variants (`50` bit/s, ITA2's figures, other tones); `EDT` (`V.21`'s channel 1 at `110` bit/s, 7 bits, even parity, 2 stop bits); and `V.21`, `V.23` and Bell 103 as their data modes. The 5-bit mode and `EDT` are half duplex: the modem sends 150 ms of mark, the characters, and 300 ms of mark after the last, and does not hear the line meanwhile; it starts no characters while the remote's carrier is on. Neither hangs up for want of carrier. The `DTE` sends and receives `ASCII`: in the 5-bit mode lower case goes as capitals, the shift codes are the modem's, and characters the code has not are dropped. A text telephone call has no answer tone: dialling, the modem goes into its mode as the dialling ends; answering, at once.

`AT+MS=V18` (or `AT+MV18S=1`) finds the remote's mode. It listens for 3 s, for a 5-bit character, an `EDT` character, `V.21`'s channel 1 at `300` bit/s (or a steady mark), a Bell 103 or `V.23` caller's mark (answering), or `V.21`'s channel 2, Bell 103's 2225 Hz or `V.23`'s 1300 Hz (calling). Hearing nothing it probes, in turn: the answer message (`+MV18AM`) and a new line in the 5-bit mode, then in `EDT`, each followed by 2 s of listening, then 3 s each of its own `V.21`, Bell 103 and `V.23` mark, listening for the answer to it; and over again until `S7` runs out. Found, a 5-bit or `EDT` remote is answered in its mode (once it is quiet, so that another automoding modem, whose probe this may have been, finds it too); `V.21`, `V.23` and Bell 103 go on as those modems do. `DTMF` text telephones (`V.18`'s `DTMF` mode) are not supported.

+FDT, +FDR, +FET, +FKS — Send, Receive, End Page, End Call

+FDT sends a page, +FDR receives one, +FET gives the command after the page sent, and +FKS (Class 2's +FK) ends the call with a DCN (+FHS:02), as in the example above.

Syntax:

- +FDT, +FDR, +FKS
- +FET=*n*

Result code	When
CONNECT	Then the page and OK; or the reports, then OK.
ERROR	With no Class 2 call.

Table 48. +FET Values

Value	Meaning
0	MPS: another page follows.
1	EOM: another document follows.
2	EOP: the last page.

+GMI, +GMM, +GMR — Identification

These commands give the manufacturer (D-Modem project), the model (D-Modem) and the revision (1.0.0, the build's version). With ? after them (AT+GMI?) they give the same.

Result code	When
OK	Always.

+GCAP — Capabilities

This command lists the command sets the modem has: +GCAP: +FCLASS,+MS.

Result code	When
OK	Always.

#UD — Unimodem Diagnostics

This command gives the last call's statistics (or this one's), as ATI11 has them, in the form of Microsoft's Unimodem diagnostics (its draft specification, rev. 0.85), for Windows' modem log and the programs that read it: a line DIAG <2A4D3263 *key=value*> for each key there is a value for, both in hexadecimal. Before any call: 0=10, 1=0 and 60=1.

Result code	When
OK	Always.

Table 10. #UD Keys

Key	Value
0	The format (10).
1	The call's setup.
10–17	The receive and transmit levels, the noise, the echoes' loss, the round trip delay.
20, 21	The modulation (V.58's codes).
22–27	The symbol rates, the carriers, the first rates.
31, 32	The renegotiations and retrains.
34, 35	The last rates.
40	The error control.
44	The compression (V.58's codes; 80 MNP 5, 81 V.44, 82 zstd).
50, 51	The flow control (&H).
52–59	The characters and frames.
60	How the call ended (V.58's *callCleared*; 2 while it goes on).

Example output: AT#UD

```
DIAG <2A4D3263 0=10>
DIAG <2A4D3263 1=7>
DIAG <2A4D3263 10=0C>
...
```


+FCC, +FIS, +FCS — Capabilities, Session Parameters

The capabilities (+FCC, Class 2's +FDCC, which sets +FIS as well) and the session's (+FIS, Class 2's +FDIS, read again at each +FDT). +FCS? gives the last session's. At the start 1,5,0,2,0,0,0,0.

Syntax:

- +FCC=*vr*,*br*,*wd*,*ln*,*df*,*ec*,*bf*,*st*
- +FIS=*vr*,*br*,...
- +FCC?, +FIS?, +FCS?
- +FCC=?, +FIS=? (give (0,1),(0-5),(0),(0-2),(0),(0-2),(0),(0-7))

Result code	When
OK	If every value is in its range.
ERROR	Otherwise.

Table 47. +FCC Values

Value	Meaning
vr	0 normal, 1 fine resolution.
br	0 to 5: 2400, 4800, 7200, 9600, 12000, 14400 bit/s.
ec	0 none, 1 or 2 error correction mode.
others	Taken in their ranges.

+FBO, +FCR, +FPS, +FHS — Bit Order, Receive, Page Status, Hangup Status

+FBO (Class 2's +FBOR): bit 0 set, the page data's first bit is the top of each octet (0, the *default*: its lowest). +FCR and +FPS are kept. +FHS? gives the last hangup status. Other +F settings that fax programs send in Class 2 (+FNR, +FIE, +FCT and the like) are kept with no effect.

Syntax:

- +FBO=*n*, +FCR=*n*, +FPS=*n*
- +FHS?

Result code	When
OK	Always.

+FLP, +FSP — Document to Poll, Request to Poll

+FLP=1 (Class 2's +FSPL): we have a document to be polled; the DIS says so, and a caller's DTC has ATA report +FCO, +FPI:"*cig*" and +FTC:*dtc* (Class 2: +FCIG, +FDTC) and OK, for +FDT to send it. +FSP=1: we poll; after a DIS that offers a document (ATD reports +FPO, Class 2 +FPOLL), +FDR sends the CIG and DTC and receives as the answerer does (+FTI, +FCS, CONNECT and the page).

Syntax:

- +FLP=*n*, +FSP=*n*
- +FLP?, +FSP?
- +FLP=?, +FSP=? (give (0,1))

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise; the caller's +FDR is ERROR without +FSP=1.

&T*n* — Loop Tests

V.54's loop tests, with Hayes' numbers. Loop 3 runs offline on a leased line (&L) with a 4-wire modulation (+MS=V29, V33 or V27TC): the modem's signal goes back into its own receiver and the line is silent. Loop 2 at the far end is asked for in band (V.54's PREP, ACK and TERM), from online command state on a call with no error correction (\N0). The self-test sends and checks V.52's 511-bit pattern. S18 above 0 ends a test after that many seconds.

Result code	When
CONNECT	For &T1 and &T6: the DTE's data comes back to it.
OK	For the others; &T0 after &T7 or &T8 first gives the self-test's bit errors, three digits (255 at most).
ERROR	For &T2 and *n* over 8, outside the state the test needs, or when the far end does not answer &T6 or &T7.

Table 11. &T*n* Commands

Command	Function
&T0	Ends the test (&T the same).
&T1	Loop 3, the local analogue loop.
&T3	Loop 2 here: the far end's data back to it.
&T4	The far end may ask for loop 2.
&T5	The far end may not ask for loop 2 (*default*, again after ATZ).
&T6	Loop 2 at the far end, the remote digital loop.
&T7	Loop 2 at the far end with the self-test.
&T8	Loop 3 with the self-test.

%E*n* — Line Quality Monitor

The modem keeps the value in S39. Its modulations retrain and renegotiate their rate by themselves.

Result code	When
OK	If *n* = 0–2.
ERROR	Otherwise.

8 Dialling, Answering and Hanging Up

Dstring — Dial

This command takes the modem off hook and dials the number in *string*, then calls. The digits and * # A B C D are dialed as DTMF, each S11 ms long with S11 ms between them; T and P choose tone or pulse dialing (S16) for the rest of the call. Pulses are dialed on an analogue line (dmodemd's -a and -usb), with the country's break, make, gap between digits and digit pattern (+GCI; * # A B C D skipped); a line that cannot pulse, such as SIP, dials them in DTMF. With X2 or X4 the modem waits for a dial tone first. In dmodemd the dial string is the SIP call's number (Section 21).

Table 12. Dial Modifiers

Modifier	Function
0-9 * # A-D	Dialed as DTMF, or as pulses for the digits with P.
L	Dial the last number again (`Dialing number...` first). Valid only as the first character of the string; ERROR while a call is held after ;.
T	Tone dialing (DTMF) from here on.
P	Pulse dialing from here on.
,	Pause for S8 seconds.
W	Wait for a dial tone (1 s of it): NO DIALTONE if none comes in S7 seconds.
@	Wait for the remote end's ringing (0.5 s of sound at least), then for 5 s of quiet after it: NO ANSWER if that does not come in S7 seconds.
;	End the dial string: once the number is dialed the modem is back in command state, off hook with the call kept, and says OK; the rest of the line runs then.
S=*n*	A stored number: ERROR (there are none).
! $	Hook flash and bong tone: skipped (a SIP call has no hook to flash).

Other characters are skipped. After a ; the call waits, silent, for the DTE: ATD*more* dials more on it (as DTMF; a ; again holds it again), ATD alone or ATO starts the calling modem's handshake, ATA the answering modem's, and ATH hangs up (OK, then NO CARRIER).


```
OK
```

In Class 2 an XON follows the sending CONNECT. +FDR's page waits for the DTE's <DC2> (a second at most); the pages are taken and confirmed as they come, and wait for +FDR. When the call ends, the modem reports the hangup status and the result of the command then under way (NO CARRIER for ATD and ATA), and goes on hook.

Table 46. +FHS Hangup Status

Value	Meaning
00	The call was done.
02	+FKS ended it.
11	No fax machine answered.
2x	Sending, phase B (the DIS, the training).
4x, 5x	Sending a page, or the post-page exchange.
7x, 9x	Receiving.

Class 2.0 gives the status in hexadecimal digits (T.32 Table 23), Class 2 in decimal.

+FLI, +FPI — Local ID, Polling ID

Our identity in TSI and CSI (+FLI, Class 2's +FLID) and in CIG when we poll (+FPI, Class 2's +FCIG; empty: +FLI's): up to 20 printable characters, the blanks in the quotes kept.

Syntax:

- +FLI="*id*", for example AT+FLI="Fax ID with Spaces"
- +FPI="*id*"
- +FLI?, +FPI? (give the identity in quotes)
- +FLI=?, +FPI=? (give (20)(32-127))

Result code	When
OK	Always.
ERROR	For more than 20 characters.

+FPR — Fax DTE Rate

The fax DTE's rate: kept, with no effect. 0 (*default*), 1, 2, 4, 8, 10 or 18.

17.1 Class 2 and 2.0

With AT+FCLASS=2.0 (T.32) or AT+FCLASS=2 (the older Class 2 that fax programs know), the modem runs T.30 itself: the DTE gives and takes the pages in T.4 MH with EOLs, <DLE> doubled, ended by <DLE><ETX>, and steers the call with the commands below. Class 2 has the older names: +FLID, +FDCC, +FDIS, +FDCS, +FBOR, +FK, +FPTS and +FHNG (either name works in either class), and its reports say +FCON, +FCSI, +FTSI, +FDIS, +FDCS, +FPTS and +FHNG. The rates are V.17, V.29 and V.27ter's; error correction mode, when +FIS has it, is the modem's own (the DTE's data is the same). The pages are MH whatever the remote uses (MR or ECM: the modem codes them again), A4 width. A call goes over to T.38 as a Class 1 call does (the same commands and results). +FAA (adaptive answer) is Class 1's, and Class 1's +FTH, +FRH, +FTM, +FRM, +FTS and +FRS are ERROR in Class 2 mode.

Example session: sending two pages, then receiving them

```
ATD<number>          +FCO            the DIS came
                     +FCI:"<id>"
                     +FIS:1,5,0,2,0,0,0,0
                     OK
AT+FDT               +FCS:1,5,0,2,0,0,0,0
                     CONNECT         DCS, training, CFR
<page><DLE><ETX>     OK
AT+FET=0             +FPS:1,0,0,0,0
                     OK              MPS, MCF
AT+FDT               CONNECT
<page><DLE><ETX>     OK
AT+FET=2             +FPS:1,0,0,0,0
                     +FHS:00
                     OK              EOP, MCF, DCN

ATA                  +FCO            the CFR went out
                     +FTI:"<id>"
                     +FCS:1,5,0,2,0,0,0,0
                     OK
AT+FDR               CONNECT
<DC2>                <page><DLE><ETX>
                     +FPS:1,<lines>,0,0,0
                     +FET:0
                     OK
AT+FDR               ... +FET:2, OK
AT+FDR               +FHS:00
```


Result code	When
CONNECT	When the call is up.
OK	After a ;.
BUSY, NO ANSWER, NO DIALTONE or NO CARRIER	When it is not.
ERROR	For S=*n*, or L with no number to dial.

P — Select Pulse Dialing

This command sets pulse dialing for the next dial (S16=0). See ATD.

Result code	When
OK	Always.

T — Select Tone Dialing

This command sets tone (DTMF) dialing for the next dial (S16=1, the *default*). See ATD.

Result code	When
OK	Always.

&P*n* — Pulse Dial Make/Break Ratio

The modem keeps the value in S28. The country's table sets the pulse times.

Result code	When
OK	If *n* = 0–3.
ERROR	Otherwise.

A — Answer

This command takes the modem off hook to answer a call. After S92 seconds it sends the answering modem's tones. In dmodemd the call that rings (RING) is answered. On a call held after a dial string's ;, ATA answers that call: ATD*number*;A dials, then answers (V.250's call-back).

Result code	When
CONNECT	When the call is up.
NO CARRIER	When no call comes up.
ERROR	If there is no call to answer.

H*n* — Hook Control

This command puts the modem on or off hook. H or H0 hangs up a call. In voice mode ATH leaves the line and goes back to data mode (Section 19).

Result code	When
OK	If *n* = 0 or 1.
ERROR	For another number, or when the hook cannot change.

Table 13. H*n* Commands

Command	Function
H0	On hook (hang up).
H1	Off hook.

+FTM, +FRM — Transmit Data, Receive Data

These commands send or receive data at modulation *m*: CONNECT, then the data with <DLE> doubled, ended by <DLE><ETX>.

Syntax:

- +FTM=*m*, +FRM=*m*
- +FTM=?, +FRM=? (give 24,48,72,73,74,96, 97,98,121,122,145,146)

Result code	When
CONNECT	Then OK after the data.
ERROR	Outside fax mode, or for a modulation the modem has not.

Table 45. +FTM and +FRM Modulations

m	Modulation
24, 48	V.27ter, 2400 and 4800 bit/s.
72, 96	V.29, 7200 and 9600 bit/s.
73, 97, 121, 145	V.17, 7200 to 14400 bit/s, long training.
74, 98, 122, 146	V.17, 7200 to 14400 bit/s, short training.

+FTH, +FRH — Transmit HDLC, Receive HDLC

These commands send or receive HDLC frames at V.21 channel 2 (300 bit/s), the only modulation for them.

Syntax:

- +FTH=3, +FRH=3
- +FTH=?, +FRH=? (give 3)

Result code	When
CONNECT	Then OK or ERROR after each frame.
ERROR	Outside fax mode.

+FMI, +FMM, +FMR — Fax Identification

These commands give the manufacturer, the model and the revision, as +GMI, +GMM and +GMR give them, in any mode.

Result code	When
OK	Always.

+FTS, +FRS — Transmit Silence, Receive Silence

+FTS sends silence for *n* times 10 ms; +FRS waits for silence of *n* times 10 ms.

Syntax:

- +FTS=*n*
- +FRS=*n*

Result code	When
OK	When it is done.
ERROR	Outside fax mode, or with no *n*.

On — Return to On-Line Data Mode

This command takes the modem back online after the escape (Section 20). On a call held after a dial string's ; it starts the calling modem's handshake (as ATD). O1 and O3 work in V.34, V.90 and V.92 calls; in the others they only go back. A retrain or renegotiation counts as the local modem's in ATI11.

Result code	When
CONNECT	When the modem is back online.
ERROR	When there is no call to go back to, or for *n* = 2 or over 3.

Table 14. O*n* Commands

Command	Function
O0	Back online (*default*).
O1	Back online, then retrain (V.250's).
O3	Back online, then renegotiate the rate (Rockwell's).

Yn — Long Space Disconnect

Other modems use Y for long space disconnect. The modem keeps the value in S161 and does nothing more.

Result code	When
OK	If *n* = 0–3.
ERROR	Otherwise.

%B, *B — Blacklisted Numbers

These commands list the numbers barred from dialing. None are kept.

Result code	When
OK	Always.

#CID, +VCID — Caller ID

This command turns caller ID on or off. With it on, the modem tells the DTE who is calling: after the first RING it sends the date and time, the caller's number and, when there is one, the caller's name, a line each. +VCID is another name for the same command.

Caller ID works on a SIP call and on a telephone line. When the caller has withheld the number or name, the modem sends P (private) in its place; when it is not known, O (out of area). Value 2 sends the whole caller ID message in hexadecimal instead, for programs that decode it themselves.

Syntax:

- AT#CID=*n* (or AT+VCID=*n*)
- AT#CID?
- AT#CID=? (gives 0,1,2)

Result code	When
OK	If *n* = 0–2.
ERROR	Otherwise.

Table 15. #CID=*n* Values

Value	Function
0	Off (*default*).
1	The fields: DATE = , TIME = , NMBR = , NAME = , a line each.
2	The whole message in hexadecimal: MESG = .

Example output: AT#CID=1, then a call

```
RING

DATE = 1030
TIME = 1043
NMBR = +15551234
NAME = Alice Smith

RING
```


+FAA — Adaptive Answer

With +FAA=1, a call the modem answers (ATA, S0) in data or fax mode is answered as a data call (its answer tone, V.8's ANSam, serves a fax machine as its CED), and found out to be a fax machine's or a data modem's:

- a fax call by the caller's CNG (1100 Hz, 0.5 s of every 3.5 s; or a burst cut short as the answer tone starts, a fax machine that stops its CNG on hearing it), the V.8 CM of a fax call (a call function of facsimile, as V.34 fax machines and some Class 1 modems send it on ANSam), the far end going over to T.38 (dmodemd's SIP calls), or a caller silent through every answer signal of the automode chain (ANSam, then V.32's, V.22's, V.21's, V.23's and Bell 103's, some 20 s, within T.30's T1 of 35 s): FAX, +FCLASS becomes 1, and the modem goes on as a Class 1 answerer: what is left of CED's 3 s, then CONNECT, as after AT+FTH=3, for the DTE's first frames;
- a data call by its modem's handshake: DATA when it comes up, then its CONNECT; +FCLASS becomes 0.

A call that ends with neither leaves +FCLASS as it was. A V.22, V.21 or Bell 103 caller, silent until it hears its own answer signal, answers its stage of the chain: DATA. In voice mode see Section 19: a calling tone on the call switches it to fax or data. Rockwell's modems give FAX and DATA too, as 33 and 35 with VO: here those are rates' CONNECTs, so 88 and 89.

Syntax:

- +FAA=*n*
- +FAA? (gives +FAA: 0)
- +FAA=? (gives +FAA: (0,1))

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

Table 44. +FAA Values

Value	Meaning
0	Answer as +FCLASS says (*default*; Z sets it).
1	Adaptive answer: fax or data.

17 Fax Commands

With AT+FCLASS=1, the modem takes T.31's Class 1 commands, the fax machine's side being the DTE's (the PBX modules and libdmodem have a T.30 engine of their own as well). As the caller, the modem sends CNG after dialing until the answerer's flags come in its first +FRH=3 (T.30 has it until the DIS).

+FCLASS — Service Class

This command sets whether the modem is a data modem, a Class 1, Class 2 or 2.0 fax modem or a voice modem. ATZ sets 0.

Syntax:

- +FCLASS=*n*
- +FCLASS? (gives the class)
- +FCLASS=? (gives 0,1,2,2.0,8)

Result code	When
OK	If *n* = 0, 1, 2, 2.0 or 8.
ERROR	Otherwise.

Table 43. +FCLASS Values

Value	Class
0	Data (*default*).
1	Fax Class 1 (T.31).
2	Fax Class 2 (Section 17.1).
2.0	Fax Class 2.0 (T.32, Section 17.1).
8	Voice (V.253, Section 19).

Technical details:

- DATE is the month and day (MMDD), TIME the hour and minute (HHMM).
- In voice mode (+FCLASS=8) the lines come as V.253's complex event report, between <DLE>X and <DLE>.; in the other modes after an empty line.
- On a telephone line the modem listens for caller ID after the first ring (North America's way, and ETSI's after a short ring). On a line it hears on hook (ALSA, a pipe, the pico-serial Line) it also listens before the ring (ETSI's after its alerting tone, the UK's, DTMF caller ID).
- It takes Bell 202 FSK and V.23 FSK (ETSI EN 300 659-1, BT SIN 227) alike, and DTMF caller ID: A and the number, or B (or D) and a reason it is absent (10 private, as P; others 0), up to C, # or a pause.
- In voice mode with the line taken it takes Type II caller ID too, a waiting call's caller: after the CPE alerting signal (2130 and 2750 Hz) it answers with DTMF A (GR-30's, a CPE without ADSI) and reports the FSK message that follows as a packet, the line's audio to the DTE silent meanwhile.
- A SIP call (dmodemd -L) has its caller ID from the INVITE: the caller's P-Asserted-Identity, else its From (the URI's user part as NMBR, the display name as NAME), the date and time the host's. A withheld number or name (the Privacy header's id, user or header, or an anonymous caller) is P; with value 2 the modem sends the MDMF message it made of them.

9 Speaker, Line and Country

Ln — Speaker Volume

This command sets the speaker's volume (S30). A SIP line has no speaker: the setting is kept. A SmartUSB56 with `dmodemd -usb-buzzer` sounds its buzzer while the speaker is on, at any volume but L0.

Result code	When
OK	If *n* = 0–3.
ERROR	Otherwise.

Table 16. L*n* Commands

Command	Function
L0	Off.
L1	Low volume.
L2	Medium volume.
L3	High volume (*default*).

Mn — Speaker Control

This command sets when the speaker is on (S29).

Result code	When
OK	If *n* = 0–3.
ERROR	Otherwise.

Table 17. M*n* Commands

Command	Function
M0	Speaker always off.
M1	Speaker on until the call is up (*default*).
M2	Speaker always on.
M3	As M1 (on other modems: not while dialing).

S104—Data Compression

%C's setting, and &K's.

- Range: 0–3
- *Default*: 3
- Units: none

S105—MNP Block Size

\A's setting.

- Range: 0–3
- *Default*: 3
- Units: none

S106—Protocol in CONNECT

\V's setting.

- Range: 0–2
- *Default*: 0
- Units: none

S161—Long Space Disconnect

Y's setting, kept. ATZ keeps it.

- Range: 0–3
- *Default*: 0
- Units: none

S60—Data Carrier Detect

`&C`'s setting, kept.

- Range: 0, 1
- *Default*: 0
- Units: none

S62—Flow Control

`&H`'s setting, kept.

- Range: 0–3
- *Default*: 0
- Units: none

S70—Connection Lines

`&A`'s setting.

- Range: 0–7
- *Default*: 0
- Units: bits

S71—Rate in CONNECT

`&E`'s setting, kept.

- Range: 0, 1
- *Default*: 0
- Units: none

S92—Answer Delay

How long the modem waits after going off hook to answer before its answer tone; 0 waits 10 ms. Elsewhere S92 is a fax transmit level: `ATS92=10` here makes the modem wait 10 s.

- Range: 0–255
- *Default*: 2
- Units: seconds

S103—Error Correction

`\N`'s setting; setting the register is `\N`.

- Range: 0–5
- *Default*: 3
- Units: none

`&Jn` — Auxiliary Relay

Accepted, changing nothing: there is no relay.

Result code	When
`OK`	If *n* = 0 or 1.
`ERROR`	Otherwise.

`&Ln` — Leased Line

This command sets whether the line is a dialled one or a leased pair or circuit, with no exchange: no dial tone, ringing or hook (S47). On a leased line `ATD` (any number, or none) calls at once, listening only for the answer tone; `ATA` answers; with S0 above 0 the modem answers by itself, with no ring, whenever it is idle. A call the line ends (`NO CARRIER`) starts again by itself 2 s later, dialled or answered as before; `ATH`, `DTR`, `ATZ` or `&L0` stop that until the next command line.

Every voice band modulation of `+MS` runs on `&L1`. On `&L2` the 4-wire modulations (`+MS=V29`, `V33`, `V27TC`) run as duplex pumps on a continuous carrier, each end starting at once with its own synchronizing signal; the others run as on `&L1`. With `S48=1`, on a call with no error correction, the modem does `V.13`'s simulated carrier control: between the `DTE`'s bursts of data the line carries `V.13`'s idle pattern, which the far end takes for carrier detect OFF, and each burst turns it ON again. A line at 48000 Hz and more (`dmodemd`'s `-r 96000`) is always leased: its mode is `+MS=VWB`, and its start-up and retrains take S7 seconds at most.

Result code	When
`OK`	If *n* = 0–2.
`ERROR`	Otherwise.

Table 18. &L*n* Commands

Command	Function
`&L0`	A dialled line (*default*).
`&L1`	A 2-wire leased line.
`&L2`	A 4-wire leased line.

+GCI — Country of Installation

This command sets the country by its T.35 code in hexadecimal (+GCI:b5 is the USA). The country sets its dial pause (S8) and hook flash (S24) times, its pulse dialing and its tones. dmodemd's -c option names the country it starts with (-countrylist lists them): one of the table's, or any of the 192 of the ITU's list of the tones of national networks (after E.180), by its name there in capitals or the table's (-c FIJI, -c UNITED_KINGDOM: UK). The table's countries have their own dialling settings; the others the USA's (ATI7: Country: FIJI (USA line)), and all of them their own busy and congestion tones. ATZ keeps the country.

Syntax:

- +GCI=*h*
- +GCI? (gives +GCI:b5)
- +GCI=? (lists the codes)

Result code	When
OK	Always.
ERROR	For a code that is not in the table.

S39—Line Quality Monitor

%E's setting, kept.

- Range: 0–2
- *Default*: 0
- Units: none

S44—V.cvm Tones Loaded

The tones loaded in the receive direction of the last V.cvm call (+CVM). Read only.

- Range: 0–255
- *Default*: 0
- Units: tones

S45—V.cvm Renegotiations

The renegotiations of the last V.cvm call. Read only.

- Range: 0–255
- *Default*: 0
- Units: none

S47—Leased Line

&L's setting: 0 a dialled line, 1 a 2-wire leased line, 2 a 4-wire one. ATZ keeps it.

- Range: 0–2
- *Default*: 0
- Units: none

S48—Simulated Carrier Control

1: V.13's simulated carrier control on a leased line, on a call with no error correction (&L). ATZ keeps it.

- Range: 0, 1
- *Default*: 0
- Units: none

S56—Result Code Set

X's setting.

- Range: 0–4
- *Default*: 4
- Units: none

S24—Hook Flash Time

The length of a hook flash. The country sets it.

- Range: 0–255
- *Default*: 20 (the country's)
- Units: 0.01 s

S28—Pulse Dial Ratio

`&P`'s setting, kept: the country's table sets the pulse times. `ATZ` keeps it.

- Range: 0–3
- *Default*: 0
- Units: none

S29—Speaker Control

`M`'s setting.

- Range: 0–3
- *Default*: 1
- Units: none

S30—Speaker Volume

`L`'s setting.

- Range: 0–3
- *Default*: 3
- Units: none

S31—Automode

`N`'s setting, and `+MS`'s second parameter.

- Range: 0, 1
- *Default*: 1
- Units: none

S32—Modulation

`+MS`'s modulation, by its number (Table 19).

- Range: the numbers of Table 19
- *Default*: 92 (200 at 48000 Hz and more)
- Units: none

10 Modulation

+MS — Modulation Selection

This command sets the modulation the modem calls or answers with, whether it may fall back (*automode* 1, as `N1`; `S31`), and the rates it may connect at, *min* to *max* bit/s. *mod* is a number or `V.250`'s name for it, in either case (`AT+MS=V34` is `AT+MS=34`). A parameter left out keeps its value: `AT+MS=,0` only turns automode off. In `V.34`, *max* caps both directions' rates (sent in its `MP` sequences).

Syntax:

- `+MS=[`*mod*`][,[`*automode*`][,[`*min*`][,[`*max*`]]]]`
- `+MS? (gives 92,1,300,56000; 200,1,300,56000 at 48000 Hz and more)`
- `+MS=? (gives (21,22,23,27,29,122,32,132,33,34,103,18,45,110,212,56,90,91,92,150,200,64),(0,1),(300-56000),(300-56000), the modulations the program has)`

Result code	When
`OK`	Always.
`ERROR`	For a modulation the modem has not, *automode* over 1, *min* over *max*, or a rate outside 300 to 56000.

Table 19. +MS Modulations

mod	Name	Standard	Description
21	`V21`	`ITU V.21`	300 bit/s `FSK`.
23	`V23C`	`ITU V.23`	1200/75 bit/s `FSK`.
103	`B103, BELL103`	Bell 103	300 bit/s `FSK`.
22	`V22`	`ITU V.22`	1200 bit/s `DPSK`.
212	`B212, BELL212A`	Bell 212A	1200 bit/s `DPSK`.
122	`V22B`	`ITU V.22bis`	2400 bit/s, `V.22` as its fallback.
32	`V32`	`ITU V.32`	4800 and 9600 bit/s.
132	`V32B`	`ITU V.32bis`	4800 to 14400 bit/s.
29	`V29`	`ITU V.29`	4800 to 9600 bit/s, 4-wire leased.
33	`V33`	`ITU V.33`	12000 and 14400 bit/s, 4-wire leased.

Table 19. +MS Modulations *(continued)*

mod	Name	Standard	Description
27	V27TC	ITU V.27ter	2400 and 4800 bit/s, 4-wire leased.
34	V34	ITU V.34	2400 to 33600 bit/s, after V.8.
90	V90	ITU V.90	As the digital modem, after V.8.
91	V91	ITU V.91	Two digital modems, after V.8.
92	V92	ITU V.92	V.90 with quick connect, PCM upstream and modem-on-hold (*default*).
56	K56	K56flex	Not implemented: runs V.90.
150	VCVM	V.cvm	Data over mobile speech paths, 175 to 3500 bit/s, after V.8 (+CVM).
200	VWB	V.wb	Wideband DMT on a dry pair, at 48000 Hz and more, up to 148656 bit/s each way.
64	CLEAR	Clear channel	64000 bit/s on a clear digital channel (an ISDN data call), no modulation (+B2).
18	V18	ITU V.18	Text telephone automoding (Section 18).
45	BAUDOT	V.18, TIA-825-A	5-bit text telephone: TTY, telex, RTTY (+MBAUDOT).
110	EDT	V.18	EDT text telephone, 110 bit/s.

The 4-Wire Modulations. V.29, V.33 and V.27ter are the 4-wire leased line modulations (&L2): each end sends on its own pair, on a carrier that stays on. *max* sets the rate each end sends at, *min* the lowest it comes down to: a receiver finds the far end's rate by itself, an end faster than the far end comes down to its rate, and one that loses its equalization twice in 20 s at its own rate takes the next rate down. A receiver that loses its equalization sends its synchronizing signal again and gets the far end's back (V.29 10, V.33 9).

V.90, V.91 and V.92. V.90 and V.92 are there as the *digital* modem (the server's side, as on a G.711 VoIP line), on an 8000 Hz G.711 line: analogue V.90 and V.92 modems calling connect at up to 56000 bit/s downstream. 90 and 92

S12—Escape Guard Time

Kept: the escape's guard time is always 0.5 s.

- Range: 0–255
- *Default*: 50
- Units: 0.02 s

S13—Echo

E's setting.

- Range: 0, 1
- *Default*: 1
- Units: none

S14—Quiet

Q's setting.

- Range: 0, 1
- *Default*: 0
- Units: none

S15—Verbose

V's setting.

- Range: 0, 1
- *Default*: 1
- Units: none

S16—Tone or Pulse Dialing

1 tone (T), 0 pulse (P).

- Range: 0, 1
- *Default*: 1
- Units: none

S18—Loop Test Timer

A loop test (&T) ends after this many seconds; 0, never. ATZ keeps it.

- Range: 0–255
- *Default*: 0
- Units: seconds

S7—Connection Completion Time-Out

How long the modem waits for the call to come up after dialing or answering: the answer and the training. The dial string's W and @ wait this long too, and voice mode's +VRN no longer. V.cvm's start-up takes 15 to 21 s, so S7 should allow for it.

- Range: 0–255
- *Default*: 60
- Units: seconds

S8—Pause Time for Comma Dial Modifier

The pause of a , in the dial string. The country (+GCI) sets it.

- Range: 0–255
- *Default*: 2 (the country's)
- Units: seconds

S9—Carrier Detect Response Time

Kept: the modulations detect the carrier by themselves.

- Range: 0–255
- *Default*: 6
- Units: 0.1 s

S10—Automatic Disconnect Delay

How long the carrier may be gone before the modem hangs up with `NO CARRIER`.

- Range: 0–255
- *Default*: 7
- Units: 0.1 s

S11—DTMF Dialing Speed

The length of each DTMF digit dialed, and of the gap after it. A value below 40 dials at 95.

- Range: 0–255
- *Default*: 100
- Units: milliseconds

offer V.91 too, which two digital modems use instead, and V.34 for the others; on a line at another sample rate they are V.34. With automode V.8 and the V.34 modem hand over to V.32bis (and its V.22bis and V.22) for a modem without V.34, and the answering modem tries V.23 and Bell 103 for one without V.8.

On an Analogue Line. On an analogue telephone line (dmodemd's -a and -usb) the modem is the call's analogue end instead: V.90 and V.92 run as the analogue modem against a V.90 or V.92 server (at 9600 Hz; see docs/hardware.md), and V.91 and CLEAR, which need a digital line, run as V.34.

V.cvm. VCVM is the proposed Recommendation of docs/v_cvm.pdf, for calls whose speech path is a mobile codec's (AMR, AMR-WB), which carry neither V.34 nor V.32: V.8 with V.22 and V.21 as the fallback, then a probing of the codec and a mode loaded for it. The start-up takes 15 to 21 s; S7 should allow for it. The connection runs LAPM. V_CVM, its old name, is still taken.

V.wb. VWB is D-Modem's own mode for a dry copper pair between two of its modems (pico-serial's WB stick, a codec at 96 kHz): discrete multitone, the caller on the lower tones and the answerer on the upper, each tone loaded from its measured SNR; see docs/dsp/vwb.md. It runs at 48000 Hz and more only, where it is the only mode and the *default* (ATZ sets it again there), as a leased line (&L1); the rates of +MS do not limit it.

Clear Channel. CLEAR is a clear 64 kbit/s digital channel, such as an ISDN B-channel's data call (a SIP call in CLEARMODE, RFC 4040, or a PBX's call with an unrestricted digital bearer): no modulation, each of the channel's octets 8 bits of the link's, `CONNECT 64000` both ways. It starts at once on ATD and ATA, with no call progress and no answer tone. Each octet's first bit is its most significant (I.460, RFC 4040). A line that says its call is clear (dmodemd's SIP for a CLEARMODE call, app_dmodem for an ISDN data call) runs it whatever +MS says. What runs on the channel is +B2's, X.75 by *default*, or V.110's rate adaption with +CBST. See docs/isdn.md.

Bn — Communication Standard Setting

ATB with no number sets V.22 at 1200 bit/s only, without automode: the same as AT+MS=22,0,1200,1200. Other modems use B0 to B3, B15 and B16 to choose between the ITU and the Bell modulation at 1200 and 300 bit/s. The modem accepts them and changes nothing: the call's negotiation and +MS choose.

Result code	When
OK	If *n* is left out, or *n* = 0–3, 15 or 16.
ERROR	Otherwise.

Table 20. B*n* Commands

Command	Function
B	V.22 at 1200 bit/s, no automode.
B0, B1	Accepted (other modems: V.22 or Bell 212A at 1200 bit/s).
B2, B3	Accepted (other modems: V.23's reverse channel).
B15, B16	Accepted (other modems: V.21 or Bell 103 at 300 bit/s).

Nn — Automode

This command sets whether the modems may find their best common modulation from the one +MS chose down (S31). It is the same as +MS's second parameter.

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

Table 21. N*n* Commands

Command	Function
N0	Only the modulation +MS chose.
N1	Automode: that modulation or the best common one below it (*default*).

S1—Ring Counter

The rings counted so far: S0 compares it with its own value.

- Range: 0–255
- *Default*: 0
- Units: rings

S2—Escape Character

The ASCII value of the character of the escape sequence, +++ (Section 20).

- Range: 0–255
- *Default*: 43 (+)
- Units: ASCII

S3—Command Line Termination Character

The character that ends a command line and the result codes.

- Range: 0–255
- *Default*: 13 (carriage return)
- Units: ASCII

S4—Response Formatting Character

The line feed after the result codes; a command line ends at it as well.

- Range: 0–255
- *Default*: 10 (line feed)
- Units: ASCII

S5—Command Line Editing Character

The backspace: it takes back the last character typed. With echo on, the modem echoes it, a space and the backspace again.

- Range: 0–255
- *Default*: 8 (backspace)
- Units: ASCII

S6—Wait Time for Dial Tone

With X2 or X4, how long the modem waits for a dial tone before NO DIALTONE: 2 s at least whatever the value, and 2 s more while a dial tone in a cadence is heard.

- Range: 0–255
- *Default*: 2
- Units: seconds

Table 42. S-Register Summary *(continued)*

Reg.	Description	Range	Unit	Default
S45	V.cvm: renegotiations (read only).	0–255	–	0
S47	Leased line (&L).	0–2	–	0
S48	V.13 simulated carrier.	0, 1	–	0
S56	Result codes and dial tone (X).	0–4	–	4
S60	Carrier detect (kept).	0, 1	–	0
S62	Flow control (kept).	0–3	–	0
S70	CONNECT's lines (&A).	0–7	–	0
S71	CONNECT's rate (kept).	0, 1	–	0
S92	Answer delay.	0–255	s	2
S103	Error correction (\N).	0–5	–	3
S104	Data compression (%C).	0–3	–	3
S105	MNP block size (\A).	0–3	–	3
S106	Protocol in CONNECT (\V).	0–2	–	0
S161	Y (kept).	0–3	–	0

16.1 S-Register Definitions

The range given is what the register means; ATS takes any value from 0 to 255 for any register but S44 and S45, which are read only. ATZ sets the registers to their *defaults*, but for S18, S28, S47, S48 and S161, which keep their values.

S0—Auto-Answer Ring Number

The number of rings the modem counts before it answers a call by itself. 0 disables auto-answer: the modem then answers only with ATA. On a leased line (&L) a value above 0 makes the modem answer, with no ring, whenever it is idle.

- Range: 0–255
- *Default*: 0
- Units: rings

Cn — Carrier Control

The modem accepts C1 so that software that sends it works. It does not have C0, which on some other modems sends no carrier (receive only).

Result code	When
OK	If *n* = 1.
ERROR	Otherwise (C alone is C0).

Table 22. C*n* Commands

Command	Function
C0	Carrier always off (not supported).
C1	Normal carrier switching (*default*).

&Bn — V.32 Auto Retrain

Other modems use &B for V.32's retrain (USRobotics': the DTE's rate fixed). The modem accepts it and changes nothing: its modulations retrain by themselves.

Result code	When
OK	If *n* = 0–2.
ERROR	Otherwise.

&Gn — V.22bis Guard Tone

Accepted, changing nothing: the modem sends no guard tone.

Result code	When
OK	If *n* = 0–2.
ERROR	Otherwise.

&N*n* — Line Rate

USRobotics' choice of the line's rate: accepted, changing nothing. +MS sets the rates.

Result code	When
OK	If *n* = 0–14.
ERROR	Otherwise.

16 S-Registers

The S-registers hold the modem's settings, 8 bits each. ATS reads and sets them: ATS*n*? gives register *n*'s value, ATS*n*=*v* sets it. Registers 0 to 255 are there; those not listed are 0 and free, kept as written. "Kept" below means set and read back, with no other effect.

Table 42. S-Register Summary

Reg.	Description	Range	Unit	Default
S0	Rings to answer after.	0–255	rings	0
S1	Ring counter.	0–255	rings	0
S2	Escape character.	0–255	ASCII	43
S3	Command line end.	0–255	ASCII	13
S4	Line feed.	0–255	ASCII	10
S5	Backspace.	0–255	ASCII	8
S6	Wait for dial tone.	0–255	s	2
S7	Wait for the call to come up.	0–255	s	60
S8	Comma's pause.	0–255	s	2
S9	Carrier detect time (kept).	0–255	0.1 s	6
S10	Carrier loss before hanging up.	0–255	0.1 s	7
S11	DTMF tone and gap.	0–255	ms	100
S12	Escape guard time (kept).	0–255	20 ms	50
S13	Echo (E).	0, 1	–	1
S14	Quiet (Q).	0, 1	–	0
S15	Verbose (V).	0, 1	–	1
S16	Tone or pulse dialing.	0, 1	–	1
S18	Loop test time.	0–255	s	0
S24	Hook flash time.	0–255	10 ms	20
S28	Pulse ratio (kept).	0–3	–	0
S29	Speaker control (M).	0–3	–	1
S30	Speaker volume (L).	0–3	–	3
S31	Automode (N).	0, 1	–	1
S32	Modulation (+MS).	Table 19	–	92
S39	Line quality (kept).	0–2	–	0
S44	V.cvm: tones loaded (read only).	0–255	tones	0

Table 41. CONNECT Rates and Their Numbers *(continued)*

Rate	n	Rate	n	Rate	n	Rate	n
7200	13	29333	47	42666	54	57333	83
9600	27	30666	48	44000	28	57600	35
12000	14	31200	22	45333	55	58000	44
14400	15	32000	40	46000	29	58666	84
16800	16	33333	49	46666	56	60000	45
19200	17	33600	23	48000	30	61333	85
21600	18	34666	50	49333	57	62666	86
		36000	42	50000	31	64000	87

10.1 V.cvm

+CVM — V.cvm Settings

For +MS=VCVM: *modes*, the modes allowed, a sum of the values below; *rate*, the signal interface's rate, 8000 or 16000; *report*, 0 or 1, asks for +CVMR on each renegotiation. D-Modem keeps *rate* and *report* but works at 8000 Hz only, without the wideband modes, and sends no +CVMR. During and after a V.cvm call, +CVM? gives a second line with that call's figures: +CVM: *raw tx*, *raw rx*, *coded tx*, *coded rx*, *symbol ms*, *tones tx*, *tones rx*, *code rate*, *renegotiations*, *erasures* (+CVM: 1600,1600,1400,1400,20.0,16,16,7/8,0,0; the tones are 0 in the parametric mode). The call's CONNECT has its coded receive rate and /CVM: CONNECT 1200/CVM, with \V1 CONNECT 1200/CVM/LAPM. S44 and S45 hold the tones loaded and the renegotiations.

Syntax:

- +CVM=[*modes*][,[*rate*][,[*report*]]]
- +CVM? (gives +CVM: 63,8000,0)
- +CVM=? (gives +CVM: (0-63),(8000,16000),(0,1))

Result code	When
OK	Always.
ERROR	For a value outside its range.

Table 23. +CVM Modes

Value	Mode
1	The robust mode.
2	Narrowband.
4	Wideband (not supported).
8	8-DPSK.
16	The amplitude rings.
32	The parametric mode.
63	All of them (*default*).

10.2 V.92 Call Waiting and Modem-on-Hold

+PCW, +PIG — V.92 Call Waiting and PCM Upstream

+PCW (0 to 2, *default* 2) is V.92's call waiting: none is detected here. +PIG (0 or 1, *default* 1) is V.92's PCM upstream, an analogue modem's setting. Kept.

+PMH — Modem-on-Hold Enable

This command sets whether the other modem may put the call on hold.

Syntax:

- +PMH=*n*
- +PMH? (gives +PMH: 0)
- +PMH=? (gives +PMH: (0-1))

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

Table 24. +PMH Values

Value	Meaning
0	The other modem may put the call on hold (*default*).
1	It may not.

+PMHT — Modem-on-Hold Timer

How long a hold the modem grants: the code of V.92's Table 33, 0 to 13; 0 grants none.

Syntax:

- +PMHT=*n*
- +PMHT? (gives +PMHT: 5)
- +PMHT=? (gives +PMHT: (0-13))

Result code	When
OK	If *n* = 0–13.
ERROR	Otherwise.

15 Result Codes

Each command line is answered with a result code, as a word (V1) or a number (V0), each on a line of its own; Q1 turns them off.

Table 40. Result Codes

Result code	Number	Description
OK	0	The command line ran.
CONNECT	1	The call is up (X0, fax and voice), or a fax command's data begins.
CONNECT *rate*	Below	A data call is up at *rate*.
RING	2	A call rings (dmodemd: every 3 s, Section 21).
NO CARRIER	3	No call came up, or the call is over.
ERROR	4	A command failed, or a line was too long.
NO DIALTONE	6	No dial tone (X2, X4).
BUSY	7	A busy tone (X3, X4).
NO ANSWER	8	No answer within S7 seconds of dialing.
FAX	88	Adaptive answer (+FAA=1): a fax call; Class 1 follows.
DATA	89	Adaptive answer: a data call; its CONNECT follows.

A data call's CONNECT gives the rate the modem receives at, in bit/s (CONNECT 33600), and with V0 that rate's number (23). With X0, in fax and in voice mode it is CONNECT (1) alone. \V1 adds the error correction and the compression (CONNECT 33600/LAPM/V42bis), and &A adds lines on the connection before it. Each rate's number is in the table below; a rate not in it is 1.

Table 41. CONNECT Rates and Their Numbers

Rate	n	Rate	n	Rate	n	Rate	n
75	80	24000	19	37333	51	50666	58
300	9	25333	81	38000	43	52000	32
600	10	26400	20	38666	52	53333	59
1200	5	26666	82	40000	25	54000	33
2400	11	28000	46	41333	53	54666	60
4800	12	28800	21	42000	26	56000	34

+CRC — Cellular Result Codes

27.007's: with 1, each ring of a call is +CRING: SYNC for a call on a clear 64 kbit/s channel (an ISDN data call: SIP's CLEARMODE, a PBX's digital bearer, an mISDN card's unrestricted digital call) and +CRING: VOICE for any other, instead of RING (in words whatever V says). A program that answers by itself (dmodem-capid, CAPI on a D-Modem) tells the two apart by it. &V lists it.

Syntax:

- +CRC=*n*
- +CRC? (gives +CRC: 0)
- +CRC=? (gives +CRC: (0,1))

Result code	When
OK	If *n* = 0 (RING, the *default*) or 1.
ERROR	Otherwise.

+PMHR — Modem-on-Hold Request

In online command mode on a V.92 connection, this command asks the other modem to go on hold for *s* seconds (1 to 960; 10 if left out).

Syntax:

- +PMHR[=*s*]

Result code	When
OK	Always.
ERROR	Outside online command mode of a V.92 call, or for *s* outside 1 to 960.

11 Error Control

+ES — Error Control Selection

V.250's error control selection: what the modem tries first as the originator (*orig*), what may follow when that fails (*orig_fb*), and what it accepts as the answerer (*ans_fb*). \N sets it, and it sets S103 to the \N with its values (as it was if none has them). V.80's Synchronous Mode and Frame Tunnelling Mode (5 and 7, 7 and 9) are not there.

Syntax:

- +ES=[*orig*][,[*orig_fb*][,[*ans_fb*]]]
- +ES? (gives +ES: 3,0,2)
- +ES=? (gives +ES: (0-4,6),(0-4),(0-6,8))

Result code	When
OK	Always.
ERROR	For a value outside its range.

Table 25. +ES Values

Parameter	Value	Meaning
orig	0, 1	No error correction.
	2	V.42 (LAPM) without the detection phase.
	3	V.42 with the detection phase (*default*).
	4	MNP first (no detection phase, no LAPM).
	6	V.80's Synchronous Access Mode (Section 11.1).
orig_fb	0, 1	None (*default* 0).
	2	V.42 or MNP, or hang up.
	3	V.42 only.
	4	MNP only (and first).
ans_fb	0, 1	No error correction.
	2, 3	V.42, MNP or none (*default* 2).
	4	V.42 or MNP, or hang up.
	5	V.42 only.
	6	MNP only.
	8	V.80's Synchronous Access Mode.

+CBST — Bearer Service Type (V.110)

27.007's bearer service: V.110's rate adaption on a clear channel (+MS=CLEAR). *name* 0 (the *default*) is asynchronous: the DTE's characters through the modem's link (\N) whatever +B2 says; 1 is synchronous: +B2's protocol in HDLC at the user rate. *ce* has no use here. CONNECT gives the user rate (with \V1 and no V.42, /V.110). &V lists it. See docs/isdn.md.

Syntax:

- +CBST=[*speed*][,[*name*][,[*ce*]]]
- +CBST? (gives +CBST: 0,0,0)
- +CBST=?

Result code	When
OK	For a *speed* below, *name* 0 or 1, *ce* 0 or 1.
ERROR	Otherwise.

Table 39. +CBST Speeds

Value	User rate
0	None (*default*): an answerer takes the rate of the caller's frames (600 to 38400) if they come.
65, 66, 68, 70	300, 1200, 2400, 4800 bit/s (intermediate rate 8k).
71	9600 bit/s (16k).
75, 79	14400, 19200 bit/s (32k).
80, 81	28800, 38400 bit/s (64k).
83	56000 bit/s (7 bits an octet, no frames).

14 ISDN and Cellular

+B2 — B-Channel Protocol

D-Modem's own, with CAPI 2.0's numbers for layer 2: what runs on a clear 64 kbit/s channel (+MS=CLEAR, or a line that says its call is clear); other modes do not look at it. &V lists it.

Syntax:

- +B2=*n*
- +B2? (gives +B2: 0)
- +B2=? (gives +B2: (0,5,7,9))

Result code	When
OK	If *n* = 0, 5, 7 or 9.
ERROR	Otherwise.

Table 38. +B2 Values

Value	Protocol
0	X.75 (LAPB in HDLC, basic mode, a window of 7, the caller at address B), the protocol of ISDN terminal adapters, BBSes and mailers: the DTE's characters go in I frames of up to 256 octets; CONNECT 64000, with \V1 CONNECT 64000/X.75; ATH sends DISC (*default*).
5	Synchronous PPP (RFC 1618): the DTE speaks PPP's asynchronous framing (RFC 1662, as pppd does on a serial port), each frame goes to the line in HDLC with its escapes undone and comes back escaped; /PPP with \V1.
7	The modem's link (V.42, MNP or plain characters, as \N says), for the clear channel of an earlier D-Modem.
9	V.120 (Q.921's frames for logical link 256 in extended mode, each I frame's information after V.120's header octet 0x83), the protocol of North American terminal adapters; /V.120 with \V1.

&Q*n* — Error Control Mode

Other modems' choice of error correction, as \N. &Q alone is &Q0. The synchronous modes are not there.

Result code	When
OK	If *n* = 0, 5, 6, 8 or 9.
ERROR	Otherwise.

Table 26. &Q*n* Commands

Command	Function
&Q0, &Q6	No error correction (\N0).
&Q5, &Q8, &Q9	V.42, then MNP, then none (\N3).

\Nn — Error Control Mode

This command sets the error correction (S103), as Rockwell's modems have it. Each value sets +ES to V.250's equal. ATS103=*n* is \N*n*.

V.42's detection phase decides between LAPM and none. The originator sends MNP's LR when the answerer sends no V.42 answer, and the answerer takes an LR (from a modem with MNP only, or one set so) as the start of MNP. With MNP only the originator starts with its LR. MNP 5 compression goes with MNP (%C); MNP's block size is \A's.

Result code	When
OK	If *n* = 0–5.
ERROR	Otherwise.

Table 27. \N*n* Commands

Command	Function	+ES
\N0	Normal: no error correction.	1,0,1
\N1	Direct: no error correction.	0,0,0
\N2	Reliable: V.42 (LAPM) or MNP, else hang up.	3,2,4
\N3	Auto-reliable: V.42, MNP, or none (*default*).	3,0,2
\N4	V.42 (LAPM) only, else hang up.	3,3,5
\N5	MNP only, else hang up.	4,4,6

&Mn — Asynchronous Communications Mode

Accepted, changing nothing (other modems: asynchronous mode; USRobotics': error correction, here \N).

Result code	When
OK	If *n* = 0, 4 or 5.
ERROR	Otherwise.

\Rn — Ring Indicator After Answer

Accepted, changing nothing.

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

\Tn — Inactivity Timer

Accepted, changing nothing.

Result code	When
OK	If *n* = 0–255.
ERROR	Otherwise.

+ILRR, +IDSR, +ILSD — DTE Rate Report, DSR, Long Space

The DTE's rate reported, DSR, long space disconnect: kept. Each 0 or 1, *default* 0.

&Dn , &Fn , &Rn , &Sn — DTR, Factory Defaults, RTS, DSR

The modem accepts these, with or without a digit, and does nothing: ATZ gives the *defaults*, and dmodemd hangs up when the DTE drops DTR whatever &D says (Section 20).

Result code	When
OK	Always.

Fn — On-Line Data Character Echo

The modem accepts F1 so that software that sends it works. Other modems' F0 echoes the data online; this modem never does.

Result code	When
OK	If *n* = 1.
ERROR	Otherwise (F alone is F0).

\Jn — Rate Adjust

Other modems' DTE rate following the line's: accepted, changing nothing.

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

\Kn — Break Control

What a break does on other modems: accepted, changing nothing.

Result code	When
OK	If *n* = 0–5.
ERROR	Otherwise.

\An — MNP Block Size

This command sets MNP's block size, the longest information field it offers (S105). As other modems do, an LR offers 64 and the 256-octet data phase optimization.

Result code	When
OK	If *n* = 0–3.
ERROR	Otherwise.

Table 28. \A*n* Commands

Command	Function
\A0	64 octets.
\A1	128 octets.
\A2	192 octets.
\A3	256 octets (*default*).

-SEC — MNP 10EC

Rockwell's MNP 10EC, and its transmit level (1,12): kept, *default* 0. -SEC? gives the values alone, without the name; =? gives (0,1),(0-30).

-C, -K, -Q,)M, @M, *H — Rockwell's MNP 10

Rockwell's MNP 10 and 10EC (cellular): the calling tone, MNP Extended Services, the V.22bis fallback, power levels and the link's speed. The modem has no MNP 10: it accepts them, changing nothing. A modem with MNP 10EC connects with V.42.

Result code	When
OK	For -C0, -C1, -K0 to -K2, -Q0, -Q1,)M0 to)M2, @M0 to @M30, *H0 to *H2.
ERROR	Otherwise.

11.1 V.80 Synchronous Access

With +ES=6 (calling) or +ES=,,8 (answering) the call has no error correction or compression: after CONNECT the modem moves the DTE's octets as a synchronous bit stream, with V.80's in-band commands after EM (19h) both ways (Table 9/V.80).

It starts in the *transparent* sub-mode: the DTE's octets go out as they are, least significant bit first, and the line's bits come back as octets; when the DTE has nothing the modem sends *syn1* and tells it <EM><under>. With +ESA's *trans_idle* 1 or 2 the receiver first hunts for the SYN, and gives the DTE nothing before it. <EM><flag> from the DTE starts the *framed* sub-mode: HDLC frames, each ended by the DTE's <EM><flag>, the modem adding the zero insertion, the flags and the FCS. It gives back each received frame's octets (without the FCS it checked) and <EM><flag> for a good one or <EM><err> for a bad one, an <EM><err> when its hunt finds a flag, and <EM><mark> for an abort or marks. <EM><mark> from the DTE goes back to transparent. EM and 99h in the data are shielded both ways (<EM><t1>, <EM><t2>; DC1 and DC3 too with DC1/DC3 flow control, +IFC); from the DTE all the codes T1 to T20 are taken. V.34's half duplex is not there.

Table 29. V.80 In-Band Commands

Command	From	Meaning
<EM><ecs>	DTE	Online command state (instead of +++, which is data); the modem answers <EM><ecs>, then OK; ATO goes back.
<EM><eot>	DTE	Hang up: <EM><eot>, then NO CARRIER.
<EM><rate><tx><rx>	DTE	The highest rates to send and to receive at (+MS's *max*), for the next retrain or renegotiation (AT+MS sets both again).
<EM><hunt>	DTE	Restart the receiver's hunt (framed, or transparent with *trans_idle* 1 or 2); what waits for the DTE is dropped.
<EM><resume>	DTE	Go on after an underrun (+ESA's *framed_un_ov*).
<EM><rtn>, <EM><rrn>	DTE	Retrain, or renegotiate the rate, as ATO1 and ATO3.
<EM><eot>	Modem	The remote's carrier is gone (before NO CARRIER).
<EM><rtn>, <EM><rrn>	Modem	A retrain or renegotiation but the DTE's own (the remote's, or the modem's after a loss of signal).
<EM><rate><tx><rx>	Modem	The rates, after each of those, or when they change in the call.
<EM><rover>	Modem	Received octets were lost (the DTE took nothing for 2048 octets).

&I*n* — XON/XOFF Flow Control

USRobotics' software flow control: accepted, changing nothing.

Result code	When
OK	If *n* = 0–5.
ERROR	Otherwise.

\Q*n* — Flow Control

Accepted, changing nothing: flow control is the pty's.

Result code	When
OK	If *n* = 0–3.
ERROR	Otherwise.

\G*n* — XON/XOFF Pass Through

Accepted, changing nothing.

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

&C*n* — Data Carrier Detect (DCD) Control

The modem keeps the value in S60. It changes nothing: a pty has no carrier line.

Result code	When
OK	If *n* = 0 or 1.
ERROR	Otherwise.

Table 37. &C*n* Commands

Command	Function
&C0	DCD always on (*default*).
&C1	DCD follows the carrier (on other modems).

13 DTE Interface and Flow Control

+IFC, +ICF, +IPR — DTE Interface

+IFC is the flow control each way (DC1/DC3 in V.80's Synchronous Access Mode, Section 11.1), +ICF the DTE's character framing, +IPR the DTE's rate (0 automatic).

Table 35. DTE Interface Parameters

Name	Default	Range
+IFC	2,2	(0-3),(0-2)
+ICF	3,3	(1-6),(0-3)
+IPR	0	0, 300, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800, 921600

&H*n* — Flow Control

The modem keeps the value in S62. Flow control is the pty's, so it changes nothing but what #UD reports.

Result code	When
OK	If *n* = 0–3.
ERROR	Otherwise.

Table 36. &H*n* Commands

Command	Function (as reported)
&H0	None (*default*).
&H1	RTS/CTS.
&H2	XON/XOFF.
&H3	Both.

Table 29. V.80 In-Band Commands *(continued)*

Command	From	Meaning
<EM><tover>	Modem	The DTE's octets were lost (the buffer full).
<EM><under>	Modem	The DTE ran out of data.
<EM><bnum>	Modem	The transmit buffer's count, with +ITF.

+ESA — Synchronous Access Mode Settings

The Synchronous Access Mode's eight settings, each left out as it is.

Syntax:

- +ESA=[*trans_idle*][,*framed_idle*...][,*syn2*]
- +ESA? (gives +ESA: 0,0,0,0,0,0,255,255)
- +ESA=? (gives +ESA: (0-2),(0,1),(0,1),(0),(0-2),(0),(0-255),(0-255))

Result code	When
OK	Always.
ERROR	For a value outside its range.

Table 30. +ESA Parameters

Parameter	Value	Meaning
trans_idle	0	*syn1* sent when the DTE has nothing; the receiver's octets as they come (*default*).
	1	The same, but the receiver hunts for *syn1*.
	2	*syn1* and *syn2* sent in turn; the receiver hunts for the two (*syn1* first). Each hunt gives the DTE the octets from the SYN on, aligned on it.
framed_idle	0	Flags between frames (*default*).
	1	Marks between frames.
framed_un_ov	0	The DTE runs out in a frame: an abort (*default*).
	1	A flag (no FCS). Either way the DTE's octets are then dropped until its <EM><resume>, which <EM><unum> and their count answer (both: <EM><under>).
hd_auto	0	Only 0.
crc_type	0	No FCS (*default*).

Table 30. +ESA Parameters *(continued)*

Parameter	Value	Meaning
	1	FCS-16.
	2	FCS-32 (V.42's).
nrzi_en	0	Only 0.
syn1, syn2	0–255	The SYN octets (*default* 255).

+ITF — Transmit Buffer Thresholds

The Synchronous Access Mode's transmit buffer: the DTE's octets in it, EM codes included, stop being taken above *off*; *on* is kept. With *report_period* not 0 the modem gives <EM><bnum> with their number every *report_period* times 10 ms.

Syntax:

- +ITF=[*off*][,[*on*][,[*report_period*]]]
- +ITF? (gives +ITF: 383,128,0)
- +ITF=? (gives +ITF: (1-4095),(0-4094),(0-500))

Result code	When
OK	Always.
ERROR	For a value outside its range, or *off* not above *on*.

+DSZ — zstd Data Compression

D-Modem's own: *on* 1 offers zstd (Zstandard, docs/v_cvm.pdf's Annex F) in V.42's XID, beside V.42bis and V.44, whenever compression is on (%C); *dict* 1 offers it with V.cvm's dictionary. A call has zstd only when the other modem offers it too (another D-Modem): CONNECT then ends in /ZSTD, and the compression result is ZSTD (70 with V0); other modems go on with V.44 or V.42bis. 0 offers V.44 and V.42bis alone.

Syntax:

- +DSZ=[*on*][,[*dict*]]
- +DSZ? (gives +DSZ: 1,1)
- +DSZ=? (gives +DSZ: (0,1),(0,1))

Result code	When
OK	Always.
ERROR	For a value outside its range.

+DS44 — V.44 Data Compression

V.44 (V.250 6.6.2), set the same way. AT+DS=0 with AT+DS44=3 offers V.44 alone, AT+DS44=0 V.42bis alone (and zstd, unless +DSZ=0), both 0 no compression, as AT%C0. zstd has the directions either has.

Syntax:

- +DS44=[*direction*][,[*neg*][,[*capability*][,...]]]
- +DS44? (gives +DS44: 3,0,0,4096,4096,255,255,12288,12288)
- +DS44=? (gives the ranges below)

Result code	When
OK	Always.
ERROR	For a value outside its range.

Table 34. +DS44 Parameters

Parameter	Values	Meaning
direction	0-3	As +DS's (*default* 3).
neg	0, 1	1: hang up when the link comes up without V.44, or zstd in its place, in those directions.
capability	0, 1	Kept: the stream method is used whatever it says.
codewords tx, rx	256-65535	The largest codewords, each way; at most 4096.
strings tx, rx	32-255	The longest strings; at most 255.
history tx, rx	512-65535	The history, each way; at most 12288.

Of each pair the smaller is used both ways.

12 Data Compression

&K*n* — Data Compression

&K0 to &K3 set data compression as on USRobotics' modems, the same as %C (S104). Rockwell's and Conexant's modems use &K for flow control: their &K4 to &K6 are accepted with no effect, and their &K3 (RTS/CTS) leaves V.42's compression on.

Result code	When
OK	If *n* = 0–6.
ERROR	Otherwise.

Table 31. &K*n* Commands

Command	Function
&K0	No compression (%C0).
&K1, &K2	V.44, V.42bis or MNP 5 (%C3).
&K3	V.44 or V.42bis, no MNP 5 (%C2).
&K4–&K6	Accepted (other modems' flow control).

%C*n* — Data Compression Control

This command sets data compression (S104). It needs error correction (\N). V.42 offers V.44 and V.42bis both, and the other modem chooses; +DS, +DS44 and +DSZ set them in detail. &K sets the same.

Result code	When
OK	If *n* = 0–3.
ERROR	Otherwise.

Table 32. %C*n* Commands

Command	Function
%C0	No compression.
%C1	MNP 5 (with MNP).
%C2	V.44 or V.42bis (with V.42's LAPM).
%C3	Either, as the call's error correction has it (*default*).

+DS — V.42bis Data Compression

V.42bis (V.250 6.6.1), within %C's compression.

Syntax:

- +DS=[*direction*][,[*neg*][,[*dict*][,[*string*]]]]
- +DS? (gives +DS: 3,0,2048,34)
- +DS=? (gives +DS: (0-3),(0,1),(512-65535),(6-250))

Result code	When
OK	Always.
ERROR	For a value outside its range.

Table 33. +DS Parameters

Parameter	Values	Meaning
direction	0-3	The DTE's directions: 0 none, 1 what it sends, 2 what it receives, 3 both (*default*).
neg	0, 1	1: hang up (NO CARRIER) when the link comes up without compression in those directions. *Default* 0.
dict	512-65535	The largest dictionary V.42's XID offers; at most 2048, the *default*.
string	6-250	The longest string offered; at most 34, the *default*.