MODBUS SIO Master Driver

1	System Configuration	3
2	Selection of External Device	9
3	Example of Communication Setting	10
4	Setup Items	46
5	Cable Diagram	54
6	Supported Device	110
7	Device Code and Address Code	113
0	Error Maccagos	11.4

Introduction

This manual describes how to connect the Display and the External Device (target PLC). In this manual, the connection procedure will be described by following the below sections:

System Configuration "1 System Configuration" (page 3) This section shows the types of External Devices which can be connected and SIO type. Selection of External Device "2 Selection of External Device" (page 9) Select a model (series) of the External Device to be connected and connection method. **Example of Communication Settings** 3 "3 Example of Communication Setting" This section shows setting examples for (page 10) communicating between the Display and the External Device. 4 Setup Items "4 Setup Items" (page 46) This section describes communication setup items on the Display. Set communication settings of the Display with GP-Pro Ex or in offline mode. Cable Diagram 5 "5 Cable Diagram" (page 54) This section shows cables and adapters for connecting the Display and the External Device. Operation

1 System Configuration

1.1 Schneider Electric SA External Devices

The following table lists system configurations for connecting Schneider Electric SA External Devices and the Display.


Series	CPU	Link I/F	SIO Type	Setting Example	Cable Diagram
	TSX 37 05 028DR1 TSX 37 08 056DR1 TSX 37 10 128DT1 TSX 37 10 128DR1 TSX 37 10 128DTK1	TER port on CPU	RS232C	Setting Example 1 (page 10)	Cable Diagram 2 (page 65)
	TSX 37 10 126DTK1 TSX 37 10 164DTK1 TSX 37 10 028AR1 TSX 37 10 028DR1	Accessory box TSX SCA 50	RS485 (2wire)	Setting Example 3 (page 14)	Cable Diagram 3 (page 66)
Micro		TER port on CPU	RS232C	Setting Example 1 (page 10)	Cable Diagram 2 (page 65)
	TSX 37 21 101 TSX 37 22 101	Accessory box TSX SCA 50	RS485 (2wire)	Setting Example 3 (page 14)	Cable Diagram 3 (page 66)
	TSX 37 21 001 TSX 37 22 001	PCMCIA card for RS232C TSX SCP 111	RS232C	Setting Example 2 (page 12)	Cable Diagram 4 (page 77)
		PCMCIA card for RS485 TSX SCP 114	RS485 (2wire)	Setting Example 3 (page 14)	Cable Diagram 5 (page 79)
Description	TSX P57 103M TSX P57 153M TSX P57 203M	PCMCIA card for RS232C TSX SCP 111	RS232C	Setting Example 4 (page 16)	Cable Diagram 4 (page 77)
Premium	TSX P57 253M TSX P57 303M TSX P57 353M TSX P57 453M	PCMCIA card for RS485 TSX SCP 114	RS485 (2wire)	Setting Example 5 (page 18)	Cable Diagram 5 (page 79)
	TWD LCAA 10DRF TWD LCAA 16DRF TWD LCAA 24DRF	Programming port on CPU	RS232C	Setting Example 6 (page 20)	Cable Diagram 2 (page 65)
Twido TWD LM 20DUK TWD LM TWD LM	TWD LMDA 20DRT TWD LMDA 40DTK TWD LMDA	TWD NAC 485T	RS485 (2wire)	Setting Example 7 (page 22)	Cable Diagram 1 (page 54)
Quantum	140 CPU 113 02 140 CPU 113 03 140 CPU 434 12A 140 CPU 534 14A	Modbus port on CPU	RS232C	Setting Example 8 (page 24)	Cable Diagram 6 (page 85)

Series	CPU	Link I/F	SIO Type	Setting Example	Cable Diagram
	171 CCS 700 00 171 CCS 700 10 171 CCS 760 00 171 CCC 760 10	Modbus port 1 on CPU	RS232C	Setting Example 9 (page 26)	Cable Diagram 7 (page 86)
Momentum	171 CCS 780 00	Modbus port 1 on CPU	RS232C	Setting Example 9 (page 26)	Cable Diagram 7 (page 86)
	171 CCC 780 10	Modbus port 2 on CPU	RS485 (4wire)	Setting Example 10 (page 28)	Cable Diagram 8 (page 87)
	171 CCC 980 20 171 CCC 980 30	Modbus port 2 on CPU	RS485 (4wire)	Setting Example 10 (page 28)	Cable Diagram 8 (page 87)

■ Connection Configuration


◆ Micro Series

• 1:1 Connection




◆ Premium Series

• 1:1 Connection




◆ Twido Series

• 1:1 Connection




• 1:n Connection




◆ Quantum Series

• 1:1 Connection



◆ Momentum Series

• 1:1 Connection



1.2 Yokogawa Electric Corporation External Devices


The following table lists system configurations for connecting Yokogawa Electric Corp. External Devices and the Display.

Series	CPU	Link I/F	SIO Type	Setting Example	Cable Diagram
		Serial port on CPU	RS232C	Setting Example 11 (page 30)	Cable Diagram 9 (page 91)
FCN	NFCP100-S00	NFLR111-S00	RS232C	Setting Example 12 (page 34)	
T CIV		NFLR121-S00	RS485 (4 wire)	Setting Example 13 (page 38)	Cable Diagram 11 (page 93)
		NFLR121-500	RS485 (2 wire)	Setting Example 14 (page 42)	Cable Diagram 12 (page 100)
FCJ	NFJT100-S100	Serial port on CONTROL UNIT	RS232C	Setting Example 11 (page 30)	Cable Diagram 9 (page 91)


■ Connection Configuration

◆ FCN/FCJ Series

• 1:1 Connection



• 1:n Connection



■ IPC COM Port

When connecting IPC with an External Device, the COM port used depends on the series and SIO type. Please refer to the IPC manual for details.

Usable port

Series		Usable Port		
Selles	RS-232C	RS-422/485(4 wire)	RS-422/485(2 wire)	
PS-2000B	COM1 ^{*1} , COM2, COM3 ^{*1} , COM4	-	-	
PS-3450A, PS-3451A, PS3000-BA, PS3001-BD	COM1, COM2*1*2	COM2*1*2	COM2*1*2	
PS-3650A (T41 model), PS-3651A (T41 model)	COM1*1	-	-	
PS-3650A (T42 model), PS-3651A (T42 model)	COM1*1*2, COM2	COM1*1*2	COM1*1*2	
PS-3700A (Pentium®4-M) PS-3710A	COM1*1, COM2*1, COM3*2, COM4	COM3*2	COM3*2	
PS-3711A	COM1*1, COM2*2	COM2*2	COM2*2	
PS4000*3	COM1, COM2	-	-	
PL3000	COM1 ^{*1*2} , COM2 ^{*1} , COM3, COM4	COM1*1*2	COM1*1*2	

^{*1} The RI/5V can be switched. Use the IPC's switch to change if necessary.

For connection with External Device, use user-created cables and disable Pin Nos. 1, 4, 6 and 9. Please refer to the IPC manual for details of pin layout.

DIP Switch setting: RS-232C

DIP Switch	Setting	Description	
1	OFF*1	Reserved (always OFF)	
2	OFF	SIO type: RS-232C	
3	OFF	510 type. R5-232c	
4	OFF	Output mode of SD (TXD) data: Always output	
5	OFF	Terminal resistance (220Ω) insertion to SD (TXD): None	
6	OFF	Terminal resistance (220Ω) insertion to RD (RXD): None	
7	OFF	Short-circuit of SDA (TXA) and RDA (RXA): Not available	
8	OFF	Short-circuit of SDB (TXB) and RDB (RXB): Not available	
9	OFF	RS (RTS) Auto control mode: Disabled	
10	OFF		

^{*1} When using PS-3450A, PS-3451A, PS3000-BA and PS3001-BD, turn ON the set value.

^{*2} Set up the SIO type with the DIP Switch. Please set up as follows according to SIO type to be used.

^{*3} When making communication between an External Device and COM port on the Expansion slot, only RS-232C is supported. However, ER (DTR/CTS) control cannot be executed because of the specification of COM port.

DIP Switch setting: RS-422/485 (4 wire)


DIP Switch	Setting	Description	
1	OFF	Reserved (always OFF)	
2	ON	SIO type: RS-422/485	
3	ON	310 type. R3-422/463	
4	OFF	Output mode of SD (TXD) data: Always output	
5	OFF	Terminal resistance (220Ω) insertion to SD (TXD): None	
6	OFF	Terminal resistance (220Ω) insertion to RD (RXD): None	
7	OFF	Short-circuit of SDA (TXA) and RDA (RXA): Not available	
8	OFF	Short-circuit of SDB (TXB) and RDB (RXB): Not available	
9	OFF	RS (RTS) Auto control mode: Disabled	
10	OFF		

DIP Switch setting: RS-422/485 (2 wire)

DIP Switch	Setting	Description	
1	OFF	Reserved (always OFF)	
2	ON	SIO type: RS-422/485	
3	ON	310 type. K3-422/403	
4	OFF	Output mode of SD (TXD) data: Always output	
5	OFF	Terminal resistance (220Ω) insertion to SD (TXD): None	
6	OFF	Terminal resistance (220Ω) insertion to RD (RXD): None Short-circuit of SDA (TXA) and RDA (RXA): Available	
7	ON		
8	ON	Short-circuit of SDB (TXB) and RDB (RXB): Available	
9	ON	RS (RTS) Auto control mode: Enabled	
10	ON		

2 Selection of External Device

Select the External Device to be connected to the Display.



Setup Items	Setup Description	
Number of Devices/ PLCs	Enter an integer from 1 to 4 to define the number of Devices/PLCs to connect to the display.	
Manufacturer	Select the manufacturer of the External Device to connect. Select "Schneider Electric SA".	
Series	Select the External Device model (series) and the connection method. Select "MODBUS SIO Master". In System configuration, make sure the External Device you are connecting is supported by "MODBUS SIO Master". "1 System Configuration" (page 3)	
Port	Select the Display port to connect to the External Device.	
Use System Area	Check this option to synchronize the system data area of the Display and the device (memory) of the External Device. When synchronized, you can use the External Device's ladder program to switch the display or display the window on the Display. Cf. GP-Pro EX Reference Manual "LS Area (Direct Access Method Area)" This feature can also be set in GP-Pro EX or in the Display's offline mode. Cf. GP-Pro EX Reference Manual "System Settings [Display Unit] - [System Area] Settings Guide" Cf. Maintenance/Troubleshooting Guide "Main Unit - System Area Settings"	


3 Example of Communication Setting

Examples of communication settings of the Display and the External Device, recommended by Pro-face, are shown.

When using MODBUS Series, use GP-Pro EX and the ladder software to set as below.

3.1 Setting Example 1

- Settings of GP-Pro EX
- ◆ Communication Settings



Default

Cancel


OK (0)

Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



[Max Query] tab 💰 Individual Device Settings Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 1008 🛨 bits Write (0FH) 800 Coil (0) 🛨 bits Read (02H) 1008 Discrete Input (1) 🛨 bits Read (04H) 63 🛨 words Input Register (3) Holding Register (4) Read (03H) 63 → words Holding Register (4) Write (10H) 61 → words Single Bit manipulation to Coil/Discrete Input

■ Settings of External Device

Use the ladder software "PL7 PRO" for communication settings.


Double-click "Hardware Configuration" from "Configuration" in "Application Browser" of "PL7 PRO". Next, double-click "Comm" in the "Configuration" dialog box. Perform the settings in the displayed dialog box.

Setup Items		Setup Description
CHANNEL	CHANNEL 0	
OHANNEL	MODBUS/JBUS LINK	MAST
Slave number	1	
Transmission speed	9600bps	
Delay between characters	5msec	
Data RTU (8 bit)		
Stop	1 bit	
Parity	Even	

Notes

3.2 Setting Example 2

- Settings of GP-Pro EX
- ◆ Communication Settings




◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.





[Max Query] tab 💰 Individual Device Settings Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 1008 🛨 bits Write (0FH) 800 Coil (0) 🛨 bits Read (02H) 1008 Discrete Input (1) 🛨 bits Read (04H) 63 🛨 words Input Register (3) Holding Register (4) Read (03H) 63 → words Holding Register (4) Write (10H) 61 → words Single Bit manipulation to Coil/Discrete Input Default

OK (0)

Cancel

■ Settings of External Device

Use the ladder software "PL7 PRO" for communication settings.


Double-click "Hardware Configuration" from "Configuration" in "Application Browser" of "PL7 PRO". Next, double-click "Comm" in the "Configuration" dialog box. Perform the settings in the displayed dialog box.

Setup Items	Setup Description	
	CHANNEL 1	
CHANNEL	TSX SCP 111 RS232 MP PCMCIA CA	RD
	MODBUS/JBUS LINK	MAST
Slave number	1	
Туре	Slave	
Transmission speed	9600bps	
Delay between characters 4msec		
Data	RTU (8 bit)	
Stop	1 bit	
Parity	Even	

Notes

3.3 Setting Example 3

- Settings of GP-Pro EX
- ◆ Communication Settings




Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



[Max Query] tab 💰 Individual Device Settings Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 1008 🛨 bits Write (0FH) 800 Coil (0) 🛨 bits Read (02H) 1008 Discrete Input (1) 🛨 bits Read (04H) 63 🛨 words Input Register (3) Holding Register (4) Read (03H) 63 → words Holding Register (4) Write (10H) 61 → words Single Bit manipulation to Coil/Discrete Input Default

OK (0)

Cancel

Settings of External Device

Use the ladder software "PL7 PRO" for communication settings.


Double-click "Hardware Configuration" from "Configuration" in "Application Browser" of "PL7 PRO". Next, double-click "Comm" in the "Configuration" dialog box. Perform the settings in the displayed dialog box.

Setup Items	Setup Description	
	CHANNEL 1	
CHANNEL	TSX SCP 114 RS485 MP PCMCIA CA	RD
	MODBUS/JBUS LINK	MAST
Slave number	1	
Туре	Slave	
Transmission speed	9600bps	
Delay between characters 4msec		
Data	RTU (8 bit)	
Stop	1 bit	
Parity	Even	

Notes

3.4 Setting Example 4

- Settings of GP-Pro EX
- ◆ Communication Settings




◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



[Max Query] tab 💰 Individual Device Settings Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 1008 🛨 bits Write (0FH) 800 Coil (0) 🛨 bits Read (02H) 1008 Discrete Input (1) 🛨 bits Read (04H) 63 🛨 words Input Register (3) Holding Register (4) Read (03H) 63 → words Holding Register (4) Write (10H) → words Single Bit manipulation to Coil/Discrete Input Default OK (0) Cancel

■ Settings of External Device

Use the ladder software "PL7 PRO" for communication settings.


Double-click "Hardware Configuration" from "Configuration" in "Application Browser" of "PL7 PRO". Next, double-click "Comm" in the "Configuration" dialog box. Perform the settings in the displayed dialog box.

Setup Items		Setup Description
	CHANNEL 1	
CHANNEL	TSX SCP 111 RS232 MP PCMCIA CARD	
	MODBUS/JBUS LINK	MAST
Туре	Slave	
Slave number	1	
Transmission speed	9600bps	
Delay between characters	4msec	
Data	RTU (8 bit)	
Stop	1 bit	
Parity	Even	

Notes

3.5 Setting Example 5

- Settings of GP-Pro EX
- ◆ Communication Settings



Default

Cancel

OK (0)

Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



[Max Query] tab 💰 Individual Device Settings Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 1008 🛨 bits Write (0FH) 800 Coil (0) 🛨 bits Read (02H) 1008 Discrete Input (1) 🛨 bits Read (04H) 63 🛨 words Input Register (3) Holding Register (4) Read (03H) 63 → words Holding Register (4) Write (10H) 61 → words Single Bit manipulation to Coil/Discrete Input

■ Settings of External Device

Use the ladder software "PL7 PRO" for communication settings.


Double-click "Hardware Configuration" from "Configuration" in "Application Browser" of "PL7 PRO". Next, double-click "Comm" in the "Configuration" dialog box. Perform the settings in the displayed dialog box.

Setup Items	Setup D	escription
CHANNEL	CHANNEL 1	
	TSX SCP 114 RS485 MP PCMCIA CARD	
	MODBUS/JBUS LINK	MAST
Туре	Slave	
Slave number	1	
Transmission speed	9600bps	
Delay between characters	4msec	
Data	RTU (8 bit)	
Stop	1 bit	
Parity	Even	

Notes

3.6 Setting Example 6

- Settings of GP-Pro EX
- ◆ Communication Settings




Device Setting


To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



[Max Query] tab



■ Settings of External Device

Use the ladder software "TwidoSoft" for communication settings.

Select "Hardware" from "TWDLMDA40DUK" in "Application Browser" of "TwidoSoft", and right-click on

"Port 1 : Remote Link, 1" to select "Edit Controller Comm Setup...".


Perform the settings in the "Controller Communication Setup" dialog box displayed next.

Setup	Items	Setup Description	
Protocol	Туре	Modbus	
	Address	1	
	Baud Rate	19200	
Parameters	Data Bits	8	
	Parity	None	
	Stop Bits	1	
End of Frame		10	
Response Timeout		10 x 100msec	
Frame Timeout		4msec	

Notes

3.7 Setting Example 7

- Settings of GP-Pro EX
- ◆ Communication Settings




Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.





[Max Query] tab 💰 Individual Device Settings PLC1 Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 2000 😛 bits Coil (0) Write (0FH) 800 🛨 bits Read (02H) Discrete Input (1) 2000 😛 bits words Input Register (3) Read (04H) 125 Holding Register (4) Read (03H) 125 → words 100 Holding Register (4) Write (10H) → words ☐ Single Bit manipulation to Coil/Discrete Input Default

OK (Q)

Settings of External Device

Use the ladder software "TwidoSoft" for communication settings.

Right-click on "Hardware" from "TWDLMDA40DUK" in "Application Browser" of "TwidoSoft" to select "Add Option...". Right-click on "Port 2: Modbus, 1" added to "Hardware" in "TWDLMDA40DUK" to select "Edit Controller Comm Setup...".


Perform the settings in the "Controller Communication Setup" dialog box displayed next.

Setup	o Items	Setup Description	
Protocol	Туре	Modbus	
	Address	1	
	Baud Rate	19200	
Parameters	Data Bits	8	
	Parity	None	
	Stop Bits	1	
End of Frame		10	
Response Timeout		10 x 100msec	
Frame Timeout		10msec	

Notes

3.8 Setting Example 8

- Settings of GP-Pro EX
- ◆ Communication Settings




Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.





[Max Query] tab 💰 Individual Device Settings PLC1 Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 2000 🛨 bits Write (0FH) Coil (0) 800 📑 bits Read (02H) Discrete Input (1) 2000 😛 bits Input Register (3) Read (04H) 125 → words Holding Register (4) Read (03H) 125 → words 100 Holding Register (4) Write (10H) → words ☐ Single Bit manipulation to Coil/Discrete Input Default OK (Q)

Settings of External Device

Use the ladder software "Concept" for communication settings.


After selecting the External Device in Quantum Series in "PLC Selection" of "Concept", select "Modbus Port Settings" and perform the settings in the "Modbus Port Settings" dialog box.

Setup Items	Setup Description
Baud	19200
Data Bits	8
Stop Bits	1
Parity	Even
Delay(ms)	10
Address	1
Head slot	0
Mode	RTU
Protocol	RS232

◆ Notes

3.9 Setting Example 9

- Settings of GP-Pro EX
- ◆ Communication Settings




Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



[Max Query] tab 💰 Individual Device Settings PLC1 Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 2000 🛨 bits Write (0FH) Coil (0) 800 📑 bits Read (02H) Discrete Input (1) 2000 😛 bits Input Register (3) Read (04H) 125 → words Holding Register (4) Read (03H) 125 → words 100 Holding Register (4) Write (10H) → words ☐ Single Bit manipulation to Coil/Discrete Input Default

OK (<u>O</u>)

■ Settings of External Device

Use the ladder software "Concept" for communication settings.


After selecting the External Device in Momentum Series in "PLC Selection" of "Concept", select "Modbus Port Settings" and perform the settings in the "Modbus Port Settings" dialog box.

Setup Items	Setup Description
Baud	19200
Data Bits	8
Stop Bits	1
Parity	Even
Delay(ms)	10
Address	1
Head slot	0
Mode	RTU
Protocol	RS232

◆ Notes

3.10 Setting Example 10

- Settings of GP-Pro EX
- ◆ Communication Settings




◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.





[Max Query] tab 💰 Individual Device Settings PLC1 Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 2000 🛨 bits Write (0FH) Coil (0) 800 📑 bits Read (02H) Discrete Input (1) 2000 😛 bits Input Register (3) Read (04H) 125 → words Holding Register (4) Read (03H) 125 → words 100 Holding Register (4) Write (10H) → words ☐ Single Bit manipulation to Coil/Discrete Input Default OK (<u>O</u>)

■ Settings of External Device

Use the ladder software "Concept" for communication settings.


After selecting the External Device in Momentum Series in "PLC Selection" of "Concept", select "Modbus Port Settings" and perform the settings in the "Modbus Port Settings" dialog box.

Setup Items	Setup Description
Baud	19200
Data Bits	8
Stop Bits	1
Parity	Even
Delay(ms)	10
Address	1
Head slot	0
Mode	RTU
Protocol	RS485

◆ Notes

3.11 Setting Example 11

- Settings of GP-Pro EX
- ◆ Communication Settings



Default


OK (<u>O</u>)

◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



💰 Individual Device Settings PLC1 Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 2000 😛 bits Coil (0) Write (0FH) 800 📑 bits Discrete Input (1) Read (02H) 2000 😛 bits Input Register (3) Read (04H) 125 🛨 words Holding Register (4) Read (03H) 125 → words Holding Register (4) Write (10H) 100 → words ☐ Single Bit manipulation to Coil/Discrete Input

[Max Query] tab

Settings of External Device

Use the Web browser and ladder software (Logic Designer) for communication settings.

<Communication Settings for the Serial Port on CPU>

1 Set IP address of the External Device to "192.168.1.1".



- For more details on how to set IP address of the External Device, refer to the online help of the dedicated tool for the FCN/FCJ basic settings (Resource Configurator).
- 2 Connect both the Ethernet ports between a PC and the External Device using the LAN cable. (Connect via HUB.)
- 3 Start up the Web browser.
- 4 Enter "http://192.168.1.1/mnt" in the address input box.
- 5 Enter [User Name] and [Password] in the displayed dialog box to login.
- 6 Click [Maintenance Menu] to display the [FCX Maintenance Menu] screen.
- 7 Click [Reboot] to display the [Reboot FCX] screen.
- **8** Check the [Reboot(Maintenance Mode)] option.
- 9 Click [OK] to display the [Reboot] screen.
- 10 Reboot the External Device. Confirm the reboot is complete.
- 11 Click [Maintenance Homepage] to display the [STARDOM FCX Maintenance Page] screen.
- 12 Click [OK] to display the [FCX Maintenance Menu] screen.
- 13 Click [Edit] to display the [Edit System Setting Files] screen.
- 14 Check the [COM1 Port Setting File] option and click [OK].

15 Set each item as follows:

Setup Items	Setup Description
Baudrate	19200
DataBitLength	8
StopBitLength	1
Parity	EVEN

- 16 Click [OK] to display the [Edit System Setting Files(RESULT)] screen.
- 17 Click [Maintenance Menu] to display the [FCX Maintenance Menu] screen.
- 18 Click [Reboot] to display the [Reboot FCX] screen.
- 19 Check the [Reboot(Online Mode)] option and click [OK].

The External Device is rebooted.


<Control Logic Download Procedures>

- 1 Start up the ladder software.
- 2 Create the control logic in order to start the MODBUS communication (RTU mode) slave function. For the example of control logic, refer to "◆Control Logic Example".
- 3 Double-click ['COM1'] next to [PORT] to display the [Variable Properties] dialog box.
- 4 Enter the connecting port name in [Name], and click [OK].
- 5 Double-click [UNIT#1] next to [STATION] to display the [Variable Properties] dialog box.
- 6 Enter the connecting station name in [Name], and click [OK].
- 7 Select [Rebuild Project] from the [Build] menu.
- 8 Double-click [Target Setting] in the project tree window to display the [Target] dialog box.
- **9** Enter "192.168.1.1" in [Host Name/IP Address].
- 10 Click [OK].
- 11 Download the communication settings to the External Device.
- 12 Reboot the External Device.

◆ Control Logic Example


To connect the Display to the External Device, the control logic is requred.

The control logic example is shown below.



3.12 Setting Example 12

- Settings of GP-Pro EX
- ◆ Communication Settings




Default

◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



[Max Query] tab 💰 Individual Device Settings PLC1 Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 2000 😛 bits Coil (0) Write (0FH) 800 📑 bits Discrete Input (1) Read (02H) 2000 😛 bits Input Register (3) Read (04H) 125 🛨 words Holding Register (4) Read (03H) 125 → words Holding Register (4) Write (10H) 100 → words ☐ Single Bit manipulation to Coil/Discrete Input

OK (<u>O</u>)

Settings of External Device

Use the dedicated tool for basic settings (Resource Configurator) and ladder software (Logic Designer) for communication settings.

- <Communication Settings for the Communication Module>
- 1 Set IP address of the External Device to "192.168.1.1".
 - For more details on how to set IP address of the External Device, refer to the online help of the dedicated tool for the FCN/FCJ basic settings.
- 2 Start up the dedicated tool for the basic settings.
- **3** From the [File] menu, select [Connection] to display the [Connect] dialog box.
- 4 Enter "192.168.1.1" in [Host].
- 5 Enter [User Name] and [Password] to login.
- 6 Select the link I/F to use from the [Controller Configuration] tree view.
- 7 Enter the port name in [Port Name].
- **8** Select [Port1] from the link I/F to use the [Controller Configuration] tree view.

9 Set specifications as follows:


Specifications	Setting
Wiring Method	-
Duplex Operation	Full-duplex
Baud Rate	19200
Data Bits	8
Parity Setting	EVEN
Stop Bits	1
Send Signal Check	NONE
Recieve Flow Control	NONE
API Error Detection	YES

- 10 Download the communication settings to the External Device.
- 11 Reboot the External Device.
 - <Control Logic Download Procedures>
 - 1 Start up the ladder software.
 - 2 Create the control logic in order to start the MODBUS communication (RTU mode) slave function. For the example of control logic, refer to "◆Control Logic Example".
- 3 Double-click ['COM1'] next to [PORT] to display the [Variable Properties] dialog box.
- 4 Enter the connecting port name in [Name], and click [OK].
- 5 Double-click [UNIT#1] next to [STATION] to display the [Variable Properties] dialog box.
- **6** Enter the connecting station name in [Name], and click [OK].
- 7 Select [Rebuild Project] from the [Build] menu.
- 8 Double-click [Target Setting] in the project tree window to display the [Target] dialog box.
- **9** Enter "192.168.1.1" in [Host Name/IP Address].
- 10 Click [OK].
- 11 Download the communication settings to the External Device.
- 12 Reboot the External Device.

◆ Control Logic Example

To connect the Display to the External Device, the control logic is requred.


The control logic example is shown below.



3.13 Setting Example 13

- Settings of GP-Pro EX
- ◆ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].




◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



[Max Query] tab 💰 Individual Device Settings PLC1 Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 2000 😛 bits Coil (0) Write (0FH) 800 📑 bits Discrete Input (1) Read (02H) 2000 😛 bits Input Register (3) Read (04H) 125 🛨 words Holding Register (4) Read (03H) 125 → words Holding Register (4) Write (10H) 100 → words ☐ Single Bit manipulation to Coil/Discrete Input Default

OK (Q)

Settings of External Device

Use the dedicated tool for basic settings (Resource Configurator) and ladder software (Logic Designer) for communication settings.

- <Communication Settings for the Communication Module>
- 1 Set IP address of the External Device to "192.168.1.1".
 - For more details on how to set IP address of the External Device, refer to the online help of the dedicated tool for the FCN/FCJ basic settings.
- 2 Start up the dedicated tool for the basic settings.
- **3** From the [File] menu, select [Connection] to display the [Connect] dialog box.
- 4 Enter "192.168.1.1" in [Host].
- 5 Enter [User Name] and [Password] to login.
- 6 Select the link I/F to use from the [Controller Configuration] tree view.
- 7 Enter the port name in [Port Name].
- **8** Select [Port1] from the link I/F to use the [Controller Configuration] tree view.

9 Set specifications as follows:

Specifications	Setting	
Wiring Method	-	
Duplex Operation	Full-duplex	
Baud Rate	19200	
Data Bits	8	
Parity Setting	EVEN	
Stop Bits	1	
Send Signal Check	NONE	
Recieve Flow Control	NONE	
API Error Detection	YES	

- 10 Download the communication settings to the External Device.
- 11 Reboot the External Device.


<Control Logic Download Procedures>

- 1 Start up the ladder software.
- 2 Create the control logic in order to start the MODBUS communication (RTU mode) slave function. For the example of control logic, refer to "◆Control Logic Example".
 - The state of the
- 3 Double-click ['COM1'] next to [PORT] to display the [Variable Properties] dialog box.
- 4 Enter the connecting port name in [Name], and click [OK].
- 5 Double-click [UNIT#1] next to [STATION] to display the [Variable Properties] dialog box.
- **6** Enter the connecting station name in [Name], and click [OK].
- 7 Select [Rebuild Project] from the [Build] menu.
- 8 Double-click [Target Setting] in the project tree window to display the [Target] dialog box.
- **9** Enter "192.168.1.1" in [Host Name/IP Address].
- 10 Click [OK].
- 11 Download the communication settings to the External Device.
- 12 Reboot the External Device.

◆ Control Logic Example

To connect the Display to the External Device, the control logic is requred.


The control logic example is shown below.



3.14 Setting Example 14

- Settings of GP-Pro EX
- ◆ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].




◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

[Equipment Configuration] tab



[Max Query] tab 💰 Individual Device Settings PLC1 Equipment Configuration Max Query Address Function Codes Max Query Coil (0) Read (01H) 2000 😛 bits Coil (0) Write (0FH) 800 📑 bits Discrete Input (1) Read (02H) 2000 😛 bits Input Register (3) Read (04H) 125 🛨 words Holding Register (4) Read (03H) 125 → words Holding Register (4) Write (10H) 100 → words ☐ Single Bit manipulation to Coil/Discrete Input Default OK (Q)

Settings of External Device

Use the dedicated tool for basic settings (Resource Configurator) and ladder software (Logic Designer) for communication settings.

- <Communication Settings for the Communication Module>
- 1 Set IP address of the External Device to "192.168.1.1".
 - For more details on how to set IP address of the External Device, refer to the online help of the dedicated tool for the FCN/FCJ basic settings.
- 2 Start up the dedicated tool for the basic settings.
- **3** From the [File] menu, select [Connection] to display the [Connect] dialog box.
- 4 Enter "192.168.1.1" in [Host].
- 5 Enter [User Name] and [Password] to login.
- 6 Select the link I/F to use from the [Controller Configuration] tree view.
- 7 Enter the port name in [Port Name].
- **8** Select [Port1] from the link I/F to use the [Controller Configuration] tree view.

9 Set specifications as follows:

Specifications	Setting	
Wiring Method	-	
Duplex Operation	Full-duplex	
Baud Rate	19200	
Data Bits	8	
Parity Setting	EVEN	
Stop Bits	1	
Send Signal Check	NONE	
Recieve Flow Control	NONE	
API Error Detection	YES	

- 10 Download the communication settings to the External Device.
- 11 Reboot the External Device.


<Control Logic Download Procedures>

- 1 Start up the ladder software.
- 2 Create the control logic in order to start the MODBUS communication (RTU mode) slave function. For the example of control logic, refer to "◆Control Logic Example".
 - " ◆ Control Logic Example" (page 45)
- 3 Double-click ['COM1'] next to [PORT] to display the [Variable Properties] dialog box.
- 4 Enter the connecting port name in [Name], and click [OK].
- 5 Double-click [UNIT#1] next to [STATION] to display the [Variable Properties] dialog box.
- **6** Enter the connecting station name in [Name], and click [OK].
- 7 Select [Rebuild Project] from the [Build] menu.
- 8 Double-click [Target Setting] in the project tree window to display the [Target] dialog box.
- 9 Enter "192.168.1.1" in [Host Name/IP Address].
- 10 Click [OK].
- 11 Download the communication settings to the External Device.
- 12 Reboot the External Device.

◆ Control Logic Example

To connect the Display to the External Device, the control logic is requred.

The control logic example is shown below.



4 Setup Items

Set communication settings of the Display with GP-Pro EX or in offline mode of the Display.


The setting of each parameter must be identical to that of External Device.

"3 Example of Communication Setting" (page 10)

4.1 Setup Items in GP-Pro EX

■ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].



Setup Items	Setup Description		
SIO Type	Select the SIO type to communicate with the External Device.		
Speed	Select speed between the External Device and the Display.		
Data Length	Select data length.		
Parity	Select how to check parity.		
Stop Bit	Select stop bit length.		
Flow Control	Select the communication control method to prevent overflow of transmission and reception data.		
Timeout	Use an integer from 1 to 127 to enter the time (s) for which the Display waits for the response from the External Device.		
Retry In case of no response from the External Device, use an integer from 0 to 255 to 6 many times the Display retransmits the command.			

continued to next page

Setup Items	Setup Description		
	Use an integer from 0 to 255 to enter standby time (ms) for the Display from receiving packets to transmitting next commands. When the check box of the default value is checked, the Wait To Send value automatically changes in the formula below by changing each value for Speed/Data Length/Parity/Stop Bit.		
	Wait To Send (ms) = $\frac{3500 \text{ x } (1 + \text{Data Length} + \text{Stop Bit} + \text{Parity})}{\text{Speed (bps)}}$		
Wait To Send	Value for the parity setting is shown below. No Parity = 0 Parity Even = 1 Parity Odd = 1		
	• After changing the Wait To Send value for the project, of which [Default Value] is checked, in the offline mode, the Wait To Send value will be recalculated when the project is received and communication settings are displayed.		
RI/VCC	You can switch RI/VCC of the 9th pin when you select RS232C for SIO type. It is necessary to change RI/5V by changeover switch of IPC when connect with IPC. Please refer to the manual of the IPC for more detail.		

NOTE


- Refer to the GP-Pro EX Reference Manual for Indirect Device.
- Cf. GP-Pro EX Reference Manual "Changing the Device/PLC at Runtime (Indirect Device)"

◆ Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]


To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.





Setup Items		Setup Description	
Slave Equipment Address		Use an integer from 1 to 247 to enter the slave equipment address of the External Device.	
Bit manipulation (set / reset) to Holding Resister		From "Clear" or "Do not clear", select treatment of the rest of the bits in the	
	Rest of the bits in this word	same word when the bit manipulation to Holding Register is performed.	
IEC61131 Syntax		Check this item when you use the IEC61131 syntax for variables. In case that you check on, select Address Mode, [0-based] or [1-based].	
Double Word word order		Select the order of storing double word data from "Low word first" or "High word first".	
Low Security Level		Put a check when lowering the format check level.	

[Max Query] tab



Setup Items		Setup Description	
Coil		Set the number of max data for device [coil] which can be read for one communication, using 16 to 2000 bits.	
	Read	• When [Single Bit manipulation to Coil/Discrete Input] is checked, set the data maximum number from 1 to 2000.	
Coil	•	Set the number of max data for device [coil] which can be written for one	
	Write	communication, using 1 to 800 bits.	
Discrete Input		Set the number of max data for device [discrete input] which can be read for one communication, using 16 to 2000 bits.	
	Read	NOTE • When [Single Bit manipulation to Coil/Discrete Input] is checked, set the data maximum number from 1 to 2000.	
Input Register		Set the number of max data for device [input register] which can be read for	
	Read	one communication, using 1 to 125 words.	
Holding Register	r	Set the number of max data for device [holding register] which can be read	
	Read	for one communication, using 1 to 125 words.	
Holding Register		Set the number of max data for device [holding register] which can be written	
	Write	for one communication, using 1 to 100 words.	
Single Bit manip Discrete Input	ulation to Coil/	Put a check when writing in or reading out coil or discreet input in bits.	


4.2 Setup Items in Offline Mode



- Refer to the Maintenance/Troubleshooting guide for information on how to enter offline mode or about the operation.
- Cf. Maintenance/Troubleshooting Guide "Offline Mode"
- The number of the setup items to be displayed for 1 page in the offline mode depends on the Display in use. Please refer to the Reference manual for details.

◆ Communication Settings

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings] in offline mode. Touch the External Device you want to set from the displayed list.



Setup Items	Setup Description			
SIO Type	Select the SIO type to communicate with the External Device. IMPORTANT To make the communication settings correctly, confirm the serial interface specifications of Display unit for [SIO Type]. We cannot guarantee the operation if a communication type that the serial interface does not support is specified. For details concerning the serial interface specifications, refer to the manual for Display unit.			
Speed	Select speed between the External Device and the Display.			
Data Length	Select data length.			
Parity	Select how to check parity.			
Stop Bit	Select stop bit length.			


continued to next page

Setup Items	Setup Description		
Flow Control	Select the communication control method to prevent overflow of transmission and reception data.		
Timeout	Use an integer from 1 to 127 to enter the time (s) for which the Display waits for the response from the External Device.		
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times the Display retransmits the command.		
Wait To Send	Use an integer from 0 to 255 to enter standby time (ms) for the Display from receiving packets to transmitting next commands.		

◆ Device Setting

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings]. Touch the External Device you want to set from the displayed list, and touch [Device].

.




Setup Items	Setup Description	
Device/PLC Name	Select the External Device for device setting. Device name is a title of External Device set with GP-Pro EX. (Initial value [PLC1])	
Slave Address	Use an integer from 1 to 247 to enter the slave equipment address of the External Device.	
Bit manipulation to HR	From "Rest of bits in word are cleared" or "Rest of bits in word are not cleared", select treatment of the rest of the bits in the same word when the bit manipulation to Holding Register is performed. (Not available to set in offline mode.)	
IEC61131 Syntax	Displays the usage status of the currently set IEC61131 syntax in ON/OFF. (Not available in offline mode.)	
Double Word word order	Displays the currently set order of storing double word data from "Low word first" or "High word first". (Not available to set in offline mode.)	

Setup Items		Setup Description	
Low Security Level		When an format check level is lowered, ON/OFF is displayed. When the level is lowered, ON is displayed. (Not available to set in offline mode.)	
Coil		Displays the number of max data for device [coil] which can be read for one	
	Read	communication. (Not available to set in offline mode.)	
Coil	•	Displays the number of max data for device [coil] which can be written for	
	Write	one communication. (Not available to set in offline mode.)	
Discrete Input		Displays the number of max data for device [discrete input] which can be	
	Read	read for one communication. (Not available to set in offline mode.)	
Input Register		Set the number of max data for device [input register] which can be read for	
	Read	one communication, using 1 to 125 words.	
Holding Register	r	Set the number of max data for device [holding register] which can be read	
	Read	for one communication, using 1 to 125 words.	
Holding Register	r	Set the number of max data for device [holding register] which can be written	
	Write	for one communication, using 1 to 100 words.	
Single Bit manipulation		ON/OFF display shows whether the coil or discreet input is written or read out in bits. If ON is displayed, writing or reading can be executed in bits. (Not available to set in offline mode.)	

Option

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings]. Touch the External Device you want to set from the displayed list, and touch [Option].



Setup Items	Setup Description		
RI/VCC	You can switch RI/VCC of the 9th pin when you select RS232C for SIO type. It is necessary to change RI/5V by changeover switch of IPC when connect with IPC. Please refer to the manual of the IPC for more detail.		

NOTE

• GP-4100 series and GP-4*01TM do not have the [Option] setting in the offline mode.

5 Cable Diagram

The cable diagram shown below may be different from the cable diagram recommended by Schneider Electric SA or Yokogawa Electric Corporation. Please be assured there is no operational problem in applying the cable diagram shown in this manual.

- The FG pin of the External Device body must be D-class grounded. Please refer to the manual of the External Device for more details.
- SG and FG are connected inside the Display. When connecting SG to the External Device, design the system
 not to form short-circuit loop.
- · Connect the isolation unit, when communication is not stabilized under the influence of a noise etc.

Cable Diagram 1

Display (Connection Port)	Cable		Notes
GP3000*1 (COM1) AGP-3302B (COM2) GP-4*01TM (COM1) ST*2 (COM2)	1A	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	
	1B	User-created cable	
GP3000*3 (COM2)	1C	Online adapter by Pro-face CA4-ADPONL-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable Online adapter by Pro-face	The cable length must be 200m or less.
	1D	CA4-ADPONL-01 + User-created cable	
IPC*4	1E	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable User-created cable	
GD 4106 (COM1)	1G	User-created cable User-created cable	-
GP-4106 (COM1)	10	User-created cable	


continued to next page


Display (Connection Port)		Cable	Notes
GP-4107 (COM1) GP-4*03T*5 (COM2) GP-4203T (COM1)	1H	User-created cable	
GP4000*6 (COM2) GP-4201T (COM1)	11	RS-422 terminal block conversion adapter by Pro-face PFXZCBADTM1*7 + User-created cable	The cable length must be 200m or less.
	1B	User-created cable	

- *1 All GP3000 models except AGP-3302B
- *2 All ST models except AST-3211A and AST-3302B
- *3 All GP3000 models except GP-3200 series and AGP-3302B
- *4 Only the COM port which can communicate by RS-422/485 (2 wire) can be used.
 - IPC COM Port (page 7)
- *5 Except GP-4203T
- *6 All GP4000 models except GP-4100 series, GP-4*01TM, GP-4201T and GP-4*03T
- *7 When using a Terminal Block Conversion Adapter (CA3-ADPTRM-01) instead of the RS-422 Terminal Block Conversion Adapter, refer to Cable Diagram 1A.

1A)


• 1:1 Connection






1B)


• 1:1 Connection






1C)


• 1:1 Connection






1D)


1:1 Connection






1E)


1:1 Connection






1F)

1:1 Connection




1:n Connection




1G)

1:1 Connection



• 1:n Connection




*1 The resistance in the Display is used as the termination resistance. Set the value of the DIP Switch on the rear of the Display as shown in the table below.


DIP Switch No.	Set Value	
1	OFF	
2	OFF	
3	ON	
4	ON	

1H)

1:1 Connection



• 1:n Connection



IMPORTANT


• The 5V output (Pin #6) on the Display is the power for the Siemens AG's PROFIBUS connector. Do not use it for other devices.


NOTE

• In COM on the GP-4107, the SG and FG terminals are isolated.

1F)

1:1 Connection






Cable Diagram 2


Display (Connection Port)		Cable	Notes
GP3000 (COM1) GP4000*1 (COM1) ST (COM1) IPC*2 PC/AT	2A	Cable by Schneider Electric Industries TSX PCX 1031 (2.5m)*3	
GP-4105 (COM1)	2B	User-created cable + Cable by Schneider Electric Industries TSX PCX 1031 (2.5m)*2	

- *1 All GP4000 models except GP-4100 series and GP-4203T
- *2 Only the COM port which can communicate by RS-232C can be used.
 - IPC COM Port (page 7)
- *3 Set the rotary switch to "3 (OTHER DIRECT)".

2A)



2B)



Cable Diagram 3

Display (Connection Port)	Cable		Notes
GP3000 ^{*1} (COM1) AGP-3302B (COM2) GP-4*01TM (COM1) ST ^{*2} (COM2)	3A	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable + Accessory box by Schneider Electric Industries TSX SCA 50	
	3В	User-created cable + Accessory box by Schneider Electric Industries TSX SCA 50	
GP3000*4 (COM2)	3C 3D	Online adapter by Pro-face CA4-ADPONL-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable + Accessory box by Schneider Electric Industries TSX SCA 50 Online adapter by Pro-face CA4-ADPONL-01 + User-created cable + Accessory box by Schneider Electric Industries TSX SCA 50	The cable length must be 10m or less.**3
IPC*5	3E	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable + Accessory box by Schneider Electric Industries TSX SCA 50 User-created cable + Accessory box by Schneider Electric Industries	The cable length must be 10m or less.*3

Display (Connection Port)		Cable	Notes
GP-4106 (COM1)	3G	User-created cable + Accessory box by Schneider Electric Industries TSX SCA 50	
GP-4107 (COM1) GP-4*03T*6 (COM2) GP-4203T (COM1)	3Н	User-created cable + Accessory box by Schneider Electric Industries TSX SCA 50	
GP4000 ^{*7} (COM2) GP-4201T (COM1)	3I	RS-422 terminal block conversion adapter by Pro-face PFXZCBADTM1*8 + User-created cable + Accessory box by Schneider Electric Industries TSX SCA 50	The cable length must be 10m or less.* ³
	3В	User-created cable + Accessory box by Schneider Electric Industries TSX SCA 50	

^{*1} All GP3000 models except AGP-3302B

^{*2} All ST models except AST-3211A and AST-3302B

^{*3} Max length between the "GP" and the "Accessory Box connected to GP". Total cable length between accessory boxes must be 1000m or less.

^{*4} All GP3000 models except GP-3200 series and AGP-3302B

^{*5} Only the COM port which can communicate by RS-422/485 (2 wire) can be used.

IPC COM Port (page 7)


^{*6} Except GP-4203T


^{*7} All GP4000 models except GP-4100 series, GP-4*01TM, GP-4201T and GP-4*03T

^{*8} When using a Terminal Block Conversion Adapter (CA3-ADPTRM-01) instead of the RS-422 Terminal Block Conversion Adapter, refer to Cable Diagram 3A.

3A)


• 1:1 Connection






3B)


• 1:1 Connection






3C)


• 1:1 Connection






3D)


• 1:1 Connection






3E)


• 1:1 Connection






3F)


1:1 Connection






3G)

1:1 Connection



• 1:n Connection




*1 The resistance in the Display is used as the termination resistance. Set the value of the DIP Switch on the rear of the Display as shown in the table below.


DIP Switch No.	Set Value
1	OFF
2	OFF
3	ON
4	ON

3H)

• 1:1 Connection



• 1:n Connection



IMPORTANT


 The 5V output (Pin #6) on the Display is the power for the Siemens AG's PROFIBUS connector. Do not use it for other devices.


NOTE

• In COM on the GP-4107, the SG and FG terminals are isolated.

3I)

• 1:1 Connection





Display (Connection Port)		Cable	Notes
GP3000 (COM1) GP4000 ^{*1} (COM1) ST (COM1) IPC ^{*2} PC/AT	4A	User-created cable + RS 232 D tap link cable by Schneider Electric TSX SCP CC 1030 (3m) + PCMCIA card for RS232C by Schneider Electric TSX SCP 111	The cable length must
GP-4105 (COM1)	4B	User-created cable + RS 232 D tap link cable by Schneider Electric TSX SCP CC 1030 (3m) + PCMCIA card for RS232C by Schneider Electric TSX SCP 111	be 15m or less. *3


^{*1} All GP4000 models except GP-4100 series and GP-4203T


 $^{^{*2}}$ Only the COM port which can communicate by RS-232C can be used.

[■] IPC COM Port (page 7)


^{*3} Total length for TSX SCP CC 1030 and User-created cable.


4A)





4B)







Display (Connection Port)		Cable	Notes
		COM port conversion adapter by Pro-face CA3-ADPCOM-01 +	
		Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01	
GP3000 ^{*1} (COM1) AGP-3302B (COM2)	5A	User-created cable + Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m)	
GP-4*01TM (COM1) ST*2 (COM2)		PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	
	5B	User-created cable + Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m)	
		+ PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	
GP3000*3 (COM2)	5C	Online adapter by Pro-face CA3-ADPONL-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable + Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m) + PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	
	5D	Online adapter by Pro-face CA4-ADPONL-01 + User-created cable + Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m) + PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	


Display (Connection Port)		Cable	Notes
		COM port conversion adapter by Pro-face CA3-ADPCOM-01	
		Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01	
	5E	+ User-created cable +	
IPC*4		Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m)	
		PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	
		User-created cable +	
	5F	Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m)	
		PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	
		User-created cable	
GP-4106 (COM1)	5G	Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m)	
		PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	
		User-created cable +	
GP-4107 (COM1) GP-4*03T*5 (COM2) GP-4203T (COM1)	5H	Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m) +	
G1-42031 (COM1)		PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	
		RS-422 terminal block conversion adapter by Pro-face PFXZCBADTM1*7	
		User-created cable	
	5I	Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m)	
GP4000*6 (COM2) GP-4201T (COM1)		PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	
		User-created cable	
	5B	+ Uni-Telway cable by Schneider Electric Industries TSX SCP CU 4030 (3m)	
		PCMCIA card for RS485 by Schneider Electric Industries TSX SCP 114	


^{*1} All GP3000 models except AGP-3302B


- *2 All ST models except AST-3211A and AST-3302B
- *3 All GP3000 models except GP-3200 series and AGP-3302B
- *4 Only the COM port which can communicate by RS-422/485 (2 wire) can be used.
 - IPC COM Port (page 7)
- *5 Except GP-4203T
- *6 All GP4000 models except GP-4100 series, GP-4*01TM, GP-4201T and GP-4*03T
- *7 When using a Terminal Block Conversion Adapter (CA3-ADPTRM-01) instead of the RS-422 Terminal Block Conversion Adapter, refer to Cable Diagram 5A.
















5G)



*1 The resistance in the Display is used as the termination resistance. Set the value of the DIP Switch on the rear of the Display as shown in the table below.

DIP Switch No.	Set Value
1	OFF
2	OFF
3	ON
4	ON

5H)




• The 5V output (Pin #6) on the Display is the power for the Siemens AG's PROFIBUS connector. Do not use it for other devices.

NOTE

• In COM on the GP-4107, the SG and FG terminals are isolated.


5I)




Display (Connection Port)		Cable	Notes
GP3000 (COM1) GP4000*1 (COM1) ST (COM1) IPC*2 PC/AT	6A	User-created cable	The cable length must be 15m or less.
GP-4105 (COM1)	6B	User-created cable	

- *1 All GP4000 models except GP-4100 series and GP-4203T
- *2 Only the COM port which can communicate by RS-232C can be used.
 - IPC COM Port (page 7)

6A)



6B)




Display (Connection Port)		Cable	
GP3000 (COM1) GP4000 ^{*1} (COM1) ST (COM1) IPC* ² PC/AT	7A	D-Shell adapter by Schneider Electric 110 XCA 203 00 + RS232 communication cable RJ45 to RJ45 by Schneider Electric 110 XCA 282 01(1m), 110 XCA 282 02(3m) or 110 XCA 282 03(6m)	The cable
GP-4105 (COM1)	7B	User-created cable + D-Shell adapter by Schneider Electric 110 XCA 203 00 + RS232 communication cable RJ45 to RJ45 by Schneider Electric 110 XCA 282 01(1m), 110 XCA 282 02(3m) or 110 XCA 282 03(6m)	length must be 9.5m or less.


^{*1} All GP4000 models except GP-4100 series and GP-4203T

IPC COM Port (page 7)

7A)



7B)



^{*2} Only the COM port which can communicate by RS-232C can be used.

Display (Connection Port)		Cable	Notes
GP3000 ^{*1} (COM1) AGP-3302B (COM2) GP-4*01TM (COM1) ST ^{*2} (COM2) IPC ^{*3}	8A	COM port conversion adapter (for COM1) by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	
	8B	User-created cable	
GP3000*4 (COM2)	8C	Online adapter by Pro-face CA4-ADPONL-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	The cable length must be 500m or less.
	8D	Online adapter by Pro-face CA4-ADPONL-01 + User-created cable	
GP-4106 (COM1)	8E	User-created cable	
GP4000*5 (COM2) GP-4201T (COM1)	8F	RS-422 terminal block conversion adapter by Pro-face PFXZCBADTM1*6 + User-created cable	
	8B	User-created cable	

^{*1} All GP3000 models except AGP-3302B

^{*2} All ST models except AST-3211A and AST-3302B

^{*3} Only the COM port which can communicate by RS-422/485 (4 wire) can be used.


[■] IPC COM Port (page 7)


^{*4} All GP3000 models except GP-3200 series and AGP-3302B

^{*5} All GP4000 models except GP-4100 series, GP-4*01TM, GP-4201T and GP-4*03T


^{*6} When using a Terminal Block Conversion Adapter (CA3-ADPTRM-01) instead of the RS-422 Terminal Block Conversion Adapter, refer to Cable Diagram 8A.


8A)






8C)






8E)



*1 The resistance in the Display is used as the termination resistance. Set the value of the DIP Switch on the rear of the Display as shown in the table below.

DIP Switch No.	Set Value
1	OFF
2	OFF
3	ON
4	ON

8F)




Display (Connection Port)		Cable	Notes
GP3000 (COM1) GP4000*1 (COM1) ST (COM1) IPC*2 PC/AT	9A	User-created cable	The cable length must be 15m or less.
GP-4105 (COM1)	9B	User-created cable	


^{*1} All GP4000 models except GP-4100 series and GP-4203T

IPC COM Port (page 7)

9A)



9B)




^{*2} Only the COM port which can communicate by RS-232C can be used.

Display (Connection Port)		Cable	Notes
GP3000 (COM1) GP4000 ^{*1} (COM1) ST (COM1) IPC ^{*2} PC/AT	10A	User-created cable	The cable length must be 15m or less.
GP-4105 (COM1)	10B	User-created cable	


^{*1} All GP4000 models except GP-4100 series and GP-4203T

■ IPC COM Port (page 7)

10A)



10B)



^{*2} Only the COM port which can communicate by RS-232C can be used.

Display (Connection Port)		Cable	Notes
GP3000 ^{*1} (COM1) AGP-3302B (COM2) GP-4*01TM (COM1) ST ^{*2} (COM2) IPC ^{*3}	11A	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	
	11B	User-created cable	
GP3000*4 (COM2)	11C	Online adapter by Pro-face CA4-ADPONL-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	The cable length must be 1000m or less.
	11D	Online adapter by Pro-face CA4-ADPONL-01 + User-created cable	
GP-4106 (COM1)	11E	User-created cable	
GP4000*5 (COM2) GP-4201T (COM1)	11F	RS-422 terminal block conversion adapter by Pro-face PFXZCBADTM1*6 + User-created cable	
	11B	User-created cable	

^{*1} All GP3000 models except AGP-3302B

^{*2} All ST models except AST-3211A and AST-3302B

^{*3} Only the COM port which can communicate by RS-422/485 (4 wire) can be used.

F ■ IPC COM Port (page 7)


^{*4} All GP3000 models except GP-3200 series and AGP-3302B


^{*5} All GP4000 models except GP-4100 series, GP-4*01TM, GP-4201T and GP-4*03T

^{*6} When using a Terminal Block Conversion Adapter (CA3-ADPTRM-01) instead of the RS-422 Terminal Block Conversion Adapter, refer to Cable Diagram 11A.

11A)


1:1 Connection






11B)


1:1 Connection






11C)


1:1 Connection






11D)

• 1:1 Connection




1:n Connection




11E)

1:1 Connection



1:n Connection




*1 The resistance in the Display is used as the termination resistance. Set the value of the DIP Switch on the rear of the Display as shown in the table below.


DIP Switch No.	Set Value
1	OFF
2	OFF
3	ON
4	ON

11F)

1:1 Connection



1:n Connection




Display (Connection Port)		Cable	Notes
GP3000 ^{*1} (COM1) AGP-3302B (COM2) GP-4*01TM (COM1) ST ^{*2} (COM2)	12A	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	
	12B	User-created cable	
GP3000*3 (COM2)	12C	Online adapter by Pro-face CA4-ADPONL-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	
	12D	Online adapter by Pro-face CA4-ADPONL-01 + User-created cable	The cable length must be 1000m or less.
IPC*4	12E	COM port conversion adapter by Pro-face CA3-ADPCOM-01 + Connector terminal block conversion adapter by Pro-face CA3-ADPTRM-01 + User-created cable	
	12F	User-created cable	
GP-4106 (COM1)	12G	User-created cable	
GP-4107 (COM1) GP-4*03T*5 (COM2) GP-4203T (COM1)	12H	12H User-created cable	
GP4000 ^{*6} (COM2) GP-420IT (COM1)	12I 12B	RS-422 terminal block conversion adapter by Pro-face PFXZCBADTM1*7 + User-created cable User-created cable	
	12B	User-created cable	


- *1 All GP3000 models except AGP-3302B
- *2 All ST models except AST-3211A and AST-3302B
- *3 All GP3000 models except GP-3200 series and AGP-3302B
- *4 Only the COM port which can communicate by RS-422/485 (2 wire) can be used.
 - IPC COM Port (page 7)
- *5 Except GP-4203T
- *6 All GP4000 models except GP-4100 series, GP-4*01TM, GP-4201T and GP-4*03T
- *7 When using a Terminal Block Conversion Adapter (CA3-ADPTRM-01) instead of the RS-422 Terminal Block Conversion Adapter, refer to Cable Diagram 12A.

12A)

1:1 Connection





1:n Connection



12B)


1:1 Connection






12C)


1:1 Connection






12D)


• 1:1 Connection






12E)

1:1 Connection




1:n Connection




12F)

• 1:1 Connection




1:n Connection




12G)

• 1:1 Connection



1:n Connection




*1 The resistance in the Display is used as the termination resistance. Set the value of the DIP Switch on the rear of the Display as shown in the table below.


DIP Switch No.	Set Value
1	OFF
2	OFF
3	ON
4	ON

12H)

1:1 Connection



• 1:n Connection



IMPORTANT


• The 5V output (Pin #6) on the Display is the power for the Siemens AG's PROFIBUS connector. Do not use it for other devices.

NOTE


• In COM on the GP-4107, the SG and FG terminals are isolated.

12I)

1:1 Connection



1:n Connection



6 Supported Device

Range of supported device address is shown in the table below. Please note that the actually supported range of the devices varies depending on the External Device to be used. Please check the actual range in the manual of your connecting equipment.

■ Micro/Premium/Twido/Quantum/Momentum Series

This address can be specified as system data area.

Device	Bit Address	Word Address	32 bits	Notes
Coil	000001 - 065536	000001 - 065521		+16+ 1
Discrete Input	100001 - 165536	100001 - 165521	[L/H]	+16+ 1) *2
Input Register		300001 - 365536	or	B: 15] *2
Holding Register	400001,00 - 465536,15 ^{*3}	400001 - 465536	[H / L] *1	_{в т} 15)

^{*1} High and low relationship of the stored data is specified by the [Double Word word order] setting of [Device Setting].

- *2 Write disable
- *3 An access method at the time of Bit Set varies depending on the [Rest of the bits in this word] setting of [Device Setting].

 - Do not clear 400001,00 465536,15

■ FCN/FCJ Series

This address can be specified as system data area.

Device	Bit Address	Word Address	32 bits	Notes
Coil	000001 - 009984	000001 - 009969		<u>+1B+</u> 1) *2
Discrete Input	100001 - 109984	100001 - 109969	[L/H]	<u>+1B+</u> 1) *2 *3
Input Register	300001.00 - 309999.15	300001 - 309999	or [H/L]	_{в т} 15) *3
Holding Register	400001.00 - 409999.15	400001 - 409999	*1	<u>⊪, 15</u>)

^{*1} High and low relationship of the stored data is specified by the [Double Word word order] setting of [Device Setting].

[&]quot;4.1 Setup Items in GP-Pro EX" (page 46)

[&]quot;4.1 Setup Items in GP-Pro EX" (page 46)

^{*2} The device access range of the External Device is specified as 1 to 9999, that of the Display, however, as up to 9984, since the Display device is accessible in 16-bit units.

^{*3} Write disable

■ Supported Function Code

Below is the list of Supported Function Code.

Function Code (Hex)	Description
FC01 (0x01)	Reads the ON/OFF status of coils (0X references) in the slave.
FC02 (0x02)	Reads the ON/OFF status of discrete inputs (1X references) in the slave.
FC03 (0x03)	Reads the binary content of holding registers (4X references) in the slave.
FC04 (0x04)	Reads the binary content of input registers (3X references) in the slave.
FC05 (0x05)	Forces a single coil (0X references) to either ON or OFF
FC06 (0x06)	Presets a value into a single holding register (4X references).
FC15 (0x0F)	Forces each coil (0X references) in a sequence of coils to either ON or OFF.
FC16 (0x10)	Presets values into a sequence of holding registers (4X references).

NOTE

• FC15 / FC16 will be used for writing. In case if the connected controller do not support these function codes, then FC05 / FC06 will be used.

■ IEC61131 address syntax

The following table gives the equivalences between the Modbus syntax and the IEC61131 syntax.

	Modbus address syntax		IEC61131syntax					
Device					0-	based	1-	based
	Format	Range	First element	Format	Range	First element	Range	First element
Coil	000001+i	i=0 to 65535	000001	%Mi	i=0 to 65535	%M00000	i=1 to 65536	%M00001
Discrete Input	100001+i	i=0 to 65535	100001	-	-	-	-	-
Input register (word)	300001+i	i=0 to 65535	300001	-	-	-	-	-
Input register (word bit)	300001+i,j	i=0 to 65535 j=0 to15	300001,00	-	-	-	-	-
Holding register (word)	400001+i	i=0 to 65535	400001	%MWi	i=0 to 65535	%MW00000	i=1 to 65536	%MW00001
Holding register (word bit)	400001+i,j	i=0 to 65535 j=0 to15	400001,00	%MWi: Xj	i=0 to 65535 j=0 to 15	%MW00000: X00	i=1 to 65535 j=0 to15	%MW00001 :X00

NOTE

- The two areas 100000 and 300000 are not accessible with the IEC syntax.
- Once you change the project which you have setup Discrete Input Register to IEC 61131 Syntax, the address will be undefined.

NOTE

- Please refer to the GP-Pro EX Reference Manual for system data area.
 - Cf. GP-Pro EX Reference Manual "LS Area (Direct Access Method Area)"
- Please refer to the precautions on manual notation for icons in the table.
 - "Manual Symbols and Terminology"

7 Device Code and Address Code

Use device code and address code when you select "Device Type & Address" for the address type in data displays.

■ Micro/Premium/Twido/Quantum/Momentum Series

Device	Device Name	Device Code (HEX)	Address Code
Coil	0	0080	Value of (word address - 1) divided by 16
Discrete Input	1	0081	Value of (word address - 1) divided by 16
Input Register	3	0001	Value of word address from which 1 is deducted
Holding Register	4	0000	Value of word address from which 1 is deducted

■ FCN/FCJ Series

Device	Device Name	Device Code (HEX)	Address Code
Coil	0	0080	Value of (word address - 1) divided by 16
Discrete Input	1	0081	Value of (word address - 1) divided by 16
Input Register	3	0001	Value of word address from which 1 is deducted
Holding Register	4	0000	Value of word address from which 1 is deducted

8 Error Messages

Error messages are displayed on the screen of Display as follows: "No.: Device Name: Error Message (Error Occurrence Area)". Each description is shown below.

Item	Description
No.	Error No.
Device Name	Name of External Device where error occurs. Device name is a title of External Device set with GP-Pro EX. (Initial value [PLC1])
Error Message	Displays messages related to the error which occurs.
	Displays IP address or device address of External Device where error occurs, or error codes received from External Device.
Error Occurrence Area	 NOTE IP address is displayed such as "IP address(Decimal): MAC address(Hex)". Device address is diplayed such as "Address: Device address". Received error codes are displayed such as "Decimal[Hex]".

Display Examples of Error Messages

"RHAA035: PLC1: Error has been responded for device write command (Error Code: 2 [02H])"



- Refer to your External Device manual for details on received error codes.
- Refer to "Display-related errors" in "Maintenance/Troubleshooting Guide" for details on the error messages common to the driver.