Halloween Screen Topper

Istruzioni e avvertenze - D3D Create by Dario

Questo piccolo programma gratuito fa "accendere" occhi, naso e bocca della zucca stampata in 3D appesa al bordo superiore del monitor: lo schermo, dietro la zucca, mostra luci arancioni con un leggero effetto candela, esattamente nella forma dei fori.



ATTENZIONE - luci tremolanti. Il programma mostra luci che possono tremolare e cambiare colore (sempre in modo graduale, senza lampi). Se tu o chi guarda lo schermo soffrite di **epilessia fotosensibile** o siete sensibili alle luci intermittenti, **non usarlo** oppure disattiva il tremolio. Interrompi subito l'uso in caso di fastidio, mal di testa, disturbi alla vista o malessere.

1. Cosa serve

- Un PC con **Windows 10 o 11**.
- **Python 3** (gratuito) - versione 3.9 o successiva.
- In alternativa, su GitHub nella sezione **Releases** trovi la versione **.exe** che non richiede Python: scarica lo ZIP, estrailo e avvia ScreenTopper_Halloween.exe.
- Il file del programma **ScreenTopper_Halloween.py** (scaricabile da github.com/D3DCreate/Halloween_screen_topper).
- Una zucca stampata della serie, con il suo supporto per il monitor.

2. Installare Python (solo la prima volta)

1. Vai su **www.python.org** > Downloads e scarica l'ultima versione per Windows.
2. Avvia l'installazione e **spunta la casella "Add python.exe to PATH"** in basso, poi clicca "Install Now".
3. Lascia le opzioni predefinite: la parte grafica (tcl/tk) necessaria al programma è già inclusa.

3. Preparare il file

- Salva **ScreenTopper_Halloween.py** in una cartella a tua scelta (es. Documenti).
- Se lo hai scaricato come **.txt**, rinominalo in **.py**. Se non vedi l'estensione: Esplora file > Visualizza > Mostra > Estensioni nomi file.
- Se copi il codice a mano, copialo **tutto e senza modificare gli spazi** a inizio riga: in Python contano.

4. Avviare il programma

- Fai **doppio clic** sul file .py.
- In alternativa apri il Prompt dei comandi nella cartella del file e scrivi:

```
python ScreenTopper_Halloween.py
```

Suggerimento: rinominando il file in **.pyw** non comparirà la finestra nera del terminale. Al primo avvio appare l'avviso sulle luci: clicca **Si** per continuare.

5. Regolazione (una volta sola)

1. Appendi la zucca al bordo del monitor.
2. Nel pannello scegli il **modello** della tua zucca (es. "Pumpkin 7 2026").
3. Attiva **"Mostra contorno guida"**: compare il profilo tratteggiato della zucca.
4. Trascina le luci col **tasto SINISTRO** del mouse finchè combaciano con i fori.
5. Trascina col **tasto DESTRO** verso destra/sinistra per ingrandire o rimpicciolire (ogni monitor ha pixel di dimensioni diverse).
6. Rifinisci con le **frecce della tastiera** (1 pixel alla volta), poi togli la guida.
7. Se ai bordi dei fori si vede ancora del bianco, aumenta il cursore **"Bordo extra luci"** (0-2 mm, di base 1,5): la luce si allarga oltre il foro e copre le piccole imprecisioni. Il guscio della zucca nasconde la luce in eccesso.

Posizione, dimensione, colori e modello vengono **salvati automaticamente** alla chiusura. Tutte le zucche della serie hanno lo stesso punto di aggancio: cambiando modello le luci restano già allineate.

6. Uso

- **Colori**: due pulsanti per occhi/naso e bocca (usati dagli effetti Candela e Respiro).
- **Effetto luce**: **Candela** (i colori scelti), **Cambio colore** (palette di Halloween con dissolvenza), **Arcobaleno lento** o **Respiro** (pulsazione lenta). Il cursore "Cambio ogni" regola la velocità di cambio colore e arcobaleno.
- **Tremolio candela**: si somma a qualsiasi effetto; regolane l'intensità o spegnilo.
- **Riduci pannello**: nasconde il pannello, le luci restano accese.
- **Chiudi tutto**: spegne le luci e salva le impostazioni.

7. Problemi comuni

- **"python" non è riconosciuto**: reinstalla Python spuntando "Add python.exe to PATH", oppure usa il comando **py** al posto di python.
- **Il programma si apre e si chiude subito**: avvialo dal Prompt dei comandi per leggere il messaggio di errore.
- **Le luci non si vedono**: i giochi e i video a schermo intero possono coprirle.
- **Windows mostra un avviso di sicurezza**: è normale per i file scaricati; scarica il programma solo dal link ufficiale.

8. Disinstallare

Cancella il file .py e la cartella **%APPDATA%\ZuccaOverlay** (contiene solo le impostazioni).

Liberatoria

- Il programma e i file collegati sono forniti **gratuitamente e "così come sono"**, per uso personale e non commerciale, **senza alcuna garanzia** di funzionamento o di idoneità a uno scopo.
- Chi scarica, installa e avvia il programma lo fa **per propria scelta e a proprio rischio**.
- Il programma mostra **luci colorate, tremolanti e che cambiano colore**: non va usato da persone (o in presenza di persone) con epilessia fotosensibile o sensibilità alla luce. L'utilizzatore è responsabile di valutarne l'idoneità per sè e per chi guarda lo schermo.
- L'autore **non risponde di alcun danno**, diretto o indiretto, a persone, animali, dati, computer, monitor o altri oggetti derivante dall'uso del programma o dell'oggetto stampato e del suo supporto (es. graffi, cadute, instabilità). Verifica che la zucca sia ben stabile e non danneggi lo schermo.
- L'autore non risponde di copie modificate o scaricate da fonti diverse da quella ufficiale.
- **Usando il programma accetti queste condizioni.** Se non le accetti, non usarlo.

Halloween Screen Topper

Instructions and warnings - D3D Create by Dario

This small free program "lights up" the eyes, nose and mouth of the 3D printed pumpkin hanging on top of your monitor: behind the pumpkin, the screen shows orange lights with a gentle candle effect, shaped exactly like the holes.



WARNING - flickering lights. The program shows lights that can flicker and change colour (always gradually, without flashes). If you or anyone watching the screen has **photosensitive epilepsy** or is sensitive to flashing lights, **do not use it** or turn the flicker off. Stop immediately in case of discomfort, headache, visual disturbance or feeling unwell.

1. What you need

- A PC with **Windows 10 or 11**.
- **Python 3** (free) - version 3.9 or later.
- Alternatively, on GitHub under **Releases** there is an **.exe** version that needs no Python: download the ZIP, extract it and run ScreenTopper_Halloween.exe.
- The program file **ScreenTopper_Halloween.py** (download from github.com/D3DCreate/Halloween_screen_topper).
- A printed pumpkin from the series, with its monitor holder.

2. Install Python (first time only)

1. Go to **www.python.org** > Downloads and get the latest version for Windows.
2. Run the installer and **tick "Add python.exe to PATH"** at the bottom, then click "Install Now".
3. Keep the default options: the graphics part (tcl/tk) the program needs is already included.

3. Prepare the file

- Save **ScreenTopper_Halloween.py** in any folder (e.g. Documents).
- If you downloaded it as **.txt**, rename it to **.py**. If you can't see extensions: File Explorer > View > Show > File name extensions.
- If you copy the code by hand, copy **all of it without changing the spaces** at the start of lines: they matter in Python.

4. Start the program

- **Double-click** the .py file.
- Or open a Command Prompt in the file's folder and type:

```
python ScreenTopper_Halloween.py
```

Tip: rename the file to **.pyw** to hide the black console window. On first start a light warning appears: click **Yes** to continue.

5. Setup (once)

1. Hang the pumpkin on the top edge of the monitor.
2. In the panel choose your pumpkin **model** (e.g. "Pumpkin 7 2026").
3. Enable **"Show outline guide"**: a dashed outline of the pumpkin appears.
4. Drag the lights with the **LEFT** mouse button until they match the holes.
5. Drag with the **RIGHT** button left/right to enlarge or shrink them (every monitor has a different pixel size).
6. Fine-tune with the **arrow keys** (1 pixel at a time), then turn the guide off.
7. If you still see white around the holes, raise the **"Extra light border"** slider (0-2 mm, default 1.5): the light grows beyond the holes and hides small misalignments. The pumpkin shell hides the extra light.

Position, size, colors and model are **saved automatically** on exit. All pumpkins of the series share the same hanging point: switching model keeps the lights aligned.

6. Use

- **Colors**: two buttons for eyes/nose and mouth (used by the Candle and Breathing effects).
- **Light effect**: **Candle** (your colors), **Color change** (Halloween palette with fades), **Slow rainbow** or **Breathing** (slow pulse). The "Change every" slider sets the speed of color change and rainbow.
- **Candle flicker**: works on top of any effect; set its intensity or turn it off.
- **Minimize panel**: hides the panel, lights stay on.
- **Close all**: turns the lights off and saves the settings.

7. Troubleshooting

- **"python" is not recognized**: reinstall Python ticking "Add python.exe to PATH", or use the **py** command instead of python.
- **The program opens and closes at once**: start it from the Command Prompt to read the error.
- **Lights not visible**: full-screen games and videos can cover them.
- **Windows shows a security warning**: normal for downloaded files; only download the program from the official link.

8. Uninstall

Delete the .py file and the folder **%APPDATA%\ZuccaOverlay** (it only holds the settings).

Disclaimer

- The program and related files are provided **free of charge and "as is"**, for personal, non-commercial use, **without any warranty** of operation or fitness for a particular purpose.
- Whoever downloads, installs and runs the program does so **by their own choice and at their own risk**.
- The program shows **coloured, flickering, colour-changing lights**: it must not be used by (or around) people with photosensitive epilepsy or light sensitivity. The user is responsible for judging whether it is suitable for themselves and for anyone watching the screen.
- The author **accepts no liability for any damage**, direct or indirect, to people, animals, data, computers, monitors or other property arising from the use of the program or of the printed object and its holder (e.g. scratches, falls, instability). Make sure the pumpkin is stable and does not damage the screen.
- The author is not responsible for modified copies or copies downloaded from unofficial sources.
- **By using the program you accept these terms.** If you do not accept them, do not use it.