

TECHNICAL COMMUNICATION PROJECT USER MANUAL

NAME: DHANESH S

ROLL NO: AM.SC.U4CSE25260

BATCH:2025-2026

TITLE:

Create a user manual for a pair of shoes that count steps, measure calories, and vibrate to give GPS directions

1. Welcome

Thank you for purchasing our smart shoes. These shoes are equipped with advanced sensors and haptic feedback technology to enhance your daily fitness tracking and navigation experience. Please read this manual carefully before use.

Who will benefit from this shoe:

These **shoes** can monitor an individual's health by tracking their travel time and **calories** burned, utilizing **GPS** technology to **track** their location

Getting started

What's in the box

- Your pair of Smart Shoes
- Wireless charging pad and USB cable
- Instruction manual
- Warranty information

Charging your shoes

Your shoes arrive with a partial charge, but you should fully charge them before your first use.

1. Plug the USB cable into a power adapter and connect it to the charging pad.
2. Place your shoes on the charging pad. The LED indicator on the shoes will light up to confirm they are charging.
3. A full charge takes approximately 2–3 hours. The LED will turn solid green when the battery is full. A full charge lasts for up to 10 days of normal use.

Connecting to the app

The companion app is your primary interface for controlling and viewing data from your shoes.

Pairing for the first time

1. **Download:** Search for the "[Manufacturer Name] Smart Shoes" app in your phone's app store.
2. **Create an account:** Open the app and follow the prompts to create your user profile. This is where you'll enter personal data like your height, weight, and age for more accurate calorie calculations.
3. **Activate Bluetooth:** Ensure Bluetooth is enabled on your phone and that your shoes are powered on.
4. **Pair:** In the app, select "Add Device" and follow the instructions to pair your shoes. The LED on your shoes will flash blue during pairing.

Performing the initial calibration

1. After pairing, the app will prompt you to calibrate your shoes.
 2. Put on your shoes and walk naturally for about 5 minutes, following the app's prompts.
 3. This calibration process allows the shoes' sensors to learn your unique stride length and walking patterns for more accurate data.
-

Fitness tracking

Your shoes automatically track your steps and estimate calories burned throughout the day, as long as they are powered on and you are wearing them.

Viewing your data

- Open the app at any time to see your daily progress.
- **Home screen:** Displays your real-time step count, calories burned, and total distance travelled.
- **History:** The app logs your activity over time, allowing you to view your performance by day, week, or month.

Understanding the data

- **Step count:** Recorded via built-in motion sensors, this is the total number of steps you have taken.
 - **Calories burned:** An estimate based on your activity, personal profile data, and motion sensors.
 - **Distance:** Calculated based on your step count and calibrated stride length.
-

GPS navigation

Your shoes use gentle vibrations to provide turn-by-turn navigation, so you don't need to look at your phone while walking.

How it works

1. **Set a destination:** In the app, use the map to find or set your destination and begin navigation.
2. **Start your journey:** The app will send directions to your shoes via Bluetooth.
3. **Left turn:** A vibration in your **left shoe** signals to turn left.
4. **Right turn:** A vibration in your **right shoe** signals to turn right.

5. **Missed turn:** A series of two quick vibrations in **both shoes** means you've gone off the planned route.
6. **Destination reached:** Three quick vibrations in **both shoes** confirm that you have reached the destination



SECURITY CONSIDERATIONS

> Bluetooth Security

- Always pair your shoes with your own device and avoid connecting to unknown or public devices.
- Turn off Bluetooth when not using the shoes to reduce the risk of unauthorized access.

> App Permissions

- The Great Step app requires access to your location and Bluetooth for navigation and tracking features.
- Only grant permissions that are necessary for the app's functionality.
- Review app permissions periodically in your phone settings.

>Data Privacy

Great Step does not share your personal data with third parties without your consent.

THINGS TO DO BEFORE USING IT

ATTENTION

1. Charge Your Shoes Fully

>Connect the charging cable to the right shoe and charge for about 2 hours until the LED indicator turns green.

2. Download and Install the Great step App

>Find the *Great* App on the Apple App Store or Google Play Store and install it on your smartphone.

3. Create an Account

>Open the app and create your personal account to save your activity data and customize settings.

4. Pair Your Shoes with Your Smartphone

>Turn on Bluetooth on your phone.

>Follow the app's instructions to connect your shoes via Bluetooth.

5. Calibrate Your Profile

Warranty information

The electronic components have a 180-day warranty, and the shoe material has a 15-day warranty from the purchase date. Coverage includes defects in materials and workmanship but excludes damage from misuse, accidents, wear and tear, or unauthorized repairs. To file a claim, contact customer support with proof of purchase; they will determine if repair, replacement, or refund is appropriate.

Customer support

For support, troubleshooting, or warranty claims, contact **info@nike.com** or visit **www.nike.com**.

6. Set Up Navigation Preferences

- Allow location permissions in the app.

- Familiarize yourself with the vibration signals for navigation in the app tutorial.

7. **Perform a Test Walk**

- Walk around briefly to ensure steps are being tracked and vibration directions work as expected.

8. **Adjust Fit and Comfort**

- Make sure your shoes fit comfortably and securely before starting longer activities.

PROHIBITION

1. Do not keep in sunlight for too long
2. **Stop using the shoes immediately if you experience any discomfort, pain, or skin irritation.**
3. Avoid using the shoes in wet or extreme weather conditions
4. Do not attempt to charge the shoes with any charger other than the one provided by the manufacturer
5. **Keep shoes away from children under 3 years old** due to small parts that may pose a choking hazard.

WARNING

- **Driving:** Always turn off gesture mode and navigation features while driving to avoid distraction. Your shoes will continue to track basic fitness data in the background.
- **Medical Use:** The shoes are for general fitness tracking only and should not be used as medical devices or for diagnosis.
- **Emergency:** In case of emergency, do not rely on your shoes to provide a reliable signal. Always use a dedicated device to contact emergency services.

Trouble Shooting

Problem	Possible Cause	Solution
Shoes won't turn on	Low or no battery charge.	Charge your shoes using the provided cable.
No GPS vibrations	Shoes are not paired or the app is not running.	Ensure your shoes are charged, turned on, and connected to the app via Bluetooth.
Inaccurate step count	Initial setup or calibration issue.	Contact customer support if issues persist.
App not connecting	Bluetooth is off or a pairing issue.	Check your phone's Bluetooth settings. Restart both your phone and your shoe

If shoes don't connect, check Bluetooth, charge level, and range. Restart the app and re-pair. For inaccurate step counts, verify app profile information and check for firmware updates. If vibrations don't work, ensure Bluetooth connection and that your phone's volume isn't muted

FEATURES

- **Connectivity:** Bluetooth 4.0
- **Pressure sensors:** To provide information on the distribution of body weight
- **Sensors:** Accelerometer, Gyroscope
- **Water Resistance:** Splash-proof (not submersible)
- **Interactive haptic based navigation:** Detects vibration in the feet and guides them to their destination
- **Battery:** Lithium-ion (rechargeable)
- **Battery Life:** Up to 4 days (depending on usage)
- **Lightweight sensors and Transmitters:** (To provide data for each foot individually)

Product components

- **Sensor module:** A compact unit containing
 - **Accelerometer and gyroscope:**
 - **GPS module**
- **Microprocessor**
- **Vibration motor**
- **Rechargeable battery**
- **Bluetooth module**

Cleaning and maintenance

- **Cleaning:** Use a damp cloth to wipe the shoes clean. Avoid submerging the shoes in water or using harsh chemical cleaners.
- **Charging:** To maximize battery life, avoid exposing the shoes to extreme temperatures while charging.
- **Storage:** Store shoes in a cool, dry place when not in use.

Warranty information

The electronic components have a 180-day warranty, and the shoe material has a 15-day warranty from the purchase date. Coverage includes defects in materials and workmanship but excludes damage from misuse, accidents, wear and tear, or unauthorized repairs. To file a claim, contact customer support with proof of purchase; they will determine if repair, replacement, or refund is appropriate.

Customer support

For support, troubleshooting, or warranty claims, contact **info@nike.com** or visit **www.nike.com**.

