

## **XDJ-XZ**

## Hardware Diagram for rekordbox dj



GROUP	No.	N	IAME	FUNCTION	+SHIFT	
1. DE	СК	*All the functions assign	ned on the right deck are th	ne same as those on the left deck shown below.		
-,	1		-1-11	Scratch (Vinyl On)	Search	
		JOG	platter wheel side	Pitch bend (Vinyl Off)		
				Pitch bend	•	
	2	TEMPO		Tempo control		
	3	TEMPO RESET		Tempo Reset		
	4	MASTER TEMPO		Master Tempo On/Off		
	5	TEMPO RANGE		Tempo Range		
		SYNC		Sync On/Off		
	6	long press		INSTANT DOUBLES		
	7	MASTER	long press	Master		
	8	JOG ADJUST		JOG ADJUST		
		JOG MODE		Vinyl On/Off		
	9	VINYL SPEED ADJUST				
	10	TRACK SEARCH		Vinyl Speed Adjust PREV / NEXT TRACK		
	11					
	12	SEARCH		BEAT JUMP (While Play: BEAT JUMP 8, While Pause: BEAT JUMP FINE)		
	13	SHIFT		Shift		
	14	REVERSE		Reverse		
	15	SLIP		SLIP mode On/Off		
	16	4/8 BEAT long press		4 BEAT Loop		
				8 BEAT Loop		
	17	LOOP IN		Loop in / Loop in adjust		
			long press	4 BEAT Loop		
	18	LOOP OUT		Loop out / Loop out adjust		
	19	RELOOP/EXIT		Reloop/Exit		
		CALL NEXT / 2X		CUE/LOOP CALL, FWD		
	-00	During loop playback		Loop Size Select (Double)		
	20			CUE/LOOP CALL, REV		
				Loop Size Select (Half)		
	21			DELETE MEMORY		
	22					
	23	PLAY/PAUSE		Play/Pause Set/call cue, Back cue		
	24	CUE				
	25	JOG RING				
		LOAD		Load tracks		
	26		Press twice	INSTANT DOUBLES		
	27			NEEDLE SEARCH		
2, EF				THE EDGE OF WATER		
3, MI)	FD					
,		AUX TRIM		SAMPLER volume when AUX SELECT off		
I, BR				Of the East Folding Wild Property of		
., טוג	1	Rotary Selector	rotate	Browse(Track/Folder Select)	Enlarged waveform Zoom In/Out	
	l '	rotary Selector	press	Jump between panels (forward)	Emarged waveform 200m in/Out	
	2	BACK	press	Jump between tree view/panels (backward)	Switch banks of Tag List/Playlist Pale	
	3					
	4	TAG TRACK/REMOVE		Add/delete track to/from TAG LIST Show Related Tracks  TRACK FILTER OPEN/CLOSE		
		TRACK FILTER				
	5	DECK QUANTIZE		Deck Quantize on/off		
	6	TIME MODE / AUTO CUE long press		TIME MODE (REMAINING / ELAPSED TIME)		
	Ľ			A.Cue On/Off		
	7	DECK 1/3 (SHORT (		Change from Deck 1 to/from Deck 3		
		DECK 2/4 (SHORT (		Change from Deck 2 to/from Deck 4		
	RFOI	RMANCE PAD	S			
5,PEF		HOT CUE		HOT CUE	KEY BOARD	
5,PEF	1	HOT COE				
5,PEF	2	BEAT LOOP		BEAT LOOP	KEY SHIFT	
5,PEF				BEAT LOOP PAD FX 1	KEY SHIFT PAD FX2	

DUP No.		NAME	FUNCTION	+SHIFT
ERFO	RMANCE PAD	S		
	PERFORMANCE	mode		
	PAD A	HOT CUE	Set/call Hot Cue A	Delete HOT CUE A
		BETAT LOOP	1/4 BEAT LOOP	1/4 BEAT LOOP
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)
5		BEAT JUMP	BEAT JUMP	
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE
		KEY SHIFT	KEY SHIFT	
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)
	DEDECRIALION	SAMPLER	SAMPLER slot1 playback	SAMPLER slot1 pause
	PERFORMANCE PAD B	mode	C-t/IIII-t C D	Delete HOT CUE B
	FADB	HOT CUE BETAT LOOP	Set/call Hot Cue B 1/2 BEAT LOOP	1/2 BEAT LOOP
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)
6		BEAT JUMP	BEAT JUMP	FAD FAT (page2)
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE
		KEY SHIFT	KEY SHIFT	Dudio Hot Cot
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)
		SAMPLER	SAMPLER slot2 playback	SAMPLER slot2 pause
	PERFORMANCE	mode		-
	PAD C	HOT CUE	Set/call Hot Cue C	Delete HOT CUE C
		BETAT LOOP	1 BEAT LOOP	1 BEAT LOOP
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)
7		BEAT JUMP	BEAT JUMP	
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE
		KEY SHIFT	KEY SHIFT	
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)
		SAMPLER	SAMPLER slot3 playback	SAMPLER slot3 pause
	PERFORMANCE	mode		
	PAD D	HOT CUE	Set/call Hot Cue D	Delete HOT CUE D
		BETAT LOOP	2 BEAT LOOP	2 BEAT LOOP
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)
8		BEAT JUMP	BEAT JUMP	D. L. LIOT OUE
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE
		KEY SHIFT	KEY SHIFT	BAR ENG (
		PAD FX2 SAMPLER	PAD FX2 (page1)	PAD FX2 (page2)
	PERFORMANCE		SAMPLER slot4 playback	SAMPLER slot4 pause
	PAD E	mode HOT CUE	Set/call Hot Cue E	Delete HOT CUE E
	FADE	BETAT LOOP	4 BEAT LOOP	4 BEAT LOOP
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)
9		BEAT JUMP	BEAT JUMP	FAD FAT (page2)
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE
		KEY SHIFT	KEY SHIFT	Delete HOT COE
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)
		SAMPLER	SAMPLER slot5 playback	SAMPLER slot5 pause
	PERFORMANCE	mode	DAMI LER SIOLO Playback	OAMI EEIT SIOIO PAUSE
	PAD F	HOT CUE	Set/call Hot Cue F	Delete HOT CUE F
		BETAT LOOP	8 BEAT LOOP	8 BEAT LOOP
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)
10		BEAT JUMP	BEAT JUMP	0.00
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE
		KEY SHIFT	KEY SHIFT	
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)
		SAMPLER	SAMPLER slot6 playback	SAMPLER slot6 pause
	PERFORMANCE	mode		
	PAD G	HOT CUE	Set/call Hot Cue G	Delete HOT CUE G
		BETAT LOOP	16 BEAT LOOP	16 BEAT LOOP
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)
11		BEAT JUMP	BEAT JUMP	BEAT JUMP Previous Page
		KEYBOARD	Select HOT CUE for KEY SHIFT	KEYBOARD Previous Page
		KEY SHIFT	KEY SHIFT	KEY SHIFT Previous Page
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)
		SAMPLER	SAMPLER slot7 playback	SAMPLER slot7 pause
	PERFORMANCE PAD H	mode	To a succession	
	PADH	HOT CUE	Set/call Hot Cue H	Delete HOT CUE H
		BETAT LOOP	32 BEAT LOOP	32 BEAT LOOP
4-		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)
12		BEAT JUMP	BEAT JUMP	BEAT JUMP Next Page
	1	KEYBOARD	Select HOT CUE for KEY SHIFT	KEYBOARD Next Page
		KEY SHIFT	KEY SHIFT	KEY SHIFT Next Page
		KEY SHIFT PAD FX2 SAMPLER	REY SHIFT PAD FX2 (page1) SAMPLER slot8 playback	PAD FX2 (page2) SAMPLER slot8 pause

© 2019 Pioneer DJ Corporation All rights reserved.