
TABLE OF CONTENTS:

- Overview (Pad Modes)
- Overview (Jog Screens)
- Overview (Decks)
- Overview (Mixer)
- MixerFX and Beat FX

- Loop section
- Beatjump section
- Sync modes
- Deck Layout
- Browser
- Transport
- Beatgrid
- Settings

- Pad hotcues
- Pad padFX/Rolls
- Pad macroFX/mixerFX
- Pad jogFX
- Pad keyboard
- Pad beatjump/loop
- Pad slicer
- Pad remix decks

DDJ-SX2/SZ: Pad modes




DDJ-SZ: General overview - Deck





DDJ-SX2: General overview - Deck






DDJ-SZ General overview - Mixer








DDJ-1000SRT: General overview - Mixer



DDJ-1000: MixerFX and UserFX









DDJ-SZ: MixerFX and UserFX







DDJ-1000/SRT: Loop Section



(DDJ-SX2/SZ)









DDJ-1000/SRT: BeatJump Section

(DDJ-SX2/SZ)














DDJ: Sync Section

	TRAKTOR MODE	SERATO MODE	ELASTIC GRID MODE
Preferences / Transport	BeatSync	Tempo Sync	BeatSync
BEAT SYNC MASTER	Toggle ON/OFF	Sync On	Sync On
OUE OUE			Sync On
			Sync Off
SHI	# BEAT SYNC	Set master deck	





CUE / LOOP TEE





Sync Off

Toggle between 3x sync modes

(DDJ-SX2/SZ)



Toggle 2-deck / 4-deck view







Toggle Parallel / Classic view








Enable/ disable layout change







ALL DDJs: Browser



DDJ-1000/SRT: Transport







(DDJ-SX2/SZ)











DDJ-1000/SRT: Beatgrid






DDJ-SX2/SZ: Beatgrid






DDJ-1000: Mapping Settings




DDJ-1000: Pad modes




Most modes have sub-pages:

- Press "mode" to cycle the top 2 pages
- Press "<" to cycle all pages one by one
- Press ">" to select a specific page
- Press "shift" to select a specific page

DDJ-SZ/SX2: Pad modes



ALL DDJs mode #1: HotCues



- Use shift to delete hot cues
- Hotcues move temporary cue as well


ALL DDJs mode #2: PadFX and Rolls

MAIN PAGES: **EXTRA PAGES:** Rolls PadFX 2 Delay / **Roll 1/8** Roll 1/4 Roll 1/2 Roll 1/1 Flanger Flux Delay #1 Delay #2 BeatSlicer **Roll 1/8** Roll 1/4 **Roll 1/2** Roll 1/1 Lofi / Lofi / Release FX BeatSlicer (NQ) (NQ) (NQ) (NQ) Slicer #2 (toggle) Slicer #1 PadFX 1 PadFX 3 Bass-O-Bass-O-Gater #1 Peak Filter Filter Pulse LaserSlicer Gater #2 Gater #3 Matic #1 Matic #2 Beat Beat Release FX Bouncer / Release FX Zzzurp Bouncer EventH (toggle) Masher #1 Masher #2 EventH (toggle)

- Use mode button to cycle top two pages
- Use "<" arrow to cycle all pages
- Use ">" or "shift" to select a specific page


ALL DDJs mode #3: MixerFX and MacroFX

MAIN PAGES: Macro FX1 MacroFX: MacroFX: MacroFX: MacroFX: WormHole **PolarWind** FlightTest LaserSlicer BeatFX: BeatFX: BeatFX: Toggle Delay T3 On/OFF Flanger Reverb MacroFX2 Bass **Event** Dark Zzzuurp Horizon Matter Matic Strrretch Strrretch Granu **Toggle** On/OFF Phase (Slow) (Fast)



- Use mode button to cycle top two pages
- Use "<" arrow to cycle all pages
- Use ">" or "shift" to select a specific page

ALL DDJs mode #4: JogFX




DECK
SELECT

OR | CORPORATION | CORPORATION


Jog FX


- Enter jogFX mode on mode4 (jog will blink)
- Touch jog to apply FX
- Turn jog to change FX
- Release jog to stop FX
- Sampler volume to Dry/Wet
- Call "hotcues" to cancel jogFX (=scratch mode)

ALL DDJs #5: Tone Play




Use shift to choose between 3x modes:






DDJs mode #6: BeatJumps and Loops




- Use "<" arrow to select beatjump mode
- Use ">" arrow to select loop mode


ALL DDJs mode #7: Slicer



Use shift to choose between 3x modes:



ALL DDJs mode #8: Sampler



Use shift to mute / Toggle 1-shot

