NUMARK (/MANUALS/HARDWARE/NUMARK.HTML) - PARTYMIX (/MANUALS/HARDWARE/NUMARK/PARTYMIX.HTML)

CONTROLS

KEY

ACTION

L   LIGHTS MODE

Change the Light Show mode. See Light Show (/manuals/hardware/numark/partymix/lights.html)

M   MASTER OUTPUT

Connect a pair of amplified speakers using a proper RCA cable

H   HEADPHONES SOCKET

Connect your Headphones using a 1/8 " cable or adapter

1   CROSSFADER

Blends audio signals from left and right decks

2   VOLUME

Adjust Volume Output for Left and Right deck

3   BASS

Adjust the Low (Bass) Equalizer Band

4   TREBLE

Adjust the High (Treble) and Mid Equalizer Band

5   GAIN

Adjust the pre-fader Output Level

6   BROWSE

Scroll through Folders or Tracks
Push to toggle focus between Folders and Songs List.
When in Folders list, push for more than 1 second to expand/collapse sub-folders

7   LOAD

Load the selected track to Left/Right deck.
Hold for more than 1 second to unload the same deck

8   MASTER GAIN

Adjust the Volume of the Master Output

9   CUE MIX

Routes Master Output to the Headphones Channel when in maximum position.
Routes decks (when PFL is enabled) to the Headphones Channel
Blends Master Output and Decks (if PFL is enabled) in all other positions

10   CUE GAIN

Adjust the Volume of the Headphones Output

11   SYNC

Match BPM and Beat Phase with the opposite deck

12   CUE

Sets current position as Temporary Cue point.
Preview track when paused while button is pressed
Jumps and stops to the Cue point when playing

13   PLAY

Play/Pause track

14   PAD MODES

Cycles through the Pad modes (Hotcues, Loops, Sampler and Effects). See Pads (/manuals/hardware/numark/partymix/pads.html)

15   PADS 1-4

The 4 numbered Pads offer different functionality depending on the selected Pad mode. See Pads (/manuals/hardware/numark/partymix/pads.html)

16   PITCH

Adjust track's tempo (BPM)

17   PFL

Sends pref-dader audio signal to the Headphones channel (for pre-listening)

18   SCRATCH

Toggles between Scratch (Vinyl) and Bend (CD) mode for the Jogwheel

19   JOG

Scratch (when Scratch mode is enabled) or Bend (when Bend mode is enabled)

Pads ❯ (/manuals/hardware/numark/partymix/pads.html)

▶ **About VirtualDJ**

What is VirtualDJ (/products/virtualdj/index.html)
Why VirtualDJ (/products/virtualdj/why.html)
What's new in v8 (/products/virtualdj/version8.html)

Download (/download/index.html)
Price & Licences (/products/virtualdj/price.html)
Content Unlimited (/products/contentunlimited.html)
Older products (/products/legacy.html)

▶ **Support**

Contact Support (/contact/index.html)
User Guides (/manuals/)
FAQ (/wiki/FAQ.html)
VDJPedia (Wiki) (/wiki/index.html)
Forums (/forums/index.html)
Plugins & Skins (/plugins/)

© Atomix Productions (/atomixproductions/index.html) | Site Map (/atomixproductions/sitemap.html)