

In addition to the periodic maintenance the following checks should be made weekly:

Check/top up engine oil
 Check/top up brake fluid reservoir
 Check/top up battery electrolyte
 Check/top up cooling system
 Check/top up washer reservoir
 Check function of original equipment, i.e. exterior lamps, wipers, and warning indicators
 Check tyres for tread depth, visually for external cuts in fabric, exposure of ply or cord structure, lumps and bulges.
 Check/adjust tyre pressures, including spare. Check tightness of wheel fastenings.

MAINTENANCE INTERVALS

Carry out the services indicated by X in column

A at 6,000-mile (10000-km) or 6-month intervals

B at 12,000-mile (20000-km) or 12-month intervals

Items included in the 3,000-mile (5000-km) or 3-month interval

Inspection Check are indicated in **column C**

	A	B	C
ENGINE			
Check/top up engine oil - Castrol XL20W 50	X	X	X
Renew engine oil and filter	X	X	
Renew carburettor air cleaner elements		X	
Top up carburettor piston dampers - SU damper oil	X	X	
Check/adjust carburettor idle speed and mixture settings*	X	X	
Renew fuel filter		X	
Renew engine filler cap		X	
Check/adjust valve clearances		X	
Check cooling/heater systems for leaks and hoses for security and condition	X	X	X
Check/top up cooling system - Forlife/antifreeze	X	X	X
Check/adjust operation of screen washers and top up reservoir - Castrol screen wash	X	X	X
Check driving belt; adjust or renew	X	X	X
Lubricate accelerator control linkage (and pedal pivot) - check operation	X	X	
IGNITION			
Clean/adjust spark plugs	X		
Renew spark plugs		X	
Check distributor points; adjust or renew	X	X	
Lubricate distributor	X	X	
Check/adjust ignition timing and distributor characteristics using electronic equipment*	X	X	
TRANSMISSION			
Check/top up gearbox (XL20W 50 and rear axle oil (EP80/90)	X	X	
Check/top up clutch fluid reservoir - Castrol Response Dot4	X	X	X
Lubricate propeller shaft	X	X	
Gearbox with - drain, clean filters, and fill with new oil			
STEERING AND SUSPENSION			
Check steering rack for oil leaks	X	X	X
Check hydraulic dampers for fluid leaks - Castrol medium damper oil	X	X	X
Check condition and security of steering unit joints and gaiter	X	X	X
Check/adjust front wheel alignment*	X	X	
Lubricate all grease points, excluding hubs - Castrol LM Grease	X	X	
BRAKES			
Check visually hydraulic pipes and unions for chafing, leaks and corrosion	X	X	X
Check/top up brake fluid reservoir - Castrol Response Dot 4/ Silicone brake fluid	X	X	X
Check/adjust foot brake and hand brake operation	X	X	X
Inspect brake pads for wear, discs for condition	X		
Inspect brake linings/pads for wear, drums/discs for condition		X	
Lubricate hand brake mechanical linkage (and cables)	X	X	
Clean servo filter element		X	
ELECTRICAL			
Check function of original equipment, i.e. interior and exterior lamps, screen wipers, horns, and warning indicators	X	X	X
Check/top up battery electrolyte	X	X	X
Clean and grease battery connections	X	X	
Check/adjust headlamp alignment*	X	X	X
Check, if necessary renew, windscreen wiper blades	X	X	X
EXHAUST, FUEL AND CLUTCH PIPES			
Check clutch pipes for leaks and chafing	X	X	X
Check fuel system for leaks, pipes and unions for chafing and corrosion*	X	X	X
Check exhaust system for leaks and security	X	X	X
Check fuel filler tank connections	X	X	X

