

SOP-007 - Heat Exchanger Cleaning Routine

Standard Operating Procedure | Tier 3

1. Purpose

Isolation and cleaning of shell-and-tube exchangers.

2. Procedure

1. Isolate and drain both shell and tube sides.
2. Open the exchanger and clean the tubes.
3. Reassemble with new gaskets and leak-test.