Load plates toward the center.
Leave space around the spray arms.
Do not block the detergent cup.

A short wash is enough for glasses.

The dishwasher warranty is printed on the card
that came in the box.

Call Pell and Sons if the pump leaks.
Have the warranty card nearby.

Twist the filter out once a month.
Rinse it under the tap.
Seat it until it clicks.

Then run a hot rinse.