Product Manual (EN)

Inflatable Costume 100% Polyester Costume

Use 4xAA Batteries (Batteries not included)

Safety Instructions

Choking hazard – small parts.

Not suitable for children under 3 years.

KEEP AWAY FROM FIRE! Flammable.

Obstructed Vision

Do not swim.

Do not drive.

Care Instructions

Surface clean only with damp cloth. Do not bleach. No not iron. Do not dry clean.

How to use this product

Please visit www.morphsuits.co.uk/howto for a video instruction!

Adult Supervision Required

.....

Giant Inflatable/ 4-Legged

1. Unzip costume and unscrew battery pack to add 4 x new AA batteries and turn on.
2. Place the battery pack into the pocket attached to inside of costume.
3. Place feet into the 2 leg holes and ensure elastic is around the ankles or leg, depending on your costume
4. Place arms inside sleeves
5. Grab the top edge of the hood and pull it over your head, ensuring the hood lining is placed behind your head with the elastic at the back neck
6. Zip up the front of the costume and fasten the velcro tab under your chin
7. Wait for the costume to inflate.

Headless / Pick-Me-Up Inflatable

1. Unzip costume and unscrew battery pack to add 4 x new AA batteries and turn on.
2. Place the battery pack into the pocket attached to inside of costume.
3. Place feet into the 2 legs holes and ensure elastic is around the ankles.
4. Put your head through the elasticated head hole and fasten the velcro at the back of
5. your neck.
6. Then place arms inside sleeves after head is inside.
7. Zip up the back of the costume.
8. Wait for the costume to inflate.

Hugger Mugger

1. Unscrew battery pack to add 4 x new AA batteries and turn on.
2. Place the battery pack inside of costume, through the zipper found at the back.
3. Once the battery pack rests inside the costume, close the zip on the back to prevent the battery pack from falling out.
4. Ensure to attach your hugger mugger correctly around your body -neck and waist-, and use the velcro patches to keep the costume in place.
5. Wait for the costume to inflate.

Vehicle Inflatable

1. Unzip costume and unscrew battery pack to add 4 x new AA batteries and turn on.
2. Place the battery pack into the pocket attached to inside of costume.
3. Stretch the base of the inflatable open. Push your head and shoulders inside. Pull head through the neck opening. Shoulders stay inside the costume.
4. Push arms through elasticated arm holes.
5. Push head through elasticated neck hole and fasten Velcro at the back of neck.
6. Ensure elasticated bottom edge of inflatable is worn at the waist with no air escaping.
7. Wait for the costume to inflate.

Ride On Inflatable

1. Unzip costume and unscrew battery pack to add 4 x new AA batteries and turn on.
2. Place the battery pack into the pocket attached to inside of costume.
3. Place feet into the 2 legs holes and ensure elastic is around the ankles or leg depending on your costume.
4. Pull costume up and ensure it is fitted around the waist.
5. Wait for the costume to inflate.

Sound Chip Astronaut

1. Unzip costume and unscrew battery pack to add 4 x new AA batteries and turn on.
2. Place the battery pack into the pocket attached to inside of costume.
3. Remove plastic tab from back of sound chip. Put back inside the pouch. Squeeze each time to activate the sound.
4. Place feet into the 2 leg holes and ensure elastic is around the ankles or legs depending on your costume.
5. Put the top of your head though the first neck hole but not through the second face hole and fasten the Velcro under the chin.
6. Place arms inside sleeves after head is inside. Zip up the back of the costume. Zip may be horizontal depending on your style of costume.

Batteries Instructions

Please keep the packaging, there is important information on it. Use 4 x new AA batteries. To insert batteries, unscrew back of battery pack. Batteries are to be replaced and handled only by adults or under adult supervision. After inserting the batteries close the lid of the battery compartment, re-insert screw and tighten. Use only batteries recommended in the instructions.

Non-rechargeable batteries are not to be recharged. Rechargeable batteries are only to be charged under adult supervision. Rechargeable batteries are to be removed from the toy before being charged. Different types of batteries or new and used batteries are not to be mixed. Batteries are to be inserted with the correct polarity (+ and -). Exhausted batteries are to be removed from the toy. Recycle, store and dispose of batteries in a safe room temperature area out of the reach of children or pets. The supply terminals are not to be short-circuited. The toy is not to be connected to more than recommended number of power supplies.

WARNING! Do not mix old and new batteries! Do not mix alkaline, standard (carbon-zinc), or re-chargeable batteries! Remove batteries from costume when not in use!