

■ FUNCTION

1. General

The wireless door lock remote control system has following functions:

Function	Outline
All Doors Lock	Pressing the LOCK button of the transmitter lock all doors.
All Doors Unlock* (2-step unlock)	Pressing the UNLOCK button of the transmitter once unlocks the driver's door, and pressing it again within 3 seconds unlocks all doors.
Trunk Opener*	Keeping the TRUNK button of the transmitter pressed longer about 0.6 seconds opens the trunk lid.
Answer Back*	● The hazard light flashes once when locking, and flashes twice when unlocking, to inform that the operation has been completed. ● The wireless door lock buzzer sounds once when locking, and sounds twice when unlocking, to inform that the operation has been completed.
Panic Alarm	Keeping the PANIC button of the transmitter pressed longer that about 1 seconds causes the following alarms to activate. ● Sounds the horn and security horn. ● Flashes the hazard warning lights head lights, and taillights. ● Illuminates the interior light.
Automatic Lock*	If none of the doors are opened within 60 seconds of being unlocked by the wireless door lock remote control, all the doors will be locked again automatically.
Door Ajar Warning*	If any door is open or ajar, pressing the LOCK button of the transmitter will cause the wireless door lock buzzer to sound for about 10 seconds.
Repeat	If a door is not locked in response to the locking operation of the transmitter, the integration relay will output a lock signal after the unlock operation.
Illuminated Entry*	When all the doors are locked, pressing the UNLOCK button causes the interior lights to illuminate simultaneously with the unlock operation.
Transmitter Recognition Code Registration Function	Enables the registering (writing or storing) of 6 types of transmitter recognition codes in the EEPROM that is contained in the main body ECU.

*: The setting function can be changed using the customized body electronics system. For details, refer to Customized Body Electrical System section on [page BE-13](#).

2. Transmitter Recognition Code Registration Function

The table below shows the 6 special code ID registration function modes through which up to 6 different codes can be registered. The codes are electrically registered (written to and stored) in the EEPROM. For details of the recognition code registration procedure, refer to the 2007 Camry Repair Manual (Pub. No. RM0250U).

Mode	Function
Rewrite Mode	Erases all previously registered codes and registers only the newly received codes. This mode is used whenever a transmitter or the main body ECU is replaced.
Add Mode	Adds a newly received code while preserving any previously registered codes. This mode is used when adding a new transmitter. If the number of codes exceeds 6, the oldest registered code is erased first.
Confirm Mode	Confirms how many codes are currently registered. When adding a new code, this mode is used to check how many codes already exist.
Prohibit Mode	To delete all the registered codes and to prohibit the wireless door lock function. This mode is used when the transmitter is lost.