

■ FUNCTION

The theft deterrent system has the following function:

Function	Outline
Alarm	When the theft deterrent system is enters the alarm state, the warning items (interior light, headlights, taillights, hazard warning lights and security horn) are operated for approximately 60 seconds.
Vehicle Horn Alarm	When the theft deterrent system is enters the alarm state, the vehicle horn is operated for approximately 60 seconds.
Alarm Indicator	When the state of the theft deterrent system enters the armed preparation or alarm state, the security indicator light is illuminated to inform the user. This indicator is also the engine immobilizer indicator, it blinks when the engine immobilizer is in an engaged state.
Forced Door Lock	The main body ECU transmits a door lock signal to all the doors when all the following conditions are satisfied. ● The theft deterrent system is in the alarm state. ● There is no key inserted in the ignition key cylinder.*¹ ● Key is not in the actuation area.*² ● One of the front doors has been unlocked. The function stops when one of the following conditions is met. ● All doors are locked. (lock function of door lock or transmitter is operated). ● The warning ends after approximately 60 seconds. ● The ignition key is inserted in the ignition key cylinder.*¹ ● Key is in the actuation area.*²
Alarm Memory	In order to inform the user that the theft deterrent system had entered the alarm state, the main body ECU will illuminate the taillights for 2 seconds when the system is switched to the disarmed state.
Panic Control	When the PANIC button of the transmitter or key is pressed, the main body ECU operates the alarm function.
Passive Mode	When the user forgets to lock the doors, the theft deterrent system operates to lock them. (When the user closes all the doors, the theft deterrent system operates to lock all the doors after a delay.)

*¹: Models without smart key system

*²: Models with smart key system