

■ CUSTOMIZED BODY ELECTRONICS SYSTEM

A hand-held tester can be used to customize the system settings.

System	Hand-Held Tester Display Content	Contents	Default Setting	Available Setting
Wireless Door Lock	TRUNK LID OPER (Trunk lid open function type)	To change the operation method of opening the trunk by the transmitter.	0.8s PR	1 TIME/ 2 TIMES /0.8s PR /OFF
	WIRELESS OPER (Wireless door lock control function)	Function to turn ON/OFF of the wireless door lock.	ON	ON/OFF
	HAZARD ANS BACK (Hazard answer back of the wireless)	Function to turn ON/OFF of the hazard answer back of the wireless door lock.	ON	ON/OFF
	WIRLS BUZZ RESP (Wireless buzzer response)	Function to turn ON/OFF of the wireless buzzer response function.	ON	ON/OFF
	OPEN DOOR WARN (Open Door Warning)	Function to make the buzzer sound for 10 seconds if the door is open when locking with the wireless door lock.	ON	ON/OFF
	AUTO LOCK DELAY (Auto lock time)	Function to change the time until re-locking after unlocking with the wireless door lock.	60 sec	30 sec /60 sec
	UNLOCK/2 OPER (2 times operation wireless unlock)	Function to unlock the driver's door by pressing the unlock button of the transmitter once and to unlock all the doors by pressing it twice. In the OFF setting, pressing one time makes all the doors unlocked.	ON	ON/OFF
	ALARM FUNCTION*1 (Panic function)	Function to operate the theft deterrent system by keeping pressing the lock button of the transmitter for 1.5 seconds. If there is the panic button, press the panic button instead of the lock button.	ON	ON/OFF
Door Lock	UNLK/KEY TWICE (Unlock w/2 times D key operation)	Function to unlock only the driver's door by doing the key operation once and to unlock all the doors by doing it twice. In the OFF setting, operating the key "UNLOCK" once makes all the doors unlocked.	ON	ON/OFF
	AUTO LOCK/SHIFT (Automatic door lock linked shift)	Function to lock the doors when shifting the lever from P range to the range other than P.	ON	ON/OFF
	AUTO LOCK (Auto lock)	Function to lock the doors when the vehicle reaches a certain speed.	OFF	ON/OFF
	AUTO UNLK/SHIFT (Automatic door unlock linked shift)	Function to unlock the doors by shifting the lever to P range from other than P range when power source/ignition switch is ON.	ON	ON/OFF
	ALL UNLK/OPN-CL (All Unlock w/D door open-close)	Function to unlock all the other doors when opening the driver's door within 10 seconds after turning the power source/ignition switch to OFF from ON.	OFF	ON/OFF

(Continued)

System	Hand-Held Tester Display Content	Contents	Default Setting	Available Setting
Illuminated Entry	LIGHTING TIME (Lighting time)	Function to change the lighting time after closing the door. (It will quickly fade out in the event the power source/ignition switch is turned ON.)	15 sec	7.5 sec/ 15 sec/ 30 sec
	I/L ON/ACC OFF (I/L when ACC OFF)	Function to light up the interior lights when power source/ignition switch is turned from “ACC” to “OFF”.	ON	ON/OFF
	I/L ON/UNLOCK (I/L ON W/Door Key Unlock)	Function to light up the interior lights when unlocking with the door key cylinder.	ON	ON/OFF
Warning	KEY LOW-BATT WRN*2 (Warn when the key battery becomes weak)	Setting a warning function for the first time when a key battery becomes weak.	ON	ON/OFF
	SEAT BELT WARN (Seat belt warning buzzer)	Function to change the seat-belt warning buzzer.	D/P ON	D/P ON/ D ON/ P ON/ D/P OFF
Light Control	LIGHT OFF DELAY (Light auto OFF delay)	Function to keep on lighting the headlight for a certain period of time after closing all the doors with the power source/ignition switch turned OFF from ON under the condition that the light control switch is at HEAD or AUTO with the headlight ON.	30 sec	OFF/ 30 sec/ 60 sec/ 90 sec
	SENSITIVITY (Turn ON luminous intensity)	To adjust the sensitivity of the lighting illumination.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
	DISP EX ON SEN (Display extinction luminous intensity)	To change the brightness of lowering the lights such as the indicator light of the combination meter, A/C indicator light, clock.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
	DISP EX OFF SEN (Display extinction release luminous intensity)	To change the brightness of canceling the lowering the lights such as the indicator light of the combination meter, A/C indicator light, clock.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
	DRL FUNCTION*3 (DRL function)	ON/OFF of the DRL function.	ON	ON/OFF

(Continued)

System	Hand-Held Tester Display Content	Contents	Default Setting	Available Setting
A/C*4	SET TEMP SHIFT (Set Temperature Shift)	To control with the shifted temperature against the display temperature.	NORMAL	+2°C/ +1°C/ NORMAL/ -1°C/ -2°C
	AIR INLET MODE (Air Inlet Mode)	In case of turning the A/C ON when you desire to make the compartment cool down quickly, this is the function to change the mode automatically to RECIRCULATED mode.	AUTO	MANU- AL/ AUTO
	COMPRESSOR MODE (Compressor Mode)	Function to turn the A/C ON automatically by pressing the AUTO button when the blower is ON and the A/C is OFF.	AUTO	MANU- AL/ AUTO
	COMPRS/DEF OPER (Compressor/Air Inlet DEF operation)	Function to turn the A/C ON automatically linking with the FRONT DEF button when A/C OFF.	LINK	NOR- MAL/ LINK
	EVAP CTRL (Evaporator Control)	Function to set the evaporator control to the AUTOMATIC position (AUTO) to save power or to the coldest position (MANUAL) to dehumidify the air and to prevent the windows fogging up.	AUTO	MANU- AL/ AUTO
	FOOT/DEF MODE (Foot/DEF auto mode)	Function to turn the air flow from FOOT/DEF ON automatically when AUTO MODE is ON.	ON	OFF/ON
	AUTO BLOW UP (Foot/DEF automatic blow up function)	Function to switch the blower level automatically when the defroster is ON.	ON	OFF/ON
	AMBIENT TMP SFT (Ambient Temperature Shift)	To control with the shifted ambient temperature against the display ambient temperature.	NORMAL	+3°C/ +2°C/ +1°C/ NORMAL/ -1°C/ -2°C/ -3°C
Smart Key*2	WARNING 7 (Select IG ON available area)	Function to choose the available area for the key to start E/G and cancel the Steering Lock.	ALL	FRONT/ ALL
	PARK WAIT TIME (Wait time to permit opening door after locking)	Setting a wait time to permit opening a door after it being locked.	3.0 sec	1.0 sec/ 2.0 sec/ 3.0 sec/ 5.5 sec
	TRUNK OPEN MODE (Trunk open mode when vehicle is locked)	Function to permit opening a trunk with the key.	ON	ON/OFF

*1: Only for models without smart key system

*2: Only for models with smart key system

*3: Except Canadian package models

*4: Only for models with automatic air conditioning