

CNC Master Reference

Code	Name	Purpose
G00	Rapid Position	Rapid traverse movement
G01	Linear Interp	Linear cut at feed rate
G02	CW Arc	Clockwise circular motion

Code	Name	Purpose
G03	CCW Arc	Counter-clockwise circular motion
G04	Dwell	Pauses tool movement
G17	XY Plane	Selects XY working plane
G18	XZ Plane	Selects XZ working plane
G19	YZ Plane	Selects YZ working plane
G20	Imperial	Sets units to inches
G21	Metric	Sets units to mm

Code	Name	Purpose
G28	Return Home	Returns axes to machine zero
G40	Comp Cancel	Cancels tool radius comp
G41	Comp Left	Cutter compensation left
G42	Comp Right	Cutter compensation right
G43	Length Comp	Tool length offset active
G54	Work Offset	Work coordinate system 1
G80	Cycle Cancel	Cancels canned cycles

Code	Name	Purpose
G81	Drill Cycle	Standard drilling cycle
G83	Peck Drill	Deep hole peck drilling
G90	Absolute	Absolute coordinate mode
G91	Incremental	Incremental distance mode
G98/ G99	Retract	Canned cycle retract plane
M00	Prog Stop	Halts program execution
M01	Opt Stop	Stops if enabled

Code	Name	Purpose
M03	Spindle CW	Spindle rotates forward
M04	Spindle CCW	Spindle rotates reverse
M05	Spindle Stop	Stops spindle rotation
M06	Tool Change	Initiates tool change
M08	Coolant ON	Turns on flood coolant
M09	Coolant OFF	Turns off coolant
M30	Prog End	Rewinds program

Code	Name	Purpose
M98	Sub-call	Calls subprogram
M99	Sub-return	Returns from subprogram