
# Assembly programming

exception and exception handler

wangw6@sustc.edu.cn



# **Topics**

- Exception vs Interruption
- Common exception
- Exception handler
  - Register in coprocessor 0
  - trap instruction
- Lab assignment

# Exception vs Interruption

- An exception is an event that disrupts the normal flow of the execution of your code
  - When an exception occurs, the CPU will figure out what is wrong by checking its status, see if it can be corrected and then continue the execution of the normal code like nothing happened.
  - E.g. Accessing to the 0x0 address in user mode will trigger an exception
- An interruption is an event caused by a device which is external to the CPU
  - E.g. 'syscall' is an interruption.

# Common exception

The following exceptions are the most common to the main processor:

- Address error exceptions, which occur when the machine references a data item that is not on its proper memory alignment or when an address is invalid for the executing process.
- Overflow exceptions, which occur when arithmetic operations compute signed values and the destination lacks the precision to store the result.
- Bus exceptions, which occur when an address is invalid for the executing process.
- Divide-by-zero exceptions, which occur when a divisor is zero

# Bad address exception

```
.text
print_string:
addi $sp,$sp,-4
sw $v0,($sp)
```

li \$v0,4 syscall

lw \$v0,(\$sp)
addi \$sp,\$sp,4

jr \$ra

Registers Coproc 1 Coproc 0							
Name	Number	Value					
\$8 (vaddr)	8	0x000000x0					
\$12 (status)	12	0x0000ff13					
\$13 (cause)	13	0x0000001					
\$14 (epc)	14	0x0040000c					

Те	xt Segment				<b>-</b>	⊿"
Bkpt	Address	Code	Basic		Source	
	0x00400000	0x23bdfffc	addi \$29, \$29, 0xfffffffc	5:	addi \$sp, \$sp, -4	•
	0x00400004	0xafa20000	sw \$2,0x00000000(\$29)	6:	sw \$v0, (\$sp)	
	0x00400008	0x24020004	addiu \$2,\$0,0x00000004	9:	li \$v0,4	
	0x0040000c	0x0000000c	syscall	10:	syscall	1
	0x00400010	0x8fa20000	lw \$2,0x00000000(\$29)	12:	lw \$v0,(\$sp)	
	0x00400014	0x23bd0004	addi \$29, \$29, 0x00000004	13:	addi \$sp, \$sp, 4	
	0x00400018	0x201fffff	addi \$31,\$0,0xffffffff	15:	addi \$ra, \$zero, Oxffffffff	
	0x0040001c	0x03e00008	jr \$31	16:	jr \$ra	

\$a0's default value is 0x00000000, which is not allowed to access in user mode

Runtime exception at 0x0040000c: address out of range 0x00000000

## Bad address exception continued

```
.data
         str: .asciiz "hello"
.text
print_string:
         addi $sp,$sp,-4
         sw $v0,($sp)
         la $a0,str
         li $v0,4
         syscall
         lw $v0,($sp)
         addi $sp,$sp,4
         addi $ra,$zero,0xffffffff
         jr $ra
```

\$ra	31	0xffffffff
pc		0xffffffff

Registers Coproc 1	Coproc 0	
Name	Number	Value
\$8 (vaddr)	8	0xffffffff
\$12 (status)	12	0x0000ff13
\$13 (cause)	13	0x00000010
\$14 (epc)	14	0xffffffff

Error in : invalid program counter value: 0xffffffff

# Bad address exception continued

```
.include "../macro_print_str.asm"
.data
                   .asciiz "data is:"
         str:
                   .byte 1:10
         bs:
                   .word 2:10
         WS:
.text
         print_string("data is:")
         add $t0,$zero,$zero
         addi $t1,$zero,10
loop_out:
         lw $a0,bs
         li $v0,1
         syscall
         add $t0,$t0,1
         bne $t0,$t1,loop_out
         end
```

Which one will trigger the exception?

Registers Coproc 1	Coproc 0	
Name	Number	Value
\$8 (vaddr)	8	0x10010009
\$12 (status)	12	0x0000ff13
\$13 (cause)	13	0x00000010
\$14 (epc)	14	0x0040002c

.include "../macro\_print\_str.asm" .data

str: .asciiz "data is:"

bs: .byte 1:10

ws: .word 2:10

.text

print\_string("data is:")
add \$t0,\$zero,\$zero
addi \$t1,\$zero,10

loop\_out:

Iw \$a0,ws
Ii \$v0,1
syscall
add \$t0,\$t0,1
bne \$t0,\$t1,loop out

end

# Arithmetic exception

Will the 'addu' trigger an exception?

How about 'sub', 'div'?

How about 'addui \$a0, \$t0, -1'?

.data

addend1: .word 0x7fffffff addend2: .word 0x7fffffff

.text

print\_string:

lw \$t0,addend1
lw \$t1,addend2
add \$a0,\$t0,\$t1

li \$v0,1 syscall

li \$v0,10 syscall

Registers Coproc 1	Coproc 0	
Name	Number	Value
\$8 (vaddr)	8	0x00000000
\$12 (status)	12	0x0000ff13
\$13 (cause)	13	0x00000030
\$14 (epc)	14	0x00400010

Tex	Text Segment						
Bkpt	Address	Code	Basic		Source		
	0x00400000	0x3c011001	lui \$1,0x00001001	6:	lw \$t0, addend1		
	0x00400004	0x8c280000	lw \$8,0x00000000(\$1)				
	0x00400008	0x3c011001	lui \$1,0x00001001	7:	lw \$t1, addend2		
	0x0040000c	0x8c290004	lw \$9,0x0000004(\$1)				
	0x00400010	0x01092020	add \$4, \$8, \$9	8:	add \$a0,\$t0,\$t1		
	0x00400014	0x24020001	addiu \$2,\$0,0x00000001	10:	li \$v0,1		
	0x00400018	0x0000000c	syscall	11:	syscall		
	0x0040001c	0x2402000a	addiu \$2,\$0,0x0000000a	13:	li \$v0,10		
	0x00400020	0x0000000c	syscall	14:	syscall		

Runtime exception at 0x00400010: arithmetic overflow

# How MIPS acts when taking an exception?

- 1. It sets up the **EPC** to point to the restart location.
- 2. CPU changes into kernel mode and disables the interrupts (BNN:MIPS does this by setting EXL bit of SR register)
- 3. Set up **the Cause register** to indicate which is wrong. So that software can tell the reason for the exception. If it is for **address exception**, for example, TLB miss and so on, the **BadVaddr register** is also set.
- 4. CPU starts fetching instructions from the exception entry point and then goes to the **exception handler.**

Up to MIPS III, we use the eret instruction to return to the original location before falling into the exception. Note that **eret** behavior is: clear the SR[EXL] bit and returns control to the adress stored in EPC.

# The register in Coprocessor 0

Registers Coproc 1	Coproc 0	
Name	Number	Value
\$8 (vaddr)	8	0x00000000
\$12 (status)	12	0x0000ff13
\$13 (cause)	13	0x00000030
\$14 (epc)	14	0x00400010

Register name	Register number	<b>Usage</b>
BadVAddr	8	memory address at which an offending memory reference occurred
Status	12	interrupt mask and enable bits
Cause	13	exception type and pending interrupt bits
EPC	14	address of instruction that caused exception

## Related instructions

### conditional trap

• teq, tne,...

#### break

Terminate program execution with exception

#### eret

 Returns from an interrupt, exception or error trap. Similar to a branch or jump instruction, eret executes the next instruction before taking effect. Use this on R4000 processor machines in place of rfe.

## Demo

How to trigger the trap? What's the output if the trap is triggered? Will the '\ndata over' be printed out or not?

.data	dmsg: .asciiz "\ndata over"	.ktext	0x80000180 move \$k0,\$v0
.text			move \$k1,\$a0 la \$a0,msg
main:	li \$v0,1		li \$v0,4 syscall
	syscall		70 0 10 C C C C C
	teqi \$v0,0		move \$v0,\$k0 move \$a0,\$k1
	la \$a0,dmsg		mfc0 \$k0,\$14
	li \$v0,4		addi \$k0,\$k0,4
	syscall		mtc0 \$k0,\$14
	li \$v0,10	.kdata	eret
	syscall	msg:	.asciiz "\nTrap generated"

# Lab Assignment (23:55 April 2, Tuesday)

- Implement an arithmetic calculator which can conduct addition and multiplication on two integers, which is input by the user.
  - 1. In the following situation an exception will be triggered:
    - 1. the addition overflow
    - 2. the multiplication result exceeds the width of a word
  - 2. The exception handler should do the following things:
    - 1. stop the program running
    - 2. output prompt information, including "runtime exception at 0x\_(the address of the instruction which triggered the exception)", and the cause of the exception (the sum is overflow, the product is bigger than the Max value of a word)
    - 3. exit the program

# Sample Result

Welcome to use the simple arithmetic calculator on unsigned number:

Please input operator: +

Please input addend: 4294967295

Please input augend: 4294967295 Runtime exception at 0x4000....,the sum is overflow

Welcome to use the simple arithmetic calculator on unsigned number:

Please input operator: + Please input addend: 15 Please input augend: 20

The sum of 15 and 20 is: 35

Welcome to use the simple arithmetic calculator on unsigned number:

Please input operator: \*

Please input multiplicand: 4294967295

Please input multiplier: 2

Runtime exception at 0x4000..., the product is bigger than the Max value of a word

Welcome to use the simple arithmetic calculator on unsigned number:

Please input operator: '

Please input multiplicand: 15

Please input multiplier: 2

The product of 15 with 2 is: 30

# Tips: usage of '.align'

.data

str: .asciiz "data is:"

bs: .byte 1:10

ws: .word 2:10


.data

str: .asciiz "data is:"

.align 2

bs: .byte 1:10

ws: .word 2:10



□ Labels				
Label	Address A			
align_exception	on.asm			
loop_out	0x00400028			
str	0x10010000			
bs	0x10010009			
ws	0x10010014			
pstr_M0	0x1001003c			
	_			
✓ Data ✓ Text				

□ Data Segment □ □ □ □ □								
Address	Value (+0)	Value (+4)	Value (+8)	Value (+c)	Value (+10)	Value (+14)	Value (+18)	Value (+1c)
0x10010000	0x61746164	0x3a736920	0x00000000	0x01010101	0x01010101	0x00000101	0x00000002	0x00000002
0x10010020	0x00000002	0x00000002	0x00000002	0x00000002	0x00000002	0x00000002	0x00000002	0x00000002

Data Segment								
Address	Value (+0)	Value (+4)	Value (+8)	Value (+c)	Value (+10)	Value (+14)	Value (+18)	Value (+1c)
0x10010000	0x61746164	0x3a736920	0x01010100	0x01010101	0x00010101	0x00000002	0x00000002	0x00000002
0x10010020	0x00000002	0x00000002	0x00000002	0x00000002	0x00000002	0x00000002	0x00000002	0x61746164

# Tips

**.align** Align the next datum on a 2 <sup>n</sup> byte boundary. For example, .align 2 aligns the next value on a word boundary. .align 0 turns off automatic alignment of .half, .word, .float, and .double directives until the next .data or .kdata directive.

**.kdata** subsequent items are stored in the kernel data segment, If the optional argument *addr* is present, subsequent items are stored starting at address *addr*.

**.ktext** subsequent items are stored in the kernel text segment, In SPIM, these items may only be instructions or words. If the optional argument *addr* is present, subsequent items are stored starting at address *addr*.