SCANNED MAINTENANCE GUIDE

Replace the oil every 5,000 miles.

Check the filter before a long journey.