PASHUPATI

Tuning Guide

What the parameters do, and how to tune a Genisom L1W for a site

Version 2.0 · 2026-10-29

For the technician who sets up and tunes a Pashupati robot. You need an SSH shell on the robot computer and some ROS 2 basics.

Revision history

Version	Date	Changes
1.0	2026-10-16	First version: Pashupati with the Genisom L1W
2.0	2026-10-29	Pashupati 3 on Dharma 0.2: robot profile, stack file, sites, new parameter names

Operating the robot is described in the Pashupati User Manual. Pashupati 3 runs on the Dharma 0.2 stack: every Dharma parameter is typed (unit, range, description) and listed by `ros2 param describe`. The parameter reference at the end of this guide is generated from Pashupati's parameter files. Units: m, s, m/s, rad/s, deg; 0-1 means a fraction.

Contents

1 How tuning works 5

1.1 Where a value comes from 5
1.2 Change a value for good 5
1.3 Try a value live 6
1.4 What the handheld changes 7
1.5 Tuning a new site, step by step 7
1.6 Work safely 8

2 The Genisom L1W 9

2.1 The robot profile 9
2.2 Speed limits 10
2.3 Stick channels and speed scaling 10

3 Protective field 12

3.1 How it works 12
3.2 Measure the braking 13
3.3 Test it 13

4 The patrol 15

4.1 Speed and motion 15
4.2 Stop points 15
4.3 Leaving and joining the route 16

5 Obstacles 17

5.1 Path shift 17
5.2 What the LiDAR sees 17

6 Sites, maps and localization 19

6.1 Sites 19
6.2 AprilTags 19
6.3 Odometry 20

7 Inspection and people 21

7.1 Pace and queue 21
7.2 Model and memory 22
7.3 Finding types 22
7.4 People counting 23

8 Handheld, camera, video, NETRA and health 24

8.1 Handheld link 24

8.2 Camera source 24
8.3 Video 25
8.4 NETRA uplink 25
8.5 Health monitor 25

9 The env file 27

10 Symptoms and fixes 29

11 Site file for the Genisom L1W 31

12 Parameter reference 32

12.1 pashupati 32
12.2 pashupati 32
12.3 pashupati_bridge 36
12.4 pashupati_inspection 37
12.5 pashupati_fleet 38

1 How tuning works

1.1 Where a value comes from

Every node starts with the defaults of its package. Pashupati then applies, in this order (later wins):

Layer	Where	Changed by
Robot profile	`src/pashupati/config/robot.yaml` (or `ROBOT_PARAMS`)	a Pashupati or robot update
Stack file	`src/pashupati/config/stack.yaml`	a Pashupati update
Site file	`/etc/pashupati/site.yaml` (`SITE_CONFIG`)	you, for this robot and site
Launch	non-empty values of `/etc/pashupati/pashupati.env`	you (chapter 9)
Live changes	in the running node	handheld, `ros2 param set`, RViz; lost at a restart, except the handheld's inspection and people settings

The **robot profile** (`robot.*`) is the one description of the robot that every node reads: kinematics, base height, footprint, speed limits and braking (chapter 2). The **stack file** holds only what Pashupati changes from the Dharma defaults; most values tuned on the robot in Pashupati 1 and 2 became the Dharma defaults.

Never change the repository on a robot: the next `git pull` conflicts with your change. Put every change in the site file. The robot driver (`l1w_driver_node`) is not a Pashupati node; its settings live in the robot package (section 2.3).

1.2 Change a value for good

1. Open the site file: `sudo nano /etc/pashupati/site.yaml`.

2. Find the node's section, or add one like the example below. Indent with spaces, two per level, never with tabs.
3. Restart the stack: `sudo systemctl restart pashupati`.
4. Check the start of the log for warnings: `journalctl -u pashupati -n 100 | grep -i warn`.

```
path_follower_node:
  ros__parameters:
    speed:
      cruise: 0.35
```

A misspelt **node** name is reported at start (*no node is called "..."*). A misspelt **parameter** is reported by the node (*undeclared parameter*), and a value out of its range stops the node with the reason. A file that is not valid YAML stops the start, so the robot never runs on defaults by accident.

1.3 Try a value live

```
pashu                                                    # ROS shell of
the stack
ros2 param describe /path_follower_node speed.cruise     # unit, range,
live or read-only
ros2 param set /path_follower_node speed.cruise 0.3
ros2 param dump /path_follower_node                      # every value in
use
```

Safety values (limits, margins, timeouts) are **read-only at runtime**: `ros2 param set` refuses them; change them in the site file and restart. The **Tuning** panel of RViz (`dharma_rviz`) edits the live parameters of any node; **Save YAML** writes them for the site file. RViz runs on a laptop with ROS 2 Humble on the robot's network: set `ROS_LOCALHOST_ONLY=0` in the env file, restart, and use the robot's `ROS_DOMAIN_ID` and `RMW_IMPLEMENTATION` on the laptop.

> **SET IT BACK**
>
> With `ROS_LOCALHOST_ONLY=0` anyone on the robot's network can send motion commands to the robot. Set it back to `1` and restart when you are done.

1.4 What the handheld changes

On the handheld	Parameter	After a restart
Patrol speed slider	`path_follower_node` `speed.cruise`, from `teleop_udp_node` `patrol_speed_min` to `patrol_speed_max` (and never above `robot.limits.max_vx`)	the site file value
Inspect the floor	`anomaly_detector_node` `enabled`	kept
Pace: Continuous, Interval, Stop points	`interval_sec`: 0, the interval, -1	kept
Model	`model`	kept
Finding types	`categories`, `alarm_categories`, `category_descriptions`	kept
Count people	`person_detector_node` `enabled`	kept
Speed 1, 2, 3	30, 60, 100 % of `teleop_udp_node` `max_vx`, `max_vy`, `max_wz` (capped by `robot.limits`)	a handheld setting
Inspection at a stop point	the dwell time stored in the route with each **Point**	in the route

Kept values are stored in `~/.pashupati/inspection.json` and `~/.pashupati/people.json` and **win over the site file**. To go back to the site file's inspection settings, stop the service, delete `inspection.json`, and start it again.

1.5 Tuning a new site, step by step

1. **The robot, once:** the robot profile and the stick channels (chapter 2).
2. **Braking:** measure it and test the protective field (chapter 3).
3. **The site:** map it, print, place and record the AprilTags (chapter 6).
4. **First route:** teach a short route and patrol it at 0.3 m/s (chapter 4).
5. **Obstacles:** a cardboard box on the route, then a person walking past (chapter 5).
6. **Full speed:** raise the patrol speed step by step, one full lap per step.

7. **Inspection and people:** pace, model, finding types, people counting (chapter 7).
8. **Save:** copy every value that works into the site file, restart, drive one more lap.

Try a change on the simulator first (`ros2 launch pashupati sim.launch.py rviz:=true`): it runs the same stack with the same files.

1.6 Work safely

- Tune in a closed area first, never in a crowd.
- Keep the ZSBot remote in reach, and someone on the handheld's STOP.
- Change one thing at a time. Write down the old and the new value.
- Start low: speeds and accelerations below what you need, then raise them step by step.
- Repeat the protective field test (section 3.3) after every change to the robot profile.

2 The Genisom L1W

2.1 The robot profile

`src/pashupati/config/robot.yaml` describes a ~0.80 × 0.56 m quadruped, field-tested on the L1W. A robot package can ship its own profile (`ROBOT_PARAMS`); to change one value for one robot, override it in the site file under `/**:` (every node reads it).

Parameter	L1W	What it is
`robot.kinematics`	omni	the L1W strafes; `diff` for a robot that cannot (then `max_vy` 0)
`robot.base_height`	0.35	m, `base_link` above the floor when standing (the floor for the LiDAR and for placing people)
`robot.footprint.front`, `.rear`, `.half_width`	0.40, 0.40, 0.28	m from `base_link` to the body's edges, legs included: the protective field, the planner, path shift and the LiDAR's self filter all use it
`robot.limits.max_vx`, `max_vy`, `max_wz`	1.0, 0.5, 1.5	nothing may command more, in AUTO or REMOTE
`robot.limits.max_accel`, `max_yaw_accel`	0.5, 1.5	m/s^2, rad/s^2
`robot.limits.max_decel`	0.6	m/s^2, braking the robot reliably achieves: **measure it** (section 3.2)
`robot.limits.reaction_time`	0.25	s, from the command to the robot actually braking

To measure the height of `base_link`, stand the robot on a flat floor, measure the height of the LiDAR above the floor, and subtract the LiDAR's height in the body: `ros2 run tf2_ros tf2_echo base_link livox_frame` (the z value). Measure the footprint again when the robot carries a payload or a cover that sticks out.

```
/**: # in the site file: a heavier L1W with a cover
  ros__parameters:
    robot:
      footprint: { front: 0.45, rear: 0.40, half_width: 0.30 }
      limits: { max_decel: 0.5 }
```

2.2 Speed limits

Parameter	L1W	Limits
`robot.limits.max_vx`, `max_vy`, `max_wz`	1.0, 0.5, 1.5	every command: the control mux clamps to them
`teleop_udp_node` `max_vx`, `max_vy`, `max_wz`	1.0, 0.5, 1.5	the handheld at speed level 3 (never above the profile)
`path_follower_node` `speed.cruise`	0.4	the patrol speed (the handheld's slider changes it)
`l1w_driver_node` `stick_max_vx`, `stick_max_vy`, `stick_max_wz`	1.0, 0.5, 1.5	the command that means a full stick (next section)

2.3 Stick channels and speed scaling

The L1W takes motion as joystick values, like its own remote. `l1w_driver_node` turns each speed command into a stick position: a command of `stick_max_vx` is a full stick forward. Its settings are in the robot package, `src/xtras/robots/genisom_l1w_ros2/l1w_driver/config/l1w_driver.yaml`. Edit them there and restart the service; they are not live.

Parameter	L1W	Meaning
`stick_max_vx`, `stick_max_vy`, `stick_max_wz`	1.0, 0.5, 1.5	speed that maps to full stick deflection
`stick_yaw_axis`, `stick_lateral_axis`	2, 1	stick channels for turning and walking sideways
`stick_invert_yaw`, `stick_invert_lateral`	false	true when the robot turns or walks sideways the wrong way

Parameter	L1W	Meaning
`cmd_timeout`	0.5	s; without a new command the stick returns to zero
`auto_control_right`	true	take motion control from the ZSBot remote when the driver connects

Check the directions once (REMOTE, speed level 1): left stick to the left must walk the robot to its left; right stick to the left must turn it to the left. If one is wrong, set its `stick_invert_*` to true.

Check the speed scale: the speed the L1W reaches at full stick depends on its speed gear (*Slow*, *Normal*, *Fast speed* in the robot actions). Patrol a straight route and compare the patrol speed with the measured speed: `ros2 topic echo /l1w/odom --field twist.twist.linear.x`. If the robot is slower or faster, set `stick_max_vx` to its value × measured speed ÷ patrol speed, and scale `stick_max_vy` and `stick_max_wz` the same way. Always patrol in the gear you checked.

3 Protective field

3.1 How it works

`control_mux_node` is the only node that commands the robot. It limits every command to a speed at which the robot can still stop a margin short of the nearest obstacle in the path it is about to sweep, in every direction (the LiDAR's 360° safety scan), from the robot profile's `max_decel` and `reaction_time` and an assumed walking speed of a person toward the robot. The Dharma guide *Safety* gives the formula.

The field always works in AUTO. In REMOTE the operator watches the robot: Pashupati drives REMOTE without the field (`field.in_remote: false` , a field-tested decision); the speed limits and the e-stop still apply. Without a fresh scan the robot does not drive itself at all.

`control_mux_node` parameter	Default	What it does
`field.in_remote`	false	true: limit REMOTE too (with `field.remote_margin`), e.g. for operators new to the robot
`field.margin`	0.15	m, gap left to the obstacle in AUTO
`field.remote_margin`	0.10	m, the same in REMOTE
`field.lateral_margin`	0.10	m, extra width of the swept path on each side
`field.human_speed`	0.5	m/s, a person walking toward the robot
`field.min_speed`	0.02	m/s, a slower allowed speed stops instead
`field.remote_degraded_speed`	0.15	m/s, the REMOTE cap while the scan is stale or blind
`field.scan_timeout_sec`	0.5	s; an older scan stops AUTO and caps REMOTE
`use_health_limit`	true	scale every command by the health monitor's speed limit (section 8.5)

`control_mux_node` parameter	Default	What it does
`remote_sources`	[handheld, dashboard]	who may drive in REMOTE (`control/remote/<source>/cmd_vel`)
`remote_timeout_sec` , `nav_timeout_sec`	0.3, 0.5	s; a silent source gets zero speed

A lower `max_decel` , a longer `reaction_time` or a bigger margin make the robot slow down earlier and stop further from obstacles. Too low, and it crawls in narrow aisles.

3.2 Measure the braking

1. Teach a straight route of at least 8 m, with free space beyond it.
2. Set the patrol speed on the handheld to the fastest you will patrol at, for example 0.6.
3. Put a tape mark on the floor in the middle of the route.
4. Start the patrol. Press **STOP** when the front of the robot passes the mark.
5. Measure the distance *d* from the mark to the front of the stopped robot.
6. max*decel* = $speed^2 \div (2 \times (_d - \text{speed} \times 0.25))$.
7. Repeat three times. Use the smallest result as `robot.limits.max_decel` .

Your own reaction is part of *d*, so the result errs on the safe side. At 0.6 m/s:

Stopping distance *d*	0.40 m	0.50 m	0.60 m	0.80 m	1.00 m
`robot.limits.max_decel`	0.72	0.51	0.40	0.28	0.21

Measure on every new kind of floor: a polished floor brakes worse than a rough one.

3.3 Test it

1. In the site file set `control_mux_node` `field.in_remote: true` and restart.
2. Put a cardboard box in an open area.
3. In REMOTE at speed level 1, drive straight at the box. The robot must slow down and stop about `field.remote_margin` (10 cm) before it. Try level 2, then from the side and backwards.
4. Set `field.in_remote` back to false (or keep it on) and restart.

If the robot gets closer than the margin, lower `robot.limits.max_decel` or raise `robot.limits.reaction_time`. Never test with a person in front of the robot.

4 The patrol

4.1 Speed and motion

All in `path_follower_node`; the speed values are live. *Pashupati* is the value with the stack file (the Dharma default where Pashupati sets nothing).

Parameter	Pashupati	What it does · when to change
`speed.cruise`	0.4	m/s, the patrol speed; keep it low in crowds
`speed.min_speed`	0.1	m/s, the slowest the speed profile goes
`speed.lateral_accel`	0.3	m/s^2, the speed in curves: lower is slower in bends
`speed.accel`, `speed.decel`	0.5, 0.3	m/s^2, starting and braking into stops (Pashupati: 0.5 to start)
`speed.approach_speed`	0.15	m/s when arriving at stop points and the route end
`speed.smoothing`	0.4	0-1, lower is smoother and slower to react
`controller`	holonomic	x, y and yaw together; strafes, keeps its heading along the route

4.2 Stop points

At each stop point the robot converges (`approach.*`), calls the inspection hook, waits for its answer, dwells for the route's dwell time, optionally backs up, and walks on.

Parameter	Pashupati	What it does
`approach.position_tolerance`, `approach.yaw_tolerance_deg`	0.05, 3.0	m, deg: how close the robot converges
`approach.min_speed`	0.04	m/s, beats the robot's joystick deadband
`approach.timeout_sec`	20	s, then it dwells where it is

Parameter	Pashupati	What it does
`hooks.inspection`	[/anomaly_detector_node/check_now]	services called at each stop; a hook whose node does not run is skipped, so `INSPECTION=false` never blocks the patrol
`hooks.inspection_timeout_sec`	20	s; VLM inference on the Jetson takes a few seconds
`inspection.reverse_distance_m`	0	m; > 0 backs up this far after the inspection (the LiDAR sectors look 360° for it)
`loop_route`	true	a closed route starts its next lap
`low_battery`, `critical_battery`	0.2, 0.1	0-1: below `low_battery` the patrol ends its lap; below `critical_battery` it pauses

4.3 Leaving and joining the route

Parameter	Pashupati	What it does
`join.max_distance`	3.0	m; a robot started beside the route walks onto it from here
`safety.off_path_slow`, `safety.off_path_stop`	0.6, 1.5	m of cross-track error: slow down, stop (*off the route*)
`safety.blocked_timeout_sec`	30	s standing in front of an obstacle before *Blocked* (Dharma: 10)
`require_localization`	true	**Start** is refused until the robot is localized

5 Obstacles

5.1 Path shift

The robot passes an obstacle by sliding sideways, never further than `path_shift.max_offset` from the route, and stops short when there is no gap.

`path_follower_node` parameter	Default	What it does
`avoidance_mode`	path_shift	or a reactive policy of `obstacle_avoidance_node`
`path_shift.max_offset`	0.8	m, furthest from the route
`path_shift.clearance`	0.10	m, gap kept between the robot's side and an obstacle
`path_shift.stop_margin`	0.40	m, stop this far before an obstacle
`path_shift.switch_cost`, `path_shift.switch_margin`	0.5, 0.05	keeps its side around an obstacle

5.2 What the LiDAR sees

`lidar_sector_node` turns the LiDAR into sectors (front, for the avoidance) and the 360° safety scan (for the protective field). The band between `filter.height_min` and `filter.height_max` above the floor (the floor is `robot.base_height` below `base_link`) counts as obstacles; the robot's own footprint, grown by `filter.self_margin`, is ignored.

Parameter	Pashupati	What it does · when to change
`filter.height_min`	0.10	m above the floor; lower sees low objects, too low sees the floor on slopes
`filter.height_max`	1.55	m above the floor (the L1W's top plus margin)
`filter.self_margin`	0.05	m around the footprint: *Slowed* or *Blocked* with nothing around, widen it 2-3 cm

Parameter	Pashupati	What it does · when to change
`front.num_sectors`, `front.fov_deg`	64, 360	the avoidance also sees behind (needed by the back-up after an inspection)

6 Sites, maps and localization

6.1 Sites

A **site** is one place: its occupancy map, its AprilTag poses and its taught routes, in `SITES_DIR/<site>/` (`~/.pashupati/sites`). `SITE` in the env file picks the site at start (empty: the last one). `MODE=teach` maps the site from the start; drive slowly through the whole place in REMOTE, then save the map (`/mapping/save`). Taught routes go to `<site>/routes/`, routes from NETRA to `<site>/netra/`.

6.2 AprilTags

The tag detector (`apriltag`, from dharma_perception) must know every tag on the site's walls; localization uses the tags' frames:

```
apriltag:
  ros__parameters:
    tag:
      ids: [2, 4]
      frames: [base_map, charging_dock]
      sizes: [0.15, 0.15] # MEASURE the printed black square
localization_node:
  ros__parameters:
    tag:
      frames: [base_map, charging_dock]
```

Place tags at about the camera's height along the route, where the robot passes 1-2 m from them. Record them while localized: `/localization/record_tags` (the handheld's **Tags**) averages the visible tags over `tag.record_duration_sec` and writes the site's `tags.json`.

`localization_node` parameter	What it does
`tag.auto_localize`	localize from the first known tag after start-up
`tag.auto_correct`	correct the pose from tags while patrolling

localization_node parameter	What it does
tag.max_distance_m, tag.max_view_angle_deg	tags further away or seen at a steeper angle are ignored
estimator.sigma_xy_per_sqrt_m	how fast the position is assumed to drift between tags

6.3 Odometry

FAST-LIO2 (fastlio_mapping_node) starts once the robot stands still. Pashupati keeps the on-line extrinsic estimation that was field-tested on the L1W (mapping.extrinsic_est_en: true) and lets odometry_gate accept a standing quadruped's lean (max_tilt_deg: 8).

7 Inspection and people

7.1 Pace and queue

`anomaly_detector_node` sends camera images to a vision-language model (Ollama, on the robot) and gets back one finding type or *none*.

Parameter	Default	What it does · when to change
`enabled`	true	live; off also unloads the model from memory and answers the stop-point hook at once
`interval_sec`	0	live: 0 continuous, > 0 one image every N s, < 0 only at stop points
`queue_max`	50	interval pace: images waiting for the model; when full, the oldest is dropped
`queue_min_change`	12	grey levels the picture must change to be queued again; 0 = every image
`queue_dir`	`~/.pashupati/inspection_queue`	waiting images survive a restart; "" = memory only
`cooldown_sec`	60	s; continuous and interval pace do not report the same type again within this time
`max_image_age_sec`	2.0	s; older camera images are not inspected
`max_image_width`	640	px; images are shrunk first
`ollama_url`	`http://127.0.0.1:11434`	the Ollama server (`OLLAMA_URL` in the env file)

7.2 Model and memory

Parameter	Default	What it does
`model`	qwen3-vl:2b-instruct	live; the model in use
`models`	three models	offered on the handheld (plus any other vision model in Ollama)
`keep_alive`	"-1"	keep the model loaded: "-1" forever, or e.g. "30m" (quoted)
`num_ctx`	2048	tokens of context; many long descriptions: 4096 (more memory)
`timeout_sec`	30	s, longest wait for one answer
`use_schema`	true	structured answers; false only for models that cannot do them

A model must be pulled before it can be used (`ollama pull <model>` , or `scripts/setup.sh install ollama` with `VLM_EXTRA_MODELS`). `setup.sh install ollama` also turns off Ollama's prompt cache, which otherwise grows to several GB of RAM.

7.3 Finding types

Parameter	Default	What it does
`categories`	[trash, spill, stain]	live; the types the model chooses from (plus *none*), up to 12
`alarm_categories`	[trash, spill]	live; only these are reported to NETRA
`category_descriptions`	[""]	live; own text per type, `"name: what to look for"`

`trash` , `spill` , `stain` , `floor_damage` and `fallen_person` have built-in descriptions. Good descriptions are short and concrete, name what is visible, and say what is **not** a finding (*not shadows, reflections or floor patterns*). `fleet_uplink_node` sends findings with at least `anomaly_min_confidence` (0.5).

7.4 People counting

`person_detector_node` finds people with YOLO11n (`PEOPLE=true` ; the handheld switches it on and off). It places people on the floor `robot.base_height` below `base_link` .

Parameter	Default	What it does · when to change
`enabled`	true	live
`confidence`	0.4	live, 0-1; boxes on things that are not people: raise it
`rate_hz`	0	live; detections per second, 0 = 5 on the GPU, 2 on the CPU
`max_range`	12	m; people further away are not placed on the map
`backend`	auto	`onnxruntime` , `opencv` or `ultralytics`

NETRA's crowd map uses `fleet_uplink_node` `crowd_cell_size` (1 m) and `crowd_window_sec` (60).

8 Handheld, camera, video, NETRA and health

8.1 Handheld link

`teleop_udp_node`, read at start:

Parameter	Default	What it does
`token`	""	shared secret; the same in the handheld. **Always set it**
`robot_name`	""	name on the handheld's start screen (empty: the computer's name)
`port`	9870	UDP port of the link and of robot discovery
`client_timeout_sec`	2.0	s; a silent handheld is dropped
`robot_commands`	[stand_up, sit_down, emergency_stop]	robot actions on the handheld: `/<ROBOT_NS>/<name>` services
`patrol_speed_min`, `patrol_speed_max`	0.1, 0.6	m/s range of the patrol speed slider
`lidar_hz`, `lidar_voxel`, `lidar_max_points`	2, 0.1, 3000	LiDAR points on the handheld's map

8.2 Camera source

`CAMERA=driver` uses the camera of the robot package (`CAMERA_TOPICS`, `/camera/camera/color`). `CAMERA=rtsp` starts `rtsp_camera` for an IP camera at `CAMERA_URL`, published on the same topics: `calibration_file` (a camera_calibration YAML, see `config/calibration.example.yaml`) rectifies the image; without one, `default_hfov_deg` (90) gives an approximate `camera_info`, enough for inspection and video but not for exact tag poses.

8.3 Video

The handheld gets H.264 over WebRTC from `video_stream_node`, started while it watches: `bitrate_kbps` (1500; weak Wi-Fi: 800), `fps` (15), `max_width` (1280), `keyframe_sec` (1.0), `encoder` (auto). Without WebRTC (`WEBRTC=false` or no MediaMTX) the handheld gets JPEG frames: `teleop_udp_node` `camera_fps` (8), `camera_jpeg_quality` (60), `camera_max_width` (640).

8.4 NETRA uplink

`fleet_uplink_node`: `server_url` (`CC_URL`), `token` (`CC_TOKEN`), `robot_id` (`ROBOT_ID` wins), `telemetry_hz` (1.0), `upload_period_sec` (5.0), `verify_tls` (true; keep it on), `spool_dir` (`~/.pashupati/spool`: findings and routes wait there while NETRA is unreachable).

8.5 Health monitor

`health_monitor_node` publishes `/health/status` (level, issues, speed limit), shown on the handheld and in NETRA. `control_mux_node` scales every command by its speed limit.

Parameter	Pashupati	Issue when
`sensors.topics`	LiDAR 5, odometry 8, sectors 5, camera_info 5, robot odometry 10	a topic runs slower (`"topic:Hz[:max_age]"`)
`degradation.rules`	LiDAR, odometry or TF stale: speed × 0.5	a degraded part slows the robot
`nodes.expected`	empty	a listed node is missing (add the driver's nodes)
`system.max_temp_c`, `system.max_memory_percent`, `system.min_disk_free_gb`	85, 92, 5	the computer is hot, full or out of disk

Parameter	Pashupati	Issue when
`startup_grace_sec`	30	s after start without missing-node issues

9 The env file

`/etc/pashupati/pashupati.env` says what runs. Restart the service after a change. Quote values with spaces, and never put a comment after a value.

Key	Genisom L1W	Meaning
`ROBOT_ID`	e.g. `l1w-01`	the robot's name in NETRA
`ROBOT_DRIVER`	`l1w_bringup`	robot package started with the stack (was `ROBOT_BRINGUP`)
`ROBOT_PARAMS`	empty	robot profile; empty: `config/robot.yaml`
`ROBOT_NS`	`l1w`	namespace of the driver's topics and services
`ROBOT_PRESTART`	`"/usr/local/bin/robot-launch stop driver-livox forward"`	stops the vendor's own LiDAR driver and motion stack first
`ROBOT_SETUP`, `ROBOT_IP`	the robot package's installer, `192.168.234.1`	the ZSBot SDK, the network check
`MODE`	`patrol`	`teach`: map `SITE` from the start
`ODOMETRY`	`fast_lio`	or `leg_kilo`
`SITE`, `SITES_DIR`	the mall's site, `~/.pashupati/sites`	the site at start (was `ROUTE` and `TAGS`)
`CAMERA`, `CAMERA_URL`, `CAMERA_TOPICS`	`driver`, empty, `/camera/camera/color`	section 8.2
`ROS_DOMAIN_ID`, `RMW_IMPLEMENTATION`	`0`, `rmw_fastrtps_cpp`	Pashupati's own DDS; the vendor stack uses another
`ROS_LOCALHOST_ONLY`	`1`	`0` only for RViz from a laptop (section 1.3)

Key	Genisom L1W	Meaning
`PEOPLE`, `INSPECTION`, `OLLAMA_URL`	`true`, `true`, empty	people counting, the VLM inspection
`SITE_CONFIG`	`/etc/pashupati/site.yaml`	the site file
`WEBRTC`, `MEDIAMTX`	`true`, empty	WebRTC video for the handheld
`CC_URL`, `CC_TOKEN`	NETRA's address, the robot's token	NETRA uplink; empty: findings are kept on the robot
`TIME_SYNC_WAIT`	`60`	s to wait at boot for the network clock
`OPENBLAS_NUM_THREADS`, `OMP_NUM_THREADS`	`1`	keep at 1: more threads waste CPU

`scripts/setup.sh check` reports a missing key, or a line that breaks the rules above.

10 Symptoms and fixes

Symptom	Look at	Try
Weaves left and right on straight parts	`speed.smoothing`, the `holonomic.*` section	smoothing 0.3
Too slow in gentle curves	`speed.lateral_accel`	0.4
Jerky starts and stops	`speed.accel`, `speed.decel`	0.3, 0.2
Walks slower or faster than the patrol speed	`stick_max_*` (section 2.3), speed gear	rescale; patrol in the checked gear
Turns or walks sideways the wrong way	`stick_invert_yaw`, `stick_invert_lateral`	true
Stops just short of a stop point and waits 20 s	`approach.min_speed`, `approach.position_tolerance`	0.06, 0.08
Leaves stop points too late	dwell time of the route, `hooks.inspection_timeout_sec`, pace	shorter dwell, faster model
Slowed or *Blocked* with nothing around	`filter.self_margin`, `filter.height_min`, floor slopes	margin +0.02; height_min +0.03
Ignores low objects (bags, boxes)	`filter.height_min`	lower 0.03 at a time, check the floor is not seen
Stops far before obstacles	`path_shift.stop_margin`, `field.margin`, `robot.limits.max_decel`	small steps; repeat the test of section 3.3
Gets too close to obstacles	`robot.limits.max_decel`, `robot.limits.reaction_time`	measure the braking again (section 3.2)

Symptom	Look at	Try
Does not pass gaps that look wide enough	`path_shift.clearance`, `path_shift.max_offset`, the footprint	clearance 0.05, larger offset
Blocked too soon or too late	`safety.blocked_timeout_sec`	to taste
Start refused: robot too far from the route	`join.max_distance`	drive closer, or raise it
Start refused: not localized	a tag in view, `/localization/start`	**Localize** on the handheld
No loc: tag not found	`apriltag` `tag.sizes`, `tag.ids`, light, `detector.decimate`	measure the tag, decimate 1.0
Same trash reported again and again	`cooldown_sec`	120-300
False findings	type description, `alarm_categories`, `anomaly_min_confidence`	describe what is not a finding; 0.6-0.7
Inspection queue always full	`interval_sec`, `model`, `max_image_width`	longer interval, smaller model
Robot slow everywhere, health *warn*	`/health/status` issues, `degradation.rules`	fix the stale sensor
Video stutters	`bitrate_kbps`, `fps`	800, 10
Handheld map lags	`lidar_hz`, `lidar_voxel`, `lidar_max_points`	1, 0.2, 1500
Findings missing in NETRA	`CC_URL`, `CC_TOKEN`, `alarm_categories`, `anomaly_min_confidence`	the log of `fleet_uplink_node`

11 Site file for the Genisom L1W

A starting point for `/etc/pashupati/site.yaml` (the repository's `src/pashupati/config/site.example.yaml` is the same). The robot itself is the robot profile; the site file holds this robot's token and actions and this site's values.

```
teleop_udp_node:
  ros__parameters:
    token: "change-me" # the same in the handheld
    robot_commands:
      [
        stand_up,
        sit_down,
        balance_stand_mode,
        move_mode,
        lock_mode,
        slow_speed,
        normal_speed,
        fast_speed,
        sdk_control_right,
        emergency_stop,
      ]

apriltag: # the tags on this site's walls
  ros__parameters:
    tag:
      ids: [2, 4]
      frames: [base_map, charging_dock]
      sizes: [0.15, 0.15] # MEASURE the printed square

path_follower_node:
  ros__parameters:
    speed:
      cruise: 0.35 # patrol speed for this site
    low_battery: 0.25

fleet_uplink_node:
  ros__parameters:
    robot_id: l1w-01 # ROBOT_ID in the env file wins
```

Each node may appear only once in the file: add more parameters under its existing heading. After a restart, `ros2 param dump /control_mux_node` (and so on) shows the values in use.

12 Parameter reference

The parameters Pashupati sets, read from its parameter files of this version (the robot profile, the stack file, and the defaults of the Pashupati packages). *Meaning* is the comment in the file. Every other Dharma parameter keeps its default: `ros2 param describe /<node> <name>`, and the Dharma manual lists them all.

12.1 pashupati

robot profile: footprint, limits, base height · `src/pashupati/config/robot.yaml`

```
/**
```

Parameter	Default	Meaning
`robot.name`	`quadruped`	model, for logs
`robot.kinematics`	`omni`	legged: vx, vy, wz; diff for a robot that cannot strafe (max_vy 0)
`robot.base_height`	`0.35`	m, base_link above the floor when standing
`robot.footprint.front`	`0.40`	
`robot.footprint.rear`	`0.40`	
`robot.footprint.half_width`	`0.28`	
`robot.limits.max_vx`	`1.0`	m/s, nothing may command more
`robot.limits.max_vy`	`0.5`	m/s
`robot.limits.max_wz`	`1.5`	rad/s
`robot.limits.max_accel`	`0.5`	m/s^2
`robot.limits.max_decel`	`0.6`	m/s^2, MEASURE: braking from full speed on the site's floor
`robot.limits.max_yaw_accel`	`1.5`	rad/s^2
`robot.limits.reaction_time`	`0.25`	s, command to the robot actually braking (sensing + transport)
`robot.frames.map`	`map`	

Parameter	Default	Meaning
`robot.frames.odom`	`odom`	
`robot.frames.base`	`base_link`	

12.2 pashupati

the Dharma stack as tuned for Pashupati · `src/pashupati/config/stack.yaml`

`fastlio_mapping_node`

Parameter	Default	Meaning
`mapping.extrinsic_est_en`	`true`	field-tested on the robot (Pashupati 2.0); Dharma's default: false

`odometry_gate`

Parameter	Default	Meaning
`max_tilt_deg`	`8.0`	a standing quadruped leans a little; catches a sitting robot

`lidar_sector_node`

Parameter	Default	Meaning
`front.num_sectors`	`64`	360 deg so the avoidance also sees behind: needed by the back-up after an inspection (path_follower_node inspection.reverse_distance_m > 0)
`front.fov_deg`	`360.0`	
`filter.height_max`	`1.55`	m above the floor (base_link + 1.20 m)

`localization_node`

Parameter	Default	Meaning
`tag.frames`	`[base_map, charging_dock]`	the AprilTag frames (dharma_perception tag.frames)

path_loader_node

Parameter	Default	Meaning
remember_file	~/.pashupati/last_route	the route loaded last comes back after a restart

path_follower_node

Parameter	Default	Meaning
loop_route	true	patrol: a closed route starts its next lap (not on low battery)
speed.accel	0.5	m/s^2 (Pashupati 2.0 linear_accel_limit)
speed.smoothing	0.4	
safety.blocked_timeout_sec	30.0	s standing in front of an obstacle before BLOCKED
hooks.inspection	[/anomaly_detector_node/check_now]	Inspection at every stop point: the VLM check answers (or, switched off, says so at once); a hook whose node does not run is skipped, so INSPECTION=false never blocks.
hooks.inspection_timeout_sec	20.0	VLM inference on the Jetson takes a few seconds
inspection.reverse_distance_m	0.0	> 0: back up this far after the inspection (360 deg scan)

control_mux_node

Parameter	Default	Meaning
use_health_limit	true	scale commands by health/status speed_scale
remote_sources	[handheld, dashboard]	control/remote/<source>/cmd_vel
field.in_remote	false	REMOTE without the protective field: the operator watches the robot (field-tested decision of Pashupati 1.0); the envelope and the e-stop still apply. sim.yaml keeps it on.

docking_node

Parameter	Default	Meaning
hooks.sit	[""]	e.g. /robot/sit
hooks.charge	[""]	e.g. /robot/charge/start
hooks.stop_charge	[""]	
hooks.stand	[""]	

health_monitor_node

Parameter	Default	Meaning
sensors.topics	[/livox/lidar:5.0, /Odometry:8.0, /perception/sector_scan:5.0, /camera/camera/color/camera_info:5.0:0, /{robot_ns}/odom:10.0]	"topic:min_hz[:max_age_sec]"; {robot_ns} is the driver namespace. The camera on; camera_info: subscribing the JPEG topic would make the driver encode every frame.
degradation.rules	["sensor:/livox/lidar=0.5", "sensor:/Odometry=0.5", "tf:*=0.5"]	

teleop_udp_node

Parameter	Default	Meaning
token	""	set it in the site file, and the same in the handheld

12.3 pashupati_bridge

handheld link, video, RTSP camera · `src/pashupati_bridge/config/bridge.yaml`

`teleop_udp_node`

Parameter	Default	Meaning
`token`	`""`	shared secret: set it in the site file and the same in the handheld app
`robot_commands`	`[stand_up, sit_down, emergency_stop]`	Commands shown on the handheld, each a std_srvs/Trigger <robot_command_prefix><name> of the robot driver (the bringup sets the prefix to /<robot_ns>/); add the robot's own in the site file (gait, speed modes, ...).
`sites_dir`	`~/dharma/map`	the handheld lists and loads the taught routes of every site here

`video_stream_node`

Parameter	Default	Meaning
`fps`	`15.0`	video frames per second
`bitrate_kbps`	`1500`	weak Wi-Fi: lower it

`rtsp_camera`

Parameter	Default	Meaning
`url`	`""`	the bringup sets camera_url:=; e.g. rtsp://192.168.1.120:8554/test
`calibration_file`	`""`	camera_calibration YAML (config/calibration.example.yaml): rectified
`default_hfov_deg`	`90.0`	camera_info without a calibration (tag poses approximate)

12.4 pashupati_inspection

VLM inspection, people · `src/pashupati_inspection/config/inspection.yaml`

anomaly_detector_node

Parameter	Default	Meaning
`model`	`qwen3-vl:2b-instruct`	any Ollama vision model; the handheld offers `models`
`categories`	`[trash, spill, stain]`	a-z 0-9 _, the model also answers "none"
`alarm_categories`	`[trash, spill]`	reported to NETRA; stain is only shown (shiny floors)
`category_descriptions`	`[""]`	own text per type, "name: what to look for"; trash, spill, stain, floor_damage and fallen_person have built-in texts
`keep_alive`	`"-1"`	keep the model loaded while the node runs ("-1"), or e.g. "30m"
`interval_sec`	`0.0`	0 back to back, > 0 every N s through the queue, < 0 stop points only
`queue_dir`	`~/.pashupati/inspection_queue`	interval frames kept across restarts

person_detector_node

Parameter	Default	Meaning
`model_path`	`~/dev/Pashupati/models/yolo11n-416.onnx`	YOLO11n exported to ONNX at 416 px (scripts/setup.sh install people_model): runs without PyTorch (ONNX Runtime, CUDA when available, else OpenCV); .pt / .engine use Ultralytics.
`rate_hz`	`0.0`	live: detections per second; 0 = 5 on the GPU, 2 on the CPU

12.5 pashupati_fleet

NETRA uplink · `src/pashupati_fleet/config/fleet.yaml`

`fleet_uplink_node`

Parameter	Default	Meaning
`server_url`	`""`	NETRA, e.g. https://netra.example.com (empty: spool only); CC_URL
`token`	`""`	robot token NETRA issued (Pengaturan -> Robot -> Tambah); CC_TOKEN
`robot_id`	`robot-01`	ROBOT_ID
`spool_dir`	`~/.pashupati/spool`	anomalies and taught routes wait here until NETRA has them
`sites_dir`	`~/dharma/map`	patrol routes from NETRA go to <site>/netra/<route_id>.csv