

KEY	S PRESSED/RESULT	DISPLAY	
ຶ 1 ເພື່ອ ຄະນາ 20	A short beep as you enter each digit and a medium beep when the 3-digit octal number is completed. The memory address increments one location.	040 102 XXX	
Ø 4 ₃₀ Ø	A short beep as you enter each digit and a medium beep when the 3-digit octal number is completed. The memory address increments one location.	040 103 XXX	
Ø ² 2 ³ 1	A short beep as you enter each digit and a medium beep when the 3-digit octal number is completed. The mem- ory address increments one location.	040 104 XXX	
^{AF} 2 6 Ø	A short beep as you enter each digit and a medium beep when the 3-digit octal number is completed. The mem- ory address increments one location.	040 105 XXX	

MEMORY ADDRESS	CONTENTS		MEMORY ADDRESS	CONTENTS
040 105	057(4K) 077(8K)		040 113 040 114	043 302
040 106	066	9	040 115	106
040 107	000		040 116	040
040 110	315		040 117	006
040 111	147		040 120	000
040 112	040		040 121	052

MEMORY ADDRESS	CONTENTS	MEMORY ADDRESS	CONTEN
040122	101	040143	040
040123	040	040144	303
040124	004	040145	121
040125	064	040146	040
040126	176	040147	172
040127	270	040150	254
040130	312	040151	300
040131	135	040152	173
040132	040	040153	255
040133	166	040154	311
040134	000		
040135	315		
040136	147		
040137	040		
040140	043		
040141	302		
040142	125		