| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
| Dpad mode              | Digital      | Select + Start + Down             |
|                        | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
| SOCD Mode              | Up Priority  | Start + PS + Up                   |
|                        | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | BOOT + RST                        |

| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
| Dpad mode              | Digital      | Select + Start + Down             |
|                        | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
| SOCD Mode              | Up Priority  | Start + PS + Up                   |
|                        | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | BOOT + RST                        |

| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
|                        | Digital      | Select + Start + Down             |
| Dpad mode              | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
| SOCD Mode              | Up Priority  | Start + PS + Up                   |
|                        | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | B00T + RST                        |

| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
|                        | Digital      | Select + Start + Down             |
| Dpad mode              | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
| SOCD Mode              | Up Priority  | Start + PS + Up                   |
|                        | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | BOOT + RST                        |

| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
| Dpad mode              | Digital      | Select + Start + Down             |
|                        | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
| SOCD Mode              | Up Priority  | Start + PS + Up                   |
|                        | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | B00T + RST                        |

| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
| Dpad mode              | Digital      | Select + Start + Down             |
|                        | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
| SOCD Mode              | Up Priority  | Start + PS + Up                   |
|                        | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | BOOT + RST                        |

| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
|                        | Digital      | Select + Start + Down             |
| Dpad mode              | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
| SOCD Mode              | Up Priority  | Start + PS + Up                   |
|                        | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | BOOT + RST                        |

| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
|                        | Digital      | Select + Start + Down             |
| Dpad mode              | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
|                        | Up Priority  | Start + PS + Up                   |
| SOCD Mode              | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | BOOT + RST                        |

| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
|                        | Digital      | Select + Start + Down             |
| Dpad mode              | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
|                        | Up Priority  | Start + PS + Up                   |
| SOCD Mode              | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | B00T + RST                        |

| FUNCTION               |              | SHORTCUT                          |
|------------------------|--------------|-----------------------------------|
| Web Configurator       |              | Start + RST<br>Access 192.168.7.1 |
|                        | Digital      | Select + Start + Down             |
| Dpad mode              | Left Analog  | Select + Start + Left             |
|                        | Right Analog | Select + Start + Right            |
|                        | Up Priority  | Start + PS + Up                   |
| SOCD Mode              | Neutral      | Start + PS + Down                 |
|                        | Last Win     | Start + PS + Left                 |
| Invert Y-Axis          |              | Start + PS + Right                |
| Reflash Mode (Bootsel) |              | B00T + RST                        |