


U?L MCIMX7D7DVM10SC SAI1_MCLK E10 F12 NVCC_SAI SAI SAI1_RXC/I2C4_SDA SAI1_RXFS/I2C4_SCL SAI1_TXD E11 SAI1_TXC SAI1_TXFS D11 SAI2_RXD E09 SAI2_TXD SAI2_TXC SAI2_TXFS E07 NVCC_SD1 SD SD1_CD_B/SD_CARD CO4 SD1_WP/SD_CARD CO4 SD1_RESET_B/SD_CARD B04 H08 NVCC_SD2 SD2_CD_B/EPD_PIN_MUX SD2_WP/USR_BT1 SD2_RESET_B/USR_BT0 K08 NVCC_SD3 J09 PVCC_SAI_SD_CAP SD3_STROBE/EMMC_NAND GO1 Sheet: /eMMC & SD Card/ File: MEMORY.sch Title: Size: A3 Date: KiCad E.D.A. kicad no-vcs-found-766357ubuntu16.04.1 ld: 6/11



U?H MCIMX7D7DVM10SC K18 NVCC_LCD LCD_CLK E20 LCD LCD_ENABLE F25 LCD_HSYNC F24 LCD_VSYNC LCD_RESET C21 LCD_DATA00 D21
LCD_DATA01 A22
LCD_DATA01 B22
LCD_DATA04 C22
LCD_DATA05 B23
LCD_DATA06 A24
LCD_DATA06 B21
LCD_DATA08 B21
LCD_DATA09 C23
LCD_DATA09 B24
LCD_DATA10 B24
LCD_DATA11 G20
LCD_DATA12 F21
LCD_DATA13 C22
LCD_DATA15 B25
LCD_DATA16 B25
LCD_DATA17 C21
LCD_DATA17 C21
LCD_DATA17 C21
LCD_DATA19
LCD_DATA10
LCD_DATA11
LCD_DATA12
LCD_DAT EPDC_D00
EPDC_D01
EPDC_D02
EPDC_D03
EPDC_D04
EPDC_D05
EPDC_D06
EPDC_D06
EPDC_D07
EPDC_D07
EPDC_D07
EPDC_D09
EPDC_D10
EPDC_D11
EPDC_D13
EPDC_D14
EPDC_D14
EPDC_D15 M18 NVCC_EPDC1 EPDC U?I MCIMX7D7DVM10SC EPDC_SDCE0 G25 EPDC_SDCE1 G24 EPDC_SDCE2 H23 EPDC_SDCE3 H22 L17 NVCC_EPDC2 MIPI_CSI_CLK_N MIPI_CSI_CLK_P MIPI CSI MIPI_CSI_DD_N MIPI_CSI_DD_P A16 B16 EPDC_SDCLK EPDC_SDLE J20 EPDC_SDOE H21 EPDC_SDSHR H20 MIPI_CSI_D1_N MIPI_CSI_D1_P EPDC_GDCLK EPDC_GDOE EPDC_GDRL EPDC_GDSP MIPI_DSI_CLK_N MIPI_DSI_CLK_P MIPI DSI
MIPI_DSI_DO_N
MIPI_DSI_DO_P EPDC_PWRCOM H24 K20 N17 PVCC_EPDC_LCD_CAP EPDC_BDR0 K24 K23 MIPI_DSI_D1_N MIPI_DSI_D1_P Sheet: /Display and MIPI/ File: DISPLAY.sch Title: Size: A3 Date: KiCad E.D.A. kicad no-vcs-found-766357ubuntu16.04.1 ld: 8/11

