## **Contents**

Operation	49
Detergent	49
Adding detergent	
Switching on the dishwasher	52
Selecting a programme	52
Starting the programme	53
Display	
Energy management	54
Programme finished	54
Switching off	
Unloading the dishwasher	55
Interrupting a programme	56
Changing a programme	56
Programme options	57
Turbo	
DetergentAgent	57
Switching off the refill indicators	58
Delay start	59
Adjust Sensor wash	61
Optimise standby	62
Factory default settings	63
Programme chart	64
Cleaning and care	68
Cleaning the wash cabinet	
Cleaning the door and the door seal	
Cleaning the door front	
Checking the filters in the wash cabinet	
Cleaning the filters	
Cleaning the spray arms	
Problem solving guide	73
Technical problems	
Water inlet fault	
Water drainage fault	
General problems	
Noises	
Unsatisfactory washing result	
Maintenance	<b>გ</b> 1
Cleaning the water inlet filter	
Cleaning the water miet merman	82