| | | DIEDOX HUDII | bleBox Hubitat Installation Instructions | | | | | | |
|----------------------------------|---|---|--|----------------------|--|--|--|--|--|
| | These instructions are based on a manual installation from the GitHub Site. A pdf copy of these instructions are | | | | | | | | |
| Note | | at the GitHub location: | | | | | | | |
| | "https://github.com/DaveGut/bleBox-Hubitat-SmartThings/tree/master/0%20-%20Hubitat" | | | | | | | | |
| 0 | Install the bleBox devices using the wBox app and assure each device is configured for your installation. This installation uses data you set in the wBox app to properly install the devices. | | | | | | | | |
| 1 | Open up Hubitat Environment (HE) and go "Apps Code" | | | | | | | | |
| 2 | Select "New App" in the upper right-hand corner. | | | | | | | | |
| Note | In lieu of copying and pasting into the editor window, use the "ImportUrl" button in the editor windows At the bottom are the URLs for importing the application and drivers. | | | | | | | | |
| 3 | Go to the Application folder on GitHub, open the application, and copy all of the code. Link: https://github.com/DaveGut/bleBox-Hubitat | | | | | | | | |
| 4 | Past the code into the app window on HE. Select Save. | | | | | | | | |
| 5 | Open up the "Drivers Code" on HE. | | | | | | | | |
| 6 | Go to the DeviceDrivers folder on GitHub. Reference the list below for the drivers you will need to install. For each of those drivers, complete the following steps. | | | | | | | | |
| | a. | Select "New Driver" in the upper | right-hand corner | | | | | | |
| | | Open the relevant driver on the | | e code. | | | | | |
| | c. | Paste the code into the window | on HE. Select Save. | | | | | | |
| 7 | _ | When done installing the required drivers, go the the HE "Apps" page. | | | | | | | |
| | | d User App" and select the app " | | | | | | | |
| | | Install bleBox Devices. Will poll your lps for devices and allow selection of devices to install. | | | | | | | |
| 8 | b. | List all available bleBox devices. Lists devices and updates IP addresses (in case of loss of IP) | | | | | | | |
| | C. | Enable Application Information Logging. For use when you need a log for problem reporting. | | | | | | | |
| | | d. Enable Application Debug Logging. For use when you need a log for problem reporting. | | | | | | | |
| 9 | Select "Install bleBox Devices" | | | | | | | | |
| 10 | From the devices to add, select the dropdown and then the devices you wish to install. | | | | | | | | |
| 11 | Select "Done". Your devices should install. | | | | | | | | |
| 12 | Open each | n device and customize your pref | erences. Complete a Save Pre | eferences. | | | | | |
| Hubitat Driver File Nomenclature | | | | | | | | | |
| bleBox Model | | Install Note | Device Type | Driver File | | | | | |
| | airSensor | | bleBox airSensor | airSensor.groovy | | | | | |
| dimmerBox | | | bleBox dimmerBox | dimmerBox.groovy | | | | | |
| gateBox | | | bleBox gateBox | gateBox.groovy | | | | | |
| shutterBox | | | bleBox shutterBox | shutterBox.groovy | | | | | |
| switchBox | | | bleBox switchBox | switchBox.groovy | | | | | |
| | | Will install two switch devices. | bleBox switchBoxD | switchBoxD.groovy | | | | | |
| tempSensor | | | bleBox tempSensor | tempSensor.groovy | | | | | |
| wLightBoxS | | | bleBox wLightBoxS | wLightBoxS.groovy | | | | | |
| | | Parent Driver (required) | bleBox wLightBox | wLightBox.groovy | | | | | |
| | | Color Type 1 (RGBW) | bleBox wLightBox Rgbw | wLightBoxRgbw.groovy | | | | | |
| | | Color Type 2 (RGB) | bleBox wLightBox Rgb | wLightBoxRgb.groovy | | | | | |
| wLightBox (requires parent and | | Color Type 3 (Mono) (installs 4 devices) | bleBox wLightBox Mono | wLightBoxMono.groovy | | | | | |
| one or two child | | ColorType 4 (RGB or W) | bleBox wLightBox Rgb | wLightBoxRgb.groovy | | | | | |
| drivers) | | (installs 2 devices) | bleBox wLightBox Mono | wLightBoxMono.groovy | | | | | |
| | | ColorType 5 or 6 (CT or CTx2) (Installs 1 device for Color Type 5 and 2 for colorType 6. | bleBox wLightBox Ct | wLightBoxCt.groovy | | | | | |

| Hubitat Driver URLs | | | | |
|---------------------|------------------------------|---|--|--|
| APPLICATION | | https://raw.githubusercontent.com/DaveGut/bleBox- Hubitat/master/Application/blebox%20Manager%20App.groovy | | |
| airSensor | | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/airSensor.groovy | | |
| dimmerBox | | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/dimmerBox.groovy | | |
| gateBox | | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/gateBox.groovy | | |
| shutterBox | | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/shutterBox.groovy | | |
| switchBox | | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/switchBox.groovy | | |
| switchBoxD | | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/switchBoxD.groovy | | |
| tempSensor | | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/tempSensor.groovy | | |
| wLightBoxS | | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/wLightBoxS.groovy | | |
| | bleBox wLightBox (PARENT) | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/wLightBox.groovy | | |
| | bleBox wLightBox Rgbw | https://raw.githubusercontent.com/DaveGut/bleBox- Hubitat/master/Drivers/wLightBoxRgbw.groovy | | |
| wLighBox | bleBox wLightBox Rgb | https://raw.githubusercontent.com/DaveGut/bleBox- Hubitat/master/Drivers/wLightBoxRgb.groovy | | |
| | bleBox wLightBox Mono | https://raw.githubusercontent.com/DaveGut/bleBox- Hubitat/master/Drivers/wLightBoxMono.groovy | | |
| | bleBox wLightBox Ct | https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/wLightBoxCt.groovy | | |