PlanSum - Quick Reference

Version 5.0.15

Usage



PlanSum [-flag] [control_file] [partition]

Optional Flags:

-Q[uiet] = execute without screen messages
-H[elp] = show program syntax and control keys
-C[ontrol] = create/update a default control file
-K[eyCheck] = list unrecognized control file keys
-P[ause] = pause before exiting
-N[oPause] = never pause before exiting
-D[etail] = execute with detailed status messages
-X[ML] = write an XML file with control keys

Purpose

- 1. Summarize the link demands generated by the Router.
- 2. Apply volume-delay equations to estimate link travel times.
- 3. Produce link volume, link delay, and turning movement files by time of day.
- 4. Produce zone or district trip tables and skim files by mode and time of day.
- 5. Summarize transit ridership demand by transit route, run, and stop.
- 6. Generate V/C ratio reports by link and link groups by time of day.
- 7. Create diurnal distributions of the start, end, and mid-trip times of each plan.
- 8. Expand travel statistics from survey plans to the total population.
- 9. Summarize transit transfer details.
- 10. Calculate intrazonal skim values based on a nearest neighbor factor.

Configuration Keys

REQ? KEY	ТҮРЕ	DEFAULT	VALUE RANGES	
TITLE	Text			
REPORT_FILE	File		filename[_partition][.prn]	
REPORT_FLAG	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N	
PROJECT_DIRECTORY	Path			
MODEL_START_TIME	Time	0:00	>= 0 [seconds], 0.0 [hours], 0:00	
MODEL_END_TIME	Time	24:00	> [model_start_time]	
UNITS_OF_MEASURE	Text	METRIC	METRIC, ENGLISH	



PlanSum Version 5.0.15 QR



Configuration Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
RANDOM_NUMBER_SEED	Int.	0	0 = computer clock, > 0 = fixed
MAX_WARNING_MESSAGES	Int.	100000	>= 0
MAX_WARNING_EXIT_FLAG	Bool	TRUE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
MAX_PROBLEM_COUNT	Int.	0	>= 0
NUMBER_OF_THREADS	Int.	1	124
PLANSUM_REPORT_*	Text		program report name

System File Keys

REQ? KEY	TYPE DEFAULT	VALUE RANGES
✓ PLAN_FILE	File	[project_directory]filename.*
NODE_FILE	File	[project_directory]filename
LINK_FILE	File	[project_directory]filename
LANE_USE_FILE	File	[project_directory]filename
CONNECTION_FILE	File	[project_directory]filename
SELECTION_FILE	File	[project_directory]filename.*
LINK_DELAY_FILE	File	[project_directory]filename
VEHICLE_TYPE_FILE	File	[project_directory]filename
NEW_LINK_DELAY_FILE	File	[project_directory]filename

File Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
ZONE_EQUIVALENCE_FILE	File		[project_directory]filename
LINK_EQUIVALENCE_FILE	File		[project_directory]filename
STOP_EQUIVALENCE_FILE	File		[project_directory]filename



PlanSum Version 5.0.15 QR



Data Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
DAILY_WRAP_FLAG	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
SUMMARY_TIME_RANGES	Text	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
SUMMARY_TIME_INCREMENT	Time	15 minutes	0, 2240 minutes
PERIOD_CONTROL_POINT	Text	MID-TRIP	START, END, MID-TRIP

Select Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
SELECT_HOUSEHOLDS	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_MODES	List	ALL	e.g., ALL or 1, 1214 or WALK, HOV2HOV4
SELECT_PURPOSES	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_START_TIMES	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
SELECT_END_TIMES	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
SELECT_ORIGINS	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_DESTINATIONS	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_TRAVELER_TYPES	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_LINKS_*	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_NODES_*	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_SUBAREA_POLYGON	File		[project_directory]filename
SELECTION_PERCENTAGE	Dec.	100.0 percent	0.01100.0 percent

Flow, Time Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
UPDATE_FLOW_RATES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
CLEAR_INPUT_FLOW_RATES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
UPDATE_TRAVEL_TIMES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
LINK_DELAY_FLOW_FACTOR	Dec.	1.0	1100000
EQUATION_PARAMETERS_*	List	BPR, 0.15, 4.0, 0.75	BPR, 0.15, 4.0, 0.75



PlanSum Version 5.0.15 QR



Control Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
NEW_TRIP_TIME_FILE	File		[project_directory]filename
NEW_LINK_VOLUME_FILE	File		[project_directory]filename

Notes

Each '_FILE' key has a corresponding '_FORMAT' key. The following file formats can be used for input and ouput files.

TEXT, BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB_DELIMITED, CSV_DELIMITED, DBASE, SQLITE3, VERSION3

