ArcSnapshot - Quick Reference

Version 5.0.4

Usage



ArcSnapshot [-flag] [control_file]

Optional Flags:

-Q[uiet] = execute without screen messages
-H[elp] = show program syntax and control keys
-C[ontrol] = create/update a default control file
-K[eyCheck] = list unrecognized control file keys
-P[ause] = pause before exiting
-N[oPause] = never pause before exiting
-D[etail] = execute with detailed status messages
-X[ML] = write an XML file with control keys

Purpose

- 1. Create ArcView shapefiles from selected records in TRANSIMS snapshot files.
- 2. Create ArcView shapefiles from selected records in TRANSIMS occupancy files.
- 3. Vehicle lane-offset locations can be drawn as polygons or points layers.
- 4. Output new snapshot files with X, Y, and bearing data updated based on the lane shape.

Configuration Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
TITLE	Text		
REPORT_FILE	File		filename[_partition][.prn]
REPORT_FLAG	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
PROJECT_DIRECTORY	Path		
MODEL_START_TIME	Time	0:00	>= 0 [seconds], 0.0 [hours], 0:00
MODEL_END_TIME	Time	24:00	> [model_start_time]
UNITS_OF_MEASURE	Text	METRIC	METRIC, ENGLISH
RANDOM_NUMBER_SEED	Int.	0	0 = computer clock, > 0 = fixed
MAX_WARNING_MESSAGES	Int.	100000	>= 0
MAX_WARNING_EXIT_FLAG	Bool	TRUE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
MAX_PROBLEM_COUNT	Int.	0	>= 0





C C.		17
(ontic	guration	KAVC
COITTIC	juiulioii	ACYS

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
NUMBER_OF_THREADS	Int.	1	124

System File Keys

REQ? KEY	TYPE D	DEFAULT	VALUE RANGES
✓ NODE_FILE	File		[project_directory]filename
✓ LINK_FILE	File		[project_directory]filename
POCKET_FILE	File		[project_directory]filename
✓ VEHICLE_TYPE_FILE	File		[project_directory]filename
SHAPE_FILE	File		[project_directory]filename
CONNECTION_FILE	File		[project_directory]filename

File Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
NOTES_AND_NAME_FIELDS	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N

Data Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
SUMMARY_TIME_RANGES	Text	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
SUMMARY_TIME_INCREMENT	Time	15 minutes	0, 2240 minutes

Select Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
SELECT_VEHICLE_TYPES	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_SUBAREA_POLYGON	File		[project_directory]filename



ArcSnapshot Version 5.0.4 QR



Draw Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
LANE_WIDTH	Dec.	3.5 meters	040 meters
CENTER_ONEWAY_LINKS	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
DRAW_VEHICLE_SHAPES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N

Projection, Smooth Data, Difference Data Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
INPUT_COORDINATE_SYSTEM	List		LATLONG, DEGREES/MILLION_DEGREES or STATEPLANE/UTM, code, FEET/METERS/MILES/KILOMETERS
INPUT_COORDINATE_ADJUSTMENT	List		X Offset, Y Offset, X Factor, Y Factor
OUTPUT_COORDINATE_SYSTEM	List		LATLONG, DEGREES/MILLION_DEGREES or STATEPLANE/UTM, code, FEET/METERS/MILES/KILOMETERS
OUTPUT_COORDINATE_ADJUSTMENT	List		X Offset, Y Offset, X Factor, Y Factor
OUTPUT_XYZ_SHAPES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
OUTPUT_XYM_SHAPES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N

Control Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
SNAPSHOT_FILE	File		[project_directory]filename
OCCUPANCY_FILE	File		[project_directory]filename
NEW_ARC_SNAPSHOT_FILE	File		[project_directory]filename
CELL_SIZE	Dec.	0.0 meters	0, 310 meters
ADD_PASSENGER_CIRCLE_SIZE	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
ADD_PASSENGER_SQUARE_SIZE	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
PAD_FILE_TIME_LABEL	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
TIME_PROCESSING_METHOD	Text	AT_INCREMENT	AT_INCREMENT, TOTAL, MAXIMUM
NEW_SNAPSHOT_FILE	File		[project_directory]filename
NEW_LINK_SUMMARY_FILE	File		[project_directory]filename



ArcSnapshot Version 5.0.4 QR



Notes

Each '_FILE' key has a corresponding '_FORMAT' key. The following file formats can be used for input and ouput files.

TEXT, BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB_DELIMITED, CSV_DELIMITED, DBASE, SQLITE3, VERSION3

