

ROBOTICS

Product manual

OmniCore C30



Trace back information:

Workspace 22B version a4

Checked in 2022-06-01

Skribenta version 5.5.019

Product manual
OmniCore C30
OmniCore

Document ID: 3HAC060860-001
Revision: P

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2019-2022 ABB. All rights reserved.
Specifications subject to change without notice.

Table of contents

Overview of this manual	9
Product documentation	13
1 Safety	15
1.1 Safety information	15
1.1.1 Limitation of liability	15
1.1.2 Safety data	16
1.1.3 Requirements on personnel	17
1.2 Safety signals and symbols	18
1.2.1 Safety signals in the manual	18
1.2.2 Safety symbols on controller labels	20
1.3 Robot stopping functions	23
1.3.1 Protective stop and emergency stop	23
1.3.2 About emergency stop	25
1.3.3 Enabling device and hold-to-run functionality	26
1.4 Robot operating modes	27
1.4.1 About the manual mode	27
1.4.2 About the automatic mode	29
1.5 Safety during installation and commissioning	30
1.6 Safety during operation	33
1.7 Safety during maintenance and repair	34
1.8 Safety during troubleshooting	35
1.9 Safety during decommissioning	36
2 Controller description	37
2.1 OmniCore C30	37
2.2 Technical data for OmniCore C30 controller	38
2.3 Safety functions and safety related data for OmniCore C30	44
2.4 The unit is sensitive to ESD	47
2.5 Handling of FlexPendant	48
2.6 Network security	49
2.7 Open source and 3rd party components in RobotWare	50
2.8 ABB Ability	51
3 Installation and commissioning	53
3.1 Introduction to installation and commissioning	53
3.2 Installation activities	54
3.3 Transporting and handling	55
3.3.1 Unpacking	55
3.3.2 Storing	56
3.4 On-site installation	57
3.4.1 Required installation space	57
3.4.2 Mounting the controller with 19" rack mounting kit [3002-1]	61
3.4.3 Mounting the controller with vertical mounting kit [3002-2]	64
3.4.4 Replacing the controller from vertical mounting kit to 19" rack mounting kit	68
3.4.5 Mounting the controller with desktop mounting kit [3001-2]	71
3.4.6 Mounting the FlexPendant holder	75
3.4.7 Changing the fan control functionality	81
3.5 Electrical connections	82
3.5.1 Connectors on the OmniCore C30 controller	82
3.5.2 Connecting cables to the controller	85
3.5.3 Connecting the manipulator to the controller	91
3.5.4 Fitting the connector	92
3.5.5 Connecting power supply to and grounding the controller	97
3.5.6 Detaching and attaching a FlexPendant	100
3.5.7 Ethernet networks on OmniCore	104

Table of contents

3.5.8	Descriptions for connectors	112
3.5.9	Configuring robot stopping functions	126
3.5.10	Programmable stop functions	130
3.6	I/O system	133
3.6.1	Available industrial networks	133
3.6.2	Scalable I/O, internal and external	135
3.7	Installing options	136
3.7.1	Installing the harness for double SMB	136
3.7.2	Installing the scalable I/O devices	141
3.7.3	Installing the Ethernet extension switch	145
3.7.4	Installing the power supply optional device and the harness 24 V extension	152
3.7.5	Installing the fieldbus master and the DeviceNet harness	167
3.8	Installing add-on devices	194
3.8.1	Installing the scalable I/O add-on devices	194
3.8.2	Installing the conveyor tracking module	195
3.8.3	Installing Integrated Vision	197
3.9	Initial test before commissioning	200
4	Maintenance	201
4.1	Maintenance schedule, OmniCore	201
4.2	Inspection activities	203
4.2.1	Inspection of controller	203
4.3	Cleaning activities	205
4.3.1	Cleaning of the controller cabinet	205
4.3.2	Cleaning the FlexPendant	206
4.4	Changing/replacing activities	208
4.4.1	Replacement of air filter element for the controller with vertical mounting kit	208
4.5	Function tests	212
4.5.1	Function test of emergency stop	212
4.5.2	Function test of manual, auto, and manual full speed mode with FlexPendant	213
4.5.3	Function test of three-position enabling device	214
4.5.4	Function test of safety switches	215
4.5.5	Function test of Automatic Stop	216
4.5.6	Function test of General Stop	217
4.5.7	Function test of external emergency stop	218
4.5.8	Function test of ESTOP_STATUS output	219
4.5.9	Function test of reduced speed control	220
5	Repair	221
5.1	Introduction to repair	221
5.2	Replacing parts inside the controller	222
5.2.1	Opening the robot controller	222
5.2.2	Replacing the axis computer	231
5.2.3	Replacing the fans	236
5.2.3.1	Replacing the standard fans	238
5.2.3.2	Replacing the small fans	251
5.2.3.3	Replacing the main computer fan	264
5.2.4	Replacing the robot signal exchange proxy	282
5.2.5	Replacing the Ethernet switch	290
5.2.6	Replacing the connected services gateway	299
5.2.7	Replacing the scalable I/O unit	308
5.2.8	Replacing the safety digital base device	313
5.2.9	Replacing the main computer	318
5.2.10	Replacing the power unit	358
5.2.11	Replacing the power supply	365
5.2.12	Replacing the drive unit	373
5.2.13	Replacing the fieldbus master	384
5.3	Replacing parts on the front panel	411
5.3.1	Replacing the manipulator signal connector (SMB)	411

5.3.2	Replacing the motor connector	416
5.3.2.1	Replacing the motor connector	418
5.3.2.2	Replacing the motor connector for CRB 15000 controller	424
5.3.3	Replacing the incoming mains connector	434
5.3.4	Replacing the HMI signal (FlexPendant) connector	439
5.3.5	Replacing the process connectors	455
5.3.6	Replacing the harness CFI connection	471
5.3.7	Replacing the IP20 power outlet connector	475
5.4	Replacing parts on the FlexPendant	491
5.4.1	Replacing the power cable and power cable cover	491
5.4.2	Replacing the joystick protection	495
5.4.3	Replacing the fasten strip	498
6	Troubleshooting	499
6.1	Introduction to troubleshooting	499
6.2	Troubleshooting fault symptoms	501
6.2.1	No LEDs are lit on the controller	502
6.2.2	Start-up failure	507
6.2.3	System update failure	511
6.2.4	Problem releasing the robot brakes	512
6.2.5	Problem starting or connecting the FlexPendant	517
6.2.6	Problem using the joystick	522
6.2.7	Controller fails to start	523
6.2.8	Reflashing firmware failure	524
6.2.9	Inconsistent path accuracy	525
6.2.10	Controller is overheated	527
6.3	Troubleshooting units	528
6.3.1	Troubleshooting LEDs in the controller	528
6.3.2	Troubleshooting the FlexPendant	529
6.3.3	Troubleshooting the drive unit	530
6.3.4	Troubleshooting the power unit	532
6.3.5	Troubleshooting fieldbuses and I/O	537
6.3.6	Troubleshooting the connected services gateway	538
6.3.7	Troubleshooting the Ethernet switch	543
6.3.8	Troubleshooting the axis computer	545
6.3.9	Troubleshooting the main computer	547
6.3.10	Troubleshooting the power supply	550
6.3.11	Troubleshooting the robot signal exchange proxy	555
7	Decommissioning	563
7.1	Introduction to decommissioning	563
7.2	Environmental information	564
8	Reference information	567
8.1	Introduction	567
8.2	Applicable standards	568
8.3	Unit conversion	569
8.4	Standard toolkit for controller	570
8.5	Screw joints	571
8.6	Weight specifications	572
8.7	Lifting accessories and lifting instructions	573
9	Spare parts	575
9.1	Controller parts	576
9.1.1	Controller system parts	579
9.1.2	Logic parts	582
9.1.3	Application parts	584
9.1.4	Cabinet parts	587

Table of contents

9.1.5	Miscellaneous parts	589
9.1.6	Cables	592
9.2	FlexPendant parts	596
9.3	Manipulator cables	597
9.3.1	Manipulator cables	597
9.3.2	Customer cables - CP/CS connectors (option)	599
9.3.3	Customer cables - Ethernet floor cables	600
Index		601

Overview of this manual

About this manual

This manual contains instructions for:

- mechanical and electrical installation of the controller
- maintenance of the controller
- mechanical and electrical repair of the controller

Usage

This manual should be used during:

- installation and commissioning, from lifting the product to its work site and securing it to the foundation, to making it ready for operation
- maintenance work
- repair work
- decommissioning work



Note

It is the responsibility of the integrator to conduct a risk assessment of the final application.

It is the responsibility of the integrator to provide safety and user guides for the robot system.

Who should read this manual?

This manual is intended for:

- installation personnel
- maintenance personnel
- repair personnel.

Prerequisites

A maintenance/repair/installation craftsman working with an ABB robot must:

- be trained by ABB and have the required knowledge of mechanical and electrical installation/repair/maintenance work.
- be trained to respond to emergencies or abnormal situations.

Product manual scope

The manual covers all variants and designs of the OmniCore C30. Some variants and designs may have been removed from the business offer and are no longer available for purchase.

References

Document name	Document ID
Product specification - OmniCore C line	3HAC065034-001

Continues on next page

Overview of this manual

Continued

Document name	Document ID
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009
<i>Operating manual - RobotStudio</i>	3HAC032104-001
<i>Operating manual - OmniCore</i>	3HAC065036-001
<i>Operating manual - Integrator's guide OmniCore</i>	3HAC065037-001
<i>Application manual - Force control with software and hardware</i>	3HAC070206-001
<i>Technical reference manual - System parameters</i>	3HAC065041-001
<i>Application manual - Functional safety and SafeMove</i>	3HAC066559-001
<i>Application manual - Connected Services</i>	3HAC028879-001
<i>Application manual - Conveyor tracking</i>	3HAC066561-001
<i>Safety manual for robot - Manipulator and IRC5 or OmniCore controller</i>	3HAC031045-001

Revisions

Revision	Description
A	First edition.
B	Published in release 19C. The following updates are made in this revision: <ul style="list-style-type: none">• The safety section is updated.• Added section about operating modes.• Updated information about residual current device.• Added IRB 1100.• Updated safety information related to IRB 14050.
D	Published in release 19D. The following updates are made in this revision: <ul style="list-style-type: none">• Removed fieldbus adapters that are not yet available.
E	Published in release 20A. The following updates are made in this revision: <ul style="list-style-type: none">• Added information about SafeMove.• Added information about single point of control.• Information regarding how to restore the hardware settings has been added in section Replacing the main computer on page 318.
F	Published in release 20B. The following updates are made in this revision: <ul style="list-style-type: none">• Updated NOTE regarding IP addresses in section "Set up the network connection".• Updated spare part levels.• Updated spare part names of cable length.• Added the note for TPU connector in desktop version.• Updated information about safety data.• Added ABB Ability on page 51.
G	Published in release 20C. The following updates are made in this revision: <ul style="list-style-type: none">• Added the replacement for filter element in vertical version.• Updated information about safety data.• Updated information about robot signal exchange proxy.

Continues on next page

Revision	Description
H	<p>Published in release 20D. The following updates are made in this revision:</p> <ul style="list-style-type: none"> Section "Network connections on the OmniCore" has been updated with NOTE regarding correct usage of the MGMT port. Added information about new fans in spare part chapter and repair chapter. Updated dimensions when all ABB cables are connected. Section Mounting the FlexPendant holder on page 75 has been updated with new installation method for the FlexPendant holder.
J	<p>Published in release 21A. The following updates are made in this revision:</p> <ul style="list-style-type: none"> Added information about OmniCore C30 for CRB 15000. Added supported robot IRB 360. Minor corrections in section "Network connections on the OmniCore". Updated images in section Fitting the connector on page 92. Added Silicone information in section Environmental information on page 564. Updated default safety circuit configuration for X14 in section Robot signal exchange proxy mating connectors on page 112. Added safety stops configuration information in section Configuring robot stopping functions on page 126. Added note for vertical mounting kit and 19" rack mounting kit in section Mounting the controller with 19" rack mounting kit [3002-1] on page 61 and Mounting the controller with vertical mounting kit [3002-2] on page 64. Minor corrections in section "Connections on the main computer". Added extension cable spare parts in section FlexPendant parts on page 596. Minor corrections in section Descriptions for connectors on page 112. Updated information about safety data.
K	<p>Published in release 21B. The following updates are made in this revision:</p> <ul style="list-style-type: none"> Added information about general stop (GS) in section Descriptions for connectors on page 112. Updated the information for configuration of safety stops, see Configuring robot stopping functions on page 126. Updated FlexPendant holder assembling procedure. Updated information about safety data. Updated images related to general stop. Added 5,000 mm power inlet cable in section Fitting the connector on page 92.
L	<p>Published in release 21C. The following updates are made in this revision:</p> <ul style="list-style-type: none"> Deleted the 30 m signal cable for IRB 1300, see Manipulator cables on page 597. Added information, see AC current in CP/CS on page 86. Sections "Network connections on OmniCore" and "Set up the network connection" replaced by Ethernet networks on OmniCore on page 104. Update content for ESOUT in section Descriptions for connectors on page 112.

Continues on next page

Overview of this manual

Continued

Revision	Description
M	Published in release 21D. The following updates are made in this revision: <ul style="list-style-type: none">• Added information about safety digital base device.• Added information about main computer fan.• Added supported robot IRB 1200, 910INV and 920.• Updated structure in section Descriptions for connectors on page 112.• Updated structure in section Controller parts on page 576.• Updated the section Ethernet networks on OmniCore on page 104.• Added connector type information of CFI harness in section X2 harness CFI connection (option) on page 121.• Removed fieldbus adapter slave throughout the manual.
N	Published in release 22A. The following updates are made in this revision: <ul style="list-style-type: none">• Added information on decoupling ES output and ES input, see Descriptions for connectors on page 112, and Configuring robot stopping functions on page 126.• Part numbers for mating connectors corrected in Robot signal exchange proxy mating connectors on page 112.• Information about I/O Network added in section Firewall settings on page 111.
P	Published in release 22B. The following updates are made in this revision: <ul style="list-style-type: none">• Minor corrections in section Descriptions for connectors on page 112.• Added note that the content of the section <i>ABB Ability</i> is only available in English (also in translated manuals).• Added related information that the approval code CMIIT ID is finally displayed on the nameplate of the product in section Troubleshooting the connected services gateway on page 538.• Updated manipulator cables in section Manipulator cables on page 597.• Information added in section Available industrial networks on page 133 that two industrial network masters can be run in parallel on the OmniCore controller.

Product documentation

Categories for user documentation from ABB Robotics

The user documentation from ABB Robotics is divided into a number of categories. This listing is based on the type of information in the documents, regardless of whether the products are standard or optional.



Tip

All documents can be found via myABB Business Portal, www.abb.com/myABB.

Product manuals

Manipulators, controllers, DressPack/SpotPack, and most other hardware is delivered with a **Product manual** that generally contains:

- Safety information.
- Installation and commissioning (descriptions of mechanical installation or electrical connections).
- Maintenance (descriptions of all required preventive maintenance procedures including intervals and expected life time of parts).
- Repair (descriptions of all recommended repair procedures including spare parts).
- Calibration.
- Decommissioning.
- Reference information (safety standards, unit conversions, screw joints, lists of tools).
- Spare parts list with corresponding figures (or references to separate spare parts lists).
- References to circuit diagrams.

Technical reference manuals

The technical reference manuals describe reference information for robotics products, for example lubrication, the RAPID language, and system parameters.

Application manuals

Specific applications (for example software or hardware options) are described in **Application manuals**. An application manual can describe one or several applications.

An application manual generally contains information about:

- The purpose of the application (what it does and when it is useful).
- What is included (for example cables, I/O boards, RAPID instructions, system parameters, software).
- How to install included or required hardware.
- How to use the application.
- Examples of how to use the application.

Continues on next page

Operating manuals

The operating manuals describe hands-on handling of the products. The manuals are aimed at those having first-hand operational contact with the product, that is production cell operators, programmers, and troubleshooters.

1 Safety

1.1 Safety information

1.1.1 Limitation of liability

Limitation of liability

Any information given in this manual regarding safety must not be construed as a warranty by ABB that the industrial robot will not cause injury or damage even if all safety instructions are complied with.

The information does not cover how to design, install and operate a robot system, nor does it cover all peripheral equipment that can influence the safety of the robot system.

In particular, liability cannot be accepted if injury or damage has been caused for any of the following reasons:

- Use of the robot in other ways than intended.
- Incorrect operation or maintenance.
- Operation of the robot when the safety devices are defective, not in their intended location or in any other way not working.
- When instructions for operation and maintenance are not followed.
- Non-authorized design modifications of the robot.
- Repairs on the robot and its spare parts carried out by in-experienced or non-qualified personnel.
- Foreign objects.
- Force majeure.

Spare parts and equipment

ABB supplies original spare parts and equipment which have been tested and approved. The installation and/or use of non-original spare parts and equipment can negatively affect the safety, function, performance, and structural properties of the robot. ABB is not liable for damages caused by the use of non-original spare parts and equipment.

1 Safety

1.1.2 Safety data

1.1.2 Safety data

Prevailing standards and directives

For the use of industrial robots, regulations must be fulfilled as described in the following standards and directives:

- EN ISO 10218-1:2011
- Machinery Directive 2006/42/EC

Performance level and category

EN ISO 10218-1 requires structure category 3 and performance level *PL d* on the robot, see EN ISO 13849-1.

Risk assessment

The results of a risk assessment performed on the robot and its intended application may determine that a safety-related control system performance other than that stated in ISO 10218 is warranted for the application.

The SISTEMA/ABB FSDT libraries contains details for the safety functions.



Note

The safety functions are divided into two types called *Basic Safety Functions* and *Extended Safety Functions*.

Performance level data

The performance level data for the respective controller variant is presented in section [*Safety functions and safety related data for OmniCore C30 on page 44*](#).

1.1.3 Requirements on personnel

General

Only personnel with appropriate training are allowed to install, maintain, service, repair, and use the robot. This includes electrical, mechanical, hydraulics, pneumatics, and other hazards identified in the risk assessment.

Persons who are under the influence of alcohol, drugs or any other intoxicating substances are not allowed to install, maintain, service, repair, or use the robot.

The plant liable must make sure that the personnel is trained on the robot, and on responding to emergency or abnormal situations.

Personal protective equipment

Use personal protective equipment, as stated in the instructions.

1 Safety

1.2.1 Safety signals in the manual

1.2 Safety signals and symbols

1.2.1 Safety signals in the manual

Introduction to safety signals

This section specifies all safety signals used in the user manuals. Each signal consists of:

- A caption specifying the hazard level (DANGER, WARNING, or CAUTION) and the type of hazard.
- Instruction about how to reduce the hazard to an acceptable level.
- A brief description of remaining hazards, if not adequately reduced.

Hazard levels

The table below defines the captions specifying the hazard levels used throughout this manual.

Symbol	Designation	Significance
	DANGER	Signal word used to indicate an imminently hazardous situation which, if not avoided, will result in serious injury.
	WARNING	Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in serious injury.
	ELECTRICAL SHOCK	Signal word used to indicate a potentially hazardous situation related to electrical hazards which, if not avoided, could result in serious injury.
	CAUTION	Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in slight injury.
	ELECTROSTATIC DISCHARGE (ESD)	Signal word used to indicate a potentially hazardous situation which, if not avoided, could result in severe damage to the product.
	NOTE	Signal word used to indicate important facts and conditions.

Continues on next page

1.2.1 Safety signals in the manual

Continued

Symbol	Designation	Significance
	TIP	Signal word used to indicate where to find additional information or how to do an operation in an easier way.

1 Safety

1.2.2 Safety symbols on controller labels

1.2.2 Safety symbols on controller labels

Introduction to safety symbols

Both the manipulator and the controller are marked with labels containing safety symbols and important information about the product. The purpose of the labels is to ensure personal safety for all personnel handling the robot, for example during installation, service, or operation.

The safety symbols are language independent, they only use graphics. The information labels contain information in text. See [Symbols and information on labels on page 20](#).



Note

The safety and information labels on the product must be observed.

Symbols and information on labels



Note



The descriptions in this section are generic, the labels can contain additional information such as values.

Label	Description
 xx1400001152	Read the user manual before use.
 xx210000104	The robot is delivered to start in automatic mode
 xx1800000835	CE label

Continues on next page

1.2.2 Safety symbols on controller labels

Continued

Label	Description
 xx1400002061	UL certified (robot with controller)
 xx1700000353	Safety UL label (for the <i>Functional Safety</i> solution together with UL mark).
 xx1700000355	SafeMove label (for <i>SafeMove Basic</i> and <i>SafeMove Pro</i> software).
 xx1900001805	Rating label (example)
 xx1400001151	Electrical shock

Continues on next page

1 Safety

1.2.2 Safety symbols on controller labels

Continued

Label	Description
 xx1800000836	Warning & caution label
 xx1400001156	High voltage inside the module even if the main switch is in the OFF position.
 xx1400001162	ESD sensitive components inside the controller.

1.3 Robot stopping functions

1.3.1 Protective stop and emergency stop

Robot stopping functions

The robot has protective and emergency stop functions (stop category 0 or 1, in accordance with IEC 60204-1).

Stop category 0	As defined in IEC 60204-1, stopping by immediate removal of power to the machine actuators.
Stop category 1	As defined in IEC 60204-1, a controlled stop with power available to the machine actuators to achieve the stop and then removal of power when the stop is achieved.

A stop function, protective or emergency stop, has a default setting for the stop category, see [Inputs to initiate a protective stop or an emergency stop on page 23](#).

The default stop category for a protective or emergency stop can be re-configured.

Activation of external safety rated devices, connected to the robot controller through dedicated discrete safety inputs or safety protocols, will initiate these stop functions.

Inputs to initiate a protective stop or an emergency stop

Inputs to initiate a stop function	Description	Default stop category	Stop category reconfigurable Y/N
Emergency Stop (ES)	Input to initiate the emergency stop function. The <i>Emergency Stop</i> function is initiated in both automatic and manual mode.	Stop category 0 For deviations, see the product manual for the manipulator.	Y
Automatic Stop (AS)/General Stop (GS)	Input to initiate the protective stop function. The protective stop function can either be configured as <i>Automatic Stop</i> (AS) or <i>General Stop</i> (GS). <i>Automatic Stop</i> (AS) is only initiated in automatic mode. <i>General Stop</i> (GS) is initiated in both manual mode and automatic mode.	Stop category 1	Y



Note

The default configuration for the protective stop function triggered by the protective stop input is *Automatic Stop*.

For example, a safety rated output from a presence sensing device, connected to AS / GS, a dedicated discrete protective stop input on the robot controller, will initiate the protective stop function in automatic mode only.

Continues on next page

1 Safety

1.3.1 Protective stop and emergency stop

Continued

The emergency stop function is a complementary protective measure and shall not be applied as a substitute for safeguarding measures or safety functions.



Note

A safety input used to initiate a protective stop must remain active for at least 100 ms.

1.3.2 About emergency stop

The emergency stop

The purpose of the emergency stop function is to avert actual or impending emergency situations arising from the behavior of persons or from an unexpected hazardous event.

The emergency stop function is to be initiated by a single human action.

The emergency stop function is a complementary protective measure and shall not be applied as a substitute for safeguarding measures and other functions or safety functions.

The effect of an activated emergency stop device is sustained until the actuator of the emergency stop device has been disengaged. This disengagement is only possible by an intentional human action on the device where the command has been initiated. The disengagement of the emergency stop device shall not restart the machinery but only permit restarting.



Note

The emergency stop device on the FlexPendant is operational when the robot is powered. Indicators to be used to verify that the robot is powered are the main switch on the cabinet or the LED indicator on the cabinet when robot is in Motors On Mode.

Recover from emergency stop

- 1 Inspect the machinery in order to detect the reason for the emergency stop device actuation.
- 2 Locate and disengage the emergency stop device or devices that initiated the emergency stop function.

1 Safety

1.3.3 Enabling device and hold-to-run functionality

1.3.3 Enabling device and hold-to-run functionality

Three-position enabling device



CAUTION

The person using the three-position enabling device is responsible to observe the safeguarded space for hazards due to robot motion and any other hazards related to the robot.

The three-position enabling device is located on the FlexPendant. When continuously held in center-enabled position, the three-position enabling device will permit robot motion and any hazards controlled by the robot. Release or compression past the center-enabled position will stop the robot motion.



CAUTION

For safe use of the three-position enabling device, the following must be implemented:

- The three-position enabling device must never be rendered inoperational in any way.
- If there is a need to enter safeguarded space, always bring the FlexPendant. This is to enforce single point of control.



CAUTION

On the IRB 14050, the three-position enabling device is not active unless a valid SafeMove configuration is active in the controller.

Hold-to-run function in manual high speed mode

The hold-to-run function for manual high speed allows movement in conjunction with the three-position enabling device when the button connected to the function is actuated manually. This hold-to-run function can only be used in manual high speed mode. In case of hazard, release or compress the three-position enabling device.

How to use the hold-to-run function for manual high speed mode is described in the operating manual for the controller.

The hold-to-run function for manual high speed mode is by default not available for YuMi with OmniCore C30. If this function is required, contact your local ABB for support.



Note

The manual high speed mode is not available in all markets.

1.4 Robot operating modes

1.4.1 About the manual mode

The manual mode

Manual mode is a control state that allows for the direct control by an operator. The operator will through positioning the three-position enabling device to the center-position allow for movement of the manipulator.

There are two manual modes:

- Manual reduced speed
- Manual high speed (optional)

Safeguard mechanisms

- Protective stop through
 - Three-position enabling device (release of or compression past the center-enabled position)
 - General Stop, GS (see actual configuration, can be configured to either AS or GS)

The mode manual reduced speed

The mode manual reduced speed, is used for jogging, teaching, programming and program verification of the robot; it may be the mode selected when performing some maintenance tasks.

In manual reduced speed mode the movement of the TCP is limited to 250 mm/s. In addition, there is a limitation on the maximum allowed speed for each axis.

Manual control of the robot from inside the safeguarded space shall be performed through the FlexPendant.



WARNING

Wherever possible, the manual mode of operation shall be performed with all persons outside the safeguarded space.

Tasks normally performed in mode manual reduced speed

The following tasks are normally performed in manual reduced speed mode.

- Set or reset I/O signals
- Creating and editing RAPID programs
- Modify system parameter values
- Starting, stepping, and stopping program execution
- Jog the manipulator
- Teach or tune programmed manipulator positions

The mode manual high speed

The mode manual high speed, is used for program verification only.

Continues on next page

1 Safety

1.4.1 About the manual mode

Continued

The three-position enabling switch must be pressed to the center-position and the hold-to-run button must be pressed to allow start of program execution, for example, execute movement instructions.

In manual high speed, the initial speed of the movement, does not exceed 250 mm/s, that is limited to a percentage of the programmed speed. The speed can be manually adjusted in steps up to the programmed speed.

When the three-position enabling device is released or fully compressed, the speed is reset to the initial speed, that is, not exceeding 250 mm/s.



WARNING

Wherever possible, the manual mode of operation shall be performed with all persons outside the safeguarded space.

Tasks normally performed in mode manual high speed

The following tasks are normally performed in manual high speed mode.

- Program verification
- Setting program pointer (to Main, to routine, to cursor, to service routine, etc.)
- Starting and stopping program execution
- Stepping program execution
- Manually adjusting speed (0–100%)

1.4.2 About the automatic mode

The automatic mode

Automatic mode is an operating mode in which the robot operates in accordance with the task program(s).

Tasks normally performed in automatic mode

The following tasks are typically performed in automatic mode:

- Start and stop of program execution.
- Increase or decrease the speed in between zero and programmed speed.
- Restore backups. Only possible when robot is at stop.
- Load, start, stop, and modify RAPID programs through remote clients.

Safeguard mechanisms

- Protective stop through
 - Automatic Stop, AS (See actual configuration for the protective stop function. The protective stop function can be be configured to either Automatic Stop, AS, or General Stop, GS.)



Note

Prior to allowing the robot to operate in automatic mode, ensure that any suspended safeguards, are returned to full functionality.

1 Safety

1.5 Safety during installation and commissioning

1.5 Safety during installation and commissioning

National or regional regulations

The integrator of the robot system is responsible for the safety of the robot system.

The integrator is responsible that the robot system is designed and installed in accordance with the safety requirements set forth in the applicable national and regional standards and regulations.

The integrator of the robot system is required to perform a risk assessment.

Layout

The robot integrated to a robot system shall be designed to allow safe access to all spaces during installation, operation, maintenance, and repair.

If robot movement can be initiated from an external control panel then an emergency stop must also be available.

If the manipulator is delivered with mechanical stops, these can be used for reducing the working space.

A perimeter safeguarding, for example a fence, shall be dimensioned to withstand the following:

- The force of the manipulator.
- The force of the load handled by the robot if dropped or released at maximum speed.
- The maximum possible impact caused by a breaking or malfunctioning rotating tool or other device fitted to the robot.

The maximum TCP speed and the maximum velocity of the robot axes are detailed in the section *Robot motion* in the product specification for the respective manipulator.

Consider exposure to hazards, such as slipping, tripping, and falling.

Hazards due to the working position and posture for a person working with or near the robot shall be considered.

Hazards due to noise emission from the robot needs to be considered.

Consider hazards from other equipment in the robot system, for example, that guards remain active until identified hazards are reduced to an acceptable level.

Allergenic material

See [Environmental information on page 564](#) for specification of allergenic materials in the product, if any.

Securing the robot to the foundation

The robot must be properly fixed to its foundation/support, as described in the respective product manual.

When the robot is installed at a height, hanging, or other than mounted directly on the floor, there will be additional hazards.

Continues on next page

Electrical safety

Incoming mains must be installed to fulfill national regulations.

The power supply wiring to the robot must be sufficiently fused and if necessary, it must be possible to disconnect it manually from the mains power.

The power to the robot must be turned off with the main switch and the mains power disconnected when performing work inside the controller cabinet. Lock and tag shall be considered.

Hazards due to stored electrical energy in the controller must be considered.

Harnesses between controller and manipulator shall be fixed and protected to avoid tripping and wear.

Wherever possible, power on/off or rebooting the robot controller shall be performed with all persons outside the safeguarded space.



Note

Use a CARBON DIOXIDE (CO₂) extinguisher in the event of a fire in the robot.

Safety devices

The integrator is responsible for that the safety devices necessary to protect people working with the robot system are designed and installed correctly.

When integrating the robot with external devices to a robot system:

- The integrator of the robot system must ensure that emergency stop functions are interlocked in accordance with applicable standards.
- The integrator of the robot system must ensure that safety functions are interlocked in accordance with applicable standards.

Other hazards

A robot may perform unexpected limited movement.



WARNING

Manipulator movements can cause serious injuries on users and may damage equipment.

The risk assessment should also consider other hazards arising from the application, such as, but not limited to:

- Water
- Compressed air
- Hydraulics

End-effector hazards require particular attention for applications which involve close human collaboration with the robot.

Continues on next page

1 Safety

1.5 Safety during installation and commissioning

Continued

Collaborative applications

If a robot is intended for a collaborative application, where occasional contact between the robot and the operator is expected, the safety aspects must still be addressed. See the product manual for the manipulator.

Verify the safety functions

Before the robot system is put into operation, verify that the safety functions are working as intended and that any remaining hazards identified in the risk assessment are mitigated to an acceptable level.

1.6 Safety during operation

Automatic operation

Verify the application in the operating mode manual reduced speed, before changing mode to automatic and initiating automatic operation.

Lock and change of operating mode

To prevent hazard, it is the responsibility of the integrator to make sure that keys used to lock or change the operating mode are handled only by authorized personnel.

Safety devices not in use

Safety devices that are not connected to the robot or robot system cannot initiate a protective or emergency stop. These must be stored out of sight so that they cannot be mistaken for being in use.

1 Safety

1.7 Safety during maintenance and repair

General

Corrective maintenance must only be carried out by personnel trained on the robot.

Maintenance or repair must be done with all electrical, pneumatic, and hydraulic power switched off, that is, no remaining hazards.

Never use the robot as a ladder, which means, do not climb on the controller, manipulator, including motors, or other parts. There are hazards of slipping and falling. The robot might be damaged.

Make sure that there are no loose screws, turnings, or other unexpected parts remaining after work on the robot has been performed.

When the work is completed, verify that the safety functions are working as intended.

Hot surfaces

Surfaces can be hot after running the robot, and touching these may result in burns. Allow the surfaces to cool down before maintenance or repair.

Hazards related to batteries

Under rated conditions, the electrode materials and liquid electrolyte in the batteries are sealed and not exposed to the outside.

There is a hazard in case of abuse (mechanical, thermal, electrical) which leads to the activation of safety valves and/or the rupture of the battery container. As a result under certain circumstances, electrolyte leakage, electrode materials reaction with moisture/water or battery vent/explosion/fire may follow.

Do not short circuit, recharge, puncture, incinerate, crush, immerse, force discharge or expose to temperatures above the declared operating temperature range of the product. Risk of fire or explosion.

Operating temperatures are listed in [Operating conditions on page 41](#).

See safety instructions for the batteries in *Material/product safety data sheet - Battery pack (3HAC043118-001)*.

Related information

See also the safety information related to installation and operation.

1.8 Safety during troubleshooting

General

When troubleshooting requires work with power switched on, special considerations must be taken:

- Safety circuits might be muted or disconnected.
- Electrical parts must be considered as *live*.
- The manipulator can move unexpectedly at any time.



DANGER

Troubleshooting on the controller while powered on must be performed by personnel trained by ABB or by ABB field engineers.

A risk assessment must be done to address both robot and robot system specific hazards.

Related information

See also the safety information related to installation, operation, maintenance, and repair.

1 Safety

1.9 Safety during decommissioning

General

See section [*Decommissioning on page 563*](#).

If the robot is decommissioned for storage, take extra precaution to reset safety devices to delivery status.

2 Controller description

2.1 OmniCore C30

About OmniCore C30

The OmniCore C30 is one of OmniCore C line compact controllers. The OmniCore C30 controller offers a compact solution suitable for most applications where there is less need for additional equipment inside.

It is used to control an ABB manipulator used in industrial applications such as material handling and machine tending.

In general, the name OmniCore C30 represents all versions.

2 Controller description

2.2 Technical data for OmniCore C30 controller

2.2 Technical data for OmniCore C30 controller


Overview of the controller

Continues on next page

2 Controller description

2.2 Technical data for OmniCore C30 controller

Continued



xx1700001054

Reference to circuit diagram	OmniCore C30	OmniCore C30 for IRB 14050	OmniCore C30 for CRB 15000
Power inlet switch	Q0	Baseline	Baseline
Power inlet connector	X0	Baseline	Baseline
Motor connector	X1	Baseline	Baseline
Manipulator signal connector (SMB)/ Customer flange interface	X2	Baseline	Baseline
Manipulator signal connector (SMB)/ Force control interface	X3	Option	N/A
HMI connector (TPU)	X4	Baseline	Baseline
IP20 DeviceNet	X17	Option	NA
IP20 Power outlet	X45	Option	N/A
Robot signal exchange proxy	K2	Baseline	Baseline
Ethernet switch	K4	Option	Baseline
Scalable I/O	K5.1	Option	Option
Axis computer	K6	Baseline	N/A
Connected Services Gateway (with antenna for 3G and WiFi)	K7	Baseline ⁱ	Option
			Baseline

Not available for CRB 15000 controller.

Only available for CRB 15000 controller.

Continues on next page

2 Controller description

2.2 Technical data for OmniCore C30 controller

Continued

Reference to circuit diagram	OmniCore C30	OmniCore C30 for IRB 14050	OmniCore C30 for CRB 15000
Power supply	T2	Baseline	Baseline
Power supply	T5	Option	N/A
Drive unit	T4	Baseline	Baseline
Power unit	A1	Baseline	Baseline
Main computer	A2	Baseline	Baseline
Standard fan	G1	Baseline	Baseline
Small fan	G2	Baseline	Baseline

i Baseline is 3G. Wired or WiFi available as option.

Dimensions

Parameter	Value
Width	Base version: 449 mm Desktop version: 509 mm
Depth	Base version: 443.5 mm Desktop version: 513.5 mm
Height	Base version: 191 mm (With foot) Base version: 175 mm (Without foot) Desktop version: 193 mm (With foot) Desktop version: 177 mm (Without foot)

Weight

The table shows the weight of the controller.

Controller	Weight
OmniCore C30	25 kg 22 kg ⁱ 18 kg ⁱⁱ

i For IRB 14050 controller.

ii For CRB 15000 controller.



Note

The weight does not include any mounting kits fitted on the controller.

Transportation and storage conditions

Parameter	Value
Minimum ambient temperature	-25°C (-13°F)
Maximum ambient temperature	+55°C (+131°F)
Maximum ambient temperature (less than 24 hrs)	+70°C (+158°F)

Continues on next page

Parameter	Value
Vibration	Max. Grms = 4 m/s ² (X & Y axis), Grms = 12.8 m/s ² (Z axis)
Bumps	Max. 5 g = 50 m/s ² (11 ms)

After storage, the operating conditions inside the controller must be met for at least 6 hours before switching on the controller (see [Operating conditions on page 41](#)).

The robot controller shall only be stored indoors, in an environment that is dry and dust-free. In addition, wind, temperature fluctuations, and condensation shall be avoided.

Operating conditions

The table shows the allowed operating conditions for the controller.

Parameter	Value
Minimum ambient temperature	+5°C (+41°F)
Maximum ambient temperature	+45°C (+113°F)
Maximum ambient altitude	2,000 m
Vibration	Max. Grms = 2.86 m/s ² (X, Y, Z axis)
Bumps	Max. 5 g = 50 m/s ² (11 ms)



Note

The humidity conditions shall apply with the environmental conditions EN 60721-3-3, climatic class 3K3. For temperatures 0-30°C, the relative humidity must not exceed 85%. For temperatures exceeding 30°C, the absolute humidity must not exceed 25g/m³.

If the environmental conditions in EN 60721-3-3, climatic class 3K3, are not possible to meet at the installation site, desiccant bags can be placed inside the controller to achieve corresponding conditions. The desiccant bags must be replaced regularly to maintain approved operating conditions.

Protection classes

	Protection class
Controller cabinet, inner compartment for electronics	IP20
FlexPendant	IP54

Noise emission

Data	Description	Note
Noise emission	The sound pressure level one meter away from each surface of the controller.	< 60 dB(A) Leq

Continues on next page

2 Controller description

2.2 Technical data for OmniCore C30 controller

Continued

Power supply

Mains	Value
Voltage for OmniCore C30	220/230 VAC, 1 phase 100-230 VAC, 1 phase ⁱ
Voltage tolerance	+10%, -15% +10%, -10% ⁱ
Frequency	50/60 Hz
Frequency tolerance	±3%

ⁱ For IRB 14050 controller and CRB 15000 controller.



Note

The 2 phases (180-degree phase shift, with grounded neutral), also called Single-phase three-wire system in North America, can be supported by this controller.

Load current

There is no integrated fuse inside the OmniCore C30 controller. Add an external fuse (time-delay) or circuit breaker (class K) according to full load current, as marked on the controller nameplate. The following table shows the recommended rating for an external fuse or circuit breaker.

Add an external circuit breaker (class K) according to full load current, as marked on the controller nameplate. The following table shows the recommended rating for an external fuse or circuit breaker.

Robot	Current (A)	Description
IRB 1100	220/230 VAC, 1 phase	10 A
IRB 1200	220/230 VAC, 1 phase	10 A
IRB 1300	220/230 VAC, 1 phase	10 A
IRB 910INV	220/230 VAC, 1 phase	10 A
IRB 920	220/230 VAC, 1 phase	10 A
IRB 360	220/230 VAC, 1 phase	10 A
IRB 14050	100-230 VAC, 1 phase	6 A
CRB 1100	220/230 VAC, 1 phase	10 A
CRB 15000	100-230 VAC, 1 phase	16 A in 100 VAC 6 A in 230 VAC

Residual current

An external earth fault protection (residual current device, RCD) is required based on the following data:

Robot	Residual Current in controller (mA)
IRB 1100	< 30 mA
IRB 1200	< 30 mA

Continues on next page

Robot	Residual Current in controller (mA)
IRB 1300	< 30 mA
IRB 910INV	< 30 mA
IRB 920	< 30 mA
IRB 360	< 30 mA
IRB 14050	< 3.5 mA
CRB 1100	< 30 mA
CRB 15000	< 3.5 mA



Note

The integrator is responsible to address local electrical requirements.

2 Controller description

2.3 Safety functions and safety related data for OmniCore C30

2.3 Safety functions and safety related data for OmniCore C30

Basic Safety Functions for OmniCore C30

The safety data is valid for the Basic Safety Functions for applicable ABB manipulators³ except IRB 14050 and CRB 15000, which have their own data detailed separately, see [Basic Safety Functions for IRB 14050, including OmniCore C30 on page 44](#) and [Basic Safety Functions for CRB 15000, including OmniCore C30 on page 45](#).

The OmniCore C30 provides safety with structure *category 3* and performance level *d* according to EN ISO 13849-1. This fulfills the safety performance requirement as stated in the robot safety standard EN ISO 10218-1.

Safety function	MTTF _D [years]	DC [%]	PFH _D [1/hour]
Emergency stop initiated from the emergency stop device on the FlexPendant	127	93	4.29E-08
Emergency stop initiated from the emergency stop input (external emergency stop device is required)	142	92	4.29E-08
Protective stop initiated from the Automatic Stop/General Stop input (external protective stop device is required)	142	92	4.29E-08
Protective stop initiated from the three-position enabling device on the FlexPendant	104	94	4.29E-08
Output reflecting the emergency stop status of the robot	276	80	1.01E-07

Basic Safety Functions for IRB 14050, including OmniCore C30

The robot, IRB 14050 manipulator and OmniCore C30, provides safety with structure *category 3* and performance level *d* according to EN ISO 13849-1⁴. This fulfills the safety performance requirement as stated in the robot safety standard EN ISO 10218-1.

The IRB 14050 manipulator is designed according to inherently safe principles with lightweight manipulator arm and padding to dampen contact force⁴.

Safety function	MTTF _D [years]	DC [%]	PFH _D [1/hour]
Emergency stop initiated from the emergency stop device on the FlexPendant	61	96	1.03E-07
Emergency stop initiated from the emergency stop input (external emergency stop device is required)	64	96	8.84E-08
Protective stop initiated from the Automatic Stop/General Stop input (external protective stop device is required)	64	96	8.84E-08
Cartesian Speed Supervision	23	0	5.19E-06

³ The supported manipulators are listed in *Product specification - OmniCore C line*.

⁴ The Cartesian Speed Supervision has a *category B* with performance level *PL b* after a comprehensive risk assessment, and thus fulfills 5.4.3 *Other control system performance criteria* in EN ISO 10218-1.

Continues on next page

Safety function	MTTF _D [years]	DC [%]	PFH _D [1/hour]
Output reflecting the emergency stop status of the robot	276	80	1.01E-07

Basic Safety Functions for CRB 15000, including OmniCore C30

For details about the performance level for the CRB 15000 robot, see *Product manual - CRB 15000*.

Extended Safety Functions (including SafeMove options)

The safety data is valid for the Extended safety functions for applicable ABB manipulators⁵ except IRB 14050 and CRB 15000, which have their own data detailed separately, see [Extended Safety Functions \(including SafeMove options\) - OmniCore C30 for IRB 14050 on page 45](#) and [Extended Safety Functions \(including SafeMove options\) - OmniCore C30 for CRB 15000 on page 46](#).

Extended Safety Functions (including SafeMove options)	MTTF _D [years]	DC _{avg} [%]	PFH _D [1/hour]
Safe Brake Ramp	144	90	4.29E-08
Stand Still Supervision (SST)	144	90	4.29E-08
Axis Speed Supervision (ASP)	144	90	4.29E-08
Tool Speed Supervision (TSP)	144	90	4.29E-08
Axis Position Supervision (APO)	144	90	4.29E-08
Tool Position Supervision (TPO)	144	90	4.29E-08
Tool Orientation Supervision (TOR)	144	90	4.29E-08
Control Error Supervision	144	90	4.29E-08

Extended Safety Functions (including SafeMove options) - OmniCore C30 for IRB 14050

Extended Safety Functions (including SafeMove options)	MTTF _D [years]	DC _{avg} [%]	PFH _D [1/hour]
Contact Application Tolerance (CAP)	370	73	1.01E-07
Safe Brake Ramp	64	95	8.84E-08
Stand Still Supervision (SST)	64	95	8.84E-08
Axis Speed Supervision (ASP) (category 0 stop/category 1 stop)	64	95	8.84E-08
Tool Speed Supervision (TSP) (category 0 stop/category 1 stop)	64	95	8.84E-08
Axis Position Supervision (APO) (category 0 stop/category 1 stop)	64	95	8.84E-08
Tool Position Supervision (TPO) (category 0 stop/category 1 stop)	64	95	8.84E-08
Tool Orientation Supervision (TOR) (category 0 stop/category 1 stop)	64	95	8.84E-08
Control Error Supervision	64	95	8.84E-08

⁵ The supported manipulators are listed in *Product specification - OmniCore C line*.

Continues on next page

2 Controller description

2.3 Safety functions and safety related data for OmniCore C30

Continued

Extended Safety Functions (including SafeMove options) - OmniCore C30 for CRB 15000

For details about the safety data for the SafeMove function for the CRB 15000 robot, see *Product manual - CRB 15000*.

Related information

[Safety data on page 16](#)

2.4 The unit is sensitive to ESD

Description

ESD (electrostatic discharge) is the transfer of electrical static charge between two bodies at different potentials, either through direct contact or through an induced electrical field. When handling parts or their containers, personnel not grounded may potentially transfer high static charges. This discharge may destroy sensitive electronics.


Safe handling

Use one of the following alternatives:

- Use a wrist strap. The wrist strap button is located inside the controller.
Wrist straps must be tested frequently to ensure that they are not damaged and are operating correctly.
- Use an ESD protective floor mat.
The mat must be grounded through a current-limiting resistor.
- Use a dissipative table mat.
The mat should provide a controlled discharge of static voltages and must be grounded.

Wrist strap button

The location of the wrist strap button is shown in the following illustration.



There is an additional wrist strap button on the main computer.

2 Controller description

2.5 Handling of FlexPendant

2.5 Handling of FlexPendant

Detached FlexPendant

A FlexPendant that is not connected to the robot must be stored out of sight so that it cannot be mistaken for being in use.

Handling and cleaning

- The FlexPendant may only be used for the purposes mentioned in this manual.
- Always use the hand-strap while holding the FlexPendant.
- Handle with care. Do not drop, throw, or give the FlexPendant strong shock. It can cause breakage or failure.
- If the FlexPendant is subjected to shock, always verify that the safety functions (three-position enabling device and emergency stop) work and are not damaged.
- Always use and store the FlexPendant in such a way that the cable does not become a tripping hazard.
- When not using the device, place it in its holder.
- Never use sharp objects (such as screwdriver or pen) for operating the touch screen. This could damage the touch screen. Instead use your finger or a stylus.
- Never clean the FlexPendant with solvents, scouring agent, or scrubbing sponges.

See the product manual for the robot controller, section *Cleaning the FlexPendant*.

- Always close the protective cap on the USB port when no USB device is connected. The port can break or malfunction if exposed to dirt or dust.
- Do not squeeze and thus damage the cable.
- Do not lay the cable over sharp edges.



CAUTION

The FlexPendant touch screen is made of glass. If the device is dropped on a hard surface or receives a significant impact the glass could break. To reduce the risk of cuts if the glass chips or cracks, do not touch or attempt to remove the broken glass.

2.6 Network security

Network security

This product is designed to be connected to and to communicate information and data via a network interface. It is your sole responsibility to provide, and continuously ensure, a secure connection between the product and to your network or any other network (as the case may be).

You shall establish and maintain any appropriate measures (such as, but not limited to, the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB Ltd and its entities are not liable for damage and/or loss related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

2 Controller description

2.7 Open source and 3rd party components in RobotWare

2.7 Open source and 3rd party components in RobotWare

Open source and 3rd party components in RobotWare

ABB products use software provided by third parties, including open source software. The following copyright statements and licenses apply to various components that are distributed inside the ABB software. Each ABB product does not necessarily use all of the listed third party software components. Licensee must fully agree and comply with these license terms or the user is not entitled to use the product. Start using the ABB software means accepting also referred license terms. The third party license terms apply only to the respective software to which the license pertains, and the third party license terms do not apply to ABB products. With regard to programs provided under the GNU general public license and the GNU lesser general public license licensor will provide licensee on demand, a machine-readable copy of the corresponding source code. This offer is valid for a period of three years after delivery of the product.

ABB software is licensed under the ABB end user license agreement, which is provided separately.

For RobotWare, there is license information in the folder \licenses in the RobotWare distribution package.

For OleOS, the Linux based operating system used on the conveyor tracking module (CTM), a list of copyright statements and licenses is available in the file /etc/licenses.txt located on the CTM board and accessible via the console port or by downloading the file over SFTP.

For the CTM application, a list of copyright statements and licenses is available in the file /opt/ABB.com/ctm/licenses.txt located on the CTM board and accessible via the console port or by downloading the file over SFTP.

2.8 ABB Ability



Note

The content of this section is only available in English.

The OmniCore™ controller hardware is delivered with a standard mobile connection (Cellular data connection), or WIFI modem and/or Ethernet connection.

Cellular data connection

If the ABB Ability™ OmniCore™ controller hardware is delivered together with a standard, free of charge (machine-to-machine or M2M) cellular data connection, it will automatically establish a connection to the ABB Ability™ digital platform once the power switch of the ABB Ability™ OmniCore™ controller hardware has been turned on and has been connected. After the establishment of the connection there will be a data flow from the OmniCore™ controller hardware to the ABB Ability™ digital platform.

ABB does not warrant or guarantee an available, stable, uninterrupted, and interference free connection through the standard cellular data connection. This is dependent on the availability and quality of the cellular data signal as provided by the telecommunications carrier on the location where the ABB Ability™ OmniCore™ hardware is installed. The cellular data connection is to be used solely in connection with the ABB Ability™ OmniCore™ controller hardware and excludes, without limitation, voice services, web browsing, music downloading and other services that are not traditionally considered as machine to machine (M2M), but human-oriented telecommunication services.

ABB has established and maintains a formal information and cybersecurity procedures which includes commercially reasonable technical and organizational measures, in order to protect the data against security breaches, accidental or unlawful destruction, loss, alteration, and unauthorized disclosure of, or access to the data.

The cellular data connection is not required for the operation of the hardware and the connectivity settings can be adjusted and turned off at any given time. Detailed information on the mobile connection is further described in the service description that can be downloaded from the following web location:

<https://share.library.abb.com/api/v4?cid=9AAC910011&dk=Manual>

Continues on next page

2 Controller description

2.8 ABB Ability

Continued

Data

ABB will not acquire any right, title and interest in the data other than the rights granted by Customer to ABB, but ABB will have the right to collect, store, aggregate, analyze or otherwise use the data for (i) providing and maintaining the hardware, services and/or the ABB software to Customer; (ii) preventing, detecting and repairing problems related to the security and/or the operation of the hardware, the platform, software; (iii) improving and developing existing services, technologies, products and/or software and developing new services, technologies, products and/or software, and all improvements and developments (including all resulting intellectual property Rights) are exclusively owned by us. In addition, we have the right to use the data for benchmarking purposes if and to the extent it is anonymized or non-confidential.

ABB Ability™ Connected Services

For as far as the robot installation includes ABB Ability™ Connected Services, this agreement is entered pursuant to and governed by the ABB Ability™ General Terms and Conditions.

ABB Ability™ Terms and Conditions:

<https://ability.abb.com/terms>

Special Terms and Conditions for ABB Ability™ Connected Services:

<https://new.abb.com/products/robotics/service/robot-registration>

3 Installation and commissioning

3.1 Introduction to installation and commissioning

General

This chapter contains assembly instructions and information for installing the OmniCore C30 at the working site.

See also the product manual for the manipulator.

The installation must be done by qualified installation personnel in accordance with the safety requirements set forth in the applicable national and regional standards and regulations.

Safety information

Before any installation work is commenced, all safety information must be observed.

There are general safety aspects that must be read through, as well as more specific safety information that describes the danger and safety risks when performing the procedures. Read the chapter [Safety on page 15](#) before performing any installation work.



Note

Always connect the OmniCore C30 and the robot to protective earth and residual current device (RCD) before connecting to power and starting any installation work.

3 Installation and commissioning

3.2 Installation activities

3.2 Installation activities

Main steps for installing the controller

Use the following main steps to install and connect the controller.

	Action	Described in
1	Unpack the controller.	Unpacking the controller on page 55.
2	Place the controller in position and bolt it to the ground.	On-site installation on page 57.
3	Connect the manipulator to the controller.	Connecting the manipulator to the controller on page 91.
4	Attach the FlexPendant to the controller.	Attaching the FlexPendant on page 103
5	Install an external circuit breaker or fuse.	Connecting power supply to and grounding the controller on page 97.
6	Connect the cabinet to protective earth.	Connecting power supply to and grounding the controller on page 97.
7	Install a residual current device (RCD).	Connecting power supply to and grounding the controller on page 97.
8	Connect incoming mains to the controller.	Connecting power supply to and grounding the controller on page 97.
9	Connect safeguards to the controller.	Connector X14 on page 112.
10	Connect, for example, Ethernet, PC, and other connections.	How to connect industrial networks, for example PROFINET, is described in the respective application manual. How to connect to a network and a PC is described in section Ethernet networks on OmniCore on page 104 . See also Operating manual - RobotStudio . See also Descriptions for connectors on page 112 .
11	Install options and add-ons (optional).	Installing options on page 136. Installing add-on devices on page 194.
12	Initial test before commissioning.	Initial test before commissioning on page 200.

3.3 Transporting and handling

3.3.1 Unpacking

Unpacking the controller



Note

If the desktop mounting kit is mounted to the controller, do not hold the TPU connector (X4) during any moving or transporting of the controller.

	Action
1	Make a visual inspection of the packaging and make sure that nothing is damaged.
2	Remove the packaging.
3	Check for any visible transport damage. Note Stop unpacking and contact ABB if transport damage is found.
4	Clean the unit with a lint-free cloth, if necessary.
5	Make sure that the lifting accessory used (if applicable) is suitable to handle the weight of the controller.
6	If the controller is not installed directly, it must be stored as described in Transportation and storage conditions on page 40 .
7	Make sure that the expected operating environment of the controller conforms to the specifications as described in Operating conditions on page 41 .
8	The controller can be taken to its installation site as described in section On-site installation on page 57 .

3 Installation and commissioning

3.3.2 Storing

3.3.2 Storing

Storing the controller

For storing, see [*Transportation and storage conditions on page 40.*](#)


3.4 On-site installation

3.4.1 Required installation space

Dimensions

The following illustration shows the required installation space for the OmniCore C30 controller. A free space is required for connecting ABB cables. Do not place any cables over the left and right covers (top cover for the vertical-mounted version) as it leads to inefficient cooling.

Base-mounted and Rack-mounted version



xx1700001055

Free space	Front	Back	Left	Right
Base-mounted	150 mm	50 mm	50 mm	50 mm
Rack-mounted	150 mm	50 mm	50 mm	50 mm


Continues on next page

3 Installation and commissioning

3.4.1 Required installation space

Continued

Vertical-mounted version




xx2000002144

Free space	Front	Back	Top	Left	Right
Vertical-mounted	150 mm	0 mm	50 mm	50 mm	50 mm


Continues on next page

The installation dimension on the back of the vertical mounted version is shown as below. M8 screw is suggested to use when secure the vertical-mounted version.



xx2000002216

Desktop-mounted version



xx2000002143

Free space	Front	Back	Left	Right
Desktop-mounted	150 mm	150 mm	50 mm	50 mm

Continues on next page


3 Installation and commissioning

3.4.1 Required installation space

Continued

Foot dimensions

The following illustration shows the dimensions between the feet of the OmniCore C30 controller, as seen from below.



xx1700001056


- The feet should only be used for positioning, not for mounting or fastening.

3.4.2 Mounting the controller with 19" rack mounting kit [3002-1]

3.4.2 Mounting the controller with 19" rack mounting kit [3002-1]

General

The OmniCore C30 controller is designed to fit in a 19" cabinet.



xx1700001065



Note

If the controller is installed in a rack (cabinet), it must be fastened in a way that prevents distortion of the controller cabinet. Preferably with angle bars along the entire side edges of the controller.



Note

If the 19" rack mounting kit and vertical mounting kit are purchased at the same time, the controller will be mounted with vertical mounting kit when delivered to the customer from ABB. The 19" rack mounting kit will be delivered as a spare part at the same time.

For detail information on replacing the vertical mounting kit to 19" rack mounting kit, see [Replacing the controller from vertical mounting kit to 19" rack mounting kit on page 68](#).

Required equipment

Equipment	Information
Mounting kit	3HAC063918-001

Continues on next page

3 Installation and commissioning



3.4.2 Mounting the controller with 19" rack mounting kit [3002-1]

Continued

Equipment	Information
Standard toolkit	See Standard toolkit for controller on page 570 .

Installing the 19" rack mounting kit to the controller

Use this procedure to install the controller in a 19" cabinet.


Action	Information								
1 Remove the screws on the front panel and the five feet from the bottom.	 xx1700001885								
2 Assemble the front and the back mounting kit.	 xx1700001883 <table border="1"><tr><td>A</td><td>Front mounting kit</td></tr><tr><td>B</td><td>Back mounting kit</td></tr><tr><td>C</td><td>Torx pan head screw M4x12 (4 pcs) Tightening torque: 1.7-1.8 Nm</td></tr><tr><td>D</td><td>Torx countersunk screw M4x10 (5 pcs) Tightening torque: 1.7-1.8 Nm</td></tr></table>	A	Front mounting kit	B	Back mounting kit	C	Torx pan head screw M4x12 (4 pcs) Tightening torque: 1.7-1.8 Nm	D	Torx countersunk screw M4x10 (5 pcs) Tightening torque: 1.7-1.8 Nm
A	Front mounting kit								
B	Back mounting kit								
C	Torx pan head screw M4x12 (4 pcs) Tightening torque: 1.7-1.8 Nm								
D	Torx countersunk screw M4x10 (5 pcs) Tightening torque: 1.7-1.8 Nm								

Continues on next page

3 Installation and commissioning

3.4.2 Mounting the controller with 19" rack mounting kit [3002-1]

Continued


	Action	Information
3	Place the controller into the 19" cabinet and fasten it with the screws.	 xx1700001884 Torx pan head screw M6x16 (4 pcs) Tightening torque: 1.7-1.8 Nm
4	Connect the antenna for Connected Services Gateway (3G or WiFi).	The antenna is preferably placed on top of the cabinet.  Note For best performance in a closed cabinet, use the option <i>Connected Services Gateway wired</i> (DSQC1041) with external Internet gateway.

3 Installation and commissioning

3.4.3 Mounting the controller with vertical mounting kit [3002-2]

General

The OmniCore C30 controller is designed to fit with a vertical mounting kit.



Note

The side with the fans should be downward when installing the controller in vertical position.



Note

If the 19" rack mounting kit and vertical mounting kit are purchased at the same time, the controller will be mounted with vertical mounting kit when delivered to the customer from ABB. The 19" rack mounting kit will be delivered as a spare part at the same time.

For detail information on replacing the vertical mounting kit to 19" rack mounting kit, see [Replacing the controller from vertical mounting kit to 19" rack mounting kit on page 68](#).

Required equipment

Equipment	Information
Mounting kit	3HAC063920-001
Standard toolkit	See Standard toolkit for controller on page 570 .

Continues on next page




3 Installation and commissioning

3.4.3 Mounting the controller with vertical mounting kit [3002-2]

Continued

Installing the vertical mounting kit to the controller

Use this procedure to install the controller in vertical position.



Action	Info/illustration				
1 Remove the left side cover screws.  Note The left side is the side without fans.	 xx1800000378				
2 Install the side cover unit.	 xx1800000379 <table border="1"><tr><td>A</td><td>Side cover unit</td></tr><tr><td>B</td><td>Torx counterink screw M4x10 (6 pcs) Tightening torque: 1.7-1.8 Nm</td></tr></table>	A	Side cover unit	B	Torx counterink screw M4x10 (6 pcs) Tightening torque: 1.7-1.8 Nm
A	Side cover unit				
B	Torx counterink screw M4x10 (6 pcs) Tightening torque: 1.7-1.8 Nm				
3 Remove the screws on the back.	 xx1800000380				

Continues on next page

3 Installation and commissioning

3.4.3 Mounting the controller with vertical mounting kit [3002-2]

Continued

Action	Info/illustration
4 Install the back hanging bracket.	 <p>A Back hanging bracket B Torx countersunk screw M4x10 (6 pcs) Tightening torque: 1.7-1.8 Nm</p>
5 Remove the right side cover screws.  Note The right side is the side with fans.	

Continues on next page

3 Installation and commissioning

3.4.3 Mounting the controller with vertical mounting kit [3002-2]

Continued

Action	Info/illustration				
6 Install the support foot units.	 xx1800000458 <table border="1"><tr><td>A</td><td>Support foot unit, 2 pcs</td></tr><tr><td>B</td><td>Torx countersunk screw M4x10 (4 pcs) Tightening torque: 1.7-1.8 Nm</td></tr></table>	A	Support foot unit, 2 pcs	B	Torx countersunk screw M4x10 (4 pcs) Tightening torque: 1.7-1.8 Nm
A	Support foot unit, 2 pcs				
B	Torx countersunk screw M4x10 (4 pcs) Tightening torque: 1.7-1.8 Nm				
7 Remove the five feet on the bottom.	 xx1800000462 <p>Torx countersunk screw M4x10 (5 pcs) Tightening torque: 1.7-1.8 Nm</p>				
8 Connect the antenna for Connected Services Gateway (3G or WiFi).	The antenna can be placed on top of the controller.				

3 Installation and commissioning

3.4.4 Replacing the controller from vertical mounting kit to 19" rack mounting kit

3.4.4 Replacing the controller from vertical mounting kit to 19" rack mounting kit

General


If the 19" rack mounting kit and vertical mounting kit are purchased at the same time, the controller will be mounted with vertical mounting kit when delivered to the customer from ABB. The vertical mounting kit can be removed and replaced with the 19" rack mounting kit.

Required equipment

Equipment	Information
Mounting kit	3HAC063918-001
Standard toolkit	See Standard toolkit for controller on page 570 .

Removing the vertical mounting kit

Use this procedure to remove the vertical mounting kit from the controller.



Action	Info/illustration				
1 Remove the screws.					
2 Remove the support foot units.					
3 Refit the screws.	 <p>xx1800000458</p> <table border="1"><tr><td>A</td><td>Support foot unit, 2 pcs</td></tr><tr><td>B</td><td>Torx countersunk screw M4x10 (4 pcs) Tightening torque: 1.7-1.8 Nm</td></tr></table>	A	Support foot unit, 2 pcs	B	Torx countersunk screw M4x10 (4 pcs) Tightening torque: 1.7-1.8 Nm
A	Support foot unit, 2 pcs				
B	Torx countersunk screw M4x10 (4 pcs) Tightening torque: 1.7-1.8 Nm				

Continues on next page

3 Installation and commissioning


3.4.4 Replacing the controller from vertical mounting kit to 19" rack mounting kit

Continued

Action	Info/illustration				
4 Remove the screws.					
5 Remove the back hanging bracket.					
6 Refit the screws.	 <p>xx1800000381</p> <table border="1"> <tr> <td>A</td> <td>Back hanging bracket</td> </tr> <tr> <td>B</td> <td>Torx countersunk screw M4x10 (6 pcs) Tightening torque: 1.7-1.8 Nm</td> </tr> </table>	A	Back hanging bracket	B	Torx countersunk screw M4x10 (6 pcs) Tightening torque: 1.7-1.8 Nm
A	Back hanging bracket				
B	Torx countersunk screw M4x10 (6 pcs) Tightening torque: 1.7-1.8 Nm				
7 Remove the screws.					
8 Remove the side cover unit.					
9 Refit the screws.	 <p>xx1800000379</p> <table border="1"> <tr> <td>A</td> <td>Side cover unit</td> </tr> <tr> <td>B</td> <td>Torx counterink screw M4x16 (6 pcs) Tightening torque: 1.7-1.8 Nm</td> </tr> </table>	A	Side cover unit	B	Torx counterink screw M4x16 (6 pcs) Tightening torque: 1.7-1.8 Nm
A	Side cover unit				
B	Torx counterink screw M4x16 (6 pcs) Tightening torque: 1.7-1.8 Nm				

Installing the 19" rack mounting kit

Use this procedure to install the controller in a 19" cabinet.



Action	Information
1 Remove the screws on the front panel.	 <p>xx2100000137</p>

Continues on next page

3 Installation and commissioning

3.4.4 Replacing the controller from vertical mounting kit to 19" rack mounting kit


Continued

Action	Information								
2 Assemble the front and the back mounting kit.	 <p>xx1700001883</p> <table border="1"> <tr> <td>A</td> <td>Front mounting kit</td> </tr> <tr> <td>B</td> <td>Back mounting kit</td> </tr> <tr> <td>C</td> <td>Torx pan head screw M4x12 (4 pcs) Tightening torque: 1.7-1.8 Nm</td> </tr> <tr> <td>D</td> <td>Torx countersunk screw M4x10 (5 pcs) Tightening torque: 1.7-1.8 Nm</td> </tr> </table>	A	Front mounting kit	B	Back mounting kit	C	Torx pan head screw M4x12 (4 pcs) Tightening torque: 1.7-1.8 Nm	D	Torx countersunk screw M4x10 (5 pcs) Tightening torque: 1.7-1.8 Nm
A	Front mounting kit								
B	Back mounting kit								
C	Torx pan head screw M4x12 (4 pcs) Tightening torque: 1.7-1.8 Nm								
D	Torx countersunk screw M4x10 (5 pcs) Tightening torque: 1.7-1.8 Nm								
3 Place the controller into the 19" cabinet and fasten it with the screws.	 <p>xx1700001884</p> <p>Torx pan head screw M6x16 (4 pcs) Tightening torque: 1.7-1.8 Nm</p>								
4 Connect the antenna for Connected Services Gateway (3G or WiFi).	<p>The antenna is preferably placed on top of the cabinet.</p> <p> Note</p> <p>For best performance in a closed cabinet, use the option <i>Connected Services Gateway wired</i> (DSQC1041) with external Internet gateway.</p>								

3.4.5 Mounting the controller with desktop mounting kit [3001-2]

General

The OmniCore C30 controller is designed to fit as a desk version, that can have a desktop mounting kit.



xx1700001887



Note


If the desktop mounting kit is mounted to the controller, do not hold the TPU connector (X4) during any moving or transporting of the controller.

Required equipment

Equipment	Information
Mounting kit	3HAC063919-001
Standard toolkit	See Standard toolkit for controller on page 570 .

Procedure

Use this procedure to install the desktop mounting kit on the controller.


	Action	Info/illustration
1	Remove the top cover from the controller.	 xx170000735

Continues on next page

3 Installation and commissioning

3.4.5 Mounting the controller with desktop mounting kit [3001-2]

Continued




Action	Info/illustration										
2 Assemble the desktop mounting kit top cover.	 <p>xx1800000377</p>										
3 Assemble the side covers with adapter cables and fasten them with screws on the top.	<table border="1"><tr><td>A</td><td>Desktop mounting kit top cover</td></tr><tr><td>B</td><td>Left side cover unit</td></tr><tr><td>C</td><td>Right side cover unit</td></tr><tr><td>D</td><td>Torx countersunk screw M3x6 (6 pcs) Tightening torque: 0.6-0.8 Nm</td></tr><tr><td>E</td><td>Torx countersunk screw M4x10 (8 pcs) Tightening torque: 1.7-1.8 Nm</td></tr></table>	A	Desktop mounting kit top cover	B	Left side cover unit	C	Right side cover unit	D	Torx countersunk screw M3x6 (6 pcs) Tightening torque: 0.6-0.8 Nm	E	Torx countersunk screw M4x10 (8 pcs) Tightening torque: 1.7-1.8 Nm
A	Desktop mounting kit top cover										
B	Left side cover unit										
C	Right side cover unit										
D	Torx countersunk screw M3x6 (6 pcs) Tightening torque: 0.6-0.8 Nm										
E	Torx countersunk screw M4x10 (8 pcs) Tightening torque: 1.7-1.8 Nm										

Continues on next page

3 Installation and commissioning

3.4.5 Mounting the controller with desktop mounting kit [3001-2]

Continued

Action	Info/illustration
<p>4 Place the controller upright and install the right and left cover unit. Lock them with screws on the bottom side and connect the cables.</p> <ul style="list-style-type: none"> • K2.X15.3 • K2.X15.4 • X4 <p>Note</p> <p>Do not hold the TPU connector (X4) during any moving or transporting of the controller.</p> <ul style="list-style-type: none"> • MGMT 	 <p>xx1800000459</p> <p>Torx countersunk screw M3x6 (6 pcs) Tightening torque: 0.6-0.8 Nm</p>  <p>xx1800000460</p>
<p>5 Keep the controller upright. Connect the adapter cables to the front cover unit, and install the front cover unit.</p>	 <p>xx1800000461</p>
<p>6 Connect the antenna for Connected Services Gateway (3G or WiFi).</p>	<p>The antenna can be placed on top of the controller.</p>

Continues on next page

3 Installation and commissioning

3.4.5 Mounting the controller with desktop mounting kit [3001-2]

Continued

	Action	Info/illustration
7	Place the controller in desired place.	

3.4.6 Mounting the FlexPendant holder



Note

To avoid dropping the FlexPendant from height, the holder should be placed in a comfortable working height.

Always use and store the FlexPendant in such a way that the cable does not become a tripping hazard.

When not using the device, place it so it does not accidentally fall.

Required equipment

Equipment	Spare part number	Note
Standard toolkit		See Standard toolkit for controller on page 570 .
FlexPendant Holder w/t E-stop cover	3HAC064927-001	



Note

The FlexPendant should always be placed in the holder when it is not used and it is not allowed to use by unauthorized person.

Continues on next page


3 Installation and commissioning

3.4.6 Mounting the FlexPendant holder

Continued

Mounting the bracket for the emergency stop on the FlexPendant holder

The FlexPendant holder is shipped without the bracket for the emergency stop assembled to the holder. They are separated as two parts.



xx2100000767

Use this procedure to mount the bracket for the emergency stop to the FlexPendant holder.


	Action	Note/illustration
1	Remove the four screws.	
2	Separate the rear part from the FlexPendant holder.	 <p>xx2000002356</p>

Continues on next page

3 Installation and commissioning

3.4.6 Mounting the FlexPendant holder

Continued

Action	Note/illustration
3	<p>Insert the bracket into the FlexPendant holder.</p>  <p>xx2100000765</p>
4	<p>Secure with the screws.</p> <p>Screws: BN33 Phillips pan head tapping screw ST2.9x13 (3 pcs) Tightening torque: 6 Nm-7.8 Nm</p>  <p>xx2100000766</p>
5	<p>Refit the rear part and secure with the screws.</p> <p>Screws: BN33 Phillips pan head tapping screw ST3.5x16 (4 pcs) Tightening torque: 9.4 Nm-12.2 Nm</p>  <p>xx2000002356</p>

Continues on next page


3 Installation and commissioning

3.4.6 Mounting the FlexPendant holder

Continued

Mounting the FlexPendant holder onto a flat surface (Horizontally)

Use this procedure to mount the FlexPendant holder onto a flat surface, like the top of the controller or a desktop.

	Action	Note/illustration
1	Clean the surface and make sure it is dry.	
2	Remove the protective liner from the tape.	 xx2000002352
3	Press the holder onto the desired place.	 xx2000002353

Hanging the FlexPendant holder with the bracket

Use this procedure to hang the FlexPendant holder on any place where can hold the bracket, like the door of the equipment.



Tip



The bracket is included when the FlexPendant is purchased.

Continues on next page

3 Installation and commissioning

3.4.6 Mounting the FlexPendant holder

Continued

Action	Note/illustration
1 Hang the FlexPendant holder to the bracket according to the screws on the bracket.	 xx2000002354
2 Hang the holder with the bracket to the desired place.	 xx2000002355

Hanging the front part of the FlexPendant holder with screws (Vertically)

Use this procedure to hang the front part of the FlexPendant holder to the desired place.



Action	Note/illustration
1 Remove the four screws.	
2 Separate the rear part from the FlexPendant holder.	 xx2000002356
3 Clean the surface and make sure it is dry.	

Continues on next page

3 Installation and commissioning

3.4.6 Mounting the FlexPendant holder

Continued

Action	Note/illustration
4 Remove the protective liner from the tape.	 xx2000002357
5 Press the holder onto the desired place.	
6 Use two M5 screws to secure the holder.	 xx2000002358

3.4.7 Changing the fan control functionality

General

The cooling fan on OmniCore C30 controllers will work on reduced speed or shut off while the controller is in motors off state to lower the sound level. This is called fan control functionality.

The fan will run with full cooling capacity when the controller is in motors on state. When changing to motors off, the fan will shut off if the temperature on the incoming air is low enough, or run in reduced speed if the temperature is too high.

When the controller state is changed to motors off, the fan will shut off after 60 seconds if the temperature on the incoming air is low enough. If the temperature is too high, then the fan will continue at reduced capacity until the temperature is low enough and then turn off the fan.

Changing the fan control functionality

Use this procedure to change the fan control functionality.

	Action	Note
1	Open the configuration editor in RobotStudio.	
2	In the topic Controller, navigate to the type Fan Control.	
3	Set the parameter <i>Turn off fan</i> to <i>NO</i> if the fan should not shut off in motors off state. The default setting is <i>YES</i> .	For more information about system parameters, see <i>Technical reference manual - System parameters</i>

3 Installation and commissioning

3.5.1 Connectors on the OmniCore C30 controller

3.5 Electrical connections

3.5.1 Connectors on the OmniCore C30 controller

General

The following section describes the connectors on the front panel of the OmniCore C30 controller.




CAUTION

Always inspect connectors for dirt or damage before connecting them to the controller. Clean or replace any damaged parts.

Connectors

The following illustration shows the connection interface on the controller.



xx1700001058

	Description	Label	Reference on the circuit diagram
A	Motor connector	X1	X1
B	FlexPendant connector (TPU)	X4	X4
C	Manipulator signal connector (SMB) ⁱ / Customer flange interface(CFI) connector ⁱⁱ	X2	X2
D	Manipulator signal connector (SMB)/ Force control interface (option)	X3	X3

Continues on next page

3 Installation and commissioning

3.5.1 Connectors on the OmniCore C30 controller

Continued

	Description	Label	Reference on the circuit diagram
E	Scalable I/O connection	I/O	K5.1
F	Robot signal exchange proxy, customer interface connection	X14/X15/X19/X20	K2-X14, K2-X15, K2-X19, K2-X20
G	Ethernet switch connection	ETHERNET SWITCH	K4
H	Power inlet switch	Q0	Q0
J	Power inlet connector	X0	X0
K	IP20 DeviceNet connector	X17	X17
L	IP20 power outlet connector	X45	X45
M	Connected Services Gateway, with Ability port (option wired) or antenna connector (options 3G or WiFi)	ABB Ability™	K7
N	WAN port	WAN	A2-X23
P	LAN port	LAN	A2-X2
Q	Management port	MGMT	A2-X3

i Not available for CRB 15000 controller.

ii Only available for CRB 15000 controller.

Power inlet switch

Use the power inlet switch to turn on and off power to the controller. It is also possible to restart the controller using the FlexPendant.



Note

When restarting the controller, wait until the LED PC STAT has turned off before turning on power again.

Continues on next page



3 Installation and commissioning

3.5.1 Connectors on the OmniCore C30 controller

Continued

Safety lock for power inlet switch

The following illustration shows the location of the safety lock for the power inlet switch.



Height when open (H)	$\leq 30 \text{ mm}$
Height when locked (H1)	$\leq 24 \text{ mm}$
Diameter (D)	4.0 mm - 4.8 mm (5/32"-6/32")

3.5.2 Connecting cables to the controller

General

A good and proper electrical installation of the robot system is necessary to ensure the best performance and prolong the lifetime of the whole robot system.

This section includes important information on how to connect cables and signals to the controller.

Signal classes

Different rules apply to the different classes when selecting and laying cables. Signals from different classes must not be mixed.

Signal class	Description
Power signals Class 4 (noisy)	Supplies external motors and brakes. Applies to the cables associated with the power inputs and outputs of variable speed drives. Cables carrying strongly interfering signals such as motor cables, DC-link load sharing, unsuppressed inductive loads, DC motors, welding equipment, etc.
Control signals Class 3 (slightly noisy)	Digital operating and data signals (digital I/O, protective stop, etc.). Applies to cables carrying slightly interfering signals: AC power supply (<1 kV), DC power (24 V), power to equipment with RFI/EMI filters, control circuits with resistive or suppressed inductive loads (such as contactors and solenoids), direct-on-line induction motors, etc.
Measurement signals Class 2 (slightly sensitive)	Analog measurement and control signals (resolver and analog I/O). This class covers ordinary analogue signals such as analogue signals (4-20 mA, 0-10V, or signals below 1 MHz), low-speed digital signals (RS232, RS485), digital (on/off) signals, limit switches, encoders, etc.
Data communication signals Class 1 (sensitive)	Gateway (fieldbus) connection, computer link. Applies to cables carrying very sensitive signals. Signals with a full-scale range less than 1 V or 1 mA, and/or a source impedance >1 kOhm, and/or a signal frequency >1 Mhz. For example high-speed digital communication (Ethernet), thermocouples, thermistors, strain gauges and flowmeters.

Selecting cables

All cables laid in the control cabinet must be capable of withstanding 70°C. In addition, the following rules apply to the cables of certain signal classes:

Signal class	Cable type
Power signals	Shielded cable with an area of at least 0.75 mm ² or AWG 18.
Control signals	Shielded cable.
Measurement signals	Shielded cable with twisted pair conductors.
Data communication signals	Shielded cable with twisted pair conductors. A specific cable should be used for field bus connections and Ethernet, according to the standard specification of the respective bus.

Continues on next page

3 Installation and commissioning

3.5.2 Connecting cables to the controller

Continued



Note

Any local standards and regulations concerning insulation and area must always be complied with.

AC current in CP/CS

For specific applications where the correct cable dimensioning can depend on the relationship between the period of the duty cycle and the thermal time constant of the cable (for example, starting against high-inertia load, intermittent duty), the cable manufacturer can provide information.

Country specific norms have to be included.

The wire is not dimensioned to take care of starting motors or transformers.

The following table shows how much AC current can be supplied with a specific temperature, and the wire size.

Wire size (mm ² //AWG)	AC current			
	40°C//104F	45°C//113F	50°C//122F	52°C//125.6F
Single wire 0.2//24	4.5	4.1	3.7	3.2
Multi wire 2 pair 0.2//24	3.6	3.3	3.0	2.6
Multi wire 4 pair 0.2//24	2.9	2.7	2.4	2.1
Multi wire 6 pair 0.2//24	2.6	2.3	2.1	1.8
Multi wire 9 pair 0.2//24	2.3	2.0	1.8	1.6
Single wire 0.5//20	7.9	7.2	6.5	5.6
Multi wire 2 pair 0.5//20	6.3	5.8	5.2	4.5
Multi wire 4 pair 0.5//20	5.1	4.7	4.2	3.6
Multi wire 6 pair 0.5//20	4.5	4.1	3.7	3.2
Multi wire 9 pair 0.5//20	4.0	3.6	3.2	2.8
Single wire 0.75//18	9.5	8.6	7.8	6.7
Multi wire 2 pair 0.75//18	7.6	6.9	6.2	5.4
Multi wire 4 pair 0.75//18	6.2	5.6	5.1	4.4
Multi wire 6 pair 0.75//18	5.4	4.9	4.4	3.8
Multi wire 9 pair 0.75//18	4.8	4.3	3.9	3.4
Single wire 1.0//17	11.0	10.0	9.0	7.8
Multi wire 2 pair 1.0//17	8.8	8.0	7.2	6.2
Multi wire 4 pair 1.0//17	7.2	6.5	5.9	5.1
Multi wire 6 pair 1.0//17	6.3	5.7	5.1	4.5
Multi wire 9 pair 1.0//17	5.5	5.0	4.5	3.9
0.75//18 three phase	8.6	7.8	7.1	5.6
1.0//17 three phase	10.3	9.4	8.4	6.7

Continues on next page

Route the cables

Routing of cables shall be done in a professional way.

- Cables of different classes, such as signal cables and power cables, must not be routed together as the power cables may introduce noise in the signal cables. The greater the separation distance, the lesser the risk for interference between the cables.
- Robot controller mains supply input cable and robot power cable should be separated even though they belong to the same class.
- If crossing cables from different classes, cables should cross at an angle close to 90 degrees.
- All external cables that are to be connected inside the controller must be shielded in the chassis before entering the cabinet.

Separation distances can be reduced if e.g. dividers are used between cables classes. Manufacturers of cable duct systems can provide information on how reduced separation distances can be achieved using their specific products.

Signal class	Cable type
Power signals	<ul style="list-style-type: none">• These signals generate a lot of interference and must be laid separate from control, measurement, and communication signals.• The shielding must be connected to a paint-free part of the panel chassis of the cabinet at both ends of the cable. Any unshielded cable must be as short as possible.• The manipulator power cables are routed on the floor and along the left side of the controller cabinet.• Cables should not be wound up like coils. This could cause an magnetic field disturbing the signals. There will also be a risk of overheating depending on the load.
Control signals	
Measurement signals	
Data communication signals	<ul style="list-style-type: none">• These signals are very sensitive to interference. To protect these signals they should not be laid along with the power signals.• In the cable, each signal must be twisted with a neutral wire.• The shielding must be connected directly to the chassis at both ends of the cable.

Shielding cables

When peripheral devices are connected to the robot system, a shielded cable is necessary to reduce coupling of the inner cable conductors to the environment they pass through.

Shielding cable requirements

- The best method for shielding is to ground the shield at both ends of the cable, provided the ends grounding are at the same potential.
- If the grounding points have different electric potentials - grounding both ends will create a ground loop allowing unwanted current to flow in the shield. In such cases one end grounding may be used. The grounding point should then be at the robot controller side.
- Cables carrying analog low-level signals is another exception where the shield should be grounded at only one end.

Continues on next page

3 Installation and commissioning


3.5.2 Connecting cables to the controller

Continued

- Most data network and field bus types have defined grounding topologies. If such grounding schemes exist, they should be followed.
- In complex interference environments, two-layer shielding may be required. The inner shield should be grounded at the controller side only end and the outer shield should be grounded at both ends. The optimum shielding is a combination of foil and braid screens.
- The best connection is one in which the shielding is extended up to and makes a solid 360° connection (shown below) with the ground plane or chassis.

Shielding example

The below example shows the shielding of a d-type connector:




xx1700001320

- A A dimpled connector body makes multiple bonds to the mating connector body all around its periphery, 360° bonding.
- B Metal, or metallized, back shell makes 360° bond to the connector body.
- C The cable shield is exposed and 360° clamped to the back shell. A tight fit is a must.

Many other 360° bonding methods and types of 360° shielded connectors are also acceptable.

Shield pigtail termination

Shield pigtail termination, as shown below, shall be avoided. If a pigtail connection cannot be avoided, make it as short as possible.



xx1700001321

Continues on next page

Ground and screen connections

The task of the grounding system is twofold - protective and functional. The primary task is to serve as protective earth (PE) for personal and equipment safety. The secondary task is to serve as a return path for common mode current.

For further information refer to EN 60204-1 and UL 1740.

Grounding requirements

The controller cabinet ground must come from the mains power supply PE.

- The grounding cable color shall be green-yellow.
- The ground for the controller cabinet, robot manipulator and peripheral devices must be the same, preferably an equipotential ground grid (mesh).
- Ground connection points must have stable inter-metallic bonding, like screw fixation. Paint, dirt, rust, and other insulating material must be removed from the contacting surfaces.

For requirements on the marking of the supply ground connection inside the control cabinet refer to UL 508C. For further details on how grounding systems should be designed refer to IEC 61000-5-2. For details of cross-sectional area of PE refer to IEC 60204-1.


Grounding installation

For information on how to connect protective earth to the OmniCore controller cabinet, see [Connecting power supply to and grounding the controller on page 97](#).

For information on how to connect protective earth for the manipulator, see the corresponding product manual.

Examples

The following figure shows 2 examples on how protective earth and the signal cable screens can be connected:



xx1200000960

Continues on next page

3 Installation and commissioning

3.5.2 Connecting cables to the controller

Continued

Example 1:

- Where a good earth connection is available on all units, the best shielding is obtained by grounding all screens at both ends on all units.

Example 2:


- If the cable is terminated where a good earth connection is not available a noise suppression capacitor can be used. The screens of the 2 cables must be connected as shown in the figure, but not connected to the chassis of the unit.

Interference elimination

Internal relay coils and other units that can generate interference inside the control cabinet are neutralized. External relay coils, solenoids and other units must be clamped in a similar way. The illustration below shows how this can be done.

Note that the turn-off time for DC relays increases after neutralization, especially if a diode is connected across the coil. Varistors give shorter turn-off times.

Neutralizing the coils lengthens the life of the switches that control them.



xx1200000961

- 1 The diode should be dimensioned for the same current as the relay coil, and a voltage of twice the supply voltage.
- 2 The varistor should be dimensioned for the same energy as the relay coil, and a voltage of twice the supply voltage.
- 3 When AC voltage is used, the components needs to be dimensioned for >500 V max voltage and 125 V nominal voltage.

The resistor should be 100 Ω, and the capacitor should be 1W 0.1 - 1 μF (typically 0.47 μF).

3.5.3 Connecting the manipulator to the controller

General

Connect the manipulator and the controller to each other after installing them. The lists below specify which cables to be used in each application.

All connectors on the controller are shown in section [Connectors on the OmniCore C30 controller on page 82](#).



CAUTION

Verify that the robot serial number is according to the number(s) in the *Declaration of Incorporation (DoI)*.

Main cable categories

All cables between the manipulator and the controller are divided into the following categories:

Cable category	Description
Manipulator cable	Handles power supply to and control of the manipulator's motors as well as feedback from the serial measurement board.
Position switch cables (option)	Handles supply to and feedback from any position switches.
Customer cables (option)	Handles communication with equipment fitted on the manipulator by the customer.
Additional axes cables (option)	Handles power supply to and control of the external axes motors as well as feedback from the servo system.

These categories above are divided into sub-categories which are specified in spare part manual. See [Manipulator cables on page 597](#).

Connecting the cables from the manipulator to the controller

	Action
1	Connect the manipulator cable to the connector X1.
2	Lock the connector with the lever.
3	Secure the cables to avoid tripping or wear.


3 Installation and commissioning

3.5.4 Fitting the connector

3.5.4 Fitting the connector


General

This section describes how to manufacture a cable for connecting the main power to the controller.



xx1700000742

Detailed view



xx1900000058

	Description
A	Gland
B	Crown clamp
C	Shielding element
D	Distance sleeve
E	Contact socket
F	Insulation inserts
G	Housing

Specifications

The following describes the cable requirements for the main power connection to the OmniCore C30 controller.

Component	Description
Cable type	Flexible oil resistant rubber
Cable area	3C x 1.5 mm ² or AWG14

Continues on next page

Included parts

The following parts are included in the delivery.

Part	Recommended supplier	Note
Connector	TE	
Cable ⁱ	3C x 1.5 mm ² H05 VV-F BLACK R/A Schuko 16A Right angle BLACK	EU
Cable ⁱⁱ	3C x 1.5 mm ² H05 VV-F ROUND BLACK Fully moulded BS1363 13A (5A fuse) Right angle BLACK	UK
Cable ⁱⁱⁱ	3C x AWG16 SVT BLACK NEMA 5-15P 15A Straight BLACK	US
Cable ⁱⁱ	3C x 1.5 mm ² sq HVCTF BLACK Japanese plug JIS C8303 12A Straight BLACK	JP
Cable ⁱ	3C x 1.5 mm ² RVV BLACK Chinese plug 3 pin 10A Straight BLACK	CN
Cable ⁱ	3C x 1.5 mm ² VV-F BLACK Australian plug 3 pin 10A Straight BLACK	AU
Cable ⁱⁱⁱ	3C x 1.5 mm ² H05 BLACK	AU

ⁱ This part is only optional for the IRB 14050, CRB 15000 and CRB 1100 controller. The cable length is 3,000 mm.

ⁱⁱ This part is only optional for the IRB 14050 controller. The cable length is 3,000 mm.

ⁱⁱⁱ This part is only optional for the IRB 14050, CRB 15000 and CRB 1100 controller. The cable length is 5,000 mm.

The following label is attached on the cables.



xx2100000809

Procedure

Use the following procedure to fit the connectors.



	Action	Note/illustration
1	Cut the cable to desired length.	

Continues on next page

3 Installation and commissioning

3.5.4 Fitting the connector

Continued




Action	Note/illustration
2 Connect the wires according to the illustration. Use a four-indent crimp tool to make the connection tight.	 xx1700000741 <p>For single phase:</p> <ul style="list-style-type: none"> A X0.1 Line (L1) B X0.2 Neutral (N) or Live (L2) C Not used D X0.PE Protective Earth (PE), grounding
3 Fit the cable through the gland and the crown clamp of the connector.	 xx1900000045
4 Strip the outer cover of the cable about 27 mm.	 xx1900000046
5 Strip the shielding copper wires of the cable about 27 mm if needed.	 xx1900000047
6 Strip the insulation of the wires about 7 mm.	 xx1900000048

Continues on next page

3 Installation and commissioning

3.5.4 Fitting the connector

Continued



Action	Note/illustration
7 Crimp the contact sockets (support cross-section from 0.35-2.5mm ²) to the cable with the four-indent crimping tool which follows the MIL-C-22520/1-01 standard at position A.	 xx1900000049
 Tip Make sure that the cross-section value for the wire you select is within the limitation of the tool you use.	
8 Cut the extra wire fillers.	
9 Press the shielding element to the crown clamp.	 xx1900000050
 Tip The installation is ok when you hear a "click" sound.	
10 Cut off the extra shielding copper wires of the cable if needed.	
11 Twist the crown clamp to secure it.	 xx1900000051
12 Open the insulation inserts for about 2 mm by pulling it apart.	 xx1900000052
13 Insert the contact sockets into insulation inserts.	
14 Close the insulation inserts.	 xx1900000055
 Tip The installation is ok when you hear a "click" sound.	

Continues on next page

3 Installation and commissioning

3.5.4 Fitting the connector

Continued

	Action	Note/illustration
15	Fit the distance sleeve on the insulation inserts.  Tip The installation is ok when you hear a "click" sound.	
16	Insert the housing to the connector.	
17	Tighten the connector with a 19 mm open-ended wrench.	 Tighten torque: 3.5Nm

3.5.5 Connecting power supply to and grounding the controller



Note


How to manufacture a cable with connector is described in section [Fitting the connector on page 92](#).



DANGER

A residual current device (RCD) must be installed.

Location of power supply connection



xx1700001060



Note

According to IEC60204-1, the power-operated switch should be installed between 600 mm to 1,900 mm above the servicing level. The switch will be easily accessible.

Location of grounding point



Note


The whole cabinet ground is connected to the X0.PE point.

Continues on next page

3 Installation and commissioning

3.5.5 Connecting power supply to and grounding the controller

Continued



xx1700001059

	Description
A	X0.1 Line (L1)
B	X0.2 Neutral (N) or Live (L2)
C	Not used
D	X0.PE Protective Earth (PE), grounding

Required equipment

Equipment	Note
Main connection cable (single phase)	L, N, PE Details see Fitting the connector on page 92 .
External earth fault protection (residual current device, RCD)	30 mA
Standard toolkit	See Standard toolkit for controller on page 570 .
Circuit diagram	Circuit diagram - OmniCore C30 , Circuit diagram - OmniCore C30 for IRB 14050 , Circuit diagram - OmniCore C30 for CRB 15000 , 3HAC059896-009, 3HAC063898-009, 3HAC072448-009

Line fusing

There is no integrated fuse in side OmniCore C30 controller. An external fuse or circuit breaker must be added by the integrator, according to the full load current rating. The full load current for the robot is marked on the controller name plate, and is also displayed in section [Load current on page 42](#).

Connecting the power

The following procedure describes how to connect the main power to the controller.



CAUTION

Always inspect the connector for dirt or damage before connecting it to the controller. Clean or replace any damaged parts.

Continues on next page

3 Installation and commissioning

3.5.5 Connecting power supply to and grounding the controller

Continued

	Action
1	Connect the main power cable to the power inlet connector X0 and lock it by rotating.

3 Installation and commissioning

3.5.6 Detaching and attaching a FlexPendant

3.5.6 Detaching and attaching a FlexPendant

Introduction

With the option *Hot swappable FlexPendant [3018-1]* it is possible to detach and attach the FlexPendant from an OmniCore controller in automatic mode, without interrupting the ongoing process.

Detaching the FlexPendant in manual mode will always result in an emergency stop.



Note

Detaching the FlexPendant is possible only if the logged in user has the **Detach the FlexPendant** grant.



CAUTION

Before detaching the FlexPendant, another emergency stop shall be available.



CAUTION

With a detached FlexPendant, there is no visual identification of the operating mode.



CAUTION

A FlexPendant that is not connected to the robot must be stored out of sight so that it cannot be mistaken for being in use.




CAUTION

The FlexPendant connector shall only be used to connect the FlexPendant.

Continues on next page

Location of FlexPendant connector

The FlexPendant connector is located on the front panel on the controller.



xx1700001061

A	FlexPendant connector
---	-----------------------

Detaching the FlexPendant in automatic mode

Use the following procedure to detach the FlexPendant in automatic mode:

- 1 On the status bar, tap the **QuickSet** button.
- 2 Tap the **Logout/Restart** tab.
- 3 In the **FlexPendant** section, tap **Detach FlexPendant**.


Continues on next page

3 Installation and commissioning

3.5.6 Detaching and attaching a FlexPendant


Continued

The **Detach FlexPendant** window is displayed.



4 Tap **Detach**.

A popup window with 30 seconds countdown timer is displayed.



5 When the countdown is progressing, detach the FlexPendant.

Continues on next page

When detached, the FlexPendant will shut down.



Note

If the FlexPendant is not detached within 30 seconds, the process for detach of the FlexPendant is aborted.



WARNING

If the FlexPendant is detached after the 30 seconds countdown has passed, the controller will enter emergency stop state.


Attaching the FlexPendant



CAUTION

Always inspect the connector for dirt or damage before attaching. Clean or replace any damaged parts.

Attach the connector to the controller and tighten the locking ring or screws.



xx1900000975



CAUTION


Make sure that the emergency stop device is not pressed in before attaching the FlexPendant.

3 Installation and commissioning

3.5.7 Ethernet networks on OmniCore

3.5.7 Ethernet networks on OmniCore

Network segment overview



xx2100002084


The Ethernet networks used by OmniCore are distributed into the following segments:

Network segment	Controller ports	Usage
Private Network	I/O (Scalable I/O) ETHERNET SWITCH	Process equipment local to this specific robot.
	MGMT (Management)	ABB service personnel.
	HMI (FlexPendant)	FlexPendant connection.
Ability Network	ABB Ability™	ABB Ability™ connection.
Public Network	WAN	Public/factory network.
I/O Network	LAN	Secondary public/factory network. Isolated from WAN.

Continues on next page

Connectors

Connectors on C line/ V line controllers



xx2100002082

	C line controller label	Description
1	I/O	ABB Scalable I/O. Connected to the controller's Private Network. Intended for chaining more ABB Scalable I/O units.
2	ETHERNET SWITCH	Connected to the controller's Private Network. Intended for connecting ABB Scalable I/O units and network based process equipment local to the controller.
3	ABB Ability™	Intended for connecting the controller to internet/ABB Ability™.
4	WAN	Connected to the controller's Public Network. Intended for connecting the robot controller to a factory wide industrial network.
5	LAN	Connected to the controller's I/O Network. Intended for connecting the robot controller to a factory wide industrial network isolated from WAN.
6	MGMT (Management)	Connected to the controller's Private Network. The MGMT port shall be used by service personnel in close proximity to the controller, with a single client connected to the controller.  Note The management port shall never be used for more than one client at a time. ABB Robotics assumes no responsibility for any errors/hazards that may appear when more than one client is used.
7	HMI (FlexPendant)	Specific connector for connecting the FlexPendant.

Continues on next page

3 Installation and commissioning

3.5.7 Ethernet networks on OmniCore

Continued

Industrial networks

Connection of industrial networks

A factory wide I/O network should be connected to the WAN port on the controller, or to the LAN port if the I/O network needs to be isolated from the network already connected to WAN.



Note

It is not supported to connect multiple ports of the OmniCore controller to the same external switch unless static VLAN isolation is applied on the external switch.




Note

Private Network segments of multiple controllers cannot be connected to each other.

Combined industrial networks

There are many possible solutions of combined industrial networks. For example, the robot controller can be both master and slave on the Public Network as well as master on the Private Network.



xx2100002085

This can be implemented by setting up an EtherNet/IP adapter on the Public Network and an EtherNet/IP scanner targeting both the Public and Private Networks at the same time. The traffic for both industrial networks on the Public Network can share the ethernet medium with each other and with other non-industrial network traffic.

Continues on next page

Configuration

Reserved IP addresses

Before configuring IP addresses manually, it is important to be aware that some ranges are reserved by the robot controller. Configuring units or networks that collide with these reserved addresses will most likely cause network problems.

The following IP address ranges are allocated for internal functions on the controller:

- 192.168.125.0 - 255
- 192.168.126.0 - 255
- 192.168.127.0 - 255

No other robot controller connected network can be on a subnet that overlaps with any of the above reserved IP addresses. If a subnet mask in the class B range has to be used, then a private address of class B must be used to avoid any overlapping. Contact your local network administrator regarding network overlapping. See section "Communication" in *Technical reference manual - System parameters*.



Note

It is not recommended using leading zeros in dot-decimal notation of IP addresses. The numbers may wrongly be interpreted as octal numbers. Different behaviors on virtual and real controllers may be experienced.

Private Network

The Private Network has a static configuration with IP address 192.168.125.1/24 and hosts a DHCP server. The purpose of the Private Network is to connect the computers within the robot controller as well as I/O networks and process equipment local to the robot. Many IP addresses are reserved on this network, so it is recommended that new units get their IP address from the DHCP server.



Note

Never connect another DHCP server to any of the ports connected to the Private Network. There cannot be two DHCP servers on the same network. It might cause an erroneous behavior of both internal and external units.

Ability Network

Configuration of the IP settings for the Ability Network shall be done manually when the controller is equipped with a wired Connected Services Gateway (DSQC1041) that is connected to an Internet gateway, using an IP address provided by the network administrator.



Note

On OmniCore E line controllers, the WAN2 port is equivalent to a wired Connected Services Gateway (DSQC1041).

The IP address configuration is done either in RobotStudio or on the FlexPendant.

Continues on next page

3 Installation and commissioning

3.5.7 Ethernet networks on OmniCore

Continued

As an exception to the reserved ranges mentioned in section [Reserved IP addresses on page 107](#), the Ability Network is allowed to configure IP addresses within the reserved range 192.168.126.0 - 255, but not within 192.168.125.0 - 255 or 192.168.127.0 - 255.

For security reasons, only outbound access on port 53 DNS and 443 HTTPS are allowed. The inbound access is blocked by an internal firewall and cannot be unblocked.



Note

For more information about connecting the Ability port to the internet, see [Application manual - Controller software OmniCore](#).

Public Network

The Public Network interface is typically connected to the factory network with a public IP address provided by the network administrator. The Public Network segment can be used for:

- Connecting a PC running RobotStudio. For more information see [Operating manual - RobotStudio](#).
- Mounting FTP or NFS disks from the controller.
- Running Industrial Ethernet protocols.

Most protocols are disabled by default in the controller firewall. See [Firewall settings on page 111](#) for information about how to enable these protocols.


The Public Network can be configured with a fixed IP address, or as a DHCP client, either in RobotStudio or from the FlexPendant:

- **Defining network settings in RobotStudio:**

- 1 In the Configuration browser, right-click the controller and select Properties\Network Settings and then Public Network.

Continues on next page

- 2 In the Public Network window, configure the network interface and click OK.**



xx2000000489

- Defining network settings on the FlexPendant:**
 - 1 On the start screen, tap **Settings**, and then select **Network** from the menu.


Continues on next page

3 Installation and commissioning

3.5.7 Ethernet networks on OmniCore

Continued

2 Select **Public Network** and configure the network interface. Tap **Apply**.




xx2100002086

I/O Network

The I/O Network is needed when an Industrial Ethernet network must be isolated from the Public Network. It can be configured either in RobotStudio or from the FlexPendant:

- Defining network settings in RobotStudio:

- In the Configuration browser, right-click the controller and select Properties\Network Settings and then I/O Network.
- In the I/O Network window, configure the network interface and click OK.




xx2200000389

Continues on next page

- **Defining network settings on the FlexPendant:**

- 1 On the start screen, tap **Settings**, and then select **Network** from the menu.
- 2 Select **I/O Network** and configure the network interface. Tap **Apply**.



xx2100002097

Firewall settings

The Firewall Management function is used to configure the network firewall on the controller. Configuration is done in RobotStudio under **Configuration\Communication\Firewall Manager** where pre-configured Network Services can be enabled or disabled:

Type	Network Service	Enable on Public Network	Enable on Private Network	Enable on I/O Network
Connected Services	Bonjour	No	Yes	No
CS Gateway 3G	ConnectedServices	No	Yes	No
CS Gateway Wi-Fi	EtherNetIP	No	Yes	No
CS Gateway Wired	Netscan	No	N/A	No
DNS Client	RapidSockets	No	Yes	No
Firewall Manager	RobAPI	No	N/A	No
FTP Client	RobotWebServices	No	N/A	No
IP Setting	syslog	Yes	Yes	No
SFTP Client				
Syslog				

xx1900000352



Note

Only pre-registered Network Services can be configured in the Firewall Manager settings. The user cannot add new Network Services in the Firewall Manager and can only change the parameters **Enable on Public Network**, **Enable on Private Network** and **Enable on I/O Network** for pre-registered Network Services.



Note

Only users with UAS grant **Modify network security properties** can modify the firewall settings.


For more information, see *Technical reference manual - System parameters*.

3 Installation and commissioning

3.5.8 Descriptions for connectors

3.5.8 Descriptions for connectors

Robot signal exchange proxy mating connectors



xx1800000552

A	Robot signal exchange proxy mating connectors
CAUTION	
Safety functions must be verified before use. Safety functions must be tested regularly.	

Connector X14

	Description
Connection	Customer Safety Interface: Automatic Stop/General Stop and external Emergency Stop
Type	Weidmüller B2CF 3.50/16/180F B2CF 3.50/16/180F SN OR BX 2*8 pins
Article number	3HAC064736-001

The connector X14 allows for connecting *protective stop* and *emergency stop* devices.

The input for protective stop can either be configured as *Automatic Stop* (AS) or *General Stop* (GS). *Automatic Stop* is only operational in automatic mode. *General Stop* is operational in both manual mode and automatic mode. See [Protective stop and emergency stop on page 23](#).

The default configuration for the protective stop function is *Automatic Stop* (AS). That is, active in automatic mode only.

Changes to the default configuration for the protective stop function, that is from *Automatic Stop* (automatic mode) to *General Stop* (both manual and automatic mode), are made in the tool RobotStudio. See [Configuring robot stopping functions](#)

Continues on next page

[on page 126](#). More information is also available in *Operating manual - RobotStudio* and *Application manual - Functional safety and SafeMove*.

External emergency stop devices can for example be required in the following cases:

- FlexPendant is detached.
- FlexPendant is placed in its holder with the emergency stop device hidden behind the emergency stop device cover.



xx1800000553

Pin	Name	Description
1	0V_CH1_CH2	Reference ground towards 24 V.
2	24V_CH2	24 V power, provided by robot controller, for ES channel 2 only.
3	ES2-	Negative side of external emergency stop input, channel 2.
4	ES2+	Positive side of external emergency stop input, channel 2.
5	ES1-	Negative side of external emergency stop input, channel 1.
6	ES1+	Positive side of external emergency stop input, channel 1.
7	0V_CH1_CH2	Reference ground towards 24 V.
8	24V_CH1	24 V power, provided by robot controller, for ES channel 1 only.
9	0V_CH1_CH2	Reference ground towards 24 V.
10	24V_CH2	24 V power, provided by robot controller, for AS/GS channel 2 only.
11	AS2/GS2-	Negative side of AS/GS input, channel 2. Customer needs to connect these pins to the reference ground of 24 V power.
12	AS2/GS2+	Positive side of AS/GS input, channel 2. Customer needs to connect these pins to a 24 V power.
13	AS1/GS1-	Negative side of AS/GS input, channel 1. Customer needs to connect these pins to the reference ground of 24 V power.
14	AS1/GS1+	Positive side of AS/GS input, channel 1. Customer needs to connect these pins to a 24 V power.
15	0V_CH1_CH2	Reference ground towards 24 V.
16	24V_CH1	24 V power, provided by robot controller, for AS/GS channel 1 only.

Continues on next page


3 Installation and commissioning

3.5.8 Descriptions for connectors

Continued

A protective stop device needs to be connected to the protective stop input. See example below.


Customer provided
protective stop device



xx2100002262

The protective stop input can be powered from an external power supply:

Customer provided
protective stop device




xx2100002264

Continues on next page

The emergency stop input needs to be connected to an emergency stop device. This to allow operation in both automatic and manual mode:


Customer provided
emergency stop device



xx2100002261

The emergency stop input can be powered from an external power supply:

Customer provided power
Customer provided
emergency stop device



xx2100002263

For more connections other than those illustrated above, carefully assess the risk before use and contact your local ABB for support.

Continues on next page

3 Installation and commissioning

3.5.8 Descriptions for connectors

Continued

Connector X15

Description											
Connection											Customer Optional Interface
Type											Weidmüller B2CF 3.50/18/180F B2CF 3.50/18/180F SN OR BX 2*9 pins
Article number											3HAC064737-001



xx1800000555



Note

NC means those pins are reserved. They cannot be electrically connected to any external signal, ground, or voltage.

Pin	Name	Description
1	MON_PB	Motors on push button input interface.
2	24V_MON	24 V power supplied by robot controller for motors on lamp and motors on push button use only. It must not be used for any other functions.
3	MON_LAMP	Motors on lamp output interface. The max sink current is 50mA.
4	24V_MON	24 V power supplied by robot controller for motors on lamp and motors on push button use only. It must not be used for any other functions.
5	NC	Reserved
6	NC	Reserved
7	NC	Reserved
8	NC	Reserved
9	NC	Reserved
10	NC	Reserved
11	ESOUT2-	Negative side of emergency stop output, channel 2.
12	ESOUT2+	Positive side of emergency stop output, channel 2.
13	ESOUT1-	Negative side of emergency stop output, channel 1.
14	ESOUT1+	Positive side of emergency stop output, channel 1.
15	NC	Reserved
16	NC	Reserved

Continues on next page

Pin	Name	Description
17	NC	Reserved
18	NC	Reserved



Note


The ESOUT1 and ESOUT2 fulfill the IEC 61131-2 Type 0,25 Output.



Note

The device connected to the ESOUT pins shall fulfill the IEC 61131-2 Type 1 Input.

If the device cannot meet the requirement, a safety PLC or relay is needed.



Note

State 0 of Emergency stop output shall be recognized as Emergency stop triggered.



Note

The maximum length of the cable connected to the ESOUT pins shall be 10 m.



Note

The cable shall be protected from external EM disturbance, suggested to use separate multicore cables.

Continues on next page

3 Installation and commissioning

3.5.8 Descriptions for connectors

Continued



Note

All external safety devices must be connected to the Customer Safety Interface.




Note

The ESOUT pins reflect the emergency status of the controller.

ESOUT can be decoupled from ES input to avoid dead-lock in an emergency stop chain, when using RobotWare 7.6 or later. On controllers running RobotWare releases prior to 7.6, it is not recommended to directly connect ESOUT pins to the ES pins on another OmniCore controller. See [Configuring robot stopping functions on page 126](#).

Although the Motors On function is available on the FlexPendant, an interface is provided in X15 for an optional Motors On push button and an indication lamp.

Customer provided device



xx1900000598

Connector X19

	Description
Connection	Customer IO power supply
Type	Weidmüller BCF 3.81/08/180F BCF 3.81/08/180F SN BK BX 8 Pins
Article number	3HAC064739-001

Continues on next page



xx1800000556

Pin	Name	Description
1	24V_IO_EXT_1	24V_IO_EXT
2	0V_IO_EXT_1	0V_IO_EXT
3	24V_IO_EXT_2	24V_IO_EXT
4	0V_IO_EXT_2	0V_IO_EXT
5	24V_IO_EXT_3	24V_IO_EXT
6	0V_IO_EXT_3	0V_IO_EXT
7	24V_IO_EXT_4	24V_IO_EXT
8	0V_IO_EXT_4	0V_IO_EXT

24V_IO_EXT is the 24 V power supply for the customer. The characteristics are shown in the following table.

Parameter	Value
Voltage	24V DC
Voltage tolerance	-3% ~ +10%
Max output current	3 A



Note

For IRB 14050, the auxiliary 24V DC power connector for electronics on the Ethernet floor cable should be connected to X19 on the front panel of the controller.

Connector X20

	Description
Connection	Customer optional power input (Not available)
Type	Weidmüller BCF 3.81/06/180F BCF 3.81/06/180F SN BK BX 6 Pins
Article number	3HAC064738-001

Continues on next page


3 Installation and commissioning

3.5.8 Descriptions for connectors

Continued


Antenna connector

The Connected Services Gateway unit has either an Ability port or an antenna connector on the front. See installation procedures in section [On-site installation on page 57](#).



xx1800000823

I/O connectors - Scalable I/O (option)



xx1700001063

A	Scalable I/O output connectors
B	Scalable I/O input connectors


The connectors contain 16 digital input signals, 16 digital output signals, 24 V and 0 V for the outputs, and 0 V for the inputs.

Note that the Digital Output requires a 24 V separate power supply.

For connection details, see *Circuit diagram - OmniCore C30*, *Circuit diagram - OmniCore C30 for IRB 14050*, *Circuit diagram - OmniCore C30 for CRB 15000*, *3HAC059896-009*, *3HAC063898-009*, *3HAC072448-009* and *Application manual - Scalable I/O*, *3HAC070208-001*.

Continues on next page

X2 harness CFI connection (option)⁶



xx2000002026

A	Harness CFI connection
---	------------------------

The X2 is provided for CP/CS connection with the robot for the customer. It is only valid for the CRB 15000 robot. The characteristics are shown in the following table.

Description	Data
Max input voltage	30 VDC
Max input current (CP pins 7,8)	1.5 A ⁱ
Max input current (CS pins 1,2,3,4)	0.5 A
Max short circuit current	40 A
CS twist pairs	Yes (pair connection pin 1 and 2, 3 and 4)
Over current protection	Yes

⁶ Only valid for CRB 15000 robot

Continues on next page


3 Installation and commissioning

3.5.8 Descriptions for connectors

Continued

Description	Data
Connector type	M12 A-code female 8 pole according to IEC 61076-2-101  Note The mating connector for CFI connection is not included in our delivery and shall be prepared by the customer.


i Max input current temperature rerating refers to curve below:



xx2100000491

Continues on next page

The pins definition for the harness CFI connection is described in the following illustration.




xx2100000498

1	CS pair1+
2	CS pair1-
3	CS pair2+
4	CS pair2-
5	Not used
6	Not used
7	CP+
8	CP-


For connection details, see *Circuit diagram - OmniCore C30 for CRB 15000, 3HAC072448-009*.

DeviceNet board connector (option)



xx2100001564

A	X17 - IP20 DeviceNet board connector
---	--------------------------------------



xx2100001565

Continues on next page

3 Installation and commissioning

3.5.8 Descriptions for connectors

Continued

The following table shows the connections to the DeviceNet connector:

I/O pin	Signal name	Wire color	Function
1	V-	black	DeviceNet network negative power (0 V)
2	CANL	blue	DeviceNet communication network terminal (low)
3	Shield	bare	Network cable shield
4	CANH	white	DeviceNet communication network terminal (high)
5	V+	red	DeviceNet network positive power (24 V DC)

This connector is internally connected with the optional DeviceNet board (DSQC1006). The X17 is the predefined connection to the DeviceNet board in main computer for the customer.




Tip

The DeviceNet network needs to be powered by a separate 24 V power supply, or the DeviceNet function will not work.

See *Application manual - DeviceNet Master/Slave, 3HAC066562-001*, section "Hardware overview" for more information on how to connect 24 V to the DeviceNet network.

For connection details, see *Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000, 3HAC059896-009, 3HAC063898-009, 3HAC072448-009*.

X45 - IP20 power outlet connector (option)



xx1700001064

A IP20 Power outlet connector

Continues on next page

This connector is internally connected with the optional power supply (DSQC3035). The X45 is the 24 V power supply for the customer. The characteristics are shown in the following table.

Parameter	Value
Voltage	24 V DC
Voltage tolerance	-3% ~ +10%
Max output current	8 A



Note

The 24 V power supply from the X45 is isolated from the controller internal logical circuit.

The 24 V power supply from the X45 is neither monitored, or on/off controlled by the controller. Residual voltage may remain shortly on X45 after turning-off the controller.

For connection details, see *Circuit diagram - OmniCore C30*, *Circuit diagram - OmniCore C30 for IRB 14050*, *Circuit diagram - OmniCore C30 for CRB 15000*, 3HAC059896-009, 3HAC063898-009, 3HAC072448-009.



Note

Connector Single-row female is delivered with the controller.

3 Installation and commissioning

3.5.9 Configuring robot stopping functions

3.5.9 Configuring robot stopping functions

Introduction

The robot stopping functions, protective and emergency stop are configured using the *Visual SafeMove* functionality in RobotStudio.



Note

The safety stop configuration and available stops is different for OmniCore prior to RobotWare 7.3

The protective stop function can be configured to be either an *Automatic Stop* (AS) or a *General Stop* (GS). When the protective stop function is configured as *General Stop* (GS), the activation of the protective stop device will initiate the protective stop in any operating mode. When the protective stop function is configured as *Automatic Stop* (AS), the activation of the protective stop device will initiate the protective stop in automatic mode only.



Note

It is not possible to configure both *Automatic Stop* and *General Stop* on the OmniCore C30 without the use of a safe fieldbus.



Note

The dedicated discrete safety input to activate the protective stop function can be configured as either *Automatic Stop* (AS) or *General Stop* (GS). For simultaneous use of AS and GS, support for a safety protocol is required. See option SafeMove.

For more information about safety configurations, see *Application manual - Functional safety and SafeMove*.

Configure the robot stopping functions in Visual SafeMove




WARNING

The new settings must be verified by test before the robot is used.

Continues on next page

Use this procedure to configure the robot stopping functions in Visual SafeMove.

1 In *Visual SafeMove*, select **Stop Configuration**.



2 Select a stop configuration and define the mode (automatic or manual).

- *ProtectiveStop* is the AS/GS input
- *ExternalEmergencyStop* is the ES input
To avoid dead-lock in an emergency stop chain, the *ExternalEmergencyStop* input can be decoupled from the ES output.
- *LocalEmergencyStop* is the emergency stop device on the FlexPendant

3 Select the stop category.

For some manipulators, only category 1 stop is available.

4 After the configuration is done, the safety configuration must be written to the controller and then a restart of the controller is required.



Tip

See also the circuit diagram, *Circuit diagram - OmniCore C30*, *Circuit diagram - OmniCore C30 for IRB 14050*, *Circuit diagram - OmniCore C30 for CRB 15000*.

Continues on next page

3 Installation and commissioning

3.5.9 Configuring robot stopping functions

Continued

Apply the configuration to the controller

Action	Note/illustration
1 In the Visual SafeMove ribbon, click on Controller and then select Write to controller.	 xx1500000801
2 A report of the safety configuration is shown. The report can be printed by clicking on Print (it is recommended to print the report since it should be used when validating the configuration). Click OK to close the report.	
3 Answer Yes when asked if you want to restart the controller.	After the restart, the downloaded configuration is active. Before running in auto mode, the configuration should be validated and locked, see Validate the configuration of robot stopping functions on page 128 .

Validate the configuration of robot stopping functions



DANGER

A stop configuration must always be validated to verify that the desired safety is achieved. If no validation is performed, or the validation is inadequate, the configuration cannot be relied on for personal safety.

Action	Expected result
1 Deactivate any supervision functions that are signal activated.	
2 Move the robot, for example with a move instruction.	
3 Set the signal configured to stop the robot in relevant operating modes. Relevant operating modes are: <ul style="list-style-type: none">• Auto: Automatic mode• General: All modes• EmergencyStop: All modes	The robot will stop.

Set the configuration to validated

When the stop configuration is validated the configuration, the status of the configuration shall be changed to **Validated** on the FlexPendant.

- 1 Log in as a user with the grant **Safety Services**.
- 2 In the **Settings** app, select the **Safety Controller**, and then **Configuration**.
- 3 Select the check box **Validated**.

Continues on next page

Set the configuration to locked

When the stop configuration is approved, the status of the configuration should be changed to **Locked** on the FlexPendant.

Running the robot in auto mode with the configuration unlocked will result in a warning message.

- 1 Log in as a user with the grant **Lock Safety Controller Configuration**.
- 2 In the **Settings** app, select the **Safety Controller**, and then **Configuration**.
- 3 Select the check box **Locked**.

Upgrading RobotWare

When upgrading RobotWare there can be differences in functionality, also when configuring the robot stopping functions. Always read the RobotWare release notes and verify the robot stopping functions by test after an upgrade. Contact your local ABB office for guidance.

RobotWare prior to 7.3

In RobotWare releases prior to 7.3, the stops are configured in the system parameters. If such a RobotWare system is upgraded to RobotWare 7.3, the stop configuration is still handled in the system parameters.

The general stop (GS) is not available in OmniCore prior to RobotWare 7.3. To include GS in an upgraded system, the safety configuration must be upgraded or a new safety configuration must be done.

RobotWare prior to 7.6

In RobotWare releases prior to 7.6, the ES input cannot be decoupled from the ES output.

The *LocalEmergencyStop* was named *InternalEmergencyStop* prior to RobotWare 7.6.

3 Installation and commissioning

3.5.10 Programmable stop functions

3.5.10 Programmable stop functions

Stopping functions

There are different methods to stop the robot, in addition to manually initiated stops.

- Stop with system input signals
- Stop with RAPID instructions
- Other stops

Stop with system input signals

In the control system, it is possible to define system input signals to be set/reset through different interactions, for example, through I/O signals. See *Application manual - Controller software OmniCore*.

The RAPID program cannot be started when any of the system input signals is high.

Pre-defined system input	Description
<i>SoftStop</i>	The RAPID program execution is stopped, and the manipulator is stopped on path with no deviation. This stop is similar to a normal program stop using stop button on the FlexPendant.
<i>QuickStop</i>	This is a faster stop of the manipulator than <i>SoftStop</i> . This stop is more stressing for the mechanics than <i>SoftStop</i> , therefore there might be a deviation on path.
<i>Stop at End of Cycle</i>	Stops the RAPID program when the complete program is executed, that means when the last instruction in the main routine has been completed.
<i>Stop at End of Instruction</i>	Stops program execution after the current instruction is completed.

All of these stops are performed without using the brakes, and the power is never disconnected. The program execution can be continued directly, for example by activating a start signal if the stop signal is set low.



Note

Only safety rated input signals are allowed to be used for safety.

Continues on next page

Stop with RAPID instructions

There are several RAPID instructions available that stops the robot.

Instruction	Description	Arguments
SystemStopAction	Stops all robots in all tasks immediately.	\Stop: similar to a normal program stop with stop button. \StopBlock: as above, but to restart the PP has to be moved. \Halt: this is like a category 0 stop, i.e. it will result in motors off state, stop of program execution and robot movements in all motion tasks. The Motors on button must be pressed before the program execution can be restarted.
Stop	The current move instruction will be finished before the robot stops. A restart will continue the program execution.	\NoRegain: the robot will not return to the stop point when restarted, e.g. after having been jogged away. \AllMoveTasks: all robots will be stopped.
StopMove	The current move instruction will be stopped immediately as a normal program stop but the program execution will continue with the next instruction. StartMove must be executed to get the robot moving again.	\AllMotionTasks: all robots will be stopped.
DebugBreak	The current move instruction and the program execution will be stopped immediately as a normal program stop. A restart of the program will continue the program execution.	
EXIT	The current move instruction and the program execution will be stopped immediately as a normal program stop. After stop the Program Pointer is lost and has to be reset to Main.	
EXITCYCLE	The current move instruction and program execution will be stopped immediately. The Program Pointer will be moved to Main and if running mode is continuous, the program will be restarted.	

Continues on next page

3 Installation and commissioning

3.5.10 Programmable stop functions

Continued

Instruction	Description	Arguments
SearchX	Search instructions can be programmed with arguments to stop the robot movement close to the point where a search hit was noticed. The program execution will continue with the next instruction.	\Stop: the robot will stop as fast as possible. This stop is performed by ramping down motion in each motor separate from each other, and as fast as possible. Since it will be without any coordination, the robot may slide off path fairly much. \SStop: the robot will stop on path but quicker than a normal program stop. This is similar to a system input <i>SoftStop</i> . \Sup: the robot will continue to the ToPoint. If more than one search hit is found, an error will be reported.

RAPID instructions are described in *Technical reference manual - RAPID Instructions, Functions and Data types*.

Other unexpected stops

Type of stop	Description
SysFail	In the control system there is a surveillance and monitoring function that can detect abnormal situations. In such cases a stop will be initiated. The robot controller must be restarted.
Power fail	In the control system there is a monitoring function that can detect power failure. In such cases a stop will be initiated.
Stop at collision	In the control system there is a monitoring function that can detect collisions. In such cases a stop will be initiated.  WARNING Special care must be taken when restarting a machine that is stopped due to a collision. The robot might make a limited move when restarted.  WARNING The revolution counters might need to be updated after a collision to ensure path accuracy.

3.6 I/O system

3.6.1 Available industrial networks

General

The controller can be fitted with a number of different boards and software based industrial networks. The software based industrial networks do not require any hardware.




Note

Two industrial network masters can be run in parallel on the OmniCore controller. It is the responsibility of the integrator to verify the behavior when two masters are used in one OmniCore.

Fieldbus connections

There is a slot available for installing a fieldbus board (PCIe) on the main computer, with process connectors on the front panel.

The software based fieldbuses are connected directly to one of the Ethernet ports.



xx2100000501

A	Slot for fieldbus, PCI express card
B	Fieldbus board (master)

Available board

The following master board is available.

Description	Article number	Type designation
DeviceNet Board	3HAC043383-001	DSQC1006

Continues on next page

3 Installation and commissioning

3.6.1 Available industrial networks

Continued

Available software based fieldbuses

The following software based fieldbuses are available as RobotWare options.

- EtherNet/IP
- PROFINET

References

For more information on how to install and configure the fieldbuses, see the respective manual.

Manual title	Article number
<i>Application manual - DeviceNet Master/Slave</i>	<i>3HAC066562-001</i>
<i>Application manual - EtherNet/IP Scanner/Adapter</i>	<i>3HAC066565-001</i>
<i>Application manual - PROFINET Controller/Device</i>	<i>3HAC066558-001</i>

3.6.2 Scalable I/O, internal and external

General

The controller can be fitted with an internal I/O unit, DSQC1030, with 16 digital inputs and 16 digital outputs.

The controller can also use external I/O units, with DSQC1030 as base unit and add-on units as extension.

Scalable I/O units

The I/O unit *DSQC1030 Digital Base* belongs to the ABB Scalable I/O system, which is a modular, compact, and scalable I/O system that consists of a base device (minimum configuration), and add-on devices.

The base device has a *Plug & Produce* interface and communicates over the default EtherNet/IP communication protocol to the robot controller. When using the standard interface, no additional RobotWare options or hardware options are required to communicate with the robot controller. When using the RobotWare option *EtherNet/IP Scanner/Adapter*, more configuration possibilities are available.

For more information about installing, configuring, and using the scalable I/O units, see *Application manual - Scalable I/O*.

Safety digital base device

The safety I/O unit *DSQC1042 Safety Digital Base* is a device that can be used to control and monitor machine safety equipment in a system. The device can be used together with the add-on devices. It uses dual channels, meaning that no undetected single fault can lead to loss of safety functions.

For more information, see *Application manual - Scalable I/O*.

3 Installation and commissioning


3.7.1 Installing the harness for double SMB

3.7 Installing options

3.7.1 Installing the harness for double SMB

Location

The illustration shows the location of the harness double SMB in the controller.



Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Harness Single SMB connection	3HAC068537-001	Harness single SMB
Harness Double SMB connection	3HAC067490-001	Harness double SMB

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	


Continues on next page

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Installing the harness double SMB

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the front panel and top cover.	See Removing the controller covers on page 222.

Removing the axis computer from the cabinet


	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none"> • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3. 	

Continues on next page


3 Installation and commissioning

3.7.1 Installing the harness for double SMB

Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	 xx1800000472
3 Loosen the screw and disconnect: <ul style="list-style-type: none">• K6.X4, K6.X5 - SMB.	

Installing the harness for double SMB


Action	Note/Illustration
1 Remove the attachment screws on the front cover.	 xx1800000727
2 Push the harness single SMB into the cabinet.	
3 Take the harness single SMB out from the upper side.	

Continues on next page


3 Installation and commissioning

3.7.1 Installing the harness for double SMB

Continued

Action	Note/Illustration
4 Insert the harness double SMB into the front panel from inside the cabinet and secure the screws.	 <p>Screws: Torx, countersunk screw M4x10 (4 pcs)</p> <p>xx1800001179</p>

Refitting the axis computer to the frame


Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  <p>xx1800000683</p>
3 Reconnect and secure the screw: • K6.X4, K6.X5 - SMB.	

Continues on next page

3 Installation and commissioning

3.7.1 Installing the harness for double SMB

Continued

	Action	Note/Illustration
4	Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000476
5	Reconnect: <ul style="list-style-type: none">• K6.X11 - A1.X3• K6.X2 - A2.X9• K6.X1 - K2.X3	

Concluding procedure


	Action	Note/Illustration
1	Refit the covers.	See Refitting the controller covers on page 227
2	Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

3.7.2 Installing the scalable I/O devices

Location

The location of the base unit used as a scalable I/O internal unit is shown in the following illustration.

When no base unit is installed, the location for the unit is covered by a slot cover that must be removed before installation.



xx1800000032

The base unit can also be used as a scalable I/O external unit, with or without add-on devices.

For more information about installing, configuring, and using the scalable I/O units, see *Application manual - Scalable I/O*.

Required parts

Part	Article number	Note
DSQC1030 Digital slot cover	3HAC065147-001	DSQC1030
Scalable I/O Digital base [3032-1]	3HAC058663-001	
Connectors digital base/add on	3HAC060919-001	
Harness Ethernet with Mini-IO	3HAC064092-001	Harness K5.1.X5 - Adapter

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	
<i>Application manual - Scalable I/O</i>	3HAC070208-001	



Continues on next page

3 Installation and commissioning

3.7.2 Installing the scalable I/O devices

Continued



Removing the digital slot cover (baseline)

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3 Press the hooks and remove the digital slot cover.	
4 Remove the front panel and top cover of the controller.	Removing the controller covers on page 222 .

Installing the scalable I/O internal base device

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page


Action	Note/Illustration
<p>2</p> <p> ELECTROSTATIC DISCHARGE (ESD)</p> <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD</i> on page 47.</p>	<p>Location of wrist strap button:</p>  <p>xx1800000683</p>
<p>3</p> <p>Connect the adapter cable to the digital base.</p> <ul style="list-style-type: none"> K5.1.X5 - Harness adapter <p>Stick the other connector onto the side of the digital base with the self-adhesive part.</p>	 <p>xx1800000938</p>
<p>4</p> <p>Connect the connectors between the adapter cable (K5.1.X5 - Adapter) and the adaptor cable (Adaptor - A2.X4/K4.X7).</p> <p> Note</p> <p>If the Ethernet extension switch is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from K4.X7.</p> <p>If the Ethernet extension unit slot cover is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from A2.X4.</p>	

Continues on next page

3 Installation and commissioning

3.7.2 Installing the scalable I/O devices

Continued

Action	Note/Illustration
5 Push the digital base into the bracket until you hear a clear clicking sound.	
6 Connect the power cable connector: <ul style="list-style-type: none">• K5.1.X4 - K2.X3	 xx1800000500

Installing scalable I/O external devices

For more information about installing, configuring, and using the scalable I/O units, see *Application manual - Scalable I/O*.


Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	
3 Prepare the scalable I/O units for external mounting as described in <i>Application manual - Scalable I/O</i> .	
4 Remove the front panel and top cover of the controller.	Removing the controller covers on page 222 .
5 Connect the external base device to the internal base device (X3) or the Ethernet switch, using an Ethernet cable.	
6 Connect an external power supply to the external base units, connector X4.	Each base device requires its own power supply.
7 Refit the front panel and top cover.	Refitting the controller covers on page 227 .
8 Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

3.7.3 Installing the Ethernet extension switch

3.7.3 Installing the Ethernet extension switch

Location

The illustration shows the location of the Ethernet extension switch in the controller.



Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Ethernet Extension unit slot cover	3HAC065126-001	
Ethernet Extension switch [3014-1]	3HAC059187-001	

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Continues on next page

3 Installation and commissioning



3.7.3 Installing the Ethernet extension switch

Continued

Installing the Ethernet extension switch

Removing the Ethernet extension unit slot cover (baseline)

Use this procedure to remove the Ethernet extension unit slot cover.

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Press the hooks and remove the Ethernet extension unit slot cover.	 xx1800000725
4	Remove the front panel, top and right covers of the controller.	Removing the controller covers on page 222



Continues on next page

3 Installation and commissioning

3.7.3 Installing the Ethernet extension switch

Continued

Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: • G2.X1-K2.X17	

Refitting the Ethernet extension switch (option)


	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

3 Installation and commissioning

3.7.3 Installing the Ethernet extension switch

Continued




Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i>	Location of wrist strap button:  xx1800000683

Continues on next page

3 Installation and commissioning

3.7.3 Installing the Ethernet extension switch

Continued

Action	Note/Illustration
3	<p>Hook up the Ethernet extension switch to the bracket and then push the switch into position.</p> <p>Note</p> <p>During the installation, there should be no gap between the upper surface of the Ethernet extension switch and the lower surface of highest bracket on the main computer.</p>  <p>xx1800000972</p>  <p>xx1800000492</p>  <p>xx1800000493</p>
4	<p>Reconnect:</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7. <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>


Continues on next page

3 Installation and commissioning

3.7.3 Installing the Ethernet extension switch

Continued

Refitting the small fan



Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Reconnect: • G2.X1-K2.X17	

Continues on next page

3 Installation and commissioning

3.7.3 Installing the Ethernet extension switch

Continued

	Action	Note/Illustration
4	Refit the fan bracket into the cabinet.	 xx1800000483
5	Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Concluding procedure


	Action	Note/Illustration
1	Refit the covers.	Refitting the controller covers on page 227
2	Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension

Location

The illustration shows the location of the power supply optional device in the controller.




xx180000035

A	Power supply baseline
B	Power supply optional

Harness 24 V extension device is an option of IP20 power outlet connector.

The illustration shows the location of the harness 24 V extension in the controller.



xx1800000740

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension

Continued



Note

The optional power supply and the harness 24 V extension must be installed at the same time.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Optional power supply	3HAC071301-001	DSQC3035
Harness DeviceNet/Harness 24V ext. cover plate	3HAC063601-001	
Harness 24V_Process output	3HAC060965-001	DSQC 688
Connector Single-row female	3HAC064743-001	Mating connector for IP20 power outlet connector

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section <i>Standard toolkit for controller on page 570</i> .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Installing the optional power supply and the harness 24 V extension

Preparations


	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see <i>Electrical safety on page 31</i> .	

Continues on next page


3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Remove the top and right covers, and the front panel of the controller.	Removing the controller covers on page 222

Removing the axis computer from the frame



Action	Note/Illustration
1 Disconnect: <ul style="list-style-type: none">• A1.X3 - K6.X11• K6.X2 - A2.X9• K6.X1 - K2.X3.	 xx1900001193
2 Remove the screws on the bracket.	
3 Loosen the screw and disconnect: <ul style="list-style-type: none">• SMB - K6.X4, K6.X5	

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension *Continued*

Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: • G2.X1-K2.X17	

Removing the main computer assembly with process plate

	Action	Note/Illustration
1	Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer.	

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none">• K2.X8 - A2.X6• (option): K2.X2 - K4.X8, A2.X1• K2.X12 - A2.K3.X6, A2.K3.X7• K2.X10 - A1.X13• K2.X21 - TempSensor• K2.X4 - A1.X9• K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1• K2.X1 - T2.X2⁷• K2.X1 - X10⁸• K2.X17 - G2.X1, G1.X2• K2.X6, K2.X11 - A1.X2• K2.X7, K2.X22 - Harn. LV robot power (X1)• K2.X9 & X13 - FlexPendant (X4)	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3⁹• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

⁷ Not available for CRB 15000 controller.


⁸ Only available for CRB 15000 controller.

⁹ For connected services gateway wired, there is no power cable.

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension *Continued*



Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁷ • A2.X9 - X1⁸ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	
<p>2 Remove the mating connectors from the front side by loosening their attachment screws.</p>	

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension

Continued



Action	Note/Illustration				
3 Remove the screws holding the process plate and the screws holding the scalable I/O bracket.	 <p>xx1800000532</p>  <p>xx1900000215</p> <table border="1"> <tr> <td>A</td><td>Screws holding the scalable I/O bracket (1 pcs)</td></tr> <tr> <td>B</td><td>Screws holding the process plate (4 pcs)</td></tr> </table>	A	Screws holding the scalable I/O bracket (1 pcs)	B	Screws holding the process plate (4 pcs)
A	Screws holding the scalable I/O bracket (1 pcs)				
B	Screws holding the process plate (4 pcs)				
4 Pull out the process plate with the assembly from the two guide pins on the mounting plate.	<p> Note</p> <p>Avoid colliding with the frame when removing the unit.</p>				

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension *Continued*

Installing the harness 24 V extension

	Action	Note/Illustration
1	Insert the harness into the front panel from inside of the cabinet and secure the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000742
2	Connect: • X45 - T5.X2.	
3	Insert the cables into the clips on the bottom of the cabinet.	 xx1900001006

Refitting the main computer assembly with process plate to the cabinet


	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension



Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx1800000683
3 Use the two guide pins to locate the assembly onto the mounting plate.	 Note Be careful with the frame of the controller when refitting the unit.

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension *Continued*

Action	Note/Illustration				
4 Fasten the assembly with the screws.  WARNING Be careful with the cables installed below the process plate.	 <p>xx1800000532</p>  <p>xx1900000215</p> <table border="1"> <tr> <td>A</td> <td>Screws, Torx pan head, M4x8 (1 pcs)</td> </tr> <tr> <td>B</td> <td>Screws, Torx pan head, M4x8 (4 pcs)</td> </tr> </table>	A	Screws, Torx pan head, M4x8 (1 pcs)	B	Screws, Torx pan head, M4x8 (4 pcs)
A	Screws, Torx pan head, M4x8 (1 pcs)				
B	Screws, Torx pan head, M4x8 (4 pcs)				
5 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.					

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none">• K2.X8 - A2.X6• (option): K2.X2 - K4.X8, A2.X1• K2.X12 - A2.K3.X6, A2.K3.X7• K2.X10 - A1.X13• K2.X21 - TempSensor• K2.X4 - A1.X9• K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1• K2.X1 - T2.X2⁵³• K2.X1 - X107⁵⁴• K2.X17 - G2.X1, G1.X2• K2.X6, K2.X11 - A1.X2• K2.X7, K2.X22 - Harn. LV robot power• K2.X9 & X13 - FlexPendant	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3ⁱ• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension *Continued*

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none">• K2.X8 - A2.X6• K2.X2 - K4.X8, A2.X1• K2.X12 - A2.K3.X6, A2.K3.X7• A2.X9 - K6.X2⁵³• A2.X9 - X1⁵⁴• A2.X5 - K7.X2• (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none">• (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none">• (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none">• K5.1.X4 - K2.X3• K5.1.X5 - Harness adapter	

ⁱ For connected services gateway wired, there is no power cable.

Fitting the optional power supply


Action	Note/Illustration
1 Fit the optional power supply.	
2 Connect: <ul style="list-style-type: none">• T5.X2 - X45.	

Continues on next page


3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension

Continued

Action	Note/Illustration		
3 Secure the optional power supply with the screws.	Screws: Torx pan head screw M4x8 (4 pcs)		
4 Connect: <ul style="list-style-type: none"> A1.X7 - T5.X1  Note The connector on the AC_in cable (3HAC061099-001) is fastened to the cable clip in the illustration when the power supply optional is not selected.	 xx1800001188 <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="padding: 2px;">A</td> <td style="padding: 2px;">Cable clip</td> </tr> </table>	A	Cable clip
A	Cable clip		


Refitting the axis computer to the frame

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Reconnect and secure the screw: <ul style="list-style-type: none"> K6.X4, K6.X5 - SMB. 	


Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension Continued

	Action	Note/Illustration
4	Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs) 
5	Reconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3	

Refitting the small fan



	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3	Reconnect: • G2.X1-K2.X17	

Continues on next page

3 Installation and commissioning

3.7.4 Installing the power supply optional device and the harness 24 V extension

Continued

Action	Note/Illustration
4 Refit the fan bracket into the cabinet.	 xx1800000483
5 Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Concluding procedure


Action	Note/Illustration
1 Refit the top cover.	Refitting the top cover on page 230
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

3.7.5 Installing the fieldbus master and the DeviceNet harness

3.7.5 Installing the fieldbus master and the DeviceNet harness

Location


The illustration shows the location of the fieldbus master in the main computer.



xx1800003420

Harness DeviceNet is an option of process connector.

The illustration shows the location of the harness DeviceNet in the controller.



xx1800000737



Note

The DeviceNet board and the DeviceNet harness must be installed at the same time.

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
DeviceNet Board	3HAC043383-001	DSQC1006
Harness DeviceNet/Harness 24V ext. cover plate	3HAC063601-001	
Harness DeviceNet connection	3HAC062150-001	DSQC1004
Connector assembly Single-row female	3HAC064901-001	Mating CONN for IP20 DeviceNet connector

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Installing the DeviceNet board and the DeviceNet harness

Preparations


	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i>	Location of wrist strap button: 
3 Remove the top and right covers, and the front panel of the controller.	Removing the controller covers on page 222



Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued


Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: <ul style="list-style-type: none">• G2.X1-K2.X17	

Removing the axis computer from the cabinet

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none">• K6.X11 - A1.X3• K6.X2 - A2.X9• K6.X1 - K2.X3.	

Continues on next page

Action	Note/Illustration
2 Remove the screws on the bracket.	
3 Loosen the screw and disconnect: <ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	

Removing the main computer assembly with process plate

Action	Note/Illustration
1 Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer.	
2 For the robot signal exchange proxy: <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2¹⁰ • K2.X1 - X107¹¹ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	

10 Not available for CRB 15000 controller.

11 Only available for CRB 15000 controller.

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3¹²• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	


¹² For connected services gateway wired, there is no power cable.

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued



Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2 ¹⁰ • A2.X9 - X1 ¹¹ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	
<p>2 Remove the mating connectors from the front side by loosening their attachment screws.</p>	

Continues on next page

3 Installation and commissioning



3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
3 Remove the screws holding the process plate and the screws holding the scalable I/O bracket.	 xx1800000532  xx1900000215
A Screws holding the scalable I/O bracket (1 pcs) B Screws holding the process plate (4 pcs)	<p>4 Pull out the process plate with the assembly from the two guide pins on the mounting plate.</p> <p> Note</p> <p>Avoid colliding with the frame when removing the unit.</p>

Continues on next page

Removing the robot signal exchange proxy

	Action	Note/Illustration
1	 ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx2000000532
2	Pull the cable ties out from the locking holes.	
3	Remove the screws and lift out the robot signal exchange proxy.  Note Avoid colliding with the frame of the controller.	 xx1800000488



Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness


Continued

Removing the Ethernet extension switch (option)


Action	Note/Illustration
1 Carefully pull the side of the Ethernet extension switch and rotate it tightly to take it out from the bracket.	 xx1800000538  xx1800000491

Continues on next page

Removing the connected services gateway

	Action	Note/Illustration
1	Carefully pull the side of the connected services gateway and rotate it tightly to take it out from the bracket.	 <p>xx1800000495 TOP VIEW</p>

Removing the main computer



	Action	Note/Illustration
1	Remove the screws holding the main computer.	 <p>xx1800000540</p>

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
2 Remove the main computer.  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	  xx1800000542

Installing the DeviceNet board




Action	Note/Illustration
1  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued



Action	Note/Illustration				
2 Remove the screws on top of the main computer and take the cover off.	 xx1800003415				
3 Remove the attachment screw on the cover of the fieldbus master and take out the cover.	 xx1800003414				
4 Insert the DeviceNet board into the card slots along the guide rail in the main computer.	 xx1800003417 <table border="1" data-bbox="944 1830 1421 1942"> <tr> <td>A</td> <td>Card slots</td> </tr> <tr> <td>B</td> <td>Guide rail</td> </tr> </table>	A	Card slots	B	Guide rail
A	Card slots				
B	Guide rail				

Continues on next page


3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

	Action	Note/Illustration
5	Secure the DeviceNet board with the screw.	Screw: Screw with flange M3x6 (1 pcs)  xx1800003416
6	Refit the cover on the main computer and secure the screws.	Screws: Torx, countersunk screw M4x10 (4 pcs)  xx1800003418

Installing the harness for DeviceNet



	Action	Note/Illustration
1	Remove the screws for the cover plate on the front panel.	 xx1800001278

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
2 Press the cover plate into the cabinet, and lift it out.	
3 Insert the harness into the front panel from inside of the cabinet and secure the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000739
4 Insert the cables into the clips on the bottom of the cabinet.	 xx1900001008

Refitting the main computer





Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued


Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532
3 Fit the main computer to the process plate.	   xx1800000543

Continues on next page


3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
4 Fasten the main computer with the screws.	Screws: Torx pan head screw M4x8 (2 pcs)  xx1800000541

Refitting the connected services gateway


Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532

Continues on next page


3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness



Continued

Action	Note/Illustration
3 Hook up the connected services gateway to the bracket and push carefully into position.  Note During the installation, the gap between the lower surface of the connected services gateway and the upper surface of the main computer should be zero.	 xx1800000497 TOP VIEW

Refitting the Ethernet extension switch (option)

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 

Continues on next page

Action	Note/Illustration
<p>3 Hook up the Ethernet extension switch to the bracket and then push the switch into position.</p> <p>Note</p> <p>During the installation, there should be no gap between the upper surface of the Ethernet extension switch and the lower surface of highest bracket on the main computer.</p> 	 xx1800000539

Refitting the robot signal exchange proxy




Action	Note/Illustration
<p>1</p> <p>DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
<p>2</p>  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532
<p>3</p>  Note Fit the robot signal exchange proxy and secure the screws. Avoid colliding with the frame of the controller.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000489
<p>4</p> Insert the cable ties into the locking holes.	 xx1800000971

Refitting the main computer assembly with process plate to the cabinet


Action	Note/Illustration
<p>1</p>  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued



Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx1800000683
3 Use the two guide pins to locate the assembly onto the mounting plate.	 Note Be careful with the frame of the controller when refitting the unit.

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration				
4 Fasten the assembly with the screws.	<p>WARNING</p> <p>Be careful with the cables installed below the process plate.</p>   <table border="1"><tr><td>A</td><td>Screws, Torx pan head, M4x8 (1 pcs)</td></tr><tr><td>B</td><td>Screws, Torx pan head, M4x8 (4 pcs)</td></tr></table>	A	Screws, Torx pan head, M4x8 (1 pcs)	B	Screws, Torx pan head, M4x8 (4 pcs)
A	Screws, Torx pan head, M4x8 (1 pcs)				
B	Screws, Torx pan head, M4x8 (4 pcs)				
5 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.					

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none">• K2.X8 - A2.X6• (option): K2.X2 - K4.X8, A2.X1• K2.X12 - A2.K3.X6, A2.K3.X7• K2.X10 - A1.X13• K2.X21 - TempSensor• K2.X4 - A1.X9• K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1• K2.X1 - T2.X2⁵³• K2.X1 - X107⁵⁴• K2.X17 - G2.X1, G1.X2• K2.X6, K2.X11 - A1.X2• K2.X7, K2.X22 - Harn. LV robot power• K2.X9 & X13 - FlexPendant	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3ⁱ• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none">• K2.X8 - A2.X6• K2.X2 - K4.X8, A2.X1• K2.X12 - A2.K3.X6, A2.K3.X7• A2.X9 - K6.X2⁵³• A2.X9 - X1⁵⁴• A2.X5 - K7.X2• (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none">• (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none">• (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none">• K5.1.X4 - K2.X3• K5.1.X5 - Harness adapter	

i For connected services gateway wired, there is no power cable.

Refitting the axis computer to the frame



Action	Note/Illustration
<p>1</p> <p> DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i>	Location of wrist strap button:  xx1800000683
3 Reconnect and secure the screw: • K6.X4, K6.X5 - SMB.	
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000476
5 Reconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3	

Refitting the small fan




Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see <i>Electrical safety on page 31.</i>	

Continues on next page

3 Installation and commissioning

3.7.5 Installing the fieldbus master and the DeviceNet harness

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47</i> .	Location of wrist strap button: 
3 Reconnect: • G2.X1-K2.X17	
4 Refit the fan bracket into the cabinet.	 xx1800000483
5 Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Continues on next page

Concluding procedure

	Action	Note/Illustration
1	Refit the covers.	<i>Refitting the controller covers on page 227</i>
2	Perform the function tests to verify that the safety features work properly, see <i>Function tests on page 212</i> .	

3 Installation and commissioning

3.8.1 Installing the scalable I/O add-on devices

3.8 Installing add-on devices


3.8.1 Installing the scalable I/O add-on devices

Overview

To install the scalable I/O add-on devices, the digital base DSQC 1030 must be installed as an external unit.

How to install the add-on devices is described in *Application manual - Scalable I/O*.

The scalable I/O add-on devices are shown in the following illustration.




xx1600002032

3.8.2 Installing the conveyor tracking module

Overview

The CTM-01 uses network communication to share conveyor speed and position data with one or more robot controllers. It contains a WAN port, which is used to connect to the robot controllers and two LAN ports that can be used for installation and service purposes.



Required parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Conveyor tracker module [3103-1]	3HNA027579-001	DSQC2000
CONNECTOR KIT - DSQC2000	3HNA029345-001	

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Continues on next page

3 Installation and commissioning


3.8.2 Installing the conveyor tracking module

Continued

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	
<i>Application manual - Conveyor tracking</i>	3HAC066561-001	
<i>Application manual - DeviceNet Master/Slave</i>	3HAC066562-001	

Installing the conveyor tracking module


	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Fit the conveyor tracking module by snapping it onto the mounting rail (not supplied from ABB).	
4	Connect the 24V power supply to the conveyor tracking module from the IP20 power outlet or other power supply.	
5	The CTM must be connected to Ethernet. There are three main installation methods for the Ethernet communication.	For more detail, see Application manual - Conveyor tracking chapter Connecting the CTM to the robot controller .
6	Connect wires to the input and output connectors as required.	See Application manual - Conveyor tracking .

For more information about the option **Conveyor Tracking**, see [Application manual - Conveyor tracking](#).

3.8.3 Installing Integrated Vision

Overview

The Integrated Vision is installed as shown in the following illustration.



xx1800003413

A	Ethernet
B	24V power supply from the customer power supply to the switch and to the cameras

Required parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
8 mm camera lens, LTC-08F	3HAC053944-001	
12.5 mm camera lens, LFC-12.5F	3HAC053944-002	
16 mm camera lens, LFC-16F1	3HAC053944-003	
25 mm camera lens, LFC-25F1	3HAC053944-004	
Integr Vision camera med. Res	3HAC053953-001	DSQC1020
Integr Vision camera high res	3HAC053954-001	DSQC1021

Continues on next page

3 Installation and commissioning

3.8.3 Installing Integrated Vision

Continued

Spare part	Article number	Note
Integr Vision power cable	3HAC051753-003	
Integr Vision ethernet cable	3HAC051736-003	


Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section <i>Standard toolkit for controller on page 570</i> .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	
<i>Application manual - Integrated Vision</i>	3HAC067707-001	

Installing Integrated Vision camera connections

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see <i>Electrical safety on page 31</i> .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47</i> .	Location of wrist strap button: 
3	Fit the cameras to the mounting rail (not supplied from ABB).	
4	Connect the Ethernet cable from the camera to any of the LAN connectors on the main computer or the Ethernet switch.	

Continues on next page

	Action	Note/Illustration
5	Connect the 24V power supply to the cameras from the IP20 power outlet connector or other power supply.	
6	Connect wires to the inputs and output connectors as required.	See <i>Application manual - Integrated Vision</i> .

For more information about the option *Integrated Vision*, see *Application manual - Integrated Vision*.

3 Installation and commissioning

3.9 Initial test before commissioning

Protective earth

Before supplying power to the robot and commissioning, verify that the cabinet is connected to protective earth according to [*Connecting power supply to and grounding the controller on page 97.*](#)

Function tests

Before commissioning, perform the function tests in section [*Function tests on page 212*](#) to verify that the safety features work properly.

4 Maintenance

4.1 Maintenance schedule, OmniCore

General

The controller must be maintained at regular intervals to ensure its function. The activities and intervals are described in this section.

Activities and intervals

Equipment	Maintenance activity	Interval	Detailed in section:
Complete controller	Inspection	12 months ⁱ	Inspecting the OmniCore C30 controller on page 203
Air filter element	Replacement	24 months *	Replacement of air filter element for the controller with vertical mounting kit on page 208
System fans	Inspection	6 months ⁱ	Inspecting the OmniCore C30 controller on page 203
Control cabinet	Cleaning		Cleaning of the controller cabinet on page 205
FlexPendant	Cleaning	When needed	Cleaning the FlexPendant on page 206
Emergency stop (FlexPendant)	Function test	12 months	Function test of emergency stop on page 212
Manual, auto and manual full speed mode with FlexPendant	Function test	12 months	Function test of manual, auto, and manual full speed mode with FlexPendant on page 213
Enable device	Function test	12 months	Function test of three-position enabling device on page 214
Safety switches	Function test	12 months	Function test of safety switches on page 215
Auto stop (tested if used)	Function test	12 months	Function test of Automatic Stop on page 216
General stop (tested if used)	Function test	12 months	Function test of General Stop on page 217
External emergency stop (tested if used)	Function test	12 months	Function test of external emergency stop on page 218
ESTOP_STATUS output (tested if used)	Function test	12 months	Function test of ESTOP_STATUS output on page 219
Reduced speed control	Function test	During commissioning	Function test of reduced speed control on page 220 .

ⁱ The interval depends on the working environment of the equipment: a cleaner environment may extend the maintenance interval and vice versa.

Continues on next page

4 Maintenance

4.1 Maintenance schedule, OmniCore

Continued




Function test after replacement of component

After replacing a component in the controller, the function tests should be performed. See [Function tests on page 212](#).

4.2 Inspection activities

4.2.1 Inspection of controller

Inspecting the OmniCore C30 controller

	Action	Note/illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Inspect connectors and cabling to make sure they are securely fastened and cabling not damaged.	
4	Inspect the fans and ventilation holes to make sure they are clean.	  xx180000062

Continues on next page

4 Maintenance

4.2.1 Inspection of controller

Continued

	Action	Note/illustration
5	After inspection: Temporarily turn the power supply on. Inspect the fans to make sure they function correctly. Switch the power off.	

4.3 Cleaning activities

4.3.1 Cleaning of the controller cabinet

Required equipment

Equipment, etc.	Note
Vacuum cleaner	ESD protected

Internal cleaning

Clean the cabinet interior with an ESD protected vacuum cleaner, if necessary.

Cleaning considerations

This section specifies some special considerations when cleaning the controller.

- Always use ESD protection.
- Always use cleaning equipment as specified above. Any other cleaning equipment may shorten the life of paint work, rust inhibitors, signs, or labels.
- Always make sure that all protective covers are fitted to the controller before cleaning.
- Never remove any covers or other protective devices when cleaning the outside of the controller.
- Never use compressed air or spray with a high pressure cleaner.
- Never leave the door open when cleaning the exterior.


4 Maintenance

4.3.2 Cleaning the FlexPendant

4.3.2 Cleaning the FlexPendant

Location

The surfaces to clean are shown in the illustration below.



xx1800000128

A	Touch screen
B	Hard buttons

Required equipment

Equipment, etc.	Note
Soft cloth	ESD protected
Water/Mild cleaning agent	

Clean the touch screen

This section describes how to clean the touch screen.

	Action	Info/Illustration
1	Lock the screen.	
2	It is safe to clean the FlexPendant when the Lock screen appears.	
3	Clean the touch screen and hardware buttons using a soft cloth and water or a mild cleaning agent.	
4	Unlock the screen, by tapping the buttons.	

Cleaning considerations

The section below specifies some special considerations when cleaning the FlexPendant:

- Use ESD Protection
- Use cleaning equipment as specified above. Any other cleaning equipment may shorten the life time of the touch screen.
- Check that all protective covers are fitted to the device before cleaning.
- Make sure that no foreign objects or liquids can penetrate into the device.

Continues on next page

4.3.2 Cleaning the FlexPendant

Continued

- Do not remove any covers before cleaning the FlexPendant.
- Do not spray with a high pressure cleaner.
- Do not clean the device, operating panel and operating elements with compressed air, solvents, scouring agent or scrubbing sponges.

4 Maintenance


4.4.1 Replacement of air filter element for the controller with vertical mounting kit

4.4 Changing/replacing activities

4.4.1 Replacement of air filter element for the controller with vertical mounting kit

Location

The air filter is located as shown in the illustration below.



Required equipment

Equipment	Note
Air filter element	
Other tools and procedures may be required. See references to these procedures in the step-by-step instructions below.	These procedures include references to the tools required.

Continues on next page


4.4.1 Replacement of air filter element for the controller with vertical mounting kit
Continued

Removing the air filter element

Preparations

Action	Note/Illustration
<p>1</p>  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Removing the left cover unit

Action	Note/Illustration
<p>1</p> Loosen the attachment screws on left cover unit.	
<p>2</p> Remove the left cover unit.	


Continues on next page

4 Maintenance

4.4.1 Replacement of air filter element for the controller with vertical mounting kit


Continued

Removing the polymeric filter element

	Action	Note/Illustration
1	Take out the polymeric filter element from the inner side of the left cover unit.	 xx2000001854

Refitting the air filter element

Refitting the polymeric filter element


	Action	Note/Illustration
1	Insert the polymeric filter element to the inner side of the left cover unit.	 xx2000001855

Refitting the left cover unit

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

4.4.1 Replacement of air filter element for the controller with vertical mounting kit
Continued

	Action	Note/Illustration
2	Refit the left cover unit to the cabinet. Secure it with the screws.	 xx2000001857

Concluding procedure

	Action	Note/Illustration
1	Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

4 Maintenance

4.5.1 Function test of emergency stop

4.5 Function tests

4.5.1 Function test of emergency stop

Overview

Validate the function of the FlexPendant emergency stop device.



Note

Also perform the test for any additional emergency stop devices.

Performing the function test

	Action	Note
1	Make a visual inspection of the emergency stop device to make sure it is not physically damaged.	If any damage is found on the emergency stop device, it must be replaced.
2	Pull and rotate the emergency stop device clockwise to verify that it is not pressed in.	
3	Power on the robot.	
4	Press the emergency stop device on the FlexPendant. Note If the event message 20223 Emergency stop conflict appears in the event log, or the event message 10013 Emergency stop state (and 90518 Safety controller Emergency stop triggered for collaborative robots) does not appear, then the test has failed and the root cause of the failure must be found.	The test is passed if the event message 10013 Emergency stop state appears in the event log. Note For collaborative robots, the event message 90518 Safety controller Emergency stop triggered appears by default. The message 10013 Emergency stop state is also available in the event log.
5	Release the emergency stop device to reset the emergency stop state.	

4.5.2 Function test of manual, auto, and manual full speed mode with FlexPendant

4.5.2 Function test of manual, auto, and manual full speed mode with FlexPendant**Overview**

Perform this function test to change the mode on the FlexPendant using the following operation:

- Status bar > Common Settings > Operating Mode (Auto/Manual/Man FS).

For more detailed information, see *Operating manual - OmniCore, 3HAC065036-001*.

Performing the function test

	Action	Note
1	Start the robot system.	
2	Change to Automatic operating mode and Motors ON state, and then run the robot in auto mode.	This test is passed if it is possible to run the robot program in auto mode. If it is not possible to run the robot program, this test is failed and the root cause of the failure must be found.
3	Change to Manual operating mode and Motors ON state, and then run the robot in manual mode.	This test is passed if it is possible to run the robot program in manual mode. If it is not possible to run the robot program, this test is failed and the root cause of the failure must be found.
4	Change to Manual Full Speed mode and Motors ON state, and then run the robot in manual full speed mode.  Note Manual full speed mode is not available in USA or Canada.	This test is passed if it is possible to run the robot program in manual full speed mode. If it is not possible to run the robot program, this test is failed and the root cause of the failure must be found.

4 Maintenance

4.5.3 Function test of three-position enabling device

4.5.3 Function test of three-position enabling device

Performing the function test

Action	Note
1 Start the robot system and turn the mode switch to manual mode.	
2 Press the three-position enabling device to the middle position and then hold the enabling device in this position.	This test is passed if the event message 10011 Motors ON state appears in the event log. If the event message 10011 Motors ON state does not appear, or if the event message 20224 Enabling device conflict appears in the event log, then the test has failed and the root cause of the failure must be found.
3 While still holding the three-position enabling device pressed, press the enabling device harder to the enable the device's third position.	This test is passed if the event message 10012 safety guard stop state appears in the event log. If the event message 10012 Safety guard stop state does not appear, or if the event message 20224 Enabling device conflict appears in the event log, then the test has failed and the root cause of the failure must be found.

4.5.4 Function test of safety switches

Performing the motor function test

	Action	Note
1	Start the robot system and change the operating mode to manual.	
2	Press the three-position enabling device to the middle position and then hold the enabling device in this position.	This test is passed if the event message 10011 Motors ON state appears in the event log. If the event message 37001 Motor on activation error appears in the event log, then the test has failed and the root cause of the failure must be found.
3	Release the three-position enabling device.	This test is passed if the event message 10012 Safety guard stop state appears in the event log. If the event message 20227 Motor contactor conflict appears in the event log, then the test has failed and the root cause of the failure must be found.

Performing the brake function test

	Action	Note
1	Start the robot system and change the operating mode to manual.	
2	Press the three-position enabling device to the middle position and then hold the enabling device in this position. While having eye contact with the manipulator, move the joystick slightly in any direction to disengage the brakes.	This test is passed if the brakes are disengaged and the manipulator can be moved. If the event message 50056 Joint collision appears in the event log, then the test has failed and the root cause of the failure must be found.
3	Release the three-position enabling device to engage the brakes.	This test is passed if the event message 10012 Safety guard stop state appears in the event log. If the event message 37101 Brake failure appears in the event log, then the test has failed and the root cause of the failure must be found.

4 Maintenance

4.5.5 Function test of Automatic Stop

4.5.5 Function test of Automatic Stop

Performing the function test

Action	Note
1 Start the robot system and change the operating mode to auto mode.	
2 Activate the Automatic Stop, for example by opening the connected robot cell door, which has interlock connection with Automatic Stop.	The test is passed if the event message 90523 Safety Controller Protective Stop triggered appears in the event log. If the event message 90523 Safety Controller Protective Stop triggered does not appear in the event log, then the test has failed and the root cause of the failure must be found.

4.5.6 Function test of General Stop

Performing the function test

	Action	Note
1	Start the robot system.	
2	Activate the General Stop.	<p>The test is passed if the event message 90523 Safety Controller Protective Stop triggered appears in the event log.</p> <p>If the event message 90523 Safety Controller Protective Stop triggered does not appear in the event log, then the test has failed and the root cause of the failure must be found.</p>

4 Maintenance

4.5.7 Function test of external emergency stop

4.5.7 Function test of external emergency stop

Overview

Perform this test on the external emergency stop device.

Performing the function test

Action	Note
1 Make a visual inspection of the external emergency stop device and the connection harness to make sure they are not physically damaged.	If any damage is found on the external emergency stop device or the connection harness, it must be replaced.
2 Pull and rotate the button on the external emergency stop device clockwise to verify that it is not pressed in.  Note If the external emergency stop device is not controlled by a push-button, make sure to verify that it is not activated.	
3 Start the robot system.	
4 Press the emergency stop device.  Note If the event message 20223 Emergency stop conflict appears in the event log, or the event message 10013 Emergency stop state (and 90518 Safety controller Emergency stop triggered for collaborative robots) does not appear, then the test has failed and the root cause of the failure must be found.	The test is passed if the event message 10013 Emergency stop state appears in the event log.  Note For collaborative robots, the event message 90518 Safety controller Emergency stop triggered appears by default. The message 10013 Emergency stop state is also available in the event log.
5 Release the external emergency stop device to reset the external emergency stop state.	

4.5.8 Function test of ESTOP_STATUS output

Overview

Perform this test on the FlexPendant emergency stop device or the external emergency stop device, with the accessory device.

Performing the function test

	Action	Note
1	Make a visual inspection of the emergency stop device, external emergency stop device, accessory device and the connection harness to make sure they are not physically damaged.	If any damage is found, it must be replaced.
2	Pull and rotate the emergency stop device clockwise to verify that it is not pressed in.  Note If the external emergency stop device is not controlled by a push-button, make sure to verify that it is not activated.	
3	Start the robot system.	
4	Press the emergency stop device.  Note If the event message 20223 Emergency stop conflict appears in the event log, or the event message 10013 Emergency stop state (and 90518 Safety controller Emergency stop triggered for collaborative robots) does not appear, then the test has failed and the root cause of the failure must be found.	The test is passed if the event message 10013 Emergency stop state appears in the event log.  Note For collaborative robots, the event message 90518 Safety controller Emergency stop triggered appears by default. The message 10013 Emergency stop state is also available in the event log.
5	Make sure that the accessory device is in emergency stop status.	
6	Release the emergency stop device or the external emergency stop device to reset the emergency stop state.	
7	Make sure that the accessory device is not in emergency stop status any more and can be reset.	

4 Maintenance

4.5.9 Function test of reduced speed control

4.5.9 Function test of reduced speed control

Performing the function test

Action	Note
1 Start the robot system and change the operating mode to manual.	
2 Create a test program where the robot moves along a known distance with a programmed speed higher than 250 mm/s.	The distance and speed must be adapted to the current installation and robot model.
3 Start the program in manual mode and measure the time it takes for the robot to travel the distance.  Tip To get accurate results, use sensors or I/O signals to measure the time.	This test is passed if the speed of the robot does not exceed 250 mm/s, otherwise the test is failed and the root cause of the failure must be found.

5 Repair

5.1 Introduction to repair

Structure of this chapter

This chapter describes all repair activities recommended for the OmniCore C30 and any external unit.

It is made up of separate procedures, each describing a specific repair activity. Each procedure contains all the information required to perform the activity, for example spare parts numbers, required special tools, and materials.

All procedures assume that the controller is easy to access from all sides and that no additional covers or equipment are fitted.



WARNING

Repair activities not described in this chapter must only be carried out by ABB. Otherwise damage to the mechanics and electronics may occur.

Required equipment

The details of the equipment required to perform a specific repair activity are listed in the respective procedures.

Safety information

There are general safety information and specific safety information. The specific safety information describes the danger and safety risks while performing specific steps in a procedure. Make sure to read through the chapter [Safety on page 15](#) before commencing any service work.



WARNING

Wait at least three minutes after powering off the controller before opening it and at least fifteen minutes until all LED indicators are off before replacing modules.



Note

When replacing a part on the OmniCore C30, report to your local ABB the serial number, the article number, and the revision of both the replaced unit and the replacement unit.

This is particularly important for safety equipment to maintain the safety integrity of the installation.

5 Repair

5.2.1 Opening the robot controller

5.2 Replacing parts inside the controller

5.2.1 Opening the robot controller

Required tools and equipment


Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	


Removing the controller covers

Preparations

	Action	Info/illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683

Continues on next page

Removing the top cover

	Action	Info/illustration
1	Remove the attachment screws.	
2	Remove the top cover.	

Removing the front panel




	Action	Info/illustration
1	Disconnect all the cables from the front panel.	

Continues on next page

5 Repair

5.2.1 Opening the robot controller

Continued



	Action	Info/illustration
2	Remove the robot signal exchange proxy connectors by removing the screws.	 xx1700001894
3	Remove the scalable I/O digital base connectors by removing the screws. (option)	 xx1800000743
4	Remove the screws and the front panel.	 xx1700001895

Removing the right side cover

	Action	Info/illustration
1	Remove the top cover.	Removing the top cover on page 223 .

Continues on next page

5.2.1 Opening the robot controller
Continued

Action	Info/illustration
2 Remove the screws.	 <p>xx1800000466</p>
3 Lift the right side cover slightly to make it leave the guide holes on the upper frame.	 <p>xx1800000467</p>
4 Remove the right side cover.	

Removing the left side cover



Action	Info/illustration
1 Remove the top cover.	Removing the top cover on page 223.

Continues on next page


5 Repair

5.2.1 Opening the robot controller

Continued


Action	Info/illustration
2 Remove the screws.	 xx1700001896
3 Lift the left side cover slightly to make it leave the guide holes on the upper frame.	
4 Remove the left side cover.	 xx1700001897

Removing the rear cover



Action	Info/illustration
1 Remove the screws.	 xx1800000468
2 Remove the rear cover.	

Continues on next page

Refitting the controller covers**Preparations**

Action	Info/illustration
<p>1</p>  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
<p>2</p>  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683

Refitting the right side cover

Action	Info/illustration
<p>1</p> Place the right side cover into the guide holes and press it into the locking position.	 xx1800000469
<p>2</p> Fasten with screws.	Screws: Torx, countersunk screw M4x10 (6 pcs)  xx1800000470

Continues on next page



5 Repair

5.2.1 Opening the robot controller

Continued

	Action	Info/illustration
3	Refit the top cover.	Refitting the top cover on page 230

Refitting the left side cover




	Action	Info/illustration
1	Place the left side cover into the guide holes and press it into the locking position.	 xx1800000027
2	Fasten with screws.	Screws: Torx, countersunk screw M4x10 (6 pcs)  xx1700001900
3	Refit the top cover.	Refitting the top cover on page 230

Refitting the front panel

	Action	Info/illustration
1	Refit the front panel using the location pins.	

Continues on next page

5.2.1 Opening the robot controller
Continued

Action	Info/illustration
2 Secure with screws.	<p>Screws: Torx, countersunk screw M4x10 (5 pcs)</p>  <p>xx1700001899</p>
3 Refit the scalable I/O digital base connectors (option) and tighten the screws.	 <p>xx1800000744</p>
4 Refit the robot signal exchange proxy connectors and tighten the screws.	 <p>xx1700001898</p>
5 Reconnect all the cables on the front panel.	


Continues on next page

5 Repair


5.2.1 Opening the robot controller

Continued

Refitting the top cover

Action	Info/illustration
1 Refit the top cover using the location pins.	Screws: Torx, countersunk screw M4x10 (8 pcs)
2 Secure it with the screws.	 <p>xx1700001893</p> <p>A Location pins</p>


Refitting the rear cover

Action	Info/illustration
1 Refit the the rear cover.	Screws: Torx, countersunk screw M4x10 (6 pcs)
2 Secure it with the screws.	 <p>xx1800000471</p>

5.2.2 Replacing the axis computer

Location

The illustration shows the location of the axis computer in the controller.



xx1700001890



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Axis Computer	3HAC029157-001	DSQC 668

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Continues on next page

5 Repair

5.2.2 Replacing the axis computer


Continued

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the axis computer

Preparations


	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3	Remove the top cover.	Removing the controller covers on page 222 .

Removing the axis computer from the cabinet

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none">• K6.X11 - A1.X3• K6.X2 - A2.X9• K6.X1 - K2.X3.	

Continues on next page

5.2.2 Replacing the axis computer
Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	 xx1800000472
3 Loosen the screw and disconnect: • K6.X4, K6.X5 - SMB.	



Continues on next page

5 Repair

5.2.2 Replacing the axis computer


Continued

Removing the axis computer

	Action	Note/Illustration
1	Remove the bracket screws.	
2	Remove the axis computer.	

Refitting the axis computer

Refitting the axis computer



	Action	Note/Illustration
1	Refit the axis computer to the bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs) 

Refitting the axis computer to the frame

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.2 Replacing the axis computer *Continued*

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Reconnect and secure the screw: • K6.X4, K6.X5 - SMB.	
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000476
5 Reconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3	

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227 .
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	


5 Repair

5.2.3 Replacing the fans

5.2.3 Replacing the fans

Location

The illustration shows the location of the fans in the controller.



xx1800000026

A	Small fan
B	Standard fan



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Standard fan	3HAC059214-001	
Standard size silent fan unit	3HAC077005-001	Used for IRB 14050 and CRB 15000 controllers
Small fan	3HAC063917-001	

Continues on next page

Spare part	Article number	Note
Small fan	3HAC077006-001	Used for IRB 14050 and CRB 15000 controllers

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Continues on next page

5 Repair

5.2.3.1 Replacing the standard fans



Note

There are two types of Standard fan used in OmniCore C30.

Make sure which type is used in your machine before do the replacement procedure.



Note

The replacement of the old fan and the new fan are both listed in this chapter, please refer to the correct procedure that you need.


- [*Replacing the standard fan on page 239*](#)
- [*Replacing the standard fan to a standard size silent fan unit on page 243*](#)
- [*Replacing the standard size silent fan unit on page 247*](#)

Continues on next page

5.2.3.1.1 Replacing the standard fan

Removing the standard fan

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3	Remove the top and right covers of the controller.	Removing the controller covers on page 222 .

Removing the standard fan




	Action	Note/Illustration
1	Disconnect standard fan: <ul style="list-style-type: none"> • G1.X2-K2.X17 	

Continues on next page

5 Repair

5.2.3.1.1 Replacing the standard fan

Continued

Action	Note/Illustration
2 Remove the fan bracket screws.	 xx1800000477
3 Slide the fan bracket a little to the left and remove it.	 xx1800000714  xx1800000478

Refitting the standard fan


Refitting the standard fan

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.3.1.1 Replacing the standard fan

Continued




Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD</i> on page 47.	Location of wrist strap button:  xx1800000683

Continues on next page

5 Repair

5.2.3.1.1 Replacing the standard fan

Continued


Action	Note/Illustration
3 Refit the standard fan with the bracket. Push and slide the bracket into position.	 xx1800000481  xx1800000715
4 Secure the screws.	Screws: Torx, countersunk screw M4x10 (4 pcs)  xx1800000482
5 Reconnect: <ul style="list-style-type: none"> G1.X2-K2.X17 	

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

5.2.3.1.2 Replacing the standard fan to a standard size silent fan unit

5.2.3.1.2 Replacing the standard fan to a standard size silent fan unit**Removing the standard fan****Preparations**

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the top and right covers of the controller.	Removing the controller covers on page 222 .

Removing the standard fan




	Action	Note/Illustration
1	Disconnect standard fan: <ul style="list-style-type: none"> • G1.X2-K2.X17 	

Continues on next page

5 Repair

5.2.3.1.2 Replacing the standard fan to a standard size silent fan unit

Continued

Action	Note/Illustration
2 Remove the fan bracket screws.	 xx1800000477
3 Slide the fan bracket a little to the left and remove it.	 xx1800000714  xx1800000478

Refitting the standard size silent fan unit



Refitting the standard size silent fan unit

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.3.1.2 Replacing the standard fan to a standard size silent fan unit

Continued




Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i>	Location of wrist strap button:  xx1800000683
3 Remove the cover screws. 4 Remove the cover from the standard size silent fan unit.	 xx2000002205

Continues on next page

5 Repair

5.2.3.1.2 Replacing the standard fan to a standard size silent fan unit

Continued

Action	Note/Illustration
5 Refit the standard fan with the bracket. Push and slide the bracket into position.	 xx2000002206  xx2000002207
6 Secure the screws.	Screws: Torx, countersunk screw M4x10 (4 pcs)  xx2000002215
7 Reconnect:	<ul style="list-style-type: none"> • G1.X2-K2.X17

Concluding procedure


Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

5.2.3.1.3 Replacing the standard size silent fan unit

5.2.3.1.3 Replacing the standard size silent fan unit

Removing the standard size silent fan unit

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the top and right covers of the controller.	Removing the controller covers on page 222 .

Removing the standard size silent fan unit




	Action	Note/Illustration
1	Disconnect standard fan: <ul style="list-style-type: none"> • G1.X2-K2.X17 	

Continues on next page

5 Repair

5.2.3.1.3 Replacing the standard size silent fan unit

Continued

Action	Note/Illustration
2 Remove the fan bracket screws.	 xx2000002106
3 Slide the fan bracket a little to the left and remove it.	 xx2000002110  xx2000002108

Refitting the standard size silent fan unit


Refitting the standard size silent fan unit

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.3.1.3 Replacing the standard size silent fan unit

Continued




Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i>	Location of wrist strap button:  xx1800000683

Continues on next page

5 Repair

5.2.3.1.3 Replacing the standard size silent fan unit

Continued

Action	Note/Illustration
3 Refit the standard fan with the bracket. Push and slide the bracket into position.	 xx2000002109  xx2000002111
4 Secure the screws.	Screws: Torx, countersunk screw M4x10 (4 pcs)  xx2000002107
5 Reconnect:	<ul style="list-style-type: none"> • G1.X2-K2.X17

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

5.2.3.2 Replacing the small fans



Note

There are two types of Small fan used in OmniCore C30.

Make sure which type is used in your machine before do the replacement procedure.



Note

The replacement of the old fan and the new fan are both listed in this chapter, please refer to the correct procedure that you need.

- [*Replacing the small fan on page 252*](#)
- [*Replacing the small fan to a new small fan on page 256*](#)
- [*Replacing the new small fan on page 260*](#)

Continues on next page


5 Repair

5.2.3.2.1 Replacing the small fan

5.2.3.2.1 Replacing the small fan



Removing the small fan

Preparations

Action	Note/Illustration
 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Remove the top and right covers of the controller.	Removing the controller covers on page 222 .

Continues on next page

Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: • G2.X1-K2.X17	

Refitting the small fan

Refitting the small fan



	Action	Note/Illustration
1	 DANGER <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

Continues on next page

5 Repair

5.2.3.2.1 Replacing the small fan

Continued

Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .
3	Reconnect: • G2.X1-K2.X17
4	Refit the fan bracket into the cabinet. 
5	Secure it with the screws. 

Continues on next page

Concluding procedure

	Action	Note/Illustration
1	Refit the covers.	<i>Refitting the controller covers on page 227.</i>
2	Perform the function tests to verify that the safety features work properly, see <i>Function tests on page 212.</i>	


5 Repair

5.2.3.2.2 Replacing the small fan to a new small fan

5.2.3.2.2 Replacing the small fan to a new small fan

Removing the small fan

Preparations



Action	Note/Illustration
 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Remove the top and right covers of the controller.	Removing the controller covers on page 222 .

Continues on next page

5.2.3.2.2 Replacing the small fan to a new small fan

Continued

Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: • G2.X1-K2.X17	

Refitting the new small fan

Refitting the small fan




	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5 Repair

5.2.3.2.2 Replacing the small fan to a new small fan

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Reconnect: <ul style="list-style-type: none"> • G2.X1-K2.X17 	
4 Refit the fan bracket into the cabinet.	 xx2000002115
5 Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx2000002113

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227 .

Continues on next page

5.2.3.2.2 Replacing the small fan to a new small fan*Continued*

	Action	Note/Illustration
2	Perform the function tests to verify that the safety features work properly, see <i>Function tests on page 212.</i>	


5 Repair

5.2.3.2.3 Replacing the new small fan

5.2.3.2.3 Replacing the new small fan



Removing the new small fan

Preparations

Action	Note/Illustration
 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Remove the top and right covers of the controller.	Removing the controller covers on page 222 .

Continues on next page

Removing the new small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx2000002112
2	Push and slide the fan bracket and lift it out.	 xx2000002114
3	Disconnect: • G2.X1-K2.X17	

Refitting the new small fan

Refitting the small fan




	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5 Repair

5.2.3.2.3 Replacing the new small fan

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Reconnect: • G2.X1-K2.X17	
4 Refit the fan bracket into the cabinet.	 xx2000002115
5 Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx2000002113

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227 .

Continues on next page


	Action	Note/Illustration
2	Perform the function tests to verify that the safety features work properly, see <i>Function tests on page 212.</i>	

5 Repair

5.2.3.3 Replacing the main computer fan

Location

The illustration shows the location of the main computer fan in the controller.



xx2100002178

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Fan with contact	3HAC060653-001	Main computer fan

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section <i>Standard toolkit for controller on page 570</i> .
ESD protective wrist band	-	

Continues on next page

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	


Removing the main computer fan



Note

The main computer fan is part of an assembly group, secured on a process plate. To remove the main computer fan, either lift out the assembly group and then remove the main computer fan, or take out the parts on top of the main computer and then remove the main computer fan.

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the top and right covers of the controller.	Removing the controller covers on page 222 .

Removing the main computer assembly with process plate

	Action	Note/Illustration
1	Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer.	

Continues on next page

5 Repair

5.2.3.3 Replacing the main computer fan

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2¹³ • K2.X1 - X107¹⁴ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3¹⁵ • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

¹³ Not available for CRB 15000 controller.


¹⁴ Only available for CRB 15000 controller.

¹⁵ For connected services gateway wired, there is no power cable.

Continues on next page

5.2.3.3 Replacing the main computer fan

Continued



Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2 ¹³ • A2.X9 - X1 ¹⁴ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	
<p>2 Remove the mating connectors from the front side by loosening their attachment screws.</p>	

Continues on next page

5 Repair

5.2.3.3 Replacing the main computer fan

Continued



Action	Note/Illustration				
3 Remove the screws holding the process plate and the screws holding the scalable I/O bracket.	  <table border="1"> <tr> <td>A</td> <td>Screws holding the scalable I/O bracket (1 pcs)</td> </tr> <tr> <td>B</td> <td>Screws holding the process plate (4 pcs)</td> </tr> </table>	A	Screws holding the scalable I/O bracket (1 pcs)	B	Screws holding the process plate (4 pcs)
A	Screws holding the scalable I/O bracket (1 pcs)				
B	Screws holding the process plate (4 pcs)				
4 Pull out the process plate with the assembly from the two guide pins on the mounting plate.  Note Avoid colliding with the frame when removing the unit.					

Continues on next page


5.2.3.3 Replacing the main computer fan

Continued

Removing the robot signal exchange proxy

	Action	Note/Illustration
1	 ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx2000000532
2	Pull the cable ties out from the locking holes.	
3	Remove the screws and lift out the robot signal exchange proxy.  Note Avoid colliding with the frame of the controller.	 xx1800000488

Removing the main computer



	Action	Note/Illustration
1	Remove the screws holding the main computer.	 xx1800000540

Continues on next page


5 Repair

5.2.3.3 Replacing the main computer fan

Continued


Action	Note/Illustration
2 Remove the main computer.  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	  xx1800000542

Removing the main computer fan

Action	Note/Illustration
1  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx2000000532

Continues on next page

5.2.3.3 Replacing the main computer fan*Continued*



Action	Note/Illustration
2	Remove the attachment screws and take off the cover.
3	 xx1800003415

Continues on next page

5 Repair

5.2.3.3 Replacing the main computer fan

Continued

Action	Note/Illustration
4 Lift the fan bracket off the hooks and remove it.	 xx2100002179
5 Take out the fan from the bracket.	 xx2100002180

Refitting the main computer fan


Preparations

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	


Continues on next page

5.2.3.3 Replacing the main computer fan

Continued

Action	Note/Illustration
<p>2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD</i> on page 47.</p>	 xx1800000683

Refitting the main computer fan



Action	Note/Illustration
<p>1  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.</p>	Location of wrist strap button:  xx2000000532

Continues on next page

5 Repair

5.2.3.3 Replacing the main computer fan


Continued

Action	Note/Illustration
2 Place the main computer fan in the bracket.	 xx2100002180
3 Position the fan bracket in the main computer using the hooks.	 xx2100002179
4 Connect the main computer fan:	<ul style="list-style-type: none">• A2.X1


Continues on next page

5.2.3.3 Replacing the main computer fan

Continued

Action	Note/Illustration
5 Refit the cover of the main computer and secure the screws.	Screws: Hexalobular socket pan head screw M3x6 (4 pcs)  xx1800003418

Refitting the main computer





Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532

Continues on next page

5 Repair

5.2.3.3 Replacing the main computer fan

Continued




Action	Note/Illustration
3	<p>Fit the main computer to the process plate.</p>    <p>xx1800000543</p>
4	<p>Fasten the main computer with the screws.</p> <p>Screws: Torx pan head screw M4x8 (2 pcs)</p>  <p>xx1800000541</p>

Continues on next page

5.2.3.3 Replacing the main computer fan

Continued

Refitting the robot signal exchange proxy

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532
3	Fit the robot signal exchange proxy and secure the screws.  Note Avoid colliding with the frame of the controller.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000489
4	Insert the cable ties into the locking holes.	 xx1800000971


Continues on next page

5 Repair

5.2.3.3 Replacing the main computer fan

Continued



Refitting the main computer assembly with process plate to the cabinet

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx1800000683
3 Use the two guide pins to locate the assembly onto the mounting plate.	 Note Be careful with the frame of the controller when refitting the unit.

Continues on next page

5.2.3.3 Replacing the main computer fan

Continued

Action	Note/Illustration				
4 Fasten the assembly with the screws.	<p>WARNING Be careful with the cables installed below the process plate.</p>  <p>xx1800000532</p>  <p>xx1900000215</p> <table border="1" data-bbox="949 1493 1413 1605"> <tr> <td>A</td><td>Screws, Torx pan head, M4x8 (1 pcs)</td></tr> <tr> <td>B</td><td>Screws, Torx pan head, M4x8 (4 pcs)</td></tr> </table>	A	Screws, Torx pan head, M4x8 (1 pcs)	B	Screws, Torx pan head, M4x8 (4 pcs)
A	Screws, Torx pan head, M4x8 (1 pcs)				
B	Screws, Torx pan head, M4x8 (4 pcs)				
5 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.					

Continues on next page

5 Repair

5.2.3.3 Replacing the main computer fan

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none">• K2.X8 - A2.X6• (option): K2.X2 - K4.X8, A2.X1• K2.X12 - A2.K3.X6, A2.K3.X7• K2.X10 - A1.X13• K2.X21 - TempSensor• K2.X4 - A1.X9• K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1• K2.X1 - T2.X2⁵³• K2.X1 - X107⁵⁴• K2.X17 - G2.X1, G1.X2• K2.X6, K2.X11 - A1.X2• K2.X7, K2.X22 - Harn. LV robot power• K2.X9 & X13 - FlexPendant	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3ⁱ• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

5.2.3.3 Replacing the main computer fan

Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁵³ • A2.X9 - X1⁵⁴ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	

ⁱ For connected services gateway wired, there is no power cable.

Concluding procedure


Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

5 Repair

5.2.4 Replacing the robot signal exchange proxy

Location

The illustration shows the location of the robot signal exchange proxy in the controller.



xx1800000028



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Signal exchange	3HAC064662-001	DSQC3037
Harness Short-circuit connector	3HAC065107-001	Mating connector for robot signal exchange proxy.
Harness 24_PC	3HAC064091-001	Harness K2.X2 - K4.X8, A2.X1
Harness dual channel safety	3HAC059273-001	Harness K2.X12 - K3.X6, K3.X7

Continues on next page

**WARNING**

NEVER open the robot signal exchange proxy.

There is residual voltage in the robot signal exchange proxy even the controller is power off in a short time.


Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the robot signal exchange proxy**Preparations**

	Action	Note/Illustration
1	DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the front panel, top and right covers of the controller.	Removing the controller covers on page 222 .



Continues on next page

5 Repair

5.2.4 Replacing the robot signal exchange proxy

Continued

Removing the small fan

Action	Note/Illustration
1 Remove the screws holding the fan.	 xx1800000479
2 Push and slide the fan bracket and lift it out.	 xx1800000480
3 Disconnect: <ul style="list-style-type: none">• G2.X1-K2.X17	

Continues on next page

5.2.4 Replacing the robot signal exchange proxy

Continued

Removing the robot signal exchange proxy



	Action	Note/Illustration
1	<p>Disconnect:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2¹⁶ • K2.X1 - X107¹⁷ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	

¹⁶ Not available for CRB 15000 controller.¹⁷ Only used for CRB 15000 controller.*Continues on next page*

5 Repair


5.2.4 Replacing the robot signal exchange proxy

Continued

Action	Note/Illustration
2 Pull the cable ties out from the locking holes.	 xx1800000971
3 Remove the screws and lift out the robot signal exchange proxy.  Note Avoid colliding with the frame of the controller.	 xx1800000488



Refitting the robot signal exchange proxy

Refitting the robot signal exchange proxy

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683

Continues on next page

5.2.4 Replacing the robot signal exchange proxy *Continued*

	Action	Note/Illustration
3	<p>Fit the robot signal exchange proxy and secure the screws.</p> <p>Note</p> <p>Avoid colliding with the frame of the controller.</p>	<p>Screws: Torx pan head screw M4x8 (4 pcs)</p>  <p>xx1800000489</p>
4	Insert the cable ties into the locking holes.	 <p>xx1800000971</p>
5	<p>Reconnect:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2¹⁸ • K2.X1 - X107¹⁹ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	

¹⁸ Not available for CRB 15000 controller.

¹⁹ Only used for CRB 15000 controller.


Continues on next page

5 Repair

5.2.4 Replacing the robot signal exchange proxy

Continued



Refitting the small fan

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Reconnect: <ul style="list-style-type: none">• G2.X1-K2.X17	

Continues on next page

5.2.4 Replacing the robot signal exchange proxy

Continued

	Action	Note/Illustration
4	Refit the fan bracket into the cabinet.	 xx1800000483
5	Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Concluding procedure


	Action	Note/Illustration
1	Refit the covers.	Refitting the controller covers on page 227.
2	Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

5 Repair

5.2.5 Replacing the Ethernet switch

Location

The illustration shows the location of the Ethernet switch in the controller.



xx1800000821



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Ethernet Extension unit slot cover	3HAC065126-001	
Ethernet Extension switch [3014-1]	3HAC059187-001	

Required tools and equipment


Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Continues on next page

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the Ethernet extension switch (option)**Preparations**

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the front panel, top and right covers of the controller.	Removing the controller covers on page 222 .



Continues on next page

5 Repair

5.2.5 Replacing the Ethernet switch

Continued

Removing the small fan

Action	Note/Illustration
1 Remove the screws holding the fan.	 xx1800000479
2 Push and slide the fan bracket and lift it out.	 xx1800000480
3 Disconnect: <ul style="list-style-type: none">• G2.X1-K2.X17	

Continues on next page

Removing the Ethernet extension switch (option)



	Action	Note/Illustration
1	<p>Disconnect:</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	

Continues on next page

5 Repair

5.2.5 Replacing the Ethernet switch

Continued

Action	Note/Illustration
2 Carefully pull the side of the Ethernet extension switch and rotate it tightly to take it out from the bracket.	 xx1800000490  xx1800000491

Refitting the Ethernet extension switch (option)


Refitting the Ethernet extension switch (option)

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.5 Replacing the Ethernet switch

Continued




Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD</i> on page 47.	Location of wrist strap button:  xx1800000683

Continues on next page

5 Repair


5.2.5 Replacing the Ethernet switch

Continued

Action	Note/Illustration
<p>3 Hook up the Ethernet extension switch to the bracket and then push the switch into position.</p> <p>Note</p> <p>During the installation, there should be no gap between the upper surface of the Ethernet extension switch and the lower surface of highest bracket on the main computer.</p>  <p>xx1800000972</p>	 <p>xx1800000492</p>  <p>xx1800000493</p>
<p>4 Reconnect:</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7. <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	

Continues on next page

Refitting the small fan



	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3	Reconnect: <ul style="list-style-type: none"> • G2.X1-K2.X17 	

Continues on next page

5 Repair

5.2.5 Replacing the Ethernet switch

Continued

Action	Note/Illustration
4 Refit the fan bracket into the cabinet.	 xx1800000483
5 Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Concluding procedure


Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

5.2.6 Replacing the connected services gateway

5.2.6 Replacing the connected services gateway

Location

The illustration shows the location of the connected services gateway in the controller. For the 3G variant, there is a sim card located inside the unit.



xx1800000823



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Connected Services-3G [3013-3]	3HAC060960-001	DSQC1039
Magnetic roof antenna, 3G	3HAC028459-001	
Sim card	3HAC066742-001	
Connected Services-WiFi [3013-2]	3HAC060962-001	DSQC1040
Magnetic roof antenna WiFi	3HAC059424-001	
Connected Services-Wired [3013-1]	3HAC061701-001	DSQC1041
Harness Ethernet with Mini-IO	3HAC061136-001	Harness A2.X5 - K7.X2

Continues on next page

5 Repair

5.2.6 Replacing the connected services gateway

Continued

Required tools and equipment


Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the connected services gateway

Preparations



	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the front panel, top and right covers of the controller.	Removing the controller covers on page 222 .

Continues on next page

5.2.6 Replacing the connected services gateway

Continued

Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: • G2.X1-K2.X17	

Removing the connected services gateway


	Action	Note/Illustration
1	Disconnect: • K7.X1 - K2.X3 ⁱ • K7.X2 - A2.X5  Note The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.	

Continues on next page

5 Repair

5.2.6 Replacing the connected services gateway

Continued

Action	Note/Illustration
2 Carefully pull the side of the connected services gateway and rotate it tightly to take it out from the bracket.	 TOP VIEW



- i For connected services gateway wired, there is no power cable.

Continues on next page

5.2.6 Replacing the connected services gateway


Continued

Removing the sim card

	Action	Note/Illustration
1	Remove the attachment screws and pull out the front cover of the connected services-3G.	 xx1900000971
2	Carefully pull out the sim card from its holder.	 xx1900000972

Refitting the connected services gateway

Refitting the sim card


	Action	Note/Illustration
1	Carefully place the sim card in its holder.	 xx1900000972
2	Refit the front cover of the connected services-3G and secure the screws.	

Continues on next page

5 Repair

5.2.6 Replacing the connected services gateway

Continued

Action	Note/Illustration
	 xx1900000971


Refitting the connected services gateway

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	

Continues on next page

5.2.6 Replacing the connected services gateway

Continued

Action	Note/Illustration
3 Hook up the connected services gateway to the bracket and push carefully into position.	<p> Note</p> <p>During the installation, the gap between the lower surface of the connected services gateway and the upper surface of the main computer should be zero.</p> 
4 Reconnect:	<ul style="list-style-type: none"> • K7.X1 - K2.X3ⁱ • K7.X2 - A2.X5

ⁱ For connected services gateway wired, there is no power cable.

Refitting the small fan




Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5 Repair

5.2.6 Replacing the connected services gateway

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47</i> .	Location of wrist strap button:  xx1800000683
3 Reconnect: • G2.X1-K2.X17	
4 Refit the fan bracket into the cabinet.	 xx1800000483
5 Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Continues on next page

Concluding procedure

	Action	Note/Illustration
1	Refit the covers.	<i>Refitting the controller covers on page 227.</i>
2	Perform the function tests to verify that the safety features work properly, see <i>Function tests on page 212.</i>	


5 Repair

5.2.7 Replacing the scalable I/O unit

5.2.7 Replacing the scalable I/O unit

Location

The illustration shows the location of the scalable I/O in the controller.



xx1800000032



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
DSQC1030 Digital slot cover	3HAC065147-001	DSQC1030
Scalable I/O Digital base [3032-1]	3HAC058663-001	
Connectors digital base/add on	3HAC060919-001	
Harness Ethernet with Mini-IO	3HAC064092-001	Harness K5.1.X5 - Adapter

Required tools and equipment


Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Continues on next page


Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	
<i>Application manual - Scalable I/O</i>	3HAC070208-001	

Removing the digital base (option)**Preparations**

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the front panel and top cover of the controller.	Removing the controller covers on page 222 .

Removing the digital base (option)


	Action	Note/Illustration
1	Disconnect: • K5.1.X4 - K2.X3	 xx1800000498

Continues on next page

5 Repair

5.2.7 Replacing the scalable I/O unit

Continued

Action	Note/Illustration
2 Push the buckle of the digital base slightly and pull out the digital base.	 xx1800000499
3 Disconnect the connectors between the adapter cable (K5.1.X5 - Adapter) and the adaptor cable (Adaptor - A2.X4/K4.X7).  Note If the Ethernet extension switch is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from K4.X7. If the Ethernet extension unit slot cover is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from A2.X4.	
4 Disconnect: <ul style="list-style-type: none"> • K5.1.X5 - Harness adapter 	



Refitting the digital base (option)

Refitting the digital base (option)

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.7 Replacing the scalable I/O unit
Continued


Action	Note/Illustration
<p>2</p> <p> ELECTROSTATIC DISCHARGE (ESD)</p> <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD</i> on page 47.</p>	<p>Location of wrist strap button:</p>  <p>xx1800000683</p>
<p>3</p> <p>Connect the adapter cable to the digital base.</p> <ul style="list-style-type: none"> K5.1.X5 - Harness adapter <p>Stick the other connector onto the side of the digital base with the self-adhesive part.</p>	 <p>xx1800000938</p>
<p>4</p> <p>Connect the connectors between the adapter cable (K5.1.X5 - Adapter) and the adaptor cable (Adaptor - A2.X4/K4.X7).</p> <p> Note</p> <p>If the Ethernet extension switch is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from K4.X7.</p> <p>If the Ethernet extension unit slot cover is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from A2.X4.</p>	

Continues on next page

5 Repair

5.2.7 Replacing the scalable I/O unit

Continued

Action	Note/Illustration
5 Push the digital base into the bracket until you hear a clear clicking sound.	
6 Connect the power cable connector: • K5.1.X4 - K2.X3	 xx1800000500

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227 .
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

Replacing scalable I/O external units


To replace scalable I/O external units, see [Application manual - Scalable I/O](#), and [Installing scalable I/O external devices on page 144](#).

5.2.8 Replacing the safety digital base device

5.2.8 Replacing the safety digital base device

Location

The illustration shows the location of the safety digital base device in the controller.



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
DSQC1042 Extended safety	3HAC062908-001	DSQC1042
Connectors Safety I/O	3HAC069538-001	

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Continues on next page

5 Repair

5.2.8 Replacing the safety digital base device


Continued

Required documents


Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	
<i>Application manual - Scalable I/O</i>	3HAC070208-001	

Removing the safety digital base device

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	Remove the front panel and top cover of the controller.	Removing the controller covers on page 222 .
3	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683


Removing the safety digital base device

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none">• K3.1.X5 - K2.X3	 xx1800000498

Continues on next page

5.2.8 Replacing the safety digital base device

Continued

Action	Note/Illustration
2 Push the buckle of the digital base slightly and pull out the digital base.	 xx1800000499
3 Disconnect the connectors between the adapter cable (K5.1.X5 - Adapter) and the adaptor cable (Adaptor - A2.X4/K4.X7). Note If the Ethernet extension switch is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from K4.X7. If the Ethernet extension unit slot cover is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from A2.X4.	
4 Disconnect: <ul style="list-style-type: none"> • K3.1.X5 - Harness adapter 	

Refitting the safety digital base device**Refitting the safety digital base device**

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5 Repair

5.2.8 Replacing the safety digital base device


Continued

Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .
3	Connect the adapter cable to the digital base. • K3.1.X5 - Harness adapter Stick the other connector onto the side of the digital base with the self-adhesive part.
4	Connect the connectors between the adapter cable (K3.1.X5 - Adapter) and the adaptor cable (Adaptor - A2.X4/K4.X7).  Note If the Ethernet extension switch is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from K4.X7. If the Ethernet extension unit slot cover is installed, connect and disconnect the adapter cable (A2.X4/K4.X7) to/from A2.X4.

Continues on next page

5.2.8 Replacing the safety digital base device

Continued

Action	Note/Illustration
5 Push the digital base into the bracket until you hear a clear clicking sound.	
6 Connect the power cable connector: • K3.1.X4 - K2.X3	 xx1800000500

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	


5 Repair

5.2.9 Replacing the main computer

5.2.9 Replacing the main computer

Location

The illustration shows the location of the main computer in the controller.



xx1800000033



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Main computer module assembly	3HAC063061-001	

Required tools and equipment



Note

For robots with the controller delivered to start in automatic mode, a FlexPendant is required after the replacement to be able to change to automatic mode.

Continues on next page

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	


**Note**

The main computer is part of an assembly group, secured on a process plate. To remove the computer, either lift out the assembly group and then remove the computer, or take out the parts on top of the computer and then the computer itself.

To remove the assembly group, see [Removing the main computer by assembly group on page 319](#).

To remove the modules on the top of the computer, see [Removing the main computer by parts on page 340](#).

Removing the main computer by assembly group**Preparations**

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683

Continues on next page



5 Repair

5.2.9 Replacing the main computer

Continued

	Action	Note/Illustration
3	Remove the front panel, top and right covers of the controller.	Removing the controller covers on page 222.

Removing the small fan


	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: <ul style="list-style-type: none">• G2.X1-K2.X17	

Removing the axis computer from the cabinet

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none">• K6.X11 - A1.X3• K6.X2 - A2.X9• K6.X1 - K2.X3.	

Continues on next page

5.2.9 Replacing the main computer
Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	
3 Loosen the screw and disconnect: <ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	

Removing the main computer assembly with process plate

Action	Note/Illustration
1 Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer.	
2 For the robot signal exchange proxy: <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2²⁰ • K2.X1 - X107²¹ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	

20 Not available for CRB 15000 controller.

21 Only available for CRB 15000 controller.

Continues on next page

5 Repair

5.2.9 Replacing the main computer


Continued

Action	Note/Illustration
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3²²• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

²² For connected services gateway wired, there is no power cable.

Continues on next page

5.2.9 Replacing the main computer
Continued



Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2²⁰ • A2.X9 - X1²¹ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	
<p>2 Remove the mating connectors from the front side by loosening their attachment screws.</p>	

Continues on next page

5 Repair



5.2.9 Replacing the main computer

Continued

Action	Note/Illustration				
3	<p>Remove the screws holding the process plate and the screws holding the scalable I/O bracket.</p>  <p>xx1800000532</p>  <p>xx1900000215</p> <table border="1" data-bbox="917 1493 1391 1650"><tr><td data-bbox="917 1493 965 1527">A</td><td data-bbox="981 1493 1391 1527">Screws holding the scalable I/O bracket (1 pcs)</td></tr><tr><td data-bbox="917 1538 965 1572">B</td><td data-bbox="981 1538 1391 1572">Screws holding the process plate (4 pcs)</td></tr></table>	A	Screws holding the scalable I/O bracket (1 pcs)	B	Screws holding the process plate (4 pcs)
A	Screws holding the scalable I/O bracket (1 pcs)				
B	Screws holding the process plate (4 pcs)				
4	<p>Pull out the process plate with the assembly from the two guide pins on the mounting plate.</p> <p>Note</p> <p>Avoid colliding with the frame when removing the unit.</p>				

Continues on next page

Removing the robot signal exchange proxy

	Action	Note/Illustration
1	 ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx2000000532
2	Pull the cable ties out from the locking holes.	
3	Remove the screws and lift out the robot signal exchange proxy.  Note Avoid colliding with the frame of the controller.	 xx1800000488


Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued


Removing the Ethernet extension switch (option)

Action	Note/Illustration
1 Carefully pull the side of the Ethernet extension switch and rotate it tightly to take it out from the bracket.	 xx1800000538  xx1800000491


Continues on next page

5.2.9 Replacing the main computer
Continued

Removing the connected services gateway

	Action	Note/Illustration
1	Carefully pull the side of the connected services gateway and rotate it tightly to take it out from the bracket.	 <p>xx1800000495 TOP VIEW</p>

Removing the main computer



	Action	Note/Illustration
1	Remove the screws holding the main computer.	 <p>xx1800000540</p>

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
2 Remove the main computer.  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	  xx1800000542





Refitting the main computer by assembly group

Refitting the main computer

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.9 Replacing the main computer Continued


	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD) <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD</i> on page 47.</p>	<p>Location of wrist strap button:</p>  <p>xx2000000532</p>
3	<p>Fit the main computer to the process plate.</p>	   <p>xx1800000543</p>

Continues on next page


5 Repair

5.2.9 Replacing the main computer

Continued


Action	Note/Illustration
4 Fasten the main computer with the screws.	Screws: Torx pan head screw M4x8 (2 pcs)  xx1800000541

Refitting the connected services gateway


Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532

Continues on next page

5.2.9 Replacing the main computer Continued

Action	Note/Illustration
<p>3 Hook up the connected services gateway to the bracket and push carefully into position.</p> <p> Note</p> <p>During the installation, the gap between the lower surface of the connected services gateway and the upper surface of the main computer should be zero.</p>	

Refitting the Ethernet extension switch (option)



Action	Note/Illustration
<p>1  DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	
<p>2  ELECTROSTATIC DISCHARGE (ESD)</p> <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47.</p>	<p>Location of wrist strap button:</p> 

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
3 Hook up the Ethernet extension switch to the bracket and then push the switch into position.  Note During the installation, there should be no gap between the upper surface of the Ethernet extension switch and the lower surface of highest bracket on the main computer.	 




Refitting the robot signal exchange proxy

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
<p>2</p>  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532
<p>3</p> Fit the robot signal exchange proxy and secure the screws.  Note Avoid colliding with the frame of the controller.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000489
<p>4</p> Insert the cable ties into the locking holes.	 xx1800000971

Refitting the main computer assembly with process plate to the cabinet


Action	Note/Illustration
<p>1</p>  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5 Repair


5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx1800000683
3 Use the two guide pins to locate the assembly onto the mounting plate.	 Note Be careful with the frame of the controller when refitting the unit.

Continues on next page

5.2.9 Replacing the main computer
Continued

Action	Note/Illustration				
<p>4 Fasten the assembly with the screws.</p> <p>WARNING</p> <p>Be careful with the cables installed below the process plate.</p>	 <p>xx1800000532</p> <p>xx1900000215</p> <table border="1" data-bbox="949 1500 1426 1596"> <tr> <td>A</td> <td>Screws, Torx pan head, M4x8 (1 pcs)</td> </tr> <tr> <td>B</td> <td>Screws, Torx pan head, M4x8 (4 pcs)</td> </tr> </table>	A	Screws, Torx pan head, M4x8 (1 pcs)	B	Screws, Torx pan head, M4x8 (4 pcs)
A	Screws, Torx pan head, M4x8 (1 pcs)				
B	Screws, Torx pan head, M4x8 (4 pcs)				
<p>5 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.</p>					

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2²⁰ • K2.X1 - X107²¹ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power • K2.X9 & X13 - FlexPendant 	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3ⁱ • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2²⁰ • A2.X9 - X1²¹ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	

ⁱ For connected services gateway wired, there is no power cable.

Refitting the axis computer to the frame



Action	Note/Illustration
<p>1  DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued




Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3 Reconnect and secure the screw: • K6.X4, K6.X5 - SMB.	
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs) 
5 Reconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3	

Refitting the small fan

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.9 Replacing the main computer
Continued

	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD) <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD</i> on page 47.</p>	Location of wrist strap button:  xx1800000683
3	Reconnect: • G2.X1-K2.X17	
4	Refit the fan bracket into the cabinet.	 xx1800000483
5	Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Continues on next page

5 Repair

5.2.9 Replacing the main computer


Continued

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Restore the hardware settings.	Restoring the hardware settings on page 356.
3 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	



Removing the main computer by parts

Preparations

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47.	Location of wrist strap button:  xx1800000683
3 Remove the front panel, top and right covers of the controller.	Removing the controller covers on page 222.

Continues on next page

Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: • G2.X1-K2.X17	

Disconnecting the connectors to the main computer assembly

	Action	Note/Illustration
1	Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer.	

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2²³ • K2.X1 - X107²⁴ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3¹ • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

²³ Not available for CRB 15000 controller.

²⁴ Only used for CRB 15000 controller.

Continues on next page

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2²⁵ • A2.X9 - X1²⁶ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	


²⁵ Not available for CRB 15000 controller.²⁶ Only used for CRB 15000 controller.

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued



Action	Note/Illustration
2 Remove the mating connectors from the front side by loosening their attachment screws.	

- i For Connected Services Gateway wired, there is no power cable.


Continues on next page

5.2.9 Replacing the main computer Continued

Removing the robot signal exchange proxy

Action	Note/Illustration
1 Pull the cable ties out from the locking holes.	 xx1800000971
2 Remove the screws and lift out the robot signal exchange proxy.  Note Avoid colliding with the frame of the controller.	 xx1800000488

Removing the Ethernet extension switch (option)

Action	Note/Illustration
1 Carefully pull the side of the Ethernet extension switch and rotate it tightly to take it out from the bracket.	 xx1800000491


Removing the connected services gateway

Continues on next page



5 Repair

5.2.9 Replacing the main computer

Continued


Action	Note/Illustration
1 Carefully pull the side of the connected services gateway and rotate it tightly to take it out from the bracket.	 xx1800000495 TOP VIEW

Removing the main computer

Action	Note/Illustration
1 Remove the screws holding the main computer.	 xx1900001194
2 Remove the two screws holding the process plate.  Tip Otherwise the main computer will have a collision with the process plate.	 xx1900001190
3 Remove the main computer.	


Continues on next page

5.2.9 Replacing the main computer Continued

Action	Note/Illustration
<p> ELECTROSTATIC DISCHARGE (ESD)</p> <p>When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.</p>	 <p>xx1900001195</p>

Refitting the main computer by parts

Refitting the main computer




Action	Note/Illustration
<p>1  DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	
<p>2  ELECTROSTATIC DISCHARGE (ESD)</p> <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47.</p>	<p>Location of wrist strap button:</p>  <p>xx1800000683</p>

Continues on next page

5 Repair


5.2.9 Replacing the main computer

Continued

	Action	Note/Illustration
3	Fit the main computer to the process plate.	 xx1900001197
4	Refit the two screws for the process plate.	<p>Screws: Torx pan head screw M4x8 (2 pcs)</p>  xx1900001190
5	Fasten the main computer with the screws.	<p>Screws: Torx pan head screw M4x8 (2 pcs)</p>  xx1900001196

Continues on next page

Refitting the connected services gateway

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	
3	Hook up the connected services gateway to the bracket and push carefully into position.  Note During the installation, the gap between the lower surface of the Connected Services Gateway and the upper surface of the main computer should be zero.	 xx1800000497 TOP VIEW

Refitting the Ethernet extension switch (option)




	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
<p>2</p>  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
<p>3</p> Hook up the Ethernet extension switch to the bracket and then push the switch into position.  Note During the installation, there should be no gap between the upper surface of the Ethernet extension switch and the lower surface of highest bracket on the main computer.  xx1800000972	 xx1800000493




Refitting the robot signal exchange proxy

Action	Note/Illustration
<p>1</p>  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
<p>2</p>  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
<p>3</p> Fit the robot signal exchange proxy and secure the screws.  Note Avoid colliding with the frame of the controller.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000489
<p>4</p> Insert the cable ties into the locking holes.	 xx1800000971

Reconnecting the connectors to the main computer assembly


Action	Note/Illustration
<p>1</p>  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx1800000683
3 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.	
For the robot signal exchange proxy: <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2²⁷ • K2.X1 - X107²⁸ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	

²⁷ Not available for CRB 15000 controller.

²⁸ Only used for CRB 15000 controller.

Continues on next page

5.2.9 Replacing the main computer
Continued

Action	Note/Illustration
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3ⁱ • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2²⁹ • A2.X9 - X1³⁰ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	

i For Connected Services Gateway wired, there is no power cable.

Refitting the small fan




Action	Note/Illustration
<p>1  DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

²⁹ Not available for CRB 15000 controller.

³⁰ Only used for CRB 15000 controller.

Continues on next page

5.2.9 Replacing the main computer
Continued

	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD) <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD</i> on page 47.</p>	Location of wrist strap button:  xx1800000683
3	Reconnect: • G2.X1-K2.X17	
4	Refit the fan bracket into the cabinet.	 xx1800000483
5	Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Continues on next page

5 Repair

5.2.9 Replacing the main computer

Continued

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Restore the hardware settings.	Restoring the hardware settings on page 356.
3 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

Restoring the hardware settings

The controller hardware settings include information such as controller type and serial number. When the main computer has been replaced, the serial number must be restored before any software can be installed, or any licences can be imported.



Note

When replacing the main computer, both the serial number and licences are lost. The serial number must be restored as described below. Licences however, can either be restored automatically when the RobotWare system is installed, or manually through **Manage Licences** in RobotWare Installation Utilities.

Action	Note/Illustration
1 Download the hardware information file (hwsettings.rsf) from MyABB, or from a previous system backup.	
2 Access the RobotWare Installation Utilities.	 xx1900000110
3 Tap Advanced, and then Restore Hardware Settings.	
4 The Restore Hardware Settings window is displayed. Follow the instructions and tap Next to proceed.	
5 Carefully read the information and then check all boxes to confirm that you agree with the ABB conditions. Tap Next to proceed.	

Continues on next page

5.2.9 Replacing the main computer

Continued

Action	Note/Illustration
6 Read the serial number on the front of the controller and type it in field Serial Number . Tap Next .	 <p>xx2000000007</p>
7 Tap Browse to open the hardware information file from its location. The restoration of the serial number is completed.	The system compares the downloaded file and the manually entered serial number to ensure that there is a match.


5 Repair

5.2.10 Replacing the power unit

5.2.10 Replacing the power unit

Location

The illustration shows the location of the power unit in the controller.



xx1800000034



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Power unit	3HAC059152-001	DSQC3044
Power unit for IRB 14050 controller	3HAC059135-001	DSQC3028
Power unit for CRB 15000 controller	3HAC072227-001	DSQC3083

Continues on next page

Required tools and equipment


Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the power unit

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the top and left covers of the controller.	Removing the controller covers on page 222 .

Removing the axis computer from the frame


	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none"> • A1.X3 - K6.X11 • K6.X2 - A2.X9 • K6.X1 - K2.X3. 	

Continues on next page

5 Repair

5.2.10 Replacing the power unit

Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	 xx1900001200
3 Loosen the screw and disconnect: <ul style="list-style-type: none">• SMB - K6.X4, K6.X5	

Removing the power unit

Action	Note/Illustration
1 Disconnect: <ul style="list-style-type: none">• A1.X13 - K2.X10• A1.X9 - K2.X4• A1.X4 - T4.X5³¹• A1.X4 - X1³²• A1.X5 - T4.X1• A1.X12 - T4.X3• A1.X1 - Incoming mains (X0)• A1.X6 - T2.X1³³• A1.X6 - X10³⁴• (Option) A1.X7 - T5.X1	
2 Open the velcro strap for the main harness. Lift the harness gently out to make room for the power unit to be removed.	

³¹ Not available for CRB 15000 controller.

³² Only used for CRB 15000 controller.



³³ Not available for CRB 15000 controller.

³⁴ Only used for CRB 15000 controller.

Continues on next page

5.2.10 Replacing the power unit

Continued

Action	Note/Illustration				
<p>3 Remove the screws and pull the power unit out from the two snaps on the mounting plate.</p> <p>! CAUTION Only the sheet metal on the power unit can be used for holding. Do not touch the connectors or the filter on the power unit.</p>	 <p>xx1800000686</p>  <p>xx1900000216</p> <table border="1"> <tr> <td>A</td> <td>Attachment screws</td> </tr> <tr> <td>B</td> <td>Snaps</td> </tr> </table>	A	Attachment screws	B	Snaps
A	Attachment screws				
B	Snaps				

Refitting the power unit**Refitting the power unit**




Action	Note/Illustration
<p>1 ! DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see <i>Electrical safety on page 31</i>.</p>	

Continues on next page

5 Repair

5.2.10 Replacing the power unit


Continued

Action	Note/Illustration				
2	<p> ELECTROSTATIC DISCHARGE (ESD)</p> <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47.</p>				
3	<p>Push the power unit until it snaps on the mounting plate and secure the screws.</p> <p>Screws: Torx pan head screw M4x8 (2 pcs)</p>  <p>xx1800000683</p>  <p>xx1800000686</p>  <p>xx1900000216</p> <table border="1" data-bbox="914 1664 1394 1785"><tr><td data-bbox="914 1664 954 1709">A</td><td data-bbox="954 1664 1394 1709">Attachment screws</td></tr><tr><td data-bbox="914 1709 954 1754">B</td><td data-bbox="954 1709 1394 1754">Snaps</td></tr></table>	A	Attachment screws	B	Snaps
A	Attachment screws				
B	Snaps				

Continues on next page

	Action	Note/Illustration
4	Reconnect: <ul style="list-style-type: none"> • A1.X13 - K2.X10 • A1.X9 - K2.X4 • A1.X4 - T4.X5³⁵ • A1.X4 - X1³⁶ • A1.X5 - T4.X1 • A1.X12 - T4.X3 • A1.X1 - Incoming mains (X0) • A1.X6 - T2.X1³⁷ • A1.X6 - X107³⁸ • (Option) A1.X7 - T5.X1 	
5	Put the main harness in place and secure it with the velcro straps.	

Refitting the axis computer to the frame

	Action	Note/Illustration
1	 DANGER <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	
2	 ELECTROSTATIC DISCHARGE (ESD) <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47.</p>	Location of wrist strap button: 
3	Reconnect: <ul style="list-style-type: none">• K6.X4, K6.X5 - SMB.	


³⁵ Not available for CRB 15000 controller.³⁶ Only used for CRB 15000 controller.³⁷ Not available for CRB 15000 controller.³⁸ Only used for CRB 15000 controller.

Continues on next page

5 Repair

5.2.10 Replacing the power unit

Continued

Action	Note/Illustration
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1900001201
5 Reconnect: <ul style="list-style-type: none">• K6.X11 - A1.X3• K6.X2 - A2.X9• K6.X1 - K2.X3	


Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

5.2.11 Replacing the power supply

Location

The illustration shows the location of the power supply in the controller.



xx1800000035

A	Power supply baseline
B	Power supply optional



WARNING

Do not touch the power supply when the DC OK LED is on.

There is residual voltage in the power supply even if the main switch is in the OFF position.



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Continues on next page

5 Repair

5.2.11 Replacing the power supply

Continued

Spare part	Article number	Note
Power supply	3HAC071301-001	DSQC3035
Optional power supply	3HAC071301-001	DSQC3035

Required tools and equipment


Equipment	Article number	Note
Standard toolkit	-	Content is defined in section <i>Standard toolkit for controller on page 570</i> .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	


Removing the power supply baseline

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see <i>Electrical safety on page 31</i> .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47</i> .	Location of wrist strap button: 
3	Remove the top cover.	Removing the controller covers on page 222 .


Continues on next page

Removing the power supply baseline

	Action	Note/Illustration
1	Disconnect: • T2.X1 - A1.X6 • T2.X2 - K2.X1	
2	Remove the screws and the power supply.	 xx1800000547

Refitting the power supply baseline

Refitting the power supply


	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683

Continues on next page

5 Repair

5.2.11 Replacing the power supply

Continued


Action	Note/Illustration
3 Fit the power supply and fasten it with screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000548
4 Reconnect and secure: <ul style="list-style-type: none"> • T2.X1 - A1.X6 • T2.X2 - K2.X1. 	

Concluding procedure

Action	Note/Illustration
1 Refit the top cover.	Refitting the top cover on page 230.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

Removing the power supply optional

Preparations


Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47.	Location of wrist strap button:  xx1800000683

Continues on next page


5.2.11 Replacing the power supply
Continued

	Action	Note/Illustration
3	Remove the top cover.	Removing the controller covers on page 222.

Removing the axis computer from the cabinet

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none"> • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3. 	
2	Remove the screws on the bracket.	 <p>xx1800000472</p>
3	Loosen the screw and disconnect: <ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	

Removing the power supply optional

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none"> • A1.X7 - T5.X1 	
2	Remove the attachment screws and lift the power supply out.	 <p>xx1800000549</p>

Continues on next page

5 Repair


5.2.11 Replacing the power supply

Continued

	Action	Note/Illustration
3	Disconnect: • T5.X2 - X45	


Refitting the power supply optional

Refitting the power supply optional


	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Fit the power supply.	
4	Reconnect: • T5.X2 - X45.	

Continues on next page

5.2.11 Replacing the power supply
Continued

Action	Note/Illustration
5 Secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000550
6 Reconnect: <ul style="list-style-type: none"> • A1.X7 - T5.X1 	

Refitting the axis computer to the frame


Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Reconnect and secure the screw: <ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	

Continues on next page

5 Repair

5.2.11 Replacing the power supply

Continued

	Action	Note/Illustration
4	Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000476
5	Reconnect: <ul style="list-style-type: none">• K6.X11 - A1.X3• K6.X2 - A2.X9• K6.X1 - K2.X3	


Concluding procedure

	Action	Note/Illustration
1	Refit the covers.	Refitting the controller covers on page 227.
2	Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

5.2.12 Replacing the drive unit

Location

The illustration shows the location of the drive unit in the controller.



xx1800000036



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Drive	3HAC063913-001	DSQC3041
Drive for IRB14050 controller	3HAC063028-001	DSQC3057
Harness DC-BUS	3HAC063344-001	Harness A1.X4 - T4.X5
Harness DC-BUS	3HAC063967-001	Only used for IRB 14050 controller.
Harness 24_SYS_DRV	3HAC064389-001	Harness A1.X5 - T4.X1

Continues on next page

5 Repair

5.2.12 Replacing the drive unit

Continued

Spare part	Article number	Note
Harness 24_SYS_DRV	3HAC067893-001	Only used for IRB 14050 controller.
Harness EtherCAT	3HAC059894-001	Harness T4.X3 - A1.X12
Harness EtherCAT	3HAC065875-001	Only used for IRB 14050 controller.

Required tools and equipment


Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the drive unit


Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683

Continues on next page

	Action	Note/Illustration
3	<p>Remove the top and rear covers.</p> <p>Tip For IRB14050 controller, only remove the top cover.</p>	<i>Removing the controller covers on page 222.</i>

Removing the axis computer from the cabinet

	Action	Note/Illustration
1	Disconnect:	
	<ul style="list-style-type: none"> • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3. 	
2	Remove the screws on the bracket.	 xx1800000472
3	Loosen the screw and disconnect:	
	<ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	



For IRB14050 controller, only disconnect the connection between the drive unit to the power supply baseline.

Removing the power supply optional


	Action	Note/Illustration
1	Disconnect:	
	<ul style="list-style-type: none"> • A1.X7 - T5.X1 	

Continues on next page

5 Repair

5.2.12 Replacing the drive unit


Continued

	Action	Note/Illustration
2	Remove the attachment screws and lift the power supply out.	 xx1800000549
3	Disconnect: <ul style="list-style-type: none">• T5.X2 - X45	


Removing the power supply baseline

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none">• T2.X1 - A1.X6• T2.X2 - K2.X1	

Continues on next page

Action	Note/Illustration
2 Remove the screws and the power supply.	 <p>xx1900001198</p>

Removing the drive unit

Action	Note/Illustration				
1 Disconnect: <ul style="list-style-type: none"> T4.X7, T4.X8, T4.X9 T4.X5 - A1.X4 T4.X3 - A1.X12 T4.X1 - A1.X5 					
2 Cut the cable tie for the DC-bus cable and move it to the other side.  Tip This is not needed for the IRB14050 controller.	 <p>xx1800000973</p>				
3 Open the cable straps for the motor connector cable and move it out of the cabinet.  Tip This is not needed for the IRB14050 controller.	<table border="1"> <tr> <td>A</td> <td>Cable tie for the DC-bus cable</td> </tr> <tr> <td>B</td> <td>Cable straps for the motor connector cable</td> </tr> </table>	A	Cable tie for the DC-bus cable	B	Cable straps for the motor connector cable
A	Cable tie for the DC-bus cable				
B	Cable straps for the motor connector cable				

Continues on next page

5 Repair

5.2.12 Replacing the drive unit

Continued

Action	Note/Illustration				
4 Remove the attachment screws and pull the drive unit out from the two snaps.	<p>Lengthened screwdriver</p> <p>xx1800000544</p> <table border="1"><tr><td>A</td><td>Screw (4 pcs)</td></tr><tr><td>B</td><td>Snaps</td></tr></table> <p>xx1800000545</p>	A	Screw (4 pcs)	B	Snaps
A	Screw (4 pcs)				
B	Snaps				

Refitting the drive unit



Refitting the drive unit

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.12 Replacing the drive unit

Continued



Action	Note/Illustration
<p>2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i></p>	<p>Location of wrist strap button:</p>  <p>xx1800000683</p>
<p>3 Push the drive unit into the snaps on the mounting plate and secure the screws.</p>	<p>Screws: Torx pan head screw M4x8 (4 pcs)</p>  <p>xx1800000546</p>

Continues on next page

5 Repair

5.2.12 Replacing the drive unit



Continued

Action	Note/Illustration				
<p>4 Fasten the DC-bus cable with a new cable tie to the drive unit.</p> <p> Tip</p> <p>This is not needed for the IRB14050 controller.</p>					
<p>5 Fasten the motor connector cable with the cable straps.</p> <p> Tip</p> <p>This is not needed for the IRB14050 controller.</p>	 <table border="1" data-bbox="917 1089 1389 1201"> <tr> <td>A</td> <td>Cable tie for the DC-bus cable</td> </tr> <tr> <td>B</td> <td>Cable straps for the motor connector cable</td> </tr> </table>	A	Cable tie for the DC-bus cable	B	Cable straps for the motor connector cable
A	Cable tie for the DC-bus cable				
B	Cable straps for the motor connector cable				
<p>6 Reconnect:</p> <ul style="list-style-type: none"> • T4.X7, T4.X8, T4.X9 • T4.X5 - A1.X4 • T4.X3 - A1.X12 • T4.X1 - A1.X5 					

Refitting the power supply

Action	Note/Illustration
<p>1  DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

Continues on next page

	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i>	Location of wrist strap button:  xx1800000683
3	Fit the power supply and fasten it with screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1900001199
4	Reconnect: <ul style="list-style-type: none"> • T2.X1 - A1.X6 • T2.X2 - K2.X1. 	

Refitting the power supply optional



	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see <i>Electrical safety on page 31.</i>	

Continues on next page

5 Repair

5.2.12 Replacing the drive unit



Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Fit the power supply.	
4 Reconnect: • T5.X2 - X45.	
5 Secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000550
6 Reconnect: • A1.X7 - T5.X1	

Refitting the axis computer to the frame

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Reconnect and secure the screw: • K6.X4, K6.X5 - SMB.	
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000476
5 Reconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3	

Concluding procedure


Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227 .
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

5 Repair

5.2.13 Replacing the fieldbus master

Location

The illustration shows the location of the fieldbus master in the controller.



xx1800003420



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
DeviceNet Board	3HAC043383-001	DSQC1006

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Continues on next page


Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the fieldbus master**Note**

The fieldbus master is part of an assembly group, secured on a process plate. To remove the fieldbus master, either lift out the assembly group and then remove the fieldbus master, or take out the parts on top of the main computer and then remove the fieldbus master.

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the top and right covers of the controller.	Removing the controller covers on page 222 .



Continues on next page

5 Repair

5.2.13 Replacing the fieldbus master

Continued

Removing the small fan


	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: <ul style="list-style-type: none">• G2.X1-K2.X17	

Removing the axis computer from the cabinet

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none">• K6.X11 - A1.X3• K6.X2 - A2.X9• K6.X1 - K2.X3.	

Continues on next page

5.2.13 Replacing the fieldbus master
Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	
3 Loosen the screw and disconnect: • K6.X4, K6.X5 - SMB.	

Removing the main computer assembly with process plate

Action	Note/Illustration
1 Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer.	
2 For the robot signal exchange proxy: • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2 ³⁹ • K2.X1 - X107 ⁴⁰ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4)	

39 Not available for CRB 15000 controller.

40 Only available for CRB 15000 controller.

Continues on next page

5 Repair

5.2.13 Replacing the fieldbus master


Continued

Action	Note/Illustration
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3⁴¹• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

⁴¹ For connected services gateway wired, there is no power cable.

Continues on next page

5.2.13 Replacing the fieldbus master
Continued



Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2³⁹ • A2.X9 - X1⁴⁰ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	
<p>2 Remove the mating connectors from the front side by loosening their attachment screws.</p>	

Continues on next page

5 Repair



5.2.13 Replacing the fieldbus master

Continued

Action	Note/Illustration				
3 Remove the screws holding the process plate and the screws holding the scalable I/O bracket.	  <table border="1" data-bbox="917 1507 1394 1657"> <tr> <td>A</td><td>Screws holding the scalable I/O bracket (1 pcs)</td></tr> <tr> <td>B</td><td>Screws holding the process plate (4 pcs)</td></tr> </table>	A	Screws holding the scalable I/O bracket (1 pcs)	B	Screws holding the process plate (4 pcs)
A	Screws holding the scalable I/O bracket (1 pcs)				
B	Screws holding the process plate (4 pcs)				
4 Pull out the process plate with the assembly from the two guide pins on the mounting plate.  Note Avoid colliding with the frame when removing the unit.					

Continues on next page

Removing the robot signal exchange proxy

	Action	Note/Illustration
1	 ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx2000000532
2	Pull the cable ties out from the locking holes.	
3	Remove the screws and lift out the robot signal exchange proxy.  Note Avoid colliding with the frame of the controller.	 xx1800000488


Continues on next page

5 Repair

5.2.13 Replacing the fieldbus master


Continued

Removing the Ethernet extension switch (option)


Action	Note/Illustration
1 Carefully pull the side of the Ethernet extension switch and rotate it tightly to take it out from the bracket.	 xx1800000538  xx1800000491

Continues on next page

Removing the connected services gateway

	Action	Note/Illustration
1	Carefully pull the side of the connected services gateway and rotate it tightly to take it out from the bracket.	 <p>xx1800000495</p> <p>TOP VIEW</p>

Removing the main computer



	Action	Note/Illustration
1	Remove the screws holding the main computer.	 <p>xx1800000540</p>

Continues on next page


5 Repair

5.2.13 Replacing the fieldbus master

Continued



Action	Note/Illustration
2 Remove the main computer.  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	  xx1800000542

Removing the fieldbus master

Action	Note/Illustration
1  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx2000000532

Continues on next page

5.2.13 Replacing the fieldbus master
Continued

Action	Note/Illustration				
2 Remove the attachment screws and take the cover off.	 <p>xx1800003415</p>				
3 Remove the attachment screw on the fieldbus master and take out the fieldbus master.  Note Be careful when you pull it out from the card slot.	 <p>xx1800003419</p> <table border="1" data-bbox="944 1426 1421 1527"> <tr> <td>A</td> <td>Card slots</td> </tr> <tr> <td>B</td> <td>Guide rail</td> </tr> </table>	A	Card slots	B	Guide rail
A	Card slots				
B	Guide rail				

Refitting the fieldbus master

Preparations


Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page


5 Repair

5.2.13 Replacing the fieldbus master

Continued



	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	 xx1800000683

Refitting the fieldbus master

	Action	Note/Illustration
1	 ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx2000000532

Continues on next page

5.2.13 Replacing the fieldbus master
Continued


Action	Note/Illustration				
2 Insert the fieldbus master straight into the card slots along the guide rail.	 <p>xx1800003417</p> <table border="1"> <tr> <td>A</td> <td>Card slots</td> </tr> <tr> <td>B</td> <td>Guide rail</td> </tr> </table>	A	Card slots	B	Guide rail
A	Card slots				
B	Guide rail				
3 Secure the fieldbus adapter with the screw.	<p>Screws: Screw with flange M3x6 (1 pcs)</p>  <p>xx1800003416</p>				

Continues on next page


5 Repair

5.2.13 Replacing the fieldbus master

Continued





Action	Note/Illustration
4 Refit the cover of the main computer and secure the screws.	Screws: Hexalobular socket pan head screw M3x6 (4 pcs)  xx1800003418

Refitting the main computer

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532

Continues on next page

5.2.13 Replacing the fieldbus master
Continued

Action	Note/Illustration
3 Fit the main computer to the process plate.	   xx1800000543
4 Fasten the main computer with the screws.	Screws: Torx pan head screw M4x8 (2 pcs)  xx1800000541



Continues on next page

5 Repair

5.2.13 Replacing the fieldbus master


Continued

Refitting the connected services gateway

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532
3 Hook up the connected services gateway to the bracket and push carefully into position.  Note During the installation, the gap between the lower surface of the connected services gateway and the upper surface of the main computer should be zero.	 xx1800000497 TOP VIEW

Continues on next page

Refitting the Ethernet extension switch (option)





	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532

Continues on next page

5 Repair

5.2.13 Replacing the fieldbus master

Continued




Action	Note/Illustration
3 Hook up the Ethernet extension switch to the bracket and then push the switch into position.  Note During the installation, there should be no gap between the upper surface of the Ethernet extension switch and the lower surface of highest bracket on the main computer. 	 xx1800000539  xx1800000972  xx180000493

Refitting the robot signal exchange proxy

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.13 Replacing the fieldbus master
Continued

Action	Note/Illustration
<p>2</p>  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx2000000532
<p>3</p> Fit the robot signal exchange proxy and secure the screws.  Note Avoid colliding with the frame of the controller.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000489
<p>4</p> Insert the cable ties into the locking holes.	 xx1800000971

Refitting the main computer assembly with process plate to the cabinet


Action	Note/Illustration
<p>1</p>  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5 Repair



5.2.13 Replacing the fieldbus master

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD)	Location of wrist strap button:  xx1800000683
3	Use the two guide pins to locate the assembly onto the mounting plate.  Note Be careful with the frame of the controller when refitting the unit.

Continues on next page

5.2.13 Replacing the fieldbus master
Continued

Action	Note/Illustration				
4 Fasten the assembly with the screws.  WARNING Be careful with the cables installed below the process plate.	  <table border="1" data-bbox="949 1500 1414 1603"> <tr> <td>A</td> <td>Screws, Torx pan head, M4x8 (1 pcs)</td> </tr> <tr> <td>B</td> <td>Screws, Torx pan head, M4x8 (4 pcs)</td> </tr> </table>	A	Screws, Torx pan head, M4x8 (1 pcs)	B	Screws, Torx pan head, M4x8 (4 pcs)
A	Screws, Torx pan head, M4x8 (1 pcs)				
B	Screws, Torx pan head, M4x8 (4 pcs)				
5 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.					

Continues on next page

5 Repair

5.2.13 Replacing the fieldbus master

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none">• K2.X8 - A2.X6• (option): K2.X2 - K4.X8, A2.X1• K2.X12 - A2.K3.X6, A2.K3.X7• K2.X10 - A1.X13• K2.X21 - TempSensor• K2.X4 - A1.X9• K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1• K2.X1 - T2.X2⁵³• K2.X1 - X107⁵⁴• K2.X17 - G2.X1, G1.X2• K2.X6, K2.X11 - A1.X2• K2.X7, K2.X22 - Harn. LV robot power• K2.X9 & X13 - FlexPendant	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3ⁱ• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁵³ • A2.X9 - X1⁵⁴ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	

ⁱ For connected services gateway wired, there is no power cable.

Refitting the axis computer to the frame



Action	Note/Illustration
<p>1  DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

Continues on next page

5 Repair

5.2.13 Replacing the fieldbus master

Continued




Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3 Reconnect and secure the screw: • K6.X4, K6.X5 - SMB.	
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs) 
5 Reconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3	

Refitting the small fan

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.2.13 Replacing the fieldbus master
Continued

	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD)	Location of wrist strap button:  xx1800000683
3	Reconnect: <ul style="list-style-type: none"> • G2.X1-K2.X17 	
4	Refit the fan bracket into the cabinet.	 xx1800000483
5	Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Continues on next page

5 Repair

5.2.13 Replacing the fieldbus master

Continued

Concluding procedure

	Action	Note/Illustration
1	Refit the covers.	Refitting the controller covers on page 227.
2	Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

5.3 Replacing parts on the front panel


5.3.1 Replacing the manipulator signal connector (SMB)

5.3 Replacing parts on the front panel

5.3.1 Replacing the manipulator signal connector (SMB)

Location

The illustration shows the location of the manipulator signal connector.



xx1800000037



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Harness Single SMB connection	3HAC068537-001	Harness single SMB
Harness Double SMB connection	3HAC067490-001	Harness double SMB

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Continues on next page

5 Repair

5.3.1 Replacing the manipulator signal connector (SMB)


Continued

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the manipulator signal connector

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3	Remove the front panel and top cover of the controller.	Removing the controller covers on page 222 .


Removing the axis computer from the cabinet

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none">• K6.X11 - A1.X3• K6.X2 - A2.X9• K6.X1 - K2.X3.	


Continues on next page

5.3.1 Replacing the manipulator signal connector (SMB)

Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	 xx1800000472
3 Loosen the screw and disconnect: • K6.X4, K6.X5 - SMB.	

Removing the manipulator signal connector

Action	Note/Illustration
1 Remove the attachment screws on the cover.	 xx1800000727
2 Push the manipulator signal connector into the cabinet.	
3 Take the manipulator signal connector out from the upper side.	

Refitting the manipulator signal connector

Refitting the manipulator signal connector


Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page


5 Repair

5.3.1 Replacing the manipulator signal connector (SMB)

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	
3 Insert the manipulator signal connector into the front panel from inner side of the cabinet.	
4 Secure it with the attachment screws.	Screws: Torx, countersunk screw M4x10 (4 pcs) 


Refitting the axis computer to the frame

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 

Continues on next page

5.3.1 Replacing the manipulator signal connector (SMB)

Continued

Action	Note/Illustration
3 Reconnect and secure the screw: • K6.X4, K6.X5 - SMB.	
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs) 
5 Reconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3	

Concluding procedure

Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	


5 Repair

5.3.2 Replacing the motor connector

5.3.2 Replacing the motor connector

Location

The illustration shows the location of the motor connector in the controller.



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Harness Motors power LV 6-axis	3HAC059527-001	Harness LV robot power 1,455 mm
Harness Motors power ULV 7-axis	3HAC065688-001	Only used for IRB 14050 controller.
Harness Motors power ULV	3HAC073522-001	Only used for CRB 15000 controller.

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .

Continues on next page

Equipment	Article number	Note
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Continues on next page


5 Repair

5.3.2.1 Replacing the motor connector


5.3.2.1 Replacing the motor connector

Removing the motor connector⁴²

Preparations

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Remove the top, right, left, rear covers and the front panel of the controller.	Removing the controller covers on page 222 .

Removing the axis computer from the frame


Action	Note/Illustration
1 Disconnect: <ul style="list-style-type: none">• A1.X3 - K6.X11• K6.X2 - A2.X9• K6.X1 - K2.X3.	
2 Remove the screws on the bracket.	
3 Loosen the screw and disconnect: <ul style="list-style-type: none">• SMB - K6.X4, K6.X5	

⁴² This procedure is not available for the CRB 15000 controllers.

Continues on next page

5.3.2.1 Replacing the motor connector
Continued

Removing the power supply optional

Action	Note/Illustration
1 Disconnect: <ul style="list-style-type: none"> • A1.X7 - T5.X1 	
2 Remove the attachment screws and lift the power supply out.	
3 Disconnect: <ul style="list-style-type: none"> • T5.X2 - X45 	

Removing the motor connector


Action	Note/Illustration
1 Disconnect the following connectors for the motor connector: <ul style="list-style-type: none"> • T4.X7, T4.X8, T4.X9 • X1 - K2.X7 & X22 • Two ground cables which connects on the left side of the cabinet frame. 	

Continues on next page

5 Repair

5.3.2.1 Replacing the motor connector

Continued

Action	Note/Illustration
2 Remove the attachment screws on the front panel.	 xx1800000729
3 Push the motor connector into the cabinet.	
4 Take the motor connector cable out from the velcro in the cabinet.  Note Make records about the sequence that cables are removed. The cables need to be installed in the same position.	
5 Take the motor connector out from the upper side.	

Refitting the motor connector⁴³



Refitting the motor connector

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see <i>Electrical safety on page 31</i> .	

⁴³ This procedure is not available for the CRB 15000 controllers.

Continues on next page

5.3.2.1 Replacing the motor connector
Continued

Action	Note/Illustration
<p>2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i></p>	<p>Location of wrist strap button:</p>  <p>xx1800000683</p>
<p>3 Insert the motor connector into the front panel from inner side of the cabinet and fasten it with the screws.</p>	<p>Screws: Torx, countersunk screw M4x10 (4 pcs)</p>  <p>xx1800000730</p>
<p>4 Reconnect:</p> <ul style="list-style-type: none"> • T4.X7, T4.X8, T4.X9 • X1 - K2.X7 & X22 • Two ground cables which connects on the left side of the cabinet frame. 	
<p>5 Secure the motor connector cables with the velcro on the frame of the cabinet.</p> <p> Tip Use the same position as from removing the motor connector.</p>	



Continues on next page

5 Repair

5.3.2.1 Replacing the motor connector

Continued



Refitting the power supply optional

Action	Note/Illustration
1	 DANGER
	<p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>
2	 ELECTROSTATIC DISCHARGE (ESD) <p>The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47.</p>
	Location of wrist strap button:
	 xx1800000683
3	Fit the power supply.
4	Reconnect: <ul style="list-style-type: none">T5.X2 - X45.
5	Secure the screws.
	Screws: Torx pan head screw M4x8 (4 pcs)
	 xx1800000550
6	Reconnect: <ul style="list-style-type: none">A1.X7 - T5.X1

Continues on next page

5.3.2.1 Replacing the motor connector
Continued

Refitting the axis computer to the frame

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Reconnect: <ul style="list-style-type: none">• K6.X4, K6.X5 - SMB.	
4	Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1900001201
5	Reconnect: <ul style="list-style-type: none">• K6.X11 - A1.X3• K6.X2 - A2.X9• K6.X1 - K2.X3	

Concluding procedure

	Action	Note/Illustration
1	Refit the covers.	Refitting the controller covers on page 227 .
2	Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	


5 Repair

5.3.2.2 Replacing the motor connector for CRB 15000 controller

5.3.2.2 Replacing the motor connector for CRB 15000 controller

Removing the motor connector for CRB 15000 controller

Preparations

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Remove the top, right, left, rear covers and the front panel of the controller.	Removing the controller covers on page 222 .

Removing the main computer assembly with process plate

Action	Note/Illustration
1 Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer.	

Continues on next page

5.3.2.2 Replacing the motor connector for CRB 15000 controller

Continued


Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2⁴⁴ • K2.X1 - X107⁴⁵ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3⁴⁶ • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

⁴⁴ Not available for CRB 15000 controller.⁴⁵ Only available for CRB 15000 controller.⁴⁶ For connected services gateway wired, there is no power cable.*Continues on next page*

5 Repair

5.3.2.2 Replacing the motor connector for CRB 15000 controller



Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2 ⁴⁴ • A2.X9 - X1 ⁴⁵ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p>Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	
<p>2 Remove the mating connectors from the front side by loosening their attachment screws.</p>	

Continues on next page

5.3.2.2 Replacing the motor connector for CRB 15000 controller

Continued

	Action	Note/Illustration				
3	<p>Remove the screws holding the process plate and the screws holding the scalable I/O bracket.</p>  	<table border="1" data-bbox="949 1495 1422 1653"> <tr> <td data-bbox="949 1495 1002 1567">A</td><td data-bbox="1002 1495 1422 1567">Screws holding the scalable I/O bracket (1 pcs)</td></tr> <tr> <td data-bbox="949 1567 1002 1653">B</td><td data-bbox="1002 1567 1422 1653">Screws holding the process plate (4 pcs)</td></tr> </table>	A	Screws holding the scalable I/O bracket (1 pcs)	B	Screws holding the process plate (4 pcs)
A	Screws holding the scalable I/O bracket (1 pcs)					
B	Screws holding the process plate (4 pcs)					
4	<p>Pull out the process plate with the assembly from the two guide pins on the mounting plate.</p> <p> Note</p> <p>Avoid colliding with the frame when removing the unit.</p>					


Continues on next page

5 Repair

5.3.2.2 Replacing the motor connector for CRB 15000 controller

Continued

Removing the motor connector

Action	Note/Illustration
1 Disconnect the following connectors for the motor connector: <ul style="list-style-type: none">• X1 - X105• X1 - X106• X1 - A1.X4• X1 - A2.X9• Two ground cables which connects on the left side of the cabinet frame.	
2 Remove the attachment screws on the front panel.	
3 Push the motor connector into the cabinet.	
4 Take the motor connector cable out from the velcro in the cabinet.  Note Make records about the sequence that cables are removed. The cables need to be installed in the same position.	
5 Take the motor connector out from the upper side.	

Refitting the motor connector for CRB 15000 controller



Refitting the motor connector

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.3.2.2 Replacing the motor connector for CRB 15000 controller

Continued

	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD)	Location of wrist strap button:
	<p>The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i></p>	 xx1800000683
3	Insert the motor connector into the front panel from inner side of the cabinet and fasten it with the screws.	Screws: Torx, countersunk screw M4x10 (4 pcs)
		 xx1800000730
4	Reconnect: <ul style="list-style-type: none"> • X1 - X105 • X1 - X106 • X1 - A1.X4 • X1 - A2.X9 • Two ground cables which connects on the left side of the cabinet frame. 	
5	Insert the cables on motor connector into the clips in the bottom of the cabinet.	
	 Tip Use the same position as from removing the motor connector.	


Continues on next page

5 Repair

5.3.2.2 Replacing the motor connector for CRB 15000 controller

Continued



Refitting the main computer assembly with process plate to the cabinet

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx1800000683
3 Use the two guide pins to locate the assembly onto the mounting plate.	 Note Be careful with the frame of the controller when refitting the unit.

Continues on next page

5.3.2.2 Replacing the motor connector for CRB 15000 controller

Continued

Action	Note/Illustration				
4 Fasten the assembly with the screws.  WARNING Be careful with the cables installed below the process plate.	  <table border="1" data-bbox="949 1493 1413 1605"> <tr> <td>A</td> <td>Screws, Torx pan head, M4x8 (1 pcs)</td> </tr> <tr> <td>B</td> <td>Screws, Torx pan head, M4x8 (4 pcs)</td> </tr> </table>	A	Screws, Torx pan head, M4x8 (1 pcs)	B	Screws, Torx pan head, M4x8 (4 pcs)
A	Screws, Torx pan head, M4x8 (1 pcs)				
B	Screws, Torx pan head, M4x8 (4 pcs)				
5 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.					

Continues on next page

5 Repair

5.3.2.2 Replacing the motor connector for CRB 15000 controller

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none">• K2.X8 - A2.X6• (option): K2.X2 - K4.X8, A2.X1• K2.X12 - A2.K3.X6, A2.K3.X7• K2.X10 - A1.X13• K2.X21 - TempSensor• K2.X4 - A1.X9• K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1• K2.X1 - T2.X2⁵³• K2.X1 - X107⁵⁴• K2.X17 - G2.X1, G1.X2• K2.X6, K2.X11 - A1.X2• K2.X7, K2.X22 - Harn. LV robot power• K2.X9 & X13 - FlexPendant	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3ⁱ• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

5.3.2.2 Replacing the motor connector for CRB 15000 controller

Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁵³ • A2.X9 - X1⁵⁴ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	

ⁱ For connected services gateway wired, there is no power cable.

Concluding procedure


Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

5 Repair

5.3.3 Replacing the incoming mains connector

Location

The illustration shows the location of the incoming mains connector in the controller.



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Harness Power input single phase	3HAC058827-001	Harness-Mains connection
Connector AC power inlet, M22 PLUG	3HAC064793-001	Mating connector for Power inlet

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .

Continues on next page

5.3.3 Replacing the incoming mains connector
Continued


Equipment	Article number	Note
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30,</i> <i>Circuit diagram - OmniCore C30</i> <i>for IRB 14050, Circuit dia-</i> <i>gram - OmniCore C30 for CRB</i> <i>15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the incoming mains connector

Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the top and left covers and the front panel of the controller.	Removing the controller covers on page 222 .

Removing the axis computer from the frame


	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none"> • A1.X3 - K6.X11 • K6.X2 - A2.X9 • K6.X1 - K2.X3. 	

Continues on next page


5 Repair

5.3.3 Replacing the incoming mains connector

Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	 xx1900001200
3 Loosen the screw and disconnect: <ul style="list-style-type: none"> • SMB - K6.X4, K6.X5 	

Removing the incoming mains connector

Action	Note/Illustration
1 Disconnect: <ul style="list-style-type: none"> • Q0 - A1.X1. • Two ground cables which connects to the left cabinet frame. 	
2 Remove the attachment screws on the front panel.	 xx1800000733
3 Push the incoming mains connector into the cabinet.	
4 Take the incoming mains connector out from the left side.	



Refitting the incoming mains connector

Refitting the incoming mains connector

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.3.3 Replacing the incoming mains connector
Continued

Action	Note/Illustration
<p>2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i></p>	Location of wrist strap button:  xx1800000683
3 Insert the incoming mains connector into the front panel from inner side of the cabinet.	
4 Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (4 pcs)  xx1800000734
5 Reconnect: <ul style="list-style-type: none"> • Q0 - A1.X1. • Two ground cables which connects to the left cabinet frame. 	

Refitting the axis computer to the frame



Action	Note/Illustration
<p>1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see <i>Electrical safety on page 31.</i></p>	

Continues on next page

5 Repair

5.3.3 Replacing the incoming mains connector

Continued

Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3 Reconnect: <ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs) 
5 Reconnect: <ul style="list-style-type: none"> • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3 	

Concluding procedure


Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227 .
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

5.3.4 Replacing the HMI signal (FlexPendant) connector

5.3.4 Replacing the HMI signal (FlexPendant) connector

Location

The illustration shows the location of the HMI signal connector in the controller.



xx1800000041



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Harness TPU connection	3HAC058870-001	Harness-TPU

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Continues on next page

5 Repair

5.3.4 Replacing the HMI signal (FlexPendant) connector


Continued

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the HMI signal connector



Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3	Remove the top and right covers and the front panel of the controller.	Removing the controller covers on page 222 .

Continues on next page

5.3.4 Replacing the HMI signal (FlexPendant) connector
Continued

Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: <ul style="list-style-type: none"> • G2.X1-K2.X17 	

Removing the axis computer from the cabinet


	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none"> • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3. 	

Continues on next page

5 Repair

5.3.4 Replacing the HMI signal (FlexPendant) connector

Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	 xx1800000472
3 Loosen the screw and disconnect: <ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	

Removing the main computer assembly with process plate

Action	Note/Illustration
1 Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer. 2 For the robot signal exchange proxy: <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2⁴⁷ • K2.X1 - X107⁴⁸ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	

⁴⁷ Not available for CRB 15000 controller.

⁴⁸ Only available for CRB 15000 controller.

Continues on next page

5.3.4 Replacing the HMI signal (FlexPendant) connector
Continued

Action	Note/Illustration
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3⁴⁹ • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	


⁴⁹ For connected services gateway wired, there is no power cable.

Continues on next page

5 Repair



5.3.4 Replacing the HMI signal (FlexPendant) connector

Continued

	Action	Note/Illustration
	<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁴⁷ • A2.X9 - X1⁴⁸ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p>Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
	<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	
2	<p>Remove the mating connectors from the front side by loosening their attachment screws.</p>	

Continues on next page

5.3.4 Replacing the HMI signal (FlexPendant) connector
Continued

	Action	Note/Illustration				
3	<p>Remove the screws holding the process plate and the screws holding the scalable I/O bracket.</p>  <p>xx1800000532</p>  <p>xx1900000215</p> <table border="1" data-bbox="946 1484 1414 1653"> <tr> <td data-bbox="946 1484 1002 1563">A</td><td data-bbox="1002 1484 1414 1563">Screws holding the scalable I/O bracket (1 pcs)</td></tr> <tr> <td data-bbox="946 1563 1002 1653">B</td><td data-bbox="1002 1563 1414 1653">Screws holding the process plate (4 pcs)</td></tr> </table>	A	Screws holding the scalable I/O bracket (1 pcs)	B	Screws holding the process plate (4 pcs)	
A	Screws holding the scalable I/O bracket (1 pcs)					
B	Screws holding the process plate (4 pcs)					
4	<p>Pull out the process plate with the assembly from the two guide pins on the mounting plate.</p> <p> Note</p> <p>Avoid colliding with the frame when removing the unit.</p>					


Continues on next page

5 Repair

5.3.4 Replacing the HMI signal (FlexPendant) connector

Continued

Removing the HMI signal connector

Action	Note/Illustration
1 Remove the cables out from the clips in the bottom of the cabinet carefully.  Note Make records about the sequence that cables are removed. The cables need to be installed in the same position.	
2 Remove the attachment screws on the front panel.	 xx1800000735
3 Push the HMI signal connector into the cabinet.	
4 Push the cables on HMI signal connector out from the clips on the bottom of the cabinet.	
5 Take the HMI signal connector out from the upper side.	




Refitting the HMI signal connector

Refitting the HMI signal connector

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.3.4 Replacing the HMI signal (FlexPendant) connector Continued

Action	Note/Illustration
<p>2</p>  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i>	Location of wrist strap button: 
<p>3</p> Insert the HMI signal connector into the front panel from inside the cabinet. Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (4 pcs) 
<p>4</p> Insert the cables on HMI signal connector into the clips on the bottom of the cabinet.  Tip Use the same position as from removing HMI connector.	


Continues on next page

5 Repair

5.3.4 Replacing the HMI signal (FlexPendant) connector



Continued

Refitting the main computer assembly with process plate to the cabinet

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx1800000683
3 Use the two guide pins to locate the assembly onto the mounting plate.	 Note Be careful with the frame of the controller when refitting the unit.

Continues on next page

5.3.4 Replacing the HMI signal (FlexPendant) connector
Continued

Action	Note/Illustration				
4 Fasten the assembly with the screws.  WARNING Be careful with the cables installed below the process plate.	  <table border="1" data-bbox="949 1500 1414 1603"> <tr> <td>A</td> <td>Screws, Torx pan head, M4x8 (1 pcs)</td> </tr> <tr> <td>B</td> <td>Screws, Torx pan head, M4x8 (4 pcs)</td> </tr> </table>	A	Screws, Torx pan head, M4x8 (1 pcs)	B	Screws, Torx pan head, M4x8 (4 pcs)
A	Screws, Torx pan head, M4x8 (1 pcs)				
B	Screws, Torx pan head, M4x8 (4 pcs)				
5 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.					

Continues on next page

5 Repair

5.3.4 Replacing the HMI signal (FlexPendant) connector

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none">• K2.X8 - A2.X6• (option): K2.X2 - K4.X8, A2.X1• K2.X12 - A2.K3.X6, A2.K3.X7• K2.X10 - A1.X13• K2.X21 - TempSensor• K2.X4 - A1.X9• K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1• K2.X1 - T2.X2⁵³• K2.X1 - X107⁵⁴• K2.X17 - G2.X1, G1.X2• K2.X6, K2.X11 - A1.X2• K2.X7, K2.X22 - Harn. LV robot power• K2.X9 & X13 - FlexPendant	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none">• K2.X2 - K4.X8, A2.X1• A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none">• Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none">• K7.X1 - K2.X3ⁱ• K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

5.3.4 Replacing the HMI signal (FlexPendant) connector
Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁵³ • A2.X9 - X1⁵⁴ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	

ⁱ For connected services gateway wired, there is no power cable.

Refitting the axis computer to the frame



Action	Note/Illustration
<p>1  DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

Continues on next page

5 Repair

5.3.4 Replacing the HMI signal (FlexPendant) connector

Continued




Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3 Reconnect and secure the screw: • K6.X4, K6.X5 - SMB.	
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)  xx1800000476
5 Reconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3	

Refitting the small fan

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.3.4 Replacing the HMI signal (FlexPendant) connector
Continued

	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD)	Location of wrist strap button:
	<p>The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i></p>	 xx1800000683
3	Reconnect: <ul style="list-style-type: none"> • G2.X1-K2.X17 	
4	Refit the fan bracket into the cabinet.	 xx1800000483
5	Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Continues on next page

5 Repair

5.3.4 Replacing the HMI signal (FlexPendant) connector

Continued


Concluding procedure

	Action	Note/Illustration
1	Refit the covers.	Refitting the controller covers on page 227.
2	Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

5.3.5 Replacing the process connectors

Location

The illustration shows the location of the process connectors in the controller.



xx1800000737



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Harness DeviceNet/Harness 24V ext. cover plate	3HAC063601-001	
Harness DeviceNet connection	3HAC062150-001	DSQC1004
Connector assembly Single-row female	3HAC064901-001	Mating CONN for IP20 DeviceNet connector

Continues on next page

5 Repair

5.3.5 Replacing the process connectors

Continued

Required tools and equipment


Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the process connectors



Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the top and right covers and the front panel of the controller.	Removing the controller covers on page 222

Continues on next page

5.3.5 Replacing the process connectors Continued

Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 <p>xx1800000479</p>
2	Push and slide the fan bracket and lift it out.	 <p>xx1800000480</p>
3	Disconnect: • G2.X1-K2.X17	

Removing the axis computer from the cabinet


	Action	Note/Illustration
1	Disconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3.	

Continues on next page

5 Repair

5.3.5 Replacing the process connectors

Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	 xx1800000472
3 Loosen the screw and disconnect: <ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	

Removing the main computer assembly with process plate

Action	Note/Illustration
1 Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer. 2 For the robot signal exchange proxy: <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2⁵⁰ • K2.X1 - X107⁵¹ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	

⁵⁰ Not available for CRB 15000 controller.

⁵¹ Only available for CRB 15000 controller.

Continues on next page

5.3.5 Replacing the process connectors
Continued

Action	Note/Illustration
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3⁵² • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	


⁵² For connected services gateway wired, there is no power cable.

Continues on next page

5 Repair

5.3.5 Replacing the process connectors



Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁵⁰ • A2.X9 - X1⁵¹ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p>Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	
<p>2 Remove the mating connectors from the front side by loosening their attachment screws.</p>	 <p>xx1800000485</p>

Continues on next page

5.3.5 Replacing the process connectors

Continued

Action	Note/Illustration				
3 Remove the screws holding the process plate and the screws holding the scalable I/O bracket.	  <table border="1" data-bbox="944 1493 1421 1650"> <tr> <td>A</td><td>Screws holding the scalable I/O bracket (1 pcs)</td></tr> <tr> <td>B</td><td>Screws holding the process plate (4 pcs)</td></tr> </table>	A	Screws holding the scalable I/O bracket (1 pcs)	B	Screws holding the process plate (4 pcs)
A	Screws holding the scalable I/O bracket (1 pcs)				
B	Screws holding the process plate (4 pcs)				
4 Pull out the process plate with the assembly from the two guide pins on the mounting plate.  Note Avoid colliding with the frame when removing the unit.					


Continues on next page

5 Repair

5.3.5 Replacing the process connectors

Continued

Removing the process connectors

Action	Note/Illustration
1 Push the cables out from the clips in the bottom of the controller carefully.  Note Make records about the sequence that cables are removed. The cables need to be installed in the same position.	
2 Remove the attachment screws on the front panel.	 xx1800000738
3 Push the process connectors into the cabinet.	
4 Push the cables on process connectors out from the clips on the bottom of the cabinet.	
5 Take the process connectors out from the upper side.	

Refitting the process connectors




Refitting the process connectors

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.3.5 Replacing the process connectors

Continued

Action	Note/Illustration
<p>2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i></p>	<p>Location of wrist strap button:</p> 
3 Insert the process connectors into the front panel from inside the cabinet.	
4 Secure it with the screws.	<p>Screws: Torx, countersunk screw M4x10 (2 pcs)</p> 
<p>5 Insert the cables on process connectors into the clips in the bottom of the cabinet.</p> <p> Tip Use the same position as from removing process connectors.</p>	


Continues on next page

5 Repair

5.3.5 Replacing the process connectors

Continued



Refitting the main computer assembly with process plate to the cabinet

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx1800000683
3 Use the two guide pins to locate the assembly onto the mounting plate.	 Note Be careful with the frame of the controller when refitting the unit.

Continues on next page

5.3.5 Replacing the process connectors

Continued

Action	Note/Illustration				
4 Fasten the assembly with the screws.  WARNING Be careful with the cables installed below the process plate.	  <table border="1" data-bbox="949 1500 1414 1596"> <tr> <td>A</td> <td>Screws, Torx pan head, M4x8 (1 pcs)</td> </tr> <tr> <td>B</td> <td>Screws, Torx pan head, M4x8 (4 pcs)</td> </tr> </table>	A	Screws, Torx pan head, M4x8 (1 pcs)	B	Screws, Torx pan head, M4x8 (4 pcs)
A	Screws, Torx pan head, M4x8 (1 pcs)				
B	Screws, Torx pan head, M4x8 (4 pcs)				
5 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.					

Continues on next page

5 Repair

5.3.5 Replacing the process connectors

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2⁵³ • K2.X1 - X107⁵⁴ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power • K2.X9 & X13 - FlexPendant 	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3ⁱ • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

5.3.5 Replacing the process connectors

Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁵³ • A2.X9 - X1⁵⁴ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	

ⁱ For connected services gateway wired, there is no power cable.

Refitting the axis computer to the frame



Action	Note/Illustration
<p>1  DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

Continues on next page

5 Repair

5.3.5 Replacing the process connectors

Continued




	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD)	Location of wrist strap button:  xx1800000683
3	Reconnect and secure the screw:	
	<ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	
4	Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs)
		 xx1800000476
5	Reconnect:	
	<ul style="list-style-type: none"> • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3 	

Refitting the small fan

	Action	Note/Illustration
1	 DANGER	Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .

Continues on next page

5.3.5 Replacing the process connectors
Continued

	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD)	Location of wrist strap button:
	<p>The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD</i> on page 47.</p>	 xx1800000683
3	Reconnect: <ul style="list-style-type: none"> • G2.X1-K2.X17 	
4	Refit the fan bracket into the cabinet.	 xx1800000483
5	Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Continues on next page

5 Repair

5.3.5 Replacing the process connectors

Continued


Concluding procedure

	Action	Note/Illustration
1	Refit the covers.	Refitting the controller covers on page 227
2	Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	

5.3.6 Replacing the harness CFI connection

Location

The illustration shows the location of the harness CFI connection which is only available for the CRB 15000 controller.



xx2000002025



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Harness CFI connection	3HAC073523-001	Only used for CRB 15000 controller.

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Continues on next page

5 Repair

5.3.6 Replacing the harness CFI connection


Continued

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the harness CFI connection


Preparations

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the front panel and top cover of the controller.	Removing the controller covers on page 222 .

Removing the harness CFI connection

	Action	Note/Illustration
1	Loosen the screw and disconnect: <ul style="list-style-type: none">• X2 - X105.• X2 - X106.	

Continues on next page

Action	Note/Illustration
2 Remove the attachment screws on the cover.	
3 Push the CFI connector into the cabinet.	
4 Take the harness CFI connection out from the upper side.	

Refitting the harness CFI connection

Refitting the harness CFI connection


Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	
3 Insert the harness CFI connection into the front panel from inner side of the cabinet.	

Continues on next page

5 Repair

5.3.6 Replacing the harness CFI connection

Continued

Action	Note/Illustration
4 Secure it with the attachment screws.	Screws: Torx, countersunk screw M4x10 (4 pcs) 
5 Reconnect and secure: • X2 - X105. • X2 - X106.	

Concluding procedure


Action	Note/Illustration
1 Refit the covers.	Refitting the controller covers on page 227.
2 Perform the function tests to verify that the safety features work properly, see Function tests on page 212.	

5.3.7 Replacing the IP20 power outlet connector

5.3.7 Replacing the IP20 power outlet connector

Location

The illustration shows the location of the IP20 power outlet connector in the controller.



xx1800000740



Note

To confirm whether this unit is available in your controller, see chapter [Overview of the controller on page 38](#).

If this unit is not available in your controller, ignore the related procedure to this unit when you do any maintenance or repair work.

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Harness DeviceNet/Harness 24V ext. cover plate	3HAC063601-001	
Harness 24V_Process output	3HAC060965-001	DSQC 688
Connector Single-row female	3HAC064743-001	Mating connector for IP20 power outlet connector

Continues on next page

5 Repair

5.3.7 Replacing the IP20 power outlet connector

Continued

Required tools and equipment


Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .
ESD protective wrist band	-	

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the IP20 power outlet connector

Preparations



	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button:  xx1800000683
3	Remove the top and right covers and the front panel of the controller.	Removing the controller covers on page 222

Continues on next page

5.3.7 Replacing the IP20 power outlet connector

Continued

Removing the small fan

	Action	Note/Illustration
1	Remove the screws holding the fan.	 xx1800000479
2	Push and slide the fan bracket and lift it out.	 xx1800000480
3	Disconnect: • G2.X1-K2.X17	

Removing the axis computer from the cabinet


	Action	Note/Illustration
1	Disconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3.	

Continues on next page

5 Repair

5.3.7 Replacing the IP20 power outlet connector

Continued

Action	Note/Illustration
2 Remove the screws on the bracket.	 xx1800000472
3 Loosen the screw and disconnect: <ul style="list-style-type: none"> • K6.X4, K6.X5 - SMB. 	

Removing the main computer assembly with process plate

Action	Note/Illustration
1 Disconnect all the connectors on the assembly group of the robot signal exchange proxy, Ethernet switch (option), connected services gateway, scalable I/O (option), and main computer. 2 For the robot signal exchange proxy: <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2⁵³ • K2.X1 - X107⁵⁴ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power (X1) • K2.X9 & X13 - FlexPendant (X4) 	

⁵³ Not available for CRB 15000 controller.

⁵⁴ Only available for CRB 15000 controller.

Continues on next page

5.3.7 Replacing the IP20 power outlet connector

Continued

Action	Note/Illustration
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3⁵⁵ • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	


⁵⁵ For connected services gateway wired, there is no power cable.

Continues on next page

5 Repair



5.3.7 Replacing the IP20 power outlet connector

Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁵³ • A2.X9 - X1⁵⁴ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p>Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4 to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p>Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	
<p>2 Remove the mating connectors from the front side by loosening their attachment screws.</p>	

Continues on next page

5.3.7 Replacing the IP20 power outlet connector
Continued

Action	Note/Illustration				
3	<p>Remove the screws holding the process plate and the screws holding the scalable I/O bracket.</p>  <p>xx1800000532</p>  <p>xx1900000215</p> <table border="1" data-bbox="949 1500 1426 1657"> <tr> <td data-bbox="949 1500 1002 1531">A</td><td data-bbox="1002 1500 1426 1531">Screws holding the scalable I/O bracket (1 pcs)</td></tr> <tr> <td data-bbox="949 1531 1002 1585">B</td><td data-bbox="1002 1531 1426 1585">Screws holding the process plate (4 pcs)</td></tr> </table>	A	Screws holding the scalable I/O bracket (1 pcs)	B	Screws holding the process plate (4 pcs)
A	Screws holding the scalable I/O bracket (1 pcs)				
B	Screws holding the process plate (4 pcs)				
4	<p>Pull out the process plate with the assembly from the two guide pins on the mounting plate.</p> <p> Note</p> <p>Avoid colliding with the frame when removing the unit.</p>				


Continues on next page

5 Repair

5.3.7 Replacing the IP20 power outlet connector

Continued

Removing the IP20 power outlet connector

	Action	Note/Illustration
1	Disconnect: <ul style="list-style-type: none">X45 - T5.X2.	
2	Push the cables out from the clips in the bottom of the controller carefully.  Note Make records about the sequence that cables are removed. The cables need to be installed in the same position.	
3	Disconnect the power supply optional.	
4	Remove the attachment screws on the front panel.	 xx1800000741
5	Push the IP20 power outlet connector into the cabinet.	
6	Push the cables on IP20 power outlet connector out from the clips on the bottom of the cabinet.	
7	Take the IP20 power outlet connector out from the upper side.	




Refitting the IP20 power outlet connector

Refitting the IP20 power outlet connector

	Action	Note/Illustration
1	 DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.3.7 Replacing the IP20 power outlet connector
Continued

Action	Note/Illustration
<p>2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i></p>	<p>Location of wrist strap button:</p> 
3 Insert the IP20 power outlet connector into the front panel from inside the cabinet.	
4 Secure it with the screws.	<p>Screws: Torx, countersunk screw M4x10 (2 pcs)</p> 
5 Reconnect the power supply optional.	
<p>6 Insert the cables on IP20 power outlet connector into the clips in the bottom of the cabinet.</p> <p> Tip Use the same position as from removing IP20 power outlet connector.</p>	
7 Reconnect: <ul style="list-style-type: none"> • X45 - T5.X2. 	


Continues on next page

5 Repair

5.3.7 Replacing the IP20 power outlet connector

Continued



Refitting the main computer assembly with process plate to the cabinet

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	
2  ELECTROSTATIC DISCHARGE (ESD) When handling the computer outside of the controller, use the wrist strap button located on the side of the computer.	Location of wrist strap button:  xx1800000683
3 Use the two guide pins to locate the assembly onto the mounting plate.	 Note Be careful with the frame of the controller when refitting the unit.

Continues on next page

5.3.7 Replacing the IP20 power outlet connector

Continued

Action	Note/Illustration				
4 Fasten the assembly with the screws.  WARNING Be careful with the cables installed below the process plate.	  <table border="1"> <tr> <td>A</td> <td>Screws, Torx pan head, M4x8 (1 pcs)</td> </tr> <tr> <td>B</td> <td>Screws, Torx pan head, M4x8 (4 pcs)</td> </tr> </table>	A	Screws, Torx pan head, M4x8 (1 pcs)	B	Screws, Torx pan head, M4x8 (4 pcs)
A	Screws, Torx pan head, M4x8 (1 pcs)				
B	Screws, Torx pan head, M4x8 (4 pcs)				
5 Reconnect all the connectors on assembly of the robot signal exchange proxy, ethernet extension-seven port switch (option), ABB ability™ connected services, scalable I/O digital base (option), and main computer.					

Continues on next page

5 Repair

5.3.7 Replacing the IP20 power outlet connector

Continued

Action	Note/Illustration
<p>For the robot signal exchange proxy:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • (option): K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • K2.X10 - A1.X13 • K2.X21 - TempSensor • K2.X4 - A1.X9 • K2.X3 - K6.X1, A2.K3.X1, K5.1.X4, K7.X1 • K2.X1 - T2.X2⁵³ • K2.X1 - X107⁵⁴ • K2.X17 - G2.X1, G1.X2 • K2.X6, K2.X11 - A1.X2 • K2.X7, K2.X22 - Harn. LV robot power • K2.X9 & X13 - FlexPendant 	
<p>For the Ethernet extension switch (option):</p> <ul style="list-style-type: none"> • K2.X2 - K4.X8, A2.X1 • A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • Harness adapter - A2.X4/K4.X7. <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p>	
<p>For the connected services gateway:</p> <ul style="list-style-type: none"> • K7.X1 - K2.X3ⁱ • K7.X2 - A2.X5 <p> Note</p> <p>The connector K7.X2 is locked; grab the connector, push it in to release it and then remove the connector.</p>	

Continues on next page

5.3.7 Replacing the IP20 power outlet connector

Continued

Action	Note/Illustration
<p>For the main computer:</p> <ul style="list-style-type: none"> • K2.X8 - A2.X6 • K2.X2 - K4.X8, A2.X1 • K2.X12 - A2.K3.X6, A2.K3.X7 • A2.X9 - K6.X2⁵³ • A2.X9 - X1⁵⁴ • A2.X5 - K7.X2 • (Option) A2.K1 - X17 <p> Note</p> <p>This cable is available when the fieldbus master and DeviceNet harness are installed.</p> <ul style="list-style-type: none"> • (Option) A2.X4 - K4.X6 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the connector A2.X4) to/from K4.X6.</p> <ul style="list-style-type: none"> • (Option) Harness adapter - A2.X4/K4.X7 <p> Note</p> <p>When Ethernet extension switch is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from K4.X7.</p> <p>When Ethernet extension unit slot cover is selected, connect and disconnect the adapter cable (Adapter - A2.X4/K4.X7) to/from A2.X4.</p>	
<p>For the digital base (option):</p> <ul style="list-style-type: none"> • K5.1.X4 - K2.X3 • K5.1.X5 - Harness adapter 	

ⁱ For connected services gateway wired, there is no power cable.

Refitting the axis computer to the frame



Action	Note/Illustration
<p>1  DANGER</p> <p>Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31.</p>	

Continues on next page

5 Repair

5.3.7 Replacing the IP20 power outlet connector

Continued




Action	Note/Illustration
2  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	Location of wrist strap button: 
3 Reconnect and secure the screw: • K6.X4, K6.X5 - SMB.	
4 Fit the axis computer bracket and secure the screws.	Screws: Torx pan head screw M4x8 (4 pcs) 
5 Reconnect: • K6.X11 - A1.X3 • K6.X2 - A2.X9 • K6.X1 - K2.X3	

Refitting the small fan

Action	Note/Illustration
1  DANGER Before doing any work inside the cabinet, disconnect the mains power. For more information, see Electrical safety on page 31 .	

Continues on next page

5.3.7 Replacing the IP20 power outlet connector
Continued

	Action	Note/Illustration
2	 ELECTROSTATIC DISCHARGE (ESD)	Location of wrist strap button:
	<p>The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47.</i></p>	 xx1800000683
3	Reconnect: <ul style="list-style-type: none"> • G2.X1-K2.X17 	
4	Refit the fan bracket into the cabinet.	 xx1800000483
5	Secure it with the screws.	Screws: Torx, countersunk screw M4x10 (2 pcs)  xx1800000484

Continues on next page

5 Repair

5.3.7 Replacing the IP20 power outlet connector

Continued

Concluding procedure

	Action	Note/Illustration
1	Refit the covers.	Refitting the controller covers on page 227
2	Perform the function tests to verify that the safety features work properly, see Function tests on page 212 .	


5.4.1 Replacing the power cable and power cable cover

5.4 Replacing parts on the FlexPendant

5.4.1 Replacing the power cable and power cable cover

Location

The illustration shows the location of the power cable, power cable gasket, and power cable cover in the FlexPendant.



xx1800001154

A	Power cable cover
B	Power cable

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Harness TPU connection	3HAC058870-001	Harness-TPU

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .

Continues on next page

5 Repair

5.4.1 Replacing the power cable and power cable cover



Continued

Equipment	Article number	Note
ESD protective wrist band	-	

Required documents



Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit dia- gram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	

Removing the power cable and power cable cover

	Action	Note/Illustration
1	 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	
2	Disconnect the FlexPendant from the controller.	
3	Remove the attachment screws for the power cable cover.	 xx1800001189
4	Remove the power cable cover.	 xx1800001190

Continues on next page

5.4.1 Replacing the power cable and power cable cover
Continued

Action	Note/Illustration
5 Disconnect two connectors to the Flex-Pendant.	 xx1800001748
6 Remove the power cable.	 xx1800001192

Refitting the power cable and power cable cover




Action	Note/Illustration
 ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section <i>The unit is sensitive to ESD on page 47</i> .	

Continues on next page

5 Repair

5.4.1 Replacing the power cable and power cable cover

Continued


Action	Note/Illustration
2	<p>Refit the power cable.</p>  <p>xx1800001193</p>
3	<p>Reconnect the power cable to the Flex-Pendant.</p>  <p>xx1800001748</p>
4	<p>Refit the power cable cover and tighten the screws.</p> <p>Screws: Torx pan head screw M4x8 (3 pcs)</p>  <p>xx1800001196</p>
5	<p>Perform the function tests to verify that the safety features work properly, see Function tests on page 212.</p>

5.4.2 Replacing the joystick protection

5.4.2 Replacing the joystick protection

Location

The illustration shows the location of the joystick protection on the FlexPendant.



xx1800001197

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Joystick guard	3HAC065408-001	

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit for controller on page 570 .

Required documents

Document	Article number	Note
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009	



Continues on next page

5 Repair

5.4.2 Replacing the joystick protection

Continued

Removing the joystick protection



Action	Note/Illustration
1  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	
2 Disconnect the FlexPendant from the controller.	
3 Remove the attachment screws.	 xx1800001198
4 Remove the joystick protection.	 xx1800001199

Refitting the joystick protection

Action	Note/Illustration
1  ELECTROSTATIC DISCHARGE (ESD) The unit is sensitive to ESD. Before handling the unit read the safety information in section The unit is sensitive to ESD on page 47 .	

Continues on next page

5.4.2 Replacing the joystick protection
Continued


	Action	Note/Illustration
2	Refit the joystick protection.	 xx1800001200
3	Secure the screws.	 xx1800001206 Countersunk head screw: ST2.9 X 10 (6 pcs)

5 Repair

5.4.3 Replacing the fasten strip

Location

The illustration shows the location of the fasten strip on the FlexPendant.



xx1900000771

Required spare parts



Note

The spare part numbers that are listed in the table can be out of date. See the latest spare parts of the OmniCore C30 via myABB Business Portal, www.abb.com/myABB.

Spare part	Article number	Note
Fasten strip	3HAC065419-001	

Replacing the fasten strip

	Action	Note/Illustration
1	Open the velcro on the fasten strip.	
2	Take the fasten strip out from the holes.	
3	Insert the new fasten strip into the holes one by one.	
4	Secure the velcro in a suitable length.	

6 Troubleshooting

6.1 Introduction to troubleshooting

Introduction

The product manual and the circuit diagram contains information that can be good when troubleshooting.

For OmniCore, all event logs from the software can be seen on the FlexPendant, or in *Technical reference manual - Event logs for RobotWare 7*.

Make sure to read through the section [Safety on page 15](#) before starting.

Troubleshooting strategies

- 1 Isolate the fault to pinpoint the cause of the problem from consequential problems.
- 2 Divide the fault chain in two.
- 3 Check communication parameters and cables.
- 4 Check that the software version is compatible with the hardware.

Work systematically

- 1 Take a look around to make sure that all screws, connectors, and cables are secured, and that the robot and other parts are clean, not damaged, and correctly fitted.
- 2 Replace one thing at a time.
- 3 Do not replace units randomly.
- 4 Make sure that there are no loose screws, turnings, or other unexpected parts remaining after work has been performed.
- 5 When the work is completed, verify that the safety functions are working as intended.

Keep a track of history

- Make a historical fault log to keep track of problems over time.
- Consult those working with the robot when the problem occurred.

Basic scenarios

What to look for during troubleshooting depends on when the fault occurred. Was the robot recently installed or was it recently repaired? The following table gives hints on what to look for in specific situations.

The robot has recently been installed	Check: <ul style="list-style-type: none">• the configuration files• connectors• options and their configuration• changes in the robot working space/movements.
---------------------------------------	---

Continues on next page

6 Troubleshooting

6.1 Introduction to troubleshooting

Continued

The robot has recently been repaired	Check: <ul style="list-style-type: none">• all connections to the replaced part• power supplies• that the correct part has been fitted• the last repair documents.
The robot recently had a software upgrade	Check: <ul style="list-style-type: none">• software versions• compatibilities between hardware and software• options and their configuration
The robot has recently been moved from one site to another (an already working robot)	Check: <ul style="list-style-type: none">• connections• software versions

6.2 Troubleshooting fault symptoms

Fault symptoms described in this manual

This manual describes how to troubleshoot the following fault symptoms:

- [*No LEDs are lit on the controller on page 502*](#)
- [*Start-up failure on page 507*](#)
- [*Problem releasing the robot brakes on page 512*](#)
- [*Problem starting or connecting the FlexPendant on page 517*](#)
- [*Problem using the joystick on page 522*](#)
- [*Controller fails to start on page 523*](#)
- [*Reflashing firmware failure on page 524*](#)
- [*Inconsistent path accuracy on page 525*](#)

Continues on next page

6 Troubleshooting

6.2.1 No LEDs are lit on the controller

6.2.1 No LEDs are lit on the controller

Description

No LEDs at all are lit in the controller.

Required test equipment

Equipment needed for troubleshooting:

Equipment	Note
Multimeter	
Insulating gloves	

Preparations


	Action
1	Make sure that the controller is switched on. Wait 30 s - 1 min to enable start-up sequence.
2	Check the FlexPendant for errors and warnings.
	<p>DANGER</p> <p>Troubleshooting on the controller while powered on must be performed by personnel trained by ABB or by ABB field engineers.</p>

Recommended working procedure

If no LEDs are lit on the controller during start-up, use this procedure to troubleshoot what might cause the problem.

Look at the following block diagram to understand how power is connected from incoming and forward.

Block diagram




xx1800001828

Continues on next page

6.2.1 No LEDs are lit on the controller

Continued

This below diagram is used for CRB 15000 controller.



xx2100000459



Note

The AC LED shows status of AC input and DC power. It should be lit when the controller is supplied with power, but will go out 15 minutes after the power is switched off.


Continues on next page

6 Troubleshooting

6.2.1 No LEDs are lit on the controller

Continued


Troubleshooting flowchart



xx1800001827

Continues on next page

Detailed working procedure

	Action	Note
1	Make sure that the power inlet switch (Q0) has been switched on.	 xx1800001306
2	If (c) is switched on, but the lamp is not lit, switch off the power and measure the voltage on X0.	Use a multimeter and insulating gloves. If there is no voltage, the cable is broken.
3	Make sure that the system is supplied with power. <ul style="list-style-type: none"> • Make sure that the RCD and circuit breaker/fuse (if used) are closed. • Measure incoming mains voltage and make sure the voltage is within the normal range. 	Use a multimeter and insulating gloves. If incoming mains is not ok, the problem is not in the robot controller. Troubleshoot incoming mains.
4	Check that the mains connection (X0) is properly connected.  Tip For more details, see <i>Circuit diagram - OmniCore C30</i> , <i>Circuit diagram - OmniCore C30 for IRB 14050</i> , <i>Circuit diagram - OmniCore C30 for CRB 15000</i> .	
5	Check that the AC input cable is properly connected.	
6	Check the output voltage of (Q0). <ul style="list-style-type: none"> • Make sure that (Q0) is closed. 	Use a multimeter and insulating gloves. Replace if damaged, see <i>Replacing the incoming mains connector on page 434</i> .
7	Confirm that the controller is for CRB 15000 or not.	<ul style="list-style-type: none"> • If the controller is for CRB 15000, troubleshoot the power unit. See <i>Troubleshooting the power unit on page 532</i>. • If the controller is not for CRB 15000, proceed with next step.

Continues on next page

6 Troubleshooting

6.2.1 No LEDs are lit on the controller

Continued

	Action	Note
8	Check connector T2.X1.	<ul style="list-style-type: none">• If abnormal, troubleshoot the power unit. See <i>Troubleshooting the power unit on page 532</i>.• If normal, troubleshoot the power supply unit. See <i>Troubleshooting the power supply on page 550</i>.

6.2.2 Start-up failure

Description

The following are possible symptoms of a start-up failure:

- 1 The LEDs are not lit on some units.
- 2 Unable to load the system software.

Required test equipment

Equipment needed for troubleshooting:

Equipment	Note
Multimeter	
Insulating gloves	
Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000	3HAC059896-009, 3HAC063898-009, 3HAC072448-009

Preparations


Action
1 Make sure that the controller is switched on. Wait 30 s - 1 min to enable start-up sequence.
2 Check the FlexPendant for errors and warnings.
 DANGER Troubleshooting on the controller while powered on must be performed by personnel trained by ABB or by ABB field engineers.

Recommended working procedure

If there seems to be a power failure during start-up, use this procedure to troubleshoot what might cause the problem.

Block diagram

Look at the following block diagram to understand how power is connected from incoming and forward.



xx1800001828


Continues on next page

6 Troubleshooting

6.2.2 Start-up failure

Continued

This below diagram is used for CRB 15000 controller.




xx2100000459



Note

The AC LED shows status of AC input and DC power. It should be lit when the controller is supplied with power, but will go out 15 minutes after the power is switched off.



Troubleshooting flowchart




xx1800001829

Continues on next page

Location of LEDs



xx1700001886



xx1800001307

Detailed working procedure

	Action	Note
1	Look at the LED AC.	<p>LED AC should be green.</p> <ul style="list-style-type: none"> If not, see Troubleshooting the power unit on page 532. If the power unit is ok, check that incoming mains is well connected and that the incoming mains switch is turned on.

Continues on next page

6 Troubleshooting

6.2.2 Start-up failure

Continued

	Action	Note
2	Look at the LED PS.	<p>LED PS should be green.</p> <ul style="list-style-type: none">• If not, see Troubleshooting the power supply on page 550.• If the power supply is ok, see Troubleshooting the power unit on page 532.• If the power unit is ok, check that the power inlet is properly connected and the power inlet switch is turned on. <p>For more details about the LEDs, see Troubleshooting the robot signal exchange proxy on page 555.</p>
3	Look at the LED MS.	<p>LED MS should be green.</p> <ul style="list-style-type: none">• If not, see Troubleshooting the robot signal exchange proxy on page 555.
4	Look at the LEDs PC and HMI.	<p>LED PC and LED HMI should be green.</p> <ul style="list-style-type: none">• If not, see Troubleshooting the robot signal exchange proxy on page 555
5	Look at the LEDs PC PWR, PC HDD, and PC STAT.	<p>For more details about the LEDs, see Troubleshooting the main computer on page 547.</p>
6	If the problem remains, contact ABB.	



Tip

For more details, see [Circuit diagram - OmniCore C30](#), [Circuit diagram - OmniCore C30 for IRB 14050](#), [Circuit diagram - OmniCore C30 for CRB 15000](#).

6.2.3 System update failure

Description

In certain scenarios, such as removing or adding certain optional features or major upgrades of installed software products versions, the previous backup may be incompatible with the newly re-configured system. Automatically reloading backup can therefore fail, resulting in system failure state after the update.

For more information about system update, see *Operating manual - Integrator's guide OmniCore*.

Recommended working procedure

To remove system failure resulting from system updates, there are two main strategies:

- A Go forward with the new system configuration and correct the errors, see [New system configuration on page 511](#).
- B Rollback all changes in the system and bring the system to the same state as it was before the update, see [Rollback all changes in the system on page 511](#).

New system configuration

- 1 Reset the RobotWare system.

The RAPID program and system parameters will be removed, and the system will be set to default state, but without system failure.

- 2 Re-implement your programs or configuration changes, or
- 3 Selectively load contents from the previous system backup and correct possible errors when loading.

Rollback all changes in the system

The previous system state can be restored through the RobotWare Installation Utilities in one of the following ways:

- 1 Restore all installed software, user and system internal data with a selected snapshot (backup copy) of the previous system state. This is the simplest way.
- 2 Perform a complete re-installation of the RobotWare system using RobotWare Installation Utilities, start the RobotWare system and then reload the previous backup.

6 Troubleshooting

6.2.4 Problem releasing the robot brakes

Description

When starting robot operation or jogging the robot, the internal robot brakes must release in order to allow movement.



Note

This chapter is not available for CRB 15000 controller.

Required test equipment

Equipment needed for troubleshooting:

Equipment	Note
Multimeter	
Insulating gloves	
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009

Preparations

	Action
1	Make sure that the controller is switched on. Wait 30 s - 1 min to enable start-up sequence.
2	Check the FlexPendant for errors and warnings.
	 DANGER Troubleshooting on the controller while powered on must be performed by personnel trained by ABB or by ABB field engineers.


Recommended working procedure

If the brakes do not release, no robot movement is possible and a number of error log messages can occur. Use this procedure to troubleshoot what might cause the problem.

Continues on next page

Look at the following block diagram to understand how power is connected from incoming and forward.

Block diagram



xx1800001835


Continues on next page

6 Troubleshooting

6.2.4 Problem releasing the robot brakes

Continued



Troubleshooting flowchart



xx1800001836

Continues on next page

Detailed working procedure

	Action	Note
1	<p>Check that the floor cable is connected from the manipulator to the motor connector X1. Visually inspect the cable for damage or extensive bending marks.</p> <p> Tip</p> <p>For more details, see <i>Circuit diagram - OmniCore C30</i>, <i>Circuit diagram - OmniCore C30 for IRB 14050</i>, <i>Circuit diagram - OmniCore C30 for CRB 15000</i>.</p>	<ul style="list-style-type: none"> If the cable is damaged, replace to a new cable and go to step 8. If the cable is not connected, repair the connection and go to step 8. If the cable is ok, go to the next step.
2	<p>Look at the LED PS on the front of the robot signal exchange proxy. LED PS should be solid green.</p>   <p>xx1700001886</p>	<p>For more details about the LEDs, see Troubleshooting the robot signal exchange proxy on page 555.</p> <ul style="list-style-type: none"> If it is not green, see Troubleshooting the power supply on page 550.
3	<p>Look at the LED MS, LED PC and LED HMI. All LEDs should be solid green.</p>	<ul style="list-style-type: none"> If LED MS is not green, see Troubleshooting the robot signal exchange proxy on page 555. If LED PC or LED HMI are not green, see Troubleshooting the power supply on page 550. If the power supply is ok, see Troubleshooting the power unit on page 532. If the power unit is ok, check that incoming mains is connected and that the incoming mains switch is turned on. If the LED PC is green, but LED PC_PWR on the main computer is not green, see Troubleshooting the main computer on page 547. If the LED HMI is green, but the FlexPendant is not starting, see Troubleshooting the FlexPendant on page 529.

Continues on next page

6 Troubleshooting

6.2.4 Problem releasing the robot brakes

Continued

	Action	Note
4	<p>Measure the power on K2.X7.</p> <p> Tip</p> <p>For more details, see <i>Circuit diagram - OmniCore C30</i>, <i>Circuit diagram - OmniCore C30 for IRB 14050</i>, <i>Circuit diagram - OmniCore C30 for CRB 15000</i>.</p>	<p>Use a multimeter and insulating gloves.</p> <ul style="list-style-type: none">If there is no power, repair the connection and go to step 8.If it is ok, go to the next step.
5	<p>Check that the connection from the robot signal exchange proxy to the motor connector is ok:</p> <ul style="list-style-type: none">K2.X7 - X1.	<ul style="list-style-type: none">If it is not, repair the connection and go to step 8.If it is ok, go to the next step.
6	<p>Check that the connection from main computer to the robot signal exchange proxy is ok:</p> <ul style="list-style-type: none">K2.X6 - A1.X2	<ul style="list-style-type: none">If it is not, repair the connection and go to step 8.If it is ok, go to the next step.
7	Try jogging the robot.	<ul style="list-style-type: none">If it is not working properly, the brake release board on the manipulator might be broken. Contact your local ABB for more information.If the brakes work normally, troubleshoot the main computer, the robot signal exchange proxy, and the power unit, one by one. If needed, replace faulty units. Go to step 8.
8	Check that the brake release function is ok.	<p>For more details on how to release the brakes, see the robot's product manual.</p> <ul style="list-style-type: none">If it is not ok, contact your local ABB.

6.2.5 Problem starting or connecting the FlexPendant

Description

The FlexPendant is not responding, either completely or intermittently.


No entries are possible, and no functions are available.



Note

If protective gloves are used, these must be compatible with touchscreens when using the FlexPendant.

The FlexPendant starts but does not display the main interface.



Required test equipment

Equipment needed for troubleshooting:

Equipment	Note
Multimeter	
Insulating gloves	
Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000	3HAC059896-009, 3HAC063898-009, 3HAC072448-009

Preparations

	Action
1	Make sure that the controller is switched on. Wait 30 s - 1 min to enable start-up sequence.
2	Check the FlexPendant for errors and warnings.

Continues on next page

6 Troubleshooting

6.2.5 Problem starting or connecting the FlexPendant

Continued


Action
<p> DANGER Troubleshooting on the controller while powered on must be performed by personnel trained by ABB or by ABB field engineers.</p>

Recommended working procedure

If the FlexPendant starts but does not display the main interface during the start-up, use this procedure to troubleshoot what might cause the problem.

Look at the following block diagram to understand how power is connected from incoming and forward.


Block diagram



xx1800001830

Continues on next page

Troubleshooting flowchart



xx1800001831


Continues on next page

6 Troubleshooting

6.2.5 Problem starting or connecting the FlexPendant

Continued

Location of LEDs



Detailed working procedure

	Action	Note
1	Try resetting the FlexPendant using the reset button located next to the USB port.	See <i>Operating manual - OmniCore</i> .
2	Check that the FlexPendant cable is correctly connected to the controller through the HMI signal connector, X4.	If it is not connected, repair the connection and go to step six. Check the pins in the connector. If it is ok, go to the next step.
3	Check the LED PC and LED HMI, they should be green.	For more details about the LEDs, see Troubleshooting the robot signal exchange proxy on page 555 . <ul style="list-style-type: none">• If the LEDs are not green, see Troubleshooting the robot signal exchange proxy on page 555.• If they are ok, go to the next step.
4	Check the FlexPendant cable for any damage.	<ul style="list-style-type: none">• If damage is found, replace the FlexPendant cable and go to step six.• If it is ok, go to the next step.
5	Check that the connection from the robot signal exchange proxy to the HMI signal connector is ok, K2.X9, 13 - X4.	<ul style="list-style-type: none">• If it is not ok, repair the connection and go to step six.• If it is ok, go to the next step.

Continues on next page

6.2.5 Problem starting or connecting the FlexPendant *Continued*

Action	Note
6 Check that the connection from the robot signal exchange proxy to the main computer is ok: <ul style="list-style-type: none">• K2.X8 - A2.X6• K2.X2 - A2.X1• K2.X12 - A2.K3.X6,7• K2.X3 - A2.K3.X1	<ul style="list-style-type: none">• If any connection fails, repair the connection and go to step six.• If the connections are ok, go to the next step.
7 If possible, test by connecting another FlexPendant. This is to eliminate the FlexPendant and cable as error sources; Test the FlexPendant with a different controller to eliminate the controller as error source.	
8 Check that the FlexPendant works normally.  Tip This is detailed in section Troubleshooting the FlexPendant on page 529 .	If it is not ok, contact your local ABB.

6 Troubleshooting

6.2.6 Problem using the joystick

6.2.6 Problem using the joystick

Description

The FlexPendant is started and responds when you push the buttons or tap on the touchscreen. However, the joystick does not work and no warnings or messages show up. It is therefore not possible to jog the robot.

Recommended working procedure

	Action	Information
1	Make sure that the joystick lock is not activated.	See <i>Operating manual - OmniCore</i> .
2	Make sure the controller is in manual mode.	
3	Make sure the FlexPendant is connected correctly to the controller.	
4	Press the reset button located next to the USB port on the back of the FlexPendant.  Note The reset button only resets the FlexPendant, not the system on the controller.	If the joystick is still not working, then replace the FlexPendant.

6.2.7 Controller fails to start

Description

If the controller fails to start, the FlexPendant is not operational.

Function description

The robot controller always runs in one of the following two modes:

- Normal operation mode (a user-created system is selected to run)
- RobotWare Installation Utilities mode (advanced maintenance mode)

In rare occasions, a serious error (in the software or the configuration of the installed system), may prevent the controller from starting properly in the normal operation mode. A typical case is when a controller is restarted after a network configuration change, causing the controller to be non-responsive from FlexPendant, RobotStudio, or FTP. To restore the robot controller from this situation, the controller can be forced to start in RobotWare Installation Utilities mode.

Forcing startup of the RobotWare Installation Utilities mode

Repeat the following action two times in a row:

- 1 Turn on the main power switch.
- 2 Wait for approximately 15 seconds.



Note

The PC STAT LED should be in flashing red state.

- 3 Turn off the main power switch.

The installed system is de-selected and in the next startup, the RobotWare Installation Utilities mode is started.

This has no effect if the controller is already in RobotWare Installation Utilities mode.



Note

Force starting the RobotWare Installation Utilities mode will not affect the files in the directories belonging to the installed system.

See also [Troubleshooting the main computer on page 547](#).

How to install systems is described in *Operating manual - Integrator's guide OmniCore*.

6 Troubleshooting

6.2.8 Reflashing firmware failure

6.2.8 Reflashing firmware failure

Description

When reflashing firmware, the automatic process can fail which will stop the system. A message is generated in the event log.

This fault usually occurs due to a lack of compatibility between hardware and software.

Recommended working procedure

If the controller stops with a message about firmware failure, use this procedure to troubleshoot what might cause the problem.

	Action	Note
1	Read the message to see which unit has failed.	
2	If the relevant unit has been replaced recently, make sure that the versions of the old and the new unit are identical.	
3	Check the software versions.	
4	If RobotWare has been updated recently, make sure that the versions of the old and the new unit are identical.	
5	If the problem remains, contact your local ABB for information about which firmware version is compatible with your hardware.	

6.2.9 Inconsistent path accuracy

Description

The path of the robot TCP is not consistent. It varies from time to time, and is sometimes accompanied by noise emerging from bearings, gearboxes, or other locations.

Possible causes

The symptom can be caused by (the causes are listed in order of probability):

- Robot not calibrated correctly.
- Robot TCP not correctly defined.
- Parallel bar damaged (applies to robots fitted with parallel bars only).
- Mechanical joint between motor and gearbox damaged. This often causes noise to be emitted from the faulty motor.
- Bearings damaged or worn (especially if the path inconsistency is coupled with clicking or grinding noises from one or more bearings).
- The wrong robot type may be connected to the controller.
- The brakes may not be releasing correctly.

Recommended working procedure

The path accuracy depends on many factors. The following table describes the most common causes of problems with the path accuracy. Depending on your installation, the recommended working procedure is to work step by step, starting with the step that seems most plausible given your circumstances.

	Action	Note
1	Study the path of the robot in motion, to find if an external force, for example, an external cable package, is colliding with or restricting the movement of the robot.	Remove the obstacles.
2	In high temperature environments, the material in the robot can expand, thereby causing inconsistent path accuracy.	Improve the ventilation around the robot.
3	Make sure the robot tool and work object are correctly defined.	How to define these are described in <i>Operating manual - OmniCore</i> .
4	Check the positions of the revolution counters.	Update if required.
5	If required, re-calibrate the robot axes.	How to calibrate the robot is described in the product manual for the robot.
6	If you hear noise that has not been there before, locate the source to define if a motor or bearing is faulty. Study the path of the robot TCP to establish which axis, and thus which motor, may be faulty.	Replace the faulty motor, gearbox, or bearing as specified in the product manual for the robot.
7	Check the trueness of the parallel bar (applies to robots fitted with parallel bars only).	Replace the faulty parallel bar as specified in the product manual for the robot.

Continues on next page

6 Troubleshooting

6.2.9 Inconsistent path accuracy

Continued

	Action	Note
8	Make sure the correct robot type is connected as specified in the system.	Update the system with the correct robot type, see <i>Operating manual - Integrator's guide OmniCore</i> .
9	Make sure the robot brakes work properly.	Proceed as detailed in section Problem releasing the robot brakes on page 512 .
10	If applicable: Check the setting for the swivel.	The swivel has an in-built resistance that needs to be set in the system parameters.

6.2.10 Controller is overheated

Required test equipment

Equipment needed for troubleshooting:

Equipment	Note
Multimeter	
Insulating gloves	
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009

Preparations

	Action
1	Make sure that the controller is switched on. Wait 30 s - 1 min to enable start-up sequence.
2	Check the FlexPendant for errors and warnings.
	 DANGER Troubleshooting on the controller while powered on must be performed by personnel trained by ABB or by ABB field engineers.

Recommended working procedure

If the controller seems to be overheated, use this procedure to troubleshoot what might cause the problem.

Detailed working procedure

	Action	Note
1	Check that the standard fans are working.	Replace malfunctioning fans, see Replacing the standard fan on page 239
2	If the problem remains, troubleshoot the power unit and/or the drive unit.	See Troubleshooting the power unit on page 532 and Troubleshooting the drive unit on page 530 .

6 Troubleshooting

6.3.1 Troubleshooting LEDs in the controller

6.3 Troubleshooting units

6.3.1 Troubleshooting LEDs in the controller

Description

The controller features a number of indication LEDs, which provide important information for troubleshooting purposes. If no LEDs light up at all when switching the system on, troubleshoot as detailed in this section.

All LEDs on the respective units, and their significance, are described in the following sections.

Units with LEDs in the controller

Drive unit ⁵⁶	Troubleshooting the drive unit on page 530
Power unit	Troubleshooting the power unit on page 532
Scalable I/O	Troubleshooting fieldbuses and I/O on page 537
ABB Ability™ Connected Services	Troubleshooting the connected services gateway on page 538
Ethernet switch	Troubleshooting the Ethernet switch on page 543
Axis computer ⁵⁶	Troubleshooting the axis computer on page 545
Main computer	Troubleshooting the main computer on page 547
Power supply ⁵⁶	Troubleshooting the power supply on page 550
Robot signal exchange proxy	Troubleshooting the robot signal exchange proxy on page 555

⁵⁶ Not available for CRB 15000 controller.

6.3.2 Troubleshooting the FlexPendant

Description

The FlexPendant communicates with the main computer. The FlexPendant is physically connected to the panel board. The cable contains the +24 V supply, two enabling device chains and emergency stop.

Procedure

The procedure below describes what to do if the FlexPendant does not work correctly.

	Action	Note
1	Try resetting the FlexPendant using the reset button located next to the USB port.	See <i>Operating manual - OmniCore</i> .
2	If the FlexPendant is not responding or does not operate correctly, see Problem starting or connecting the FlexPendant on page 517 .	 Note If protective gloves are used, these must be compatible with touchscreens when using the FlexPendant.
3	Check the cable for connections and integrity.	
4	Check the 24 V power supply.	
5	Read the error event log message and follow any instructions of references.	

For more information on the FlexPendant, see *Operating manual - OmniCore*.


6 Troubleshooting

6.3.3 Troubleshooting the drive unit

6.3.3 Troubleshooting the drive unit

Location

The illustration shows the location of the drive unit in the controller.




xx1800000036

LEDs


The illustration below shows the indication LEDs on the drive unit.

OmniCore C30



xx1800000575

OmniCore C30 for IRB 14050



xx1800001849

A	Ethernet LEDs (yellow)
B	Ethernet LEDs (green)
C	Status LED

Continues on next page

6.3.3 Troubleshooting the drive unit *Continued*

Description	Significance
Ethernet LEDs	<p>Shows the status of Ethernet communication between the drive unit and the power unit.</p> <p>Green:</p> <ul style="list-style-type: none">• Off: 10 Mbps data rate is selected.• On: 100 Mbps data rate is selected. <p>Yellow:</p> <ul style="list-style-type: none">• Flashing: The two units are communicating on the Ethernet channel.• Steady: A LAN link is established.• Off: A LAN link is <i>not</i> established.
Drive unit status LED	<p>The status indicator LED can be used to identify the following status during startup/power on:</p> <ol style="list-style-type: none">1 Red, steady: Default when power is available.2 Red, flashing: Power is on, self-test is ongoing, operating system is loading.3 Green, flashing: Application is loaded and waiting for communication.4 Green, steady: Drive unit is operational. <p>If the LED does not turn steady green after 30-60 sec, the status indicator LED can be used to identify the following issues:</p> <ul style="list-style-type: none">• No color: Power to the drive unit is missing.• Red, steady: Internal error.• Red, flashing: Firmware error or self-test failure.• Green, flashing: Communication error to another module.


6 Troubleshooting

6.3.4 Troubleshooting the power unit

6.3.4 Troubleshooting the power unit

Location

The illustration below shows the location of the power unit in the controller.




xx1800000034

LEDs


The illustration below shows the LEDs on the power unit.

OmniCore C30




xx18000000576

OmniCore C30 for IRB 14050



xx1800001850

OmniCore C30 for CRB 15000



xx2100000460

A	Ethernet LEDs (yellow)
B	Ethernet LEDs (green)
C	Status LED

Continues on next page

Description	
Power unit status LED	<p>The status indicator LED can be used to identify the following status during startup/power on:</p> <ul style="list-style-type: none">1 Red, steady: Default when power is available.2 Red, flashing: Power is on, self-test is ongoing, operating system is loading.3 Green, flashing⁵⁷: Application is loaded and waiting for communication.4 Green, steady: Power unit is operational. <p>If the LED does not turn steady green after 30-60sec, then the status indicator LED can be used to identify the following issues:</p> <ul style="list-style-type: none">• No color: Power to the power unit is missing.• Red, steady: Internal error.• Red, flashing: Firmware error or self-test failure.• Green, flashing⁵⁷: Communication error to another module.



Note

When troubleshooting the power unit for an CRB 15000 controller, there is only two status:

- Red, the power unit is broken. Replace it.
- Green, the power unit is ok.

Required test equipment

Equipment needed for troubleshooting:

Equipment	Note
Multimeter	
Insulating gloves	
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009

Preparations

	Action
1	Check the FlexPendant for errors and warnings.
2	Power the controller off. Wait one minute, power the controller on.
3	Wait 30-60 seconds after power-on. Make sure that the control system power is in run-time mode.

⁵⁷ Not available for CRB 15000 controller.


Continues on next page

6 Troubleshooting

6.3.4 Troubleshooting the power unit

Continued

Troubleshooting flowchart



xx1800002357

Troubleshooting procedure

The troubleshooting table is supposed to be used as a detailed instruction together with the troubleshooting flowchart.


	Action	Note
1	<p>Check the connections between connectors Q1, Q2⁵⁸ & X2.</p> <p>Tip</p> <p>For more details, see <i>Circuit diagram - OmniCore C30</i>, <i>Circuit diagram - OmniCore C30 for IRB 14050</i>, <i>Circuit diagram - OmniCore C30 for CRB 15000</i>.</p>	<p>Open the top cover of the controller and check the connections between connectors Q1, Q2 & adapter X2.</p> <p>How to open the controller is described in Opening the robot controller on page 222.</p> <ul style="list-style-type: none">If the connection is OK, proceed with step 2.If there is a problem with the connection, repair the connection and start over.

⁵⁸ The connectors Q1, Q2 are not available for the DSQC3028 power unit on IRB14050 controller. No need to check the connectors in IRB14050 controller.

Continues on next page

6.3.4 Troubleshooting the power unit

Continued

Action	Note
2 Power on the controller. Check the indicator LED MS on the power unit.	<p>Make sure that the controller power supply is in run-time mode.</p> <p>Wait at least 1 min after power-on.</p> <p>If the LED MS is:</p> <ul style="list-style-type: none"> • Green, proceed with step 8. • Flashing red/green: a firmware upgrade error has occurred. This is not supposed to happen during runtime mode, proceed with step 12. • Pulsing red: replace the power unit, step 12. • Not lit or red: The controller does not have sufficient DC input voltage. Proceed with step 3.
3 Measure the 24 V DC input voltage to the power unit. <ul style="list-style-type: none"> • X5 • X9 	<p>Use a multimeter and insulating gloves.</p> <p>The input voltage should be 24 V.</p> <p>Make sure that connectors X5, X9 are connected properly on both ends.</p> <ul style="list-style-type: none"> • If the 24 V DC input voltage is normal, proceed with step 8. • If the 24 V DC input voltage is abnormal, proceed with the next step.
4 Check connection to the robot signal exchange proxy. <ul style="list-style-type: none"> • A1.X9 (Power unit) - K2.X4 	<p>If the connection is OK, proceed with the next step.</p> <p>If there is a problem with the connection, repair the connection and go to step 2.</p>
5 Measure the AC output voltage.  xx1900000043	<p>Use a multimeter and insulating gloves.</p> <p>The output voltage should be 230 V/110 V.</p> <p>Make sure that connectors X6, X7 are connected properly on both ends.</p> <ul style="list-style-type: none"> • If the output voltage is normal, Troubleshooting the power supply on page 550, and then Troubleshooting the robot signal exchange proxy on page 555. • If the output voltage is abnormal, proceed with step 6.
6 Measure the AC input voltage. <ul style="list-style-type: none"> • A1.X1 - A1.K1 	<p>Use a multimeter and insulating gloves.</p> <p>The AC input voltage should be 230 V/110 V.</p> <p>Make sure that connector X1 is connected properly on both ends.</p> <ul style="list-style-type: none"> • If the input voltage is normal, proceed with step 12. • If the input voltage is abnormal, proceed with the next step.
7 Check the connection from the power inlet to the power unit.	<ul style="list-style-type: none"> • If the connection is OK, troubleshoot No LEDs are lit on the controller on page 502. • If there is a problem with the connection, repair the connection and start over.
8 Check the LEDs of the Ethernet ports X3, X12 on the power unit.	<ul style="list-style-type: none"> • If the LEDs are normal, proceed with step 10. • If the LEDs are abnormal, proceed with the next step.

Continues on next page

6 Troubleshooting

6.3.4 Troubleshooting the power unit

Continued

	Action	Note
9	Check the connection of the Ethernet cables.	<ul style="list-style-type: none">If the connection is OK, proceed with step 12.If there is a problem with the connection, repair the connection and go to step 8.
10	Measure the AC OK signal.	<p>Use a multimeter and insulating gloves. The AC OK should be 0 V.</p> <p>Make sure that connector X13 is connected properly on both ends.</p> <ul style="list-style-type: none">If the AC OK signal is 24 V, proceed with step 12.If the AC OK signal is 0 V, proceed with the next step.
11	Check event log if there is a message about DC-link voltage.	If message numbers 34401/34402, proceed with step 12 . If not, power unit is ok.
12	The power unit may be faulty, replace it and verify that the fault has been fixed.	How to replace the unit is detailed in Replacing the power unit on page 358 .

6.3.5 Troubleshooting fieldbuses and I/O

Further information


Information about how to troubleshoot the fieldbuses and I/O units can be found in the manual for the respective fieldbus or I/O unit. See [References on page 9](#).

6 Troubleshooting

6.3.6 Troubleshooting the connected services gateway


Location

The illustration shows the location of the connected services gateway in the controller.



LEDs for options 3G or WiFi

The illustration below shows the LEDs on the connected services gateway (3G or WiFi).



A	STATUS LED
B	LINK, 3G status or WiFi status LED
C	RF, signal strength status LEDs
D	Factory reset pin hole

Continues on next page

Description	Significance
STATUS LED (red/green)	<p>Startup sequence:</p> <ul style="list-style-type: none"> 1 Red continuously: Default at power up. 2 Red, flashing: Power on self-test ongoing, operating system is loading. 3 Green flashing: Loading application. 4 Green solid: Startup completed OK. <p>If the LED does not turn steady green after 30-60sec, it can be used to identify the following issues:</p> <p>Fault indication:</p> <ul style="list-style-type: none"> • No color: Power to the unit is missing. • Red, solid or flashing: Internal error. Replace the unit. • Green, flashing continuously: Communication error to another module, view error messages.
LINK	<p>For the connected services 3G, an orange LED indicator, externally visible on the front, indicates the status of the 3G connection.</p> <p>Orange:</p> <ul style="list-style-type: none"> • ON, flashing: 3G modem on, searching network. • ON, solid: 3G modem on and connected to network.
LINK	<p>For the connected services Wi-Fi, an orange LED indicator, externally visible on the front, indicates the status of the Wi-Fi connection.</p> <p>Orange:</p> <ul style="list-style-type: none"> • ON, flashing: Wi-Fi transceiver on, searching network. • ON, solid: Wi-Fi transceiver on and connected to network.
RF, signal strength status LEDs	<p>Three (3) LEDs indicating the Wi-Fi or 3G signal level.</p> <ul style="list-style-type: none"> • ON: The unit is connected to the network and working ok. • OFF: Problem with connector, antenna, or sim card.

Required test equipment

Equipment needed for troubleshooting:

Equipment	Note
Multimeter	
Insulating gloves	

Preparations

	Action
1	Check the FlexPendant for errors and warnings.
2	Power the controller off. Wait one minute, power the controller on.
3	<p>Wait 30-60 seconds after power-on. Make sure that the control system power is in run-time mode.</p>


Continues on next page

6 Troubleshooting

6.3.6 Troubleshooting the connected services gateway

Continued

Troubleshooting flowchart for options 3G or WiFi



xx1900000139

Continues on next page

Troubleshooting procedure for options 3G or WiFi

The troubleshooting table is supposed to be used as a detailed instruction together with the troubleshooting flowchart.

	Action	Note
1	Check the STATUS LED on the Connected Services Gateway.	If the LED is: <ul style="list-style-type: none">• Red/green, flashing: An internal error has occurred, proceed with step 11.• OFF, the unit is faulty, or it does not have sufficient input voltage, or the connection of the connector X2 is not ok. Proceed with step 3.
2	Check the LINK LED on the Connected Services Gateway.	If the LED is: <ul style="list-style-type: none">• OFF, the unit is faulty, or it does not have sufficient input voltage, or the connection of the connector X2 is not ok. Proceed with step 3.• Flashing: An internal error has occurred, proceed with step 11.
3	Measure the input voltage to the Connected Services Gateway.	Use a multimeter and insulating gloves. The input voltage should be 24 V. Make sure that connector X1 is connected properly on both ends. <ul style="list-style-type: none">• If the input voltage is normal, proceed with step 4.• If the input voltage is abnormal, Troubleshooting the robot signal exchange proxy on page 555.
4	Check that the connector X2 is well connected and the network connection properties are available.	Make sure that connector X2 is connected properly on both ends. <ul style="list-style-type: none">• If the connection is OK, proceed with step 5.• If there is a problem with the connection, repair the connection and go back to step 1.
5	Check the indicator RF LEDs on the Connected Services Gateway.	If the RF LEDs are: <ul style="list-style-type: none">• ON, the Connected Services Gateway is connected to network and works well.• OFF, the Connected Services Gateway is faulty or the connection of the connector X3 is not ok. Proceed with step 6.



Tip

For more details, see [Circuit diagram - OmniCore C30](#), [Circuit diagram - OmniCore C30 for IRB 14050](#), [Circuit diagram - OmniCore C30 for CRB 15000](#).

Continues on next page

6 Troubleshooting

6.3.6 Troubleshooting the connected services gateway

Continued

	Action	Note
6	Check that the connector X3 is well connected.	<p>Make sure that connector X3 is connected properly on both ends.</p> <ul style="list-style-type: none">If the connection is OK, proceed with step 7.If there is a problem with the connection, repair the connection and go back to step 5.
7	Check that the right type of the antenna is connected properly.  Tip Try moving the antenna to different locations if the RF signal level is low.	<ul style="list-style-type: none">If the antenna is not working, repair the connection or move the antenna to a location with better RF signal.If the antenna is ok, proceed with step 11.
8	On the FlexPendant, check the connection log in Backup and Restore .	<p>Verify that the configuration is done correctly.</p> <p>Verify that the mobile operator is detected (for 3G).</p>
9	For 3G, use a cell phone to test that the sim card is working. For WiFi, use a cell phone to verify the WiFi access.  Note When testing with a cell phone, use the same configuration on the cell phone.	See the Connected Services Gateway configuration in <i>Operating manual - Integrator's guide OmniCore</i> .
10	For 3G and WiFi, check the antenna connectivity.	
11	The Connected Services Gateway may be faulty, replace it and verify that the problem is resolved.	How to replace the unit is described in Replacing the connected services gateway on page 299 .

Related information


All documents can be found via myABB Business Portal, www.abb.com/myABB.

The approval code CMIIT ID is finally displayed on the nameplate of the product.

6.3.7 Troubleshooting the Ethernet switch

Location


The illustration shows the location of the Ethernet switch in the controller.



xx1800000821

LEDs

The illustration below shows the indication LEDs on the Ethernet switch.



xx1800000584

A	Status LED
---	------------

Continues on next page

6 Troubleshooting

6.3.7 Troubleshooting the Ethernet switch


Continued

Description	Significance
Status LED	<p>Startup sequence:</p> <ul style="list-style-type: none">1 No color: Input voltage is outside specified voltage or internal fault in the switch.2 Green, solid: The switch is operational. <p>If the LED does not turn steady green, the status indicator LED can be used to identify the following issues:</p> <p>Fault indication:</p> <ul style="list-style-type: none">• No color: If input voltage is within specified voltage limits and the LED is not lit then replace the switch.
Ethernet LEDs	<p>Shows the status of Ethernet links.</p> <p>Green:</p> <ul style="list-style-type: none">• Off:10 Mbps data rate is selected.• On:100/1000 Mbps data rate is selected. <p>Yellow:</p> <ul style="list-style-type: none">• Flashing: The Ethernet is active on link.• Solid: A LAN link is established.• Off: A LAN link is <i>not</i> established.

6.3.8 Troubleshooting the axis computer

Location


The illustration shows the location of the axis computer in the controller.



xx1700001890

LEDs

The illustration below shows the LEDs on the axis computer.



xx1800000581

A	Ethernet LED (yellow)
B	Ethernet LED (green)
C	Status LED

Continues on next page

6 Troubleshooting

6.3.8 Troubleshooting the axis computer


Continued

Description	Significance
Axis computer status LED	<p>Normal sequence during startup:</p> <ul style="list-style-type: none">1 Red, solid: Default at power-up.2 Red, flashing: Establish connection to main computer and load program to axis computer.3 Green, flashing: Start-up of axis computer program and connect peripheral units.4 Green, solid: Start-up sequence ready. Application is running. <p>The following indicates errors:</p> <ul style="list-style-type: none">• No color: No power to axis computer or internal error (hardware/firmware).• Red, solid: The axis computer has failed to initialize basic hardware.• Red, flashing continuously: Missing connection to main computer, main computer start-up problem or RobotWare installation problem.• Green, flashing continuously: Missing connections to peripheral units or RobotWare start-up problem.
Ethernet LED	<p>Shows the status of Ethernet communication.</p> <p>Green:</p> <ul style="list-style-type: none">• Off: 10 Mbps data rate is selected.• On: 100 Mbps data rate is selected. <p>Yellow:</p> <ul style="list-style-type: none">• Flashing: The two units are communicating on the Ethernet channel.• Solid: A LAN link is established.• Off: A LAN link is <i>not</i> established.

6.3.9 Troubleshooting the main computer

Location


The illustration shows the location of the main computer in the controller.



xx1800000033

LEDs

The illustration below shows the LEDs on the main computer:



xx1800000585

A	Power status LED
B	HDD status LED
C	Status LED

Continues on next page

6 Troubleshooting

6.3.9 Troubleshooting the main computer

Continued

Description	Significance
Power status, PC PWR (green)	<p>The power status LED indicates the status of the power supply and the main computer hardware and firmware.</p> <p>Normal behavior:</p> <ul style="list-style-type: none">Off: During a normal startup the LED is off, until the COM Express module inside the computer unit is started.On solid: After completion of startup the LED is steady on. <p>After start-up phase (30-60 seconds):</p> <ul style="list-style-type: none">Off: Power input voltage is not in normal range. <p>Failure during startup (off between blinks). One to four short blinks, one second off. This is repeated until power off.</p> <ul style="list-style-type: none">Internal fail of power, FPGA, and/or the COM Express module.Replace the computer unit. <p>Power failure during runtime (fast flashing between blinks). One to five blinks, 20 fast flashing blinks. This is repeated until power off.</p> <ul style="list-style-type: none">Temporary voltage drop, cycle the power to the controller.Check the power supply voltage to the computer unit.Replace the computer unit.
Disk status, PC HDD	<p>The disk status LED indicates access to the main computer persistent memory.</p> <p>Normal behavior:</p> <ul style="list-style-type: none">No color at power on: R34 FPGA is loaded on the main board.Yellow: Access (read/write) to internal mass memory.
Computer status, PC STAT (red/green)	<p>The computer status LED indicates the startup progress of RobotWare on the main computer.</p> <p>Normal behavior:</p> <ol style="list-style-type: none">Red, solid: Default when turning on the power.Red, flashing: Initial self-test is ongoing and the operating system is loading.Green, even flashing (~1Hz): The operating system is loaded and RobotWare is initializing.Green, uneven flashing: The RobotWare system failed to load or is not installed.Green, solid: The computer is operational and the RobotWare system is fully loaded. <p>If the LED does not turn steady green after approximately 5 minutes then the LED can be used to identify the following issues:</p> <ul style="list-style-type: none">No color: The internal power initialization failed. Restart the controller. Replace the main computer if the problem remains.Red, solid: Internal error. Restart the controller. Replace the main computer if the problem remains.Red, flashing continuously: Failed to load the operating system. Restart the controller. See Controller fails to start on page 523. Replace the main computer if the problem remains.Green, even flashing continuously (~1Hz): Failure during start up. Check error messages on FlexPendant. See Controller fails to start on page 523.Green, uneven flashing: RobotWare Installation Utilities mode.

Troubleshooting procedure

	Action	Note
1	If the LEDs do not turn steady after approximately 5 minutes then restart the controller and check the LEDs again.	See LEDs on page 547 .

Continues on next page


	Action	Note
2	Force start the RobotWare Installation Utilities mode, see Controller fails to start on page 523 .	
3	Re-install RobotWare, if possible.	
4	The main computer may be faulty, replace it and verify that the fault has been fixed.	See Replacing the main computer on page 318 .

6 Troubleshooting

6.3.10 Troubleshooting the power supply

Location

The illustration below shows the location of the system power supply in the controller.




xx180000035

A	Power supply baseline
B	Power supply optional

Continues on next page

LEDs

The illustration below shows the LEDs on the power supply.



xx1800000582

A	DC OK LED
Description	Significance
DC OK LED	Green: All DC outputs are above the specified minimum levels. Off: One or more DC outputs are below the specified minimum level.

Required test equipment

Equipment needed for troubleshooting.

Equipment	Note
Multimeter	
Insulating gloves	
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009

Preparations

Action
1 Check the FlexPendant for errors and warnings.
2 Power the controller off. Wait one minute, power the controller on.
3 Wait 30-60 seconds after power-on. Make sure that the control system power is in run-time mode.


Continues on next page

6 Troubleshooting

6.3.10 Troubleshooting the power supply

Continued

Troubleshooting flowchart



xx1800001823

Troubleshooting procedure

The troubleshooting table is supposed to be used as a detailed instruction together with the troubleshooting flowchart.

	Test	Note
1	Check the LED (labelled DC OK) on the power supply.	If the LED is: <ul style="list-style-type: none">• Green: the power supply should be working properly.• Off: either the power supply is faulty or it does not have sufficient input voltage. Proceed with step 2.

Continues on next page

6.3.10 Troubleshooting the power supply

Continued

	Test	Note
2	Measure the DC voltage while the output is connected to the robot signal exchange proxy or some other load.	<p>Use a multimeter and insulating gloves.</p> <p>Measure at the DC output connector X2. The voltage should be: $+24 \text{ V} < U < +27 \text{ V}$.</p> <ul style="list-style-type: none"> If the voltage measured at the load falls below $+24 \text{ V}$, voltage drops in the cables and connectors. If the correct voltage is detected and the DC OK LED is green, the power supply is working properly. If the correct voltage is detected and the DC OK LED is off, the power supply is regarded as faulty but does not have to be replaced instantly. If the DC OK voltage is higher than 27 V, proceed with step 10. If the DC OK voltage is below 24 V, proceed with step 3.
3	Power the controller OFF and measure the resistance.	Use a multimeter and insulating gloves.
4	<p>Check for short circuit on DC output.</p> <p>Check both the DC output connector X2 on the power supply and the input connector X1 on the robot signal exchange proxy.</p>	<p>Measure the resistance between voltage pins and ground. The resistance should not be less than 10 ohm.</p> <p> Note</p> <p>Do not measure the resistance between pins. Dual pins are used for both power supply and ground.</p> <ul style="list-style-type: none"> If no short circuit is found, proceed with step 6. If a short circuit is found on the power supply, proceed with step 10. If a short circuit is found on the robot signal exchange proxy, get that unit working. Verify that the fault has been fixed and restart this guide if necessary.
5	Switch on power to the controller.	
6	Measure the input voltage on the power supply.	<p>Use a multimeter and insulating gloves.</p> <p>Voltage should be: $172 \text{ V} < U < 276 \text{ V}$ for a 230 V system.</p> <ul style="list-style-type: none"> If the input voltage is correct, proceed with step 10. If no or the wrong input voltage is detected, proceed with step 7.
7	Make sure that the connection between the power supply and the power unit is ok.	<ul style="list-style-type: none"> If the connection is OK, proceed with step 8. If the connection is faulty, repair the connection. Verify that the fault has been fixed and restart this guide if necessary.
8	Make sure that the supplied input voltage to the controller is correct.	<ul style="list-style-type: none"> If the input voltage is correct, proceed with step 9. If the input voltage is faulty, correct it. Verify that the fault has been fixed and restart this guide if necessary.

Continues on next page

6 Troubleshooting

6.3.10 Troubleshooting the power supply


Continued

Test	Note
9	<p>Check the cabling.</p> <p>Make sure that the cabling is correctly connected and not faulty.</p> <ul style="list-style-type: none">If the cabling is OK, see Troubleshooting the power unit on page 532. Verify that the fault has been fixed and restart this guide if necessary.If the cabling is found unconnected or faulty, connect/replace it. Verify that the fault has been fixed and restart this guide if necessary.
10	<p>The power supply may be faulty, replace it and verify that the fault has been fixed.</p>

6.3.11 Troubleshooting the robot signal exchange proxy

Location

The illustration below shows the location of the robot signal exchange proxy in the controller.



xx1800000028

Continues on next page


6 Troubleshooting

6.3.11 Troubleshooting the robot signal exchange proxy

Continued

LEDs

The illustration below shows the LEDs on the robot signal exchange proxy:



xx1700001886

	Description	Significance
MS	<p>Status LED (bi-colored green/red) for the robot signal exchange proxy.</p> <p>Note</p> <p>The status LED light stays on for a long time after power to the controller is gone. This is due to the capacitors in the robot signal exchange proxy.</p>	<p>The status indicator LED can be used to identify the following status during startup/power on:</p> <ul style="list-style-type: none">Red, solid: Default when power is available.Red, flashing: Power on self-test ongoing, operating system is loading.Green, flashing: Application is loaded and waiting for communication.Green, solid: Module is operational. <p>If the LED does not turn steady green after 30-60 sec, the status LED can be used to identify the following issues:</p> <ul style="list-style-type: none">No color: Power to the robot signal exchange proxy is missing.Red, solid: Internal error.Red, flashing: Firmware error or self-test failure.Green, flashing: Communication error to another module.

Continues on next page

6 Troubleshooting

6.3.11 Troubleshooting the robot signal exchange proxy

Continued

	Description	Significance
AS1/GS1 & AS2/GS2	Automatic Stop/General Stop LEDs (green) AS1/GS1 : Automatic Stop/General Stop LED channel 1 AS2/GS2 : Automatic Stop/General Stop LED channel 2	Automatic Stop/General Stop LED can be used to identify the following status: <ul style="list-style-type: none">• No color (not lit): Automatic Stop/General Stop input loop is open.• Green, solid: Automatic Stop/General Stop input loop is closed.
ES1 & ES2	External emergency stop LEDs (green) ES1 : External emergency stop LED channel 1 ES2 : External emergency stop LED channel 2	External emergency stop LED can be used to identify the following status: <ul style="list-style-type: none">• No color (not lit): External emergency stop input loop is open.• Green, solid: External emergency stop input loop is closed.
ES-OUT1 & ES-OUT2	Emergency stop output LEDs (green) ES1 : Emergency stop output LED channel 1 ES2 : Emergency stop output LED channel 2	Emergency stop output LED can be used to identify the following status: <ul style="list-style-type: none">• No color (not lit): Emergency stop output is in State 0 (0V) status.• Green, solid: Emergency stop output is in State 1 (24V) status.
MON	Motors_ON LED (white)	Motors_ON LED can be used to identify the following status: <ul style="list-style-type: none">• No color: Motors_ON function is off.• White, solid: Motors_ON function is on.• White, flashing: safety loop is open, for example after an emergency stop.
AC	ACOK LED (green)	ACOK LED can be used to identify the following status: <ul style="list-style-type: none">• No color: AC OK signal is de-active or logic power failure.• Green, solid: AC OK signal is active and logic power available.
PS	Internal power (24 V power supply) input LED (green)	Internal power input LED can be used to identify the following status: <ul style="list-style-type: none">• No color: Internal power input voltage is not in normal range.• Green, solid: Internal power input voltage is in normal range.
PC	Main computer power output LED (green)	Main computer power output LED can be used to identify the following status: <ul style="list-style-type: none">• No color: Main computer power output voltage is not in normal range.• Green, solid: Main computer power output voltage is in normal range.
HMI	FlexPendant power output LED (green)	FlexPendant power output LED can be used to identify the following status: <ul style="list-style-type: none">• No color: FlexPendant power output voltage is not in normal range.• Green, solid: FlexPendant power output voltage is in normal range.

Continues on next page

6 Troubleshooting

6.3.11 Troubleshooting the robot signal exchange proxy

Continued

	Description	Significance
EP	External power input LED (green)	External power input LED can be used to identify the following status: <ul style="list-style-type: none">• No color: External power input voltage is not in normal range.• Green, solid: External power input voltage is in normal range.

Required test equipment

Equipment needed for troubleshooting.


Equipment	Note
Multimeter	
Insulating gloves	
<i>Circuit diagram - OmniCore C30, Circuit diagram - OmniCore C30 for IRB 14050, Circuit diagram - OmniCore C30 for CRB 15000</i>	3HAC059896-009, 3HAC063898-009, 3HAC072448-009

Preparations

	Action
1	Check the FlexPendant for errors and warnings.
2	Power the controller off. Wait one minute, power the controller on.
3	Wait 30-60 seconds after power-on. Make sure that the control system power is in run-time mode.

Continues on next page

Troubleshooting flowchart



xx1800002356

Troubleshooting procedure

The troubleshooting table is supposed to be used as a detailed instruction together with the troubleshooting flowchart.

	Test	Action
1	Turn off power until all LEDs (except MS, which is solid red) are off. Then turn on power and wait 1 minute.	

Continues on next page

6 Troubleshooting

6.3.11 Troubleshooting the robot signal exchange proxy

Continued

	Test	Action
2	Check the indicator LED MS.	If the LED_MS is: <ul style="list-style-type: none">• Green, proceed with step 6.• Flashing red/green, a firmware upgrade error has occurred. This is not supposed to happen during runtime mode, proceed with step 11.• OFF, either the robot signal exchange proxy is faulty or it does not have sufficient input voltage. Proceed with step 3.
3	Measure the input voltage to the robot signal exchange proxy.  Tip For more details, see <i>Circuit diagram - OmniCore C30</i> , <i>Circuit diagram - OmniCore C30 for IRB 14050</i> , <i>Circuit diagram - OmniCore C30 for CRB 15000</i> .	Use a multimeter and insulating gloves. The input voltage should be 24 V. Make sure that connector X1 is connected properly on both ends. <ul style="list-style-type: none">• If the input voltage is normal, proceed with step 6.• If the input voltage is abnormal, proceed with step 4.
4	Confirm that the controller is for CRB 15000 or not.	<ul style="list-style-type: none">• If the controller is for CRB 15000, see Troubleshooting the power unit on page 532.• If the controller is not for CRB 15000, proceed with step 5.
5	Check connection to the power supply unit.	<ul style="list-style-type: none">• If the connection is OK, Troubleshooting the power supply on page 550.• If there is a problem with the connection, repair the connection and start over.
6	Measure the 24 V DC outputs voltage.	Use a multimeter and insulating gloves. The output voltage should be 24 V. Make sure that connectors X2, X3, X4, X5, X17 and X19 are connected properly on both ends. <ul style="list-style-type: none">• If the output voltage is normal, proceed with step 7.• If the output voltage is abnormal, proceed with step 11.
7	Check the indicator LEDs AS1, AS2, ES1, ES2.	The indicator LEDs are labelled AS1, AS2, ES1, ES2. If the LEDs LED_AS1, AS2, ES1, ES2 are: <ul style="list-style-type: none">• On (solid green), the robot signal exchange proxy works well.• Off, either the robot signal exchange proxy is faulty or it does not have sufficient input voltage. Proceed with step 8.
8	Check that the customer interface connectors are connected to X14 and X15.  Tip For more details, see <i>Circuit diagram - OmniCore C30</i> , <i>Circuit diagram - OmniCore C30 for IRB 14050</i> , <i>Circuit diagram - OmniCore C30 for CRB 15000</i> .	If the customer interface connectors are not properly connected to X14 and X15, the signals to and from the robot signal exchange proxy will be interpreted incorrectly. <ul style="list-style-type: none">• If the connection is OK, proceed with step 9.• If there is a problem with the connection, repair the connection and go to step 7.

Continues on next page

6.3.11 Troubleshooting the robot signal exchange proxy

Continued

	Test	Action
9	Check external safety accessories.	Use a multimeter and insulating gloves. Measure the continuity in the connector. If there is resistance, troubleshoot the external equipment.
10	Measure the AC OK signal.	Use a multimeter and insulating gloves. The AC OK should be 0 V. Make sure that connector X10 is connected properly on both ends. <ul style="list-style-type: none">• If the AC OK signal is 24 V, see Troubleshooting the power unit on page 532.• If the AC OK signal is 0 V, proceed with step 11.
11	The robot signal exchange proxy may be faulty, replace it and verify that the fault has been fixed.	How to replace the unit is detailed in Replacing the robot signal exchange proxy on page 282 .

This page is intentionally left blank

7 Decommissioning

7.1 Introduction to decommissioning

Introduction

This section contains information to consider when taking a product, robot or controller, out of operation.

It deals with how to handle potentially dangerous components and potentially hazardous materials.



Note

The decommissioning process shall be preceded by a risk assessment.

General

All used grease/oils and dead batteries **must** be disposed of in accordance with the current legislation of the country in which the robot and the control unit are installed.

If the robot or the control unit is partially or completely disposed of, the various parts **must** be grouped together according to their nature (which is all iron together and all plastic together), and disposed of accordingly. These parts **must** also be disposed of in accordance with the current legislation of the country in which the robot and control unit are installed.

Disposal of storage media

Before disposal of any storage equipment (anything from an SD card to a complete controller), make sure that all sensitive information has been deleted.



Tip

To remove all data from the OmniCore controller, use the **Delete user data** function (part of **Delete RobotWare system** function) in RobotWare. See *Operating manual - Integrator's guide OmniCore*.

7 Decommissioning

7.2 Environmental information


7.2 Environmental information

Introduction

ABB robots contain components in different materials. During decommissioning, all materials should be dismantled, recycled, or reused responsibly, according to the relevant laws and industrial standards. Robots or parts that can be reused or upcycled helps to reduce the usage of natural resources.

Symbol

The following symbol indicates that the product must not be disposed of as common garbage. Handle each product according to local regulations for the respective content (see table below).



xx1800000058

Materials used in the product

The table specifies some of the materials in the product and their respective use throughout the product.

Dispose components properly according to local regulations to prevent health or environmental hazards.

Material	Example application
Aluminium	Heat sinks on power supplies and drive units
Batteries, Lithium	Main computer
Brominated flame retardants	Electronics
Copper	Cables
Lead	Electronics
Plastic/rubber	Cables, connectors, etc.
Silicone	Power supply ⁱ
Steel	Cabinet structure, plates, screws, etc.

ⁱ Silicone can be used in the manufacturing of the module but is removed by design. However, there might be a small residue left on delivery.

Continues on next page

China RoHS symbol

The following symbol shows the information to hazardous substances and the environmental protection use period of OmniCore C30 according to "Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products (SJ/T 11364-2014) ".



xx1900000804

Orange symbol with a number in it: The product contains certain hazardous substances and can be used safely during its environmental protection use period (as indicated by the number in the center) which should enter into the recycling system after its environmental protection use period.



Note

This form and environmental protection use period label are based on the regulation in China. These are not necessary to be concerned in other countries.

This page is intentionally left blank

8 Reference information

8.1 Introduction

General

This chapter includes general information, complementing the more specific information in the different procedures in the manual.

8 Reference information

8.2 Applicable standards

8.2 Applicable standards

General

The product is compliant with ISO 10218-1:2011, *Robots for industrial environments - Safety requirements - Part 1 Robots*, and applicable parts in the normative references, as referred to from ISO 10218-1:2011. In case of deviation from ISO 10218-1:2011, these are listed in the declaration of incorporation. The declaration of incorporation is part of the delivery.

Robot standards

Standard	Description
ISO 9283	Manipulating industrial robots – Performance criteria and related test methods
ISO 9787	Robots and robotic devices – Coordinate systems and motion nomenclatures
ISO 9946	Manipulating industrial robots – Presentation of characteristics

Other standards used in design

Standard	Description
IEC 60204	Safety of machinery - Electrical equipment of machines - Part 1: General requirements, normative reference from ISO 10218-1
IEC 61000-6-2	Electromagnetic compatibility (EMC) – Part 6-2: Generic standards – Immunity standard for industrial environments
IEC 61000-6-4	Electromagnetic compatibility (EMC) – Part 6-4: Generic standards – Emission standard for industrial environments
ISO 13849-1:2006	Safety of machinery - Safety related parts of control systems - Part 1: General principles for design, normative reference from ISO 10218-1

Region specific standards and regulations

Standard	Description
ANSI/UL 1740	Safety standard for robots and robotic equipment
CAN/CSA Z 434-03	Industrial robots and robot Systems - General safety requirements
EN ISO 10218-1	Robots and robotic devices — Safety requirements for industrial robots — Part 1: Robots

8.3 Unit conversion

Converter table

Use the following table to convert units used in this manual.

Quantity	Units		
Length	1 m	3.28 ft.	39.37 in
Weight	1 kg	2.21 lb.	
Weight	1 g	0.035 ounces	
Pressure	1 bar	100 kPa	14.5 psi
Force	1 N	0.225 lbf	
Moment	1 Nm	0.738 lbf-ft	
Volume	1 L	0.264 US gal	

8 Reference information

8.4 Standard toolkit for controller

8.4 Standard toolkit for controller

General

All service (repair, maintenance and installation) instructions contain lists of tools required to perform the specified activity. All special tools, that is, all tools that are not considered as standard tools as defined below, are listed in their instructions respectively.

This way, the tools required are the sum of the standard toolkit and any tools listed in the instructions.

Standard toolkit for controller

Tool	Description
Screw driver, Torx	Tx10
Screw driver, Torx	Tx20
Screw driver, Torx	Tx25
Ball tipped screw driver, Torx	Tx25
Screw driver, flat blade	4 mm
Screw driver, flat blade	8 mm
Screw driver, flat blade	12 mm
Screw driver	Phillips-1
Box spanner	8 mm

Toolkit recommended for troubleshooting

Tool	Note
Normal shop tools	Contents as specified above.
Multimeter	-
Camera	To document problems or procedures

8.5 Screw joints

General

This section details how to tighten the various types of screw joints on the controller. The instructions and torque values are valid for screw joints comprised of metallic materials and do *not* apply to soft or brittle materials.

Tightening torque

Before tightening any screw, note the following:

- Determine whether a standard tightening torque or special torque is to be applied. The standard torques are specified in the tables below. Any special torques are specified in the Repair, Maintenance or Installation procedure description. Any special torque specified overrides the standard value.
- Use the *correct tightening torque* for each type of screw joint.
- Only use *correctly calibrated* torque keys.
- Always *tighten the joint by hand*, and never use pneumatic tools.
- Use the *correct tightening technique*, i.e. *do not jerk*. Tighten the screw in a slow, flowing motion.
- Maximum allowed total deviation from the specified value is 10%!

The table below specifies the recommended standard tightening torque for *oil-lubricated screws with slotted or cross-recess heads*.

Dimension	Tightening torque (Nm) Class 4.8, oil-lubricated
M2.5	0.25
M3	0.5
M4	1.2
M5	2.5
M6	5.0

8 Reference information

8.6 Weight specifications

8.6 Weight specifications

Definition

In all repair and maintenance instructions, weights of the components handled are sometimes specified. All components exceeding 22 kg (50 lbs) are highlighted in this way.

To avoid injury, ABB recommends the use of lifting equipment when handling components with a weight exceeding 22 kg.

Example

Below is an example of how a weight specification is presented:



CAUTION

The transformer weighs 55 kg! All lifting equipment used must be sized accordingly!

8.7 Lifting accessories and lifting instructions

General

Many repair and maintenance activities require different pieces of lifting accessories, which are specified in each procedure.

The use of each piece of lifting accessories is *not* detailed in the activity procedure, but in the instruction delivered with each piece of lifting accessories.

The instructions delivered with the lifting accessories should be stored for later reference.

This page is intentionally left blank

9 Spare parts

Spare part level

ABB spare parts are categorized into two levels, L1 and L2. Always check the part level before conducting a service work on a spare part.

- L1 spare parts

The L1 parts can be replaced in the field. The maintenance and replacement instructions given in the related product manuals must be strictly followed. If there are any problems, contact your local ABB for support.

- L2 spare parts

To replace the L2 parts require specialized training and might need special tools. Only ABB field service personnel or qualified personnel trained by ABB can replace L2 parts.

Continues on next page

9 Spare parts

9.1 Controller parts

9.1 Controller parts




Note

Removed parts and spare parts must not be disassembled or opened.

Baseline parts

The illustration below shows the placement of the controller system parts in the recommended spare part list.




xx1800000824

	Spare part number	Description	Type	Spare part level
A	3HAC058870-001	Harness TPU connection		L1
B	3HAC065107-001	Harness Short-circuit connector	Mating connector for robot signal exchange proxy.	L1
C	3HAC058827-001	Harness Power input single phase	Harness-Mains connection	L1

Continues on next page

	Spare part num-ber	Description	Type	Spare part level
D	3HAC064793-001	Connector AC power inlet, M22 PLUG	Mating connector for Power inlet	L1



xx1800000833

	Spare part num-ber	Description	Type	Spare part level
E	3HAC029157-001	Axis Computer	DSQC 668	L1
F	3HAC071301-001	Power supply	DSQC3035	L1


Continues on next page

9 Spare parts

9.1 Controller parts

Continued

	Spare part num-ber	Description	Type	Spare part level
G	3HAC064662-001	Signal exchange	DSQC3037	L1




xx1800000834

	Spare part num-ber	Description	Type	Spare part level
H	3HAC063061-001	Main computer module assembly		L1

Continues on next page

9.1.1 Controller system parts

Drive units



xx1800002901

	Spare part number	Description	Type	Spare part level
A	3HAC063913-001	Drive	DSQC3041	L1
B	3HAC063028-001	Drive for IRB14050 controller	DSQC3057	L1


Continues on next page

9 Spare parts

9.1.1 Controller system parts

Continued


Power units



xx1800002902

	Spare part number	Description	Type	Spare part level
A	3HAC059152-001	Power unit	DSQC3044	L1
B	3HAC059135-001	Power unit for IRB 14050 controller	DSQC3028	L1
C	3HAC072227-001	Power unit for CRB 15000 controller	DSQC3083	L1

Continues on next page

Harness motors power

xx1800002903


	Spare part num- ber	Description	Type	Spare part level
A	3HAC059527-001	Harness Motors power LV 6-axis		L1
B	3HAC065688-001	Harness Motors power ULV 7-axis	Only used for IRB 14050 controller.	L1
C	3HAC073522-001	Harness Motors power ULV	Only used for CRB 15000 controller.	L1

9 Spare parts

9.1.2 Logic parts

9.1.2 Logic parts


DeviceNet board



xx1800000827

	Spare part number	Description	Type	Spare part level
A	3HAC043383-001	DeviceNet Board (option)	DSQC1006	L1

Connected services gateway



xx1800000828

	Spare part number	Description	Type	Spare part level
A	3HAC060960-001	Connected Services-3G [3013-3] (baseline)		L1
B	3HAC028459-001	Magnetic roof antenna, 3G (baseline)		L1

Continues on next page


	Spare part number	Description	Type	Spare part level
C	3HAC060962-001	Connected Services-WiFi [3013-2] (option)		L1
D	3HAC059424-001	Magnetic roof antenna WiFi (option)		L1
E	3HAC061701-001	Connected Services-Wired [3013-1] (option)	DSQC1041	L1
-	3HAC066742-001	Sim card		L1

9 Spare parts

9.1.3 Application parts

9.1.3 Application parts


Ethernet switches



xx1800000829

	Spare part number	Description	Type	Spare part level
A	3HAC065126-001	Ethernet Extension unit slot cover (baseline)		L1
B	3HAC059187-001	Ethernet Extension switch [3014-1] (option)		L1


Power supply device



xx1800001146

Continues on next page

	Spare part number	Description	Type	Spare part level
A	3HAC071301-001	Power supply	DSQC3035	L1

Scalable I/O devices

xx1800000826

	Spare part number	Description	Type	Spare part level
A	3HAC065147-001	DSQC1030 Digital slot cover (baseline)		L1
B	3HAC058663-001	Scalable I/O Digital base [3032-1] (option) ⁱ		L1
C	3HAC060919-001	Connectors digital base/add on		L1
D	3HAC058664-001	Digital add-on [3033-2] (Add-on)	DSQC1031	L1
E	3HAC058665-001	Analog add-on [3034-2] (Add-on)	DSQC1032	L1
-	3HAC060925-001	Connectors I/O Analog (Add-on)		L1
F	3HAC058666-001	Relay add-on [3035-2] (Add-on)	DSQC1033	L1
-	3HAC060926-001	Connectors I/O Relay (Add-on)		L1

ⁱ Select 3HAC064092-001 when Scalable I/O Digital base [3032-1] is selected.


Continues on next page

9 Spare parts

9.1.3 Application parts

Continued

Safety digital base device




xx2100000990


	Spare part num- ber	Description	Type	Spare part level
-	3HAC062908-001	DSQC1042 Extended safety		L1
-	3HAC069538-001	Connectors Safety I/O		L1

9.1.4 Cabinet parts

Fans



xx2000002194



xx2100002181

	Spare part number	Description	Type	Spare part level
A	3HAC063917-001	Small fan		L1
B	3HAC059214-001	Standard fan		L1
C	3HAC077006-001	Small fan	Used for IRB 14050 and CRB 15000 controllers	L1

Continues on next page


9 Spare parts

9.1.4 Cabinet parts

Continued

	Spare part number	Description	Type	Spare part level
D	3HAC077005-001	Standard size silent fan unit	Used for IRB 14050 and CRB 15000 controllers	L1
-	3HAC060653-001	Fan with contact	Main computer fan	L1

Process, fieldbus and I/O connectors




xx1800000831

	Spare part number	Description	Type	Spare part level
A	3HAC063601-001	Harness DeviceNet/Harness 24V ext. cover plate (baseline)		L1
B	3HAC062150-001	Harness DeviceNet connection (option)	DSQC1004	L1
C	3HAC064901-001	Connector assembly Single-row female (option)	Mating CONN for IP20 DeviceNet connector	L1

9.1.5 Miscellaneous parts


Manipulator signal connectors (SMB)



xx1800000825

	Spare part number	Description	Type	Spare part level
A	3HAC068537-001	Harness Single SMB connection		L1
B	3HAC067490-001	Harness Double SMB connection (option)		L1

Customer flange interface (CFI)



xx2000002430

Continues on next page


9 Spare parts

9.1.5 Miscellaneous parts

Continued

	Spare part number	Description	Type	Spare part level
A	3HAC073523-001	Harness CFI connection	Only used for CRB 15000 controller.	L1

IP20 Power outlet connectors




xx1800000832

	Spare part number	Description	Type	Spare part level
A	3HAC063601-001	Harness DeviceNet/Harness 24V ext. cover plate (baseline)		L1
B	3HAC060965-001	Harness 24V_Process output (option)		L1
C	3HAC064743-001	Connector Single-row female (option)		L1

Continues on next page


Fieldbus adapter slaves



xx1800000830

	Spare part number	Description	Type	Spare part level
A	3HAC062390-001	Fieldbus slot cover (baseline)		L1
B	3HAC045973-001	DeviceNet Slave Fieldbus adaptor [3030-1] (option)	DSQC1004	L1

Additional spare parts



xx1800001153

	Spare part number	Description	Type	Spare part level
A	3HNA027579-001	Conveyor tracker module [3103-1]	DSQC2000	L1
-	3HNA029345-001	CONNECTOR KIT - DSQC2000		L1


9 Spare parts

9.1.6 Cables

9.1.6 Cables

Cables

Cables on the frame




xx1900000874

	Spare part number	Description	Type	Spare part level
A	3HAC061075-001	Harness Ethernet with Mini-IO	Harness Adapter - A2.X4/K4.X7	L1
B	3HAC064019-001	Harness TempSensor with cable	Harness K2.X21 - TempSensor	L1
C	3HAC064020-001	Harness 24_SYS_DRV	Harness K2.X4 - A1.X9	L1
D	3HAC061099-001	Harness AC input of power supply	Harness A1.X6, A1.X7 - T2,T5	L1
E	3HAC059271-001	Harness 24_Cooling	Harness K2.X17 - Cooling	L1
F	3HAC061097-001	Harness 24_Trunk	Harness K2.X1 - T2.X2	L1
G	3HAC064092-001	Harness Ethernet with Mini-IO	Harness K5.1.X5 - Adapter	L1

Continues on next page

Cables on the drive unit



xx1900000872

	Spare part num-ber	Description	Type	Spare part level
A	3HAC063344-001	Harness DC-BUS	Harness A1.X4 - T4.X5	L1
B	3HAC064389-001	Harness 24_SYS_DRV	Harness A1.X5 - T4.X1	L1
C	3HAC059894-001	Harness EtherCAT	Harness T4.X3 - A1.X12	L1
D	3HAC063967-001	Harness DC-BUS	Only used for IRB 14050 controller.	L1

Continues on next page

9 Spare parts

9.1.6 Cables


Continued

	Spare part number	Description	Type	Spare part level
E	3HAC067893-001	Harness 24_SYS_DRV	Only used for IRB 14050 controller.	L1
F	3HAC065875-001	Harness EtherCAT	Only used for IRB 14050 controller.	L1

Cable on the power unit

	Spare part number	Description	Type	Spare part level
-	3HAC073524-001	Harness 24_Trunk extension	Harness X107 - A1.X6 Only used for CRB 15000 controller.	L1


Cables on the ABB Ability™ Connected Services unit



xx1900000875

	Spare part number	Description	Type	Spare part level
A	3HAC061136-001	Harness Ethernet with Mini-IO	Harness A2.X5 - K7.X2	L1

Continues on next page

Cables on the robot signal exchange proxy

xx1900000873

	Spare part number	Description	Type	Spare part level
A	3HAC064091-001	Harness 24_PC	Harness K2.X2 - K4.X8, A2.X1	L1
B	3HAC059273-001	Harness dual channel safety	Harness K2.X12 - K3.X6, K3.X7	L1


9 Spare parts

9.2 FlexPendant parts

9.2 FlexPendant parts

FlexPendant parts

The illustration below shows the placement of the controller system parts in the recommended spare part list.



xx1800000974

	Spare part number	Description	Type	Spare part level
A	3HAC064211-001	FlexPendant	DSQC3060	L1
B	3HAC064927-001	FlexPendant Holder w/t E-stop cover		L1
C	3HAC065401-001	Power cable cover		L1
D	3HAC065408-001	Joystick guard		L1
E	3HAC064448-002 3HAC064448-001	FlexPendant power cable 3 m FlexPendant power cable 10 m		L1
F	3HAC065419-001	Fasten strip		L1

9.3 Manipulator cables

9.3.1 Manipulator cables

Power cables, IRB 1100, 1300, 910INV, 920

Power cable length	Article number	Power cable level
Power cable, straight connector, 3 m	3HAC077245-001	L1
Power cable, straight connector, 7 m	3HAC077245-002	L1
Power cable, straight connector, 15 m	3HAC077245-003	L1
Power cable, angled connector, 3 m	3HAC077247-001	L1
Power cable, angled connector, 7 m	3HAC077247-002	L1
Power cable, angled connector, 15 m	3HAC077247-003	L1

Power cables, IRB 1200, CRB 1100

Power cable length	Article number	Power cable level
Power cable 3 m	3HAC061139-001	L1
Power cable 7 m	3HAC061139-002	L1
Power cable 15 m	3HAC061139-003	L1

Power cables, IRB 14050

Power cable length	Article number	Power cable level
Power cable 3 m	3HAC061139-001	L1
Power cable 7 m	3HAC061139-002	L1

Floor cables, IRB 360

The floor cable contains the power cable and signal cable.

Power cable length	Article number	Power cable level
Floor cable 3 m	3HAC062959-003	L1
Floor cable 7 m	3HAC062959-004	L1
Floor cable 15 m	3HAC062959-005	L1
Floor cable 22 m	3HAC062959-006	L1
Floor cable 30 m	3HAC062959-007	L1

Continues on next page

9 Spare parts

9.3.1 Manipulator cables

Continued

Control cable, CRB 15000

The control cable contains the control cable hybrid power.

Power cable length	Article number	Power cable level
Control cable hybrid power 7 m	3HAC073212-002	L1

Signal cables, IRB 1100, 1300, 910INV, 920, CRB 1100

Singal cable length	Article number	Singal cable level
Signal cable, shielded: 3 m	3HAC067446-001	L1
Signal cable, shielded: 7 m	3HAC067446-002	L1
Signal cable, shielded: 15 m	3HAC067446-003	L1

Signal cables, IRB 1200

Singal cable length	Article number	Singal cable level
3 m	3HAC080671-001	L1
7 m	3HAC080671-002	L1
15 m	3HAC080671-003	L1

Signal cables, IRB 14050

Singal cable length	Article number	Singal cable level
Signal cable, shielded: 3 m	3HAC067446-001	L1
Signal cable, shielded: 7 m	3HAC067446-002	L1

9.3.2 Customer cables - CP/CS connectors (option)**CP/CS cables, IRB 1100, 1300, 910INV, 920**

CP/CS cable length	Article number	CP/CS cable level
3 m	3HAC067449-001	L1
7 m	3HAC067449-002	L1
15 m	3HAC067449-003	L1

CP/CS cables, CRB 1100

CP/CS cable length	Article number	CP/CS cable level
3 m, with lamp unit cabling	3HAC078069-001	L1
7 m, with lamp unit cabling	3HAC078069-002	L1
15 m, with lamp unit cabling	3HAC078069-003	L1

9 Spare parts

9.3.3 Customer cables - Ethernet floor cables

Ethernet floor cables, IRB 1100, 1300, 910INV, 920 (option)

One end is RJ45, one end is X-code.

Ethernet floor cable length	Article number	Ethernet floor cable level
Eth.RJ45_X floor cable, 7 m	3HAC067447-002	L1
Eth.RJ45_X floor cable, 15 m	3HAC067447-003	L1

Ethernet floor cables, CRB 1100 (option)

Ethernet floor cable length	Article number	Ethernet floor cable level
7 m, with lead-through device cabling	3HAC077020-001	L1

Ethernet floor cables, IRB 14050

One end is RJ45 and auxiliary 24V DC power connector⁵⁹ for electronics inside IRB14050, one end is M12 A-code 8 pin Eth.

Ethernet floor cable length	Article number	Ethernet floor cable level
3 m	3HAC063855-001	L1
7 m	3HAC063855-002	L1

⁵⁹ The auxiliary 24V DC power connector should be connected to X19 on the front panel of the controller.

Index

2

24V extension
installing, 152

3

3rd party software, 50

A

ABB Ability Connected Services Gateway
replacing, 299

allergenic material, 30

aluminum

disposal, 564

ambient temperature

operation, 41

storage, 40

AS

configuring, 126

assembly instructions, 53

assessment of hazards and risks, 30

automatic mode, 29

automatic stop, 126

function test, 216

axis computer

LED, 545

replacing, 231

B

batteries

disposal, 564

brakes not releasing, 512

brominated flame retardants

disposal, 564

C

cabinet lock, 31

cables, 91

carbon dioxide extinguisher, 31

category 0 stop, 23

category 1 stop, 23

cleaning

FlexPendant, 48

cleaning of the controller, 205

cleaning the FlexPendant, 206

climbing on robot, 34

Connected Services Gateway

LED, 538

replacing, 299

test equipment, 539

troubleshooting flowchart, 540

connection

manipulator cables, 91

controller

symbols, 20

controller fails to start, 523

controller mode, 523

cooling fan

replacing, 236

copper

disposal, 564

covers, 222, 227

D

damaged bearings, 525

damaged parallel bar, 525

desktop mounting kit, 71
detaching FlexPendant, 100
DeviceNet
installing, 168
dimensions, 40
disconnecting FlexPendant, 100
disposal of storage media, 563
double SMB harness
installing, 136
drive unit
LED, 530
replacing, 373

E

earth fault protection, 97
emergency stop, 23
function test, 212
emergency stops, 25
enabling device, 26
function test, 214
EN ISO 13849-1, 16
environmental information, 564
ESD
damage elimination, 47
sensitive equipment, 47

esd elimination, 47

Ethernet

installing, 145

Ethernet extension switch

installing, 145

Ethernet switch

LED, 543

replacing, 290

external I/O

installing, 141

replacing, 308

F

fan

replacing, 236

silencing, 81

fan control functionality, 81

faulty calibration, 525

faulty TCP definition, 525

fieldbus master

installing, 167

replacing, 384

fire extinguishing, 31

firewall settings, 111

firmware, reflashing failure, 524

FlexPendant

blue screen, 517

cleaning, 48

connecting, disconnecting, 100

storage, 48

FlexPendant connector, 439

FlexPendant holder, 75

FlexPendant joystick not working, 522

FlexPendant not responding, 517

FlexPendant not starting, 517

function tests, 212

G

general stop, 126, 217

grounding, 97

GS

configuring, 126

Index

- H**
hanging
 installed hanging, 30
harness 24V extension
 installing, 152
harness double SMB
 installing, 136
hazard levels, 18
hazardous material, 564
height
 installed at a height, 30
hold-to-run, 26
hot surfaces, 34
HRA, 30
- I**
I/O connectors, 120
industrial network, 133
installation activities, 54
installation space, 57
instructions for assembly, 53
integrator responsibility, 30
internal I/O
 installing, 141
 replacing, 308
- J**
jogging not possible, 522
joystick not working, 522
- K**
key of the mode switch, 33
- L**
labels
 controller, 20
lead
 disposal, 564
LED
 axis computer, 545
 Connected Services Gateway, 538
 drive unit, 530
 Ethernet switch, 543
 main computer, 547
 power supply, 551
 power unit, 532
 robot signal exchange proxy, 556
LEDs , indication, 502
LEDs not lit, 502
licenses, 50
limitation of liability, 15
Lithium
 disposal, 564
lock and tag, 31
- M**
main computer
 LED, 547
 replacing, 318
main power supply, 123–124
manipulator cables, 91
manual full speed mode, 27
manual high speed mode, 27
manual mode, 27
manual reduced speed, 27
mode switch key, 33
motor contactors
- function test, 215
MTTF_D, 16, 45
- N**
national regulations, 30
network security, 49
noise, 525
normal operation mode, 523
- O**
open source software, OSS, 50
operating conditions, 41
operating mode
 automatic mode, 29
 function test, 213
 manual full speed mode, 27
 manual mode, 27
 manual reduced speed, 27
optional power supply
 installing, 152
original spare parts, 15
- P**
path accuracy, 525
pedestal
 installed on pedestal, 30
performance level, PL, 16
personnel
 requirements, 17
PFH_D, 16, 45
PL, performance level, 16
plastic
 disposal, 564
power
 turn on and off, 83
power failure during start-up, 507
power inlet switch, 83
power supply
 LED, 551
 replacing, 365
 test equipment, 551
 troubleshooting flowchart, 552
power supply optional
 installing, 152
power unit
 LED, 532
 replacing, 358
 test equipment, 533
 troubleshooting flowchart, 534
PPE, 17
problem releasing the robot brakes, 512
product standards, 568
protection classes, 41
protection type, 41
protective equipment, 17
protective stop
 definition, 23
protective wear, 17
- R**
rack mounting, 61
RCD, 97
recovering from emergency stops, 25
recycling, 564
reduced speed control
 function test, 220
reflashing firmware failure, 524

- regional regulations, 30
remote I/O
 installing, 141
 replacing, 308
removing
 covers, 222
replacements, report, 221
report replacements, 221
required performance level, PLr, 16
residual current device, 97
responsibility and validity, 15
restart controller, 83
risk of burns, 34
robot
 protection class, 41
 protection types, 41
robot signal exchange proxy
 connectors, 112
 LED, 556
 replacing, 282
 test equipment, 558
 troubleshooting flowchart, 559
RobotWare Installation Utilities mode, 523
rubber
 disposal, 564
- S**
safeguarding, 23
safeguard mechanisms
 automatic mode, 29
 manual mode, 27
safety
 ESD, 47
 fire extinguishing, 31
 signals, 18
 signals in manual, 18
 stop functions, 23
 symbols, 18
 symbols on controller, 20
safety devices, 31
safety digital base
 replacing, 313
safety lock, 84
safety signals
 in manual, 18
safety standards, 568
scalable I/O, 135
 connectors, 120
 installing, 141
 replacing, 308
scalable I/O external, 135
scalable I/O internal, 135
signals
 safety, 18
 silent fan, 81
 sim card
 replacing, 299
 software licenses, 50
 standards, 568
 ANSI, 568
 CAN, 568
 start controller, 83
 steel
 disposal, 564
 stop category 0, 23
 stop category 1, 23
 stops
 overview, 23
 storage conditions, 40
 switch
 Ethernet Extension, 145
 symbols
 safety, 18
system integrator requirements, 30
system update failure, 511
- T**
teach pendant
 detach, attach, 100
temperatures
 operation, 41
 storage, 40
three-position enabling device, 26
 function test, 214
tightening torque, 571
TPU
 connecting, disconnecting, 100
transportation conditions, 40
troubleshooting
 safety, 35
- U**
upcycling, 564
users
 requirements, 17
- V**
validity and responsibility, 15
vertical mounting, 64
- W**
weight, 40
wrist strap, 47
- X**
X45 IP20, 123–124



ABB AB
Robotics & Discrete Automation
S-721 68 VÄSTERÅS, Sweden
Telephone +46 (0) 21 344 400

ABB AS
Robotics & Discrete Automation
Nordlysvegen 7, N-4340 BRYNE, Norway
Box 265, N-4349 BRYNE, Norway
Telephone: +47 22 87 2000

ABB Engineering (Shanghai) Ltd.
Robotics & Discrete Automation
No. 4528 Kangxin Highway
PuDong New District
SHANGHAI 201319, China
Telephone: +86 21 6105 6666

ABB Inc.
Robotics & Discrete Automation
1250 Brown Road
Auburn Hills, MI 48326
USA
Telephone: +1 248 391 9000

abb.com/robotics