

PACKML UNIT/MACHINE IMPLEMENTATION GUIDE

Part 1: PackML Interface State Manager

Summary

This document "PackML Interface State Manager is the first part of the PackML unit/machine Implementation Guide. The PackML unit/machine Implementation Guide is a Best Practice Recommendation based on ANSI/ISA TR88.00.02-2015. The purpose of this guideline is to help companies with different knowledge levels to implement PackML interfaces on Units/Machines. This document contains best practice recommendations based on the real implementation of PackML interfaces by a number of OMAC member companies as well as other users.

This document is the first part in a series of document related to build PackML unit/machines. Further documents are forthcoming and will focus on issues such as PackML Machine software code structure, PackML network connections, PackML and Safety, PackML and Line Integration and PackML HMI.

Author: Ph.D. Carsten Nøkleby, SESAM-World

Ver. 1.00 Page 0 of 97



1. Contents

2. Exe	ecutive Summary	4
2.1	Purpose	4
2.2	Goals	4
2.3	Background	4
2.4	Related PackML documents in process	5
3. Sco	ope of the Implementation Guide	6
3.1	PackML Interface State Manager	8
4. Ter	rminologies, Definitions and Abbreviations	9
4.1	ISA 88.01	9
4.2	The ISA 88 Physical Model	9
4.3	ISA 88 Recipe Management – unit/machine control recipe parameters	10
5. Ide	entifying and defining a Unit	13
6. The	e PackML Interface State Model	15
6.1	The syntax of the PackML state model	15
6.2	The PackML Interface State Model	15
6.3	Colours used for the PackML State Model	17
6.4	The PackML State Model from a unit/machine perspective	17
6.5	The PackML State Model from an internal and external perspective	19
6.6 orde	The PackML State Model from a unit/machine parameter perspective – productio lers 20	n
7. Pac	ckML Event State Manager	23
7.1	Resetting	24
7.2	Starting	26
7.3	Execute	28
7.4	Holding	30
7.5	Unholding	35
7.6	Suspending	39
7.7	Unsuspending	42
7.8	Completing	45
7.9	Stopping	47
7.10	0 Aborting	49
7.11	1 Mapping table	52
7.12	2 Mapping Alarms to event triggers to PackML	54
8. Pac	ckML Control Command definitions	55
8 1	PackML Commands	55



8.2	Specification of commands on unit HMI and from External system	59
9. PackN	IL Interface State definition	59
10. Unit	control modes	64
11. Pack	Tags	66
11.1	Description and definition of PackTags	68
12. Exan	nple of Unit Controller Functionality	69
12.1	Syntax and Symbolic description	69
12.2	Prepare unit/machine	70
12.3	Start unit/machine	71
12.4	Stop unit/machine from Unit panel/HMI	73
12.5	Stop unit/machine from external system	74
12.6	Operator Break and pause on unit/machine	76
12.7	Resume unit/machine after break from External System	77
12.8	Stop Unit from unit panel/HMI	78
12.9	Abort unit/machine	80
12.10	Re-start unit from unit panel/HMI after stop or abort	81
12.11	Re-start unit from External system after stop or abort	82
12.12	Alarm and warning on unit	83
12.1	2.1 PackML alarm and event state management table	84
12.13	Background task: OEE	86
12.14	Background task: Mode & State	87
12.15	Suspend: Starvation or saturation	89
12.16	Unsuspend	90
13. Refer	rence information	91
13.1	Definitions and abbreviations	91
13.2	References	92
13.3	List of people involved in preparation of the guideline	93
13.4	Support	95
13.5	The author	95
14. Vers	ion History	96



This page is initially left blank.

Ver. 1.00



2. Executive Summary

2.1 PURPOSE

This PackML Interface State Manager document is the first part of the PackML unit/machine Implementation Guide, which is a Best Practice Recommendation based on ANSI/ISA TR88.00.02-2015. This guideline will help companies, with varying levels of knowledge and experience, to gain familiarity with the ANSI/ISA TR88.00.02-2015 technical report, and how to apply the procedures described to real-world machine applications. The PackML Interface State Manager is focused on the execution of a Production Order on a machine, and not how the machine performing its control functions. A unit/machine is defined as a collection of physical equipment and control functions that perform one or more major processing functions. A unit/machine can be a single machine or a subset of a whole packaging line.

The background information for this document has been collected from four workgroup meetings held in 2015 and 2016. The practical experience from the members of the workgroup has been used to construct ready-to-use, generic and vendor-independent implementation models.

This PackML implementation guide is intended for Machine Suppliers, system integrators and End Users. This guideline describes the requirements for a unit/machine to be compliant with the PackML standard as described in ANSI/ISA TR88.00.02-2015, and provides examples of implementations that can be used as guidance for specific machines.

2.2 Goals

This PackML implementation guide provides a definition of the minimum requirements of a PackML interface. For example, there are practical examples on how different conditions can be handled when an error or event occurs on the equipment level that generates an alarm or warning. It also addresses how different interpretation from different users may be reconciled. The guideline provides examples of how to configure the PackML State model transitions according to specific End User requirements.

Furthermore, the guideline takes the maturity level of Machine Suppliers into consideration, as well as Machine Suppliers readiness or ability to implement PackML partly or fully.

Benefits for both End Users and Machine Suppliers include:

- Easy integration of unit/machines and test of interfaces
- Reduction of integration cost for a complete packaging line.
- Same operator Interface from a supervisory system
- Faster interface specification
- Less risk / Less uncertainty in commercial contract
- Less training effort
- Reliable data, e.g. OEE, energy data
- Replace one unit/machine at a line
- Etc.

2.3 BACKGROUND

The OMAC End Users want to achieve a unified way of interfacing with units/machines on the factory floor. Providing this unified interface will ensure easy integration with a supervisory control system. There are similar interfaces to all units, and the units have the same data structure interfaces available.

Ver. 1.00 Page 4 of 97



By applying a unified user interface based on the PackML State Model an operator can be guided in case of an unplanned stoppage. Furthermore, there can be common event handling on all units, providing the End User the possibility to view stop reasons in a common way for all units.

The interface described in this document is built on the international reference model PackML defined by The International Society of Automation (ISA). The interface follows the PackML State Model as described in the reference ANSI/ISA TR88.00.02-2015.

Basic understanding and knowledge of the TR88.00.02 technical report is required before reading this Best Practice Recommendation. In fact, it is strongly recommended to have the report in hand when reading this document.

A unit/machine is defined as a collection of physical equipment and control functions that perform one or more major processing functions. A unit/machine can be a single machine or a subset of a whole packaging line. The term unit and machine are used interchangeably in this document.

Machine Suppliers are defined as companies or organizations that provide PackML compliant unit/machines. End users are defined as companies or organizations that use PackML compliant unit/machines in production facilities.

2.4 RELATED PACKML DOCUMENTS IN PROCESS

This document is the first part in a series of documents related to build PackML unit/machines. Further documents¹ will come and have focus on issues like:

- Part 1: PackML Interface State Manager
- Part 2: PackML Machine Software Code Structure
- Part 3: PackML Network Connections
- Part 4: PackML and Safety
- Part 5: PackML and Line Integration
- Part 6: PackML User Interface HMI

Ver. 1.00 Page 5 of 97

¹ The list is not complete and there could be changes in the document titles.



3. Scope of the Implementation Guide

The PackML unit/machine Implementation Guide Part 1 focuses only on an individual unit/machine and its PackML Interface implementation, without any relationship to other units/machines or equipment.

The document does not cover how several Units/Machines are operated together in a line.

The PackML specification is an implementation of the ANSI/ISA-TR88.00.02-2015, Machine and unit/machine States. As an implementation example of ANSI/ISA-88.00.01, it covers the following two application examples:

- 1. PackML Interface State Manager²
- 2. PackML Machine State Manager (Not part of this document³)

The focus of the PackML unit/machine Implementation Guide Part 1 is the "PackML Interface State Manager", equal to the top (blue) part of Figure 1.




Figure 1: The definition of PackML Interface State Manager and PackML Machine State Manager

Machine Suppliers wanting to use the PackML state model for their internal Machine State Manager have two scenarios shown in Figure 2:

- 1) PackML gateway unit/machine
- 2) Full PackML compliant unit/machine

Ver. 1.00 Page 6 of 97

² TR88.00.02 describes a "base state model and the PackTags data area is used to drive action into the OEM's "PackML Machine State Manager" using the PackTags Command, Status and Admin tags.

³ The full Make2Pack decomposition approach is part of ISA88.00.05-2013-Draft [Ref. No. S88-5].



The focus of the PackML unit/machine Implementation Guide Part 1 is the PackML Gateway solution and covers the PackML Interface State Manager.




Figure 2: Mapping 4 of PackML Interface State Manger and Integrated Machine State Manager & PackML Interface

To implement a PackML gateway, Machine Suppliers must map the PackML Interface state model to their specific internal state logic³.

Machine Suppliers that use a PackML gateway unit/machine, must specify the mapping between the PackML Interface State Manager and their specific Machine State Manager. Normally, all Machine Suppliers should be able to fulfil the mapping to the PackML Interface State Manager.

When Machine Suppliers have a Machine State Manager based on PackML it is not necessary to specify any mapping between the PackML Interface State Manager and the Machine State Manager because they are the same⁵.

The PackML gateway approach makes sense for legacy equipment, and for Machine Suppliers that have fixed requirements for internal machine state logic.

To obtain a full PackML unit/machine it is often required that the unit/machine must be reprogrammed in accordance with ISA-88 [Ref. S88-1], PackML [Ref TR88] and Make2Pack [Ref. S88-5-Draft].

Ver. 1.00

⁴ The mapping table is in section 7.11.

⁵ In the case where a machine has multiple state managers, only one state manager should be presented to external systems, with appropriate mapping defined.



3.1 PACKML INTERFACE STATE MANAGER

The PackML Interface State Manager is used for communication with the unit/machine from Panels, HMIs or external systems. The Interface is used to get status of the unit/machine, start the unit/machine, stop the unit/machine, change parameters, etc.

The PackML Interface State Manager provides a single communication interface between the HMI or other external control system (e.g. other unit/machine or supervisory control system) and the unit/machine.

The PackML Interface State Manager can either be implemented in the same control system (CPU) as the Machine State Manager or in a separate control system. A full PackML unit/machine will have one common Interface and one Machine State Manager that is totally integrated with the Machine State Manager.

From a communication point of view, a unit/machine has a single PackML Interface State Manager, which gives one interface for the operation of the unit/machine from an HMI and/or external control system.

For example, a unit/machine may have three internal drive controllers but it is seen as one unit/machine from a user and operator point of view. For example, a depalletizer that consists of some infeed conveyors, a robot and some outfeed conveyors is seen as a single unit/machine. The definition of the individual unit/machine is often related to the primary processing scope performed.

Ver. 1.00 Page 8 of 97



4. TERMINOLOGIES, DEFINITIONS AND ABBREVIATIONS

4.1 ISA 88.01

The standard ANSI/ISA-88.00.01-2010 [Ref. S88-1] is not about just BATCH Industries! The standard applies to different types of production processes: discrete, continuous, and batch industries.

S88-1 is a model and methodology for designing & operating control system for flexible manufacturing. Its architecture and models are independent of the underlying control system (PLC, DCS, PC, etc.) and independent of the underlying basic control algorithms.

The goal of the S88-1 is to allow recipe development without the service of a control systems engineer, and without control system reprogramming required.

4.2 THE ISA 88 PHYSICAL MODEL

The ANSI/ISA-88.00.01-2010 [Ref. S88-1] and the ANSI/ISA-TR88.00.02-2015 [TR88] define the levels of equipment and machines via a Physical Model, as shown in Figure 3. The PackML Machine Implementation Guide focuses only on the unit/machine in the physical model described below. The unit/machine in the ISA 88 Physical Model is equivalent to a Machine such as a Depalletizer, a Bagger, a Filler, a Capper, a Box Filler, a Palletizer, etc.




Figure 3: The ISA 88 Physical model mapped to Packing Equipment

Ver. 1.00 Page 9 of 97



The ISA Physical model has the following levels:

- Enterprise / Site / Area (Out of scope of this document).
- Process Cell
 - The entire collection of equipment needed to execute a single recipe from start to finish Production Order.
 - Consists of one or more units
- Unit/machine Machine
 - A collection of equipment modules and control modules
 - Usually centered on a major piece of equipment
 - Frequently operates on or contains the complete Production Order.
 - May operate on or contain only a portion of the complete Production Order.
 - Cannot operate on or contain more than one Production Order at a time⁶
- Equipment Module
 - · A collection of control modules or other equipment modules
 - Can carry out a finite number of minor processing activities, i.e., phases
 - Contains all the necessary processing equipment to carry out these processing activities
 - For example, an equipment module might consist of, e.g. a circulation pump, a
 chilled water valve, a steam valve and a temperature controller. In this case the
 equipment module would represent a temperature control system
- · Control Module
 - A collection of sensors, actuators, other control modules, and associated processing equipment
 - · Acts as a single entity from a control standpoint
 - · Is the direct connection to the process through its sensor and actuators
 - Examples of Control Modules: Valve, Pump, Motor, Pressure Controller, Limit Switch, ...

4.3 ISA 88 RECIPE MANAGEMENT – UNIT/MACHINE CONTROL RECIPE PARAMETERS

Process related unit/machine parameters are used to specify which process specific task the unit/machine has to perform. The process related unit/machine parameters represent what the

Ver. 1.00 Page 10 of 97

⁶ In case it is necessary to run more than one production order at one time it is necessary to have several PackML Interface State Managers on the machine. An alternative is to have a buffer with several productions orders to be executed. It is then up to the machine to step through the production orders according to the PackML Interface State Manager.



unit/machine should do for a specific production order, such as glue amounts or printer label format. In relation to ISA 88 [Ref. S88-1], such parameters are called control recipe parameters.

The focus within this guide is only Control Recipe parameters. No other recipe management elements are in scope.

The Control Recipe parameters represent the specific process related parameters that can be configured on the Unit/Machine for preforming a specific task. For example, a Palletizer may have parameters that specify the packing pattern and number of layers on a pallet.

A PackML unit/machine should be able to handle process related machine parameters, represented as Control Recipe parameters, which are process relevant and process related parameters.




Figure 4: ISA physical model and ISA Recipe Management

The <u>Recipe</u> is the necessary set of information that uniquely defines the production requirements of a specific product. The relationship between recipes and equipment is shown in Figure 4.

- One <u>General Recipe</u> per produced material, maintained at the enterprise level (ERP system and defines the Bill of Materials BOM).
- One <u>Site Recipe</u> per site and produced material, maintained at the site for local materials, language, or segment of production.
- One <u>Master Recipe</u> per production line (Process Cell) and produced material.
- One <u>Control Recipe</u> per production order that describes the parameters which need to be set in the unit/machine for the production of one specific product. An example could be

Ver. 1.00 Page 11 of 97



a palletizer unit/machine that receives the three process related parameters for a production order: Packing pattern, number of layers and interleaf between layers.

Hint: The Control Recipe parameters for a unit/machine need to be defined collaboratively with the Machine Supplier and End User. The process related parameters do not have to reflect the internal unit/machine parameters. A unit/machine can have several hundred or thousand internal parameters that do not have any interest for the End User.

Hint: A set of control recipe parameters has a 1:1 relation to a production order. In some industries a production order can be called a "production run" or even just a batch.

Hint: From the view of the unit/machine it makes no difference, if the control recipe parameters are transferred from other system or just entered directly on the HMI interface of the unit/machine itself.

Hint: The following are useful or critical in determining the scope of the Control Recipe parameters:

- Quality relevant parameters in regard of process⁷
- Risk based evaluation which parameters can have a bigger impact on production

As an example Heat Sealing can have the process related unit/machine control recipe parameters: speed, time temperature, pressure, contact area, temperature of material, variation of foil thickness, material layer.

The process related unit/machine parameters that are really relevant and critical for the unit/machine can be identified through a Failure Mode and Effects Analysis (FMEA) working together with the End User experts.

Ver. 1.00 Page 12 of 97

-

⁷ For example, quality related parameters could be recipe name/numbers combined with other product specifying parameters (The unit/machine would have a local recipe management system that automatic loads all the required internal machine parameter set into the machine for the downloaded recipe name/number.)



5. Identifying and defining a Unit

A unit/machine is defined as a collection of physical equipment and control functions that perform one or more major processing functions. A unit/machine can be a single machine or a subset of a whole packaging line.

A unit/machine is functionally or physically defined through a common unit/machine Interface. The PackML Interface State Manager provides a single communication interface between the HMI or other external control system and the unit/machine, as shown in Figure 6.

An error on a unit/machine may stop all the subsystems within the unit/machine and generate an alarm or warning. Often the safety circuit defines the boarder of a unit/machine in a packaging line.

If an error on a unit/machine only stops part of the subsystems and generates an alarm or warning, the individual subsystem could be defined as an individual unit, but this is not required.

Hint: A PackML Interface is defined for each part of a unit that handles a specific product. A unit/machine can only handle one production order at a time.

For example, a unit/machine can have 3 internal drive controllers but is perceived as one unit/machine from a user situation and operator access.

For example a depalletizer, may consist of infeed conveyers, a robot, outfeed conveyers and is seen as one unit/machine, as shown in Figure 5.





Figure 5: A PackML unit/machine made up of different system elements.

Ver. 1.00 Page 13 of 97








Figure 6: Example of units/machines mapping to one PackML interface, even when the unit/machine contains several controls systems.

For a unit/machine which executes more than one independent process, a PackML interface is required for each of the independent process. For example a palletizer with two independent packing cells in the same line, needs to have two PackML interfaces.

A unit/machine can implement the PackML State Manager Gateway (PackML GW) in two different ways; one where the software code for the PackML Gateway is part of the unit/machine, and the second where the PackML Gateway code is located and executed within an external system such as a PLC or micro-controller.




Figure 7 PackML implementation levels

There are three main types of PackML integrations levels as shown in Figure 7:

• Unit/machine integration level type A:

The unit/machine uses a PackML Gateway which runs either locally or externally – it will mainly expose the PackTags8. The unit/machine is controlled by an existing Machine State Model and the internal machine States are mapped to the PackML Interface State Model via the PackML Gateway. This means that the Machine Supplier needs to define the mapping between the machine existing code and the PackML Gateway. The PackML Gateway will communicate to other systems using the PackML interface and PackTags.

• Unit/machine integration level type B:

The unit/machine implements the PackML Gateway code and PackML Interface State Manager in the software code of the unit/machine's control system. The main difference between integration level A and B is the location of the PackML gateway code. This

Ver. 1.00 Page 14 of 97

⁸ See section 11 of this document for an introduction to PackTags.



implementation will expose the PackTags and the PackML state model. The PackML interface is to be mapped to the existing control code of the machine.

• Unit/machine integration level type C9:

The unit/machine program is structured according to PackML and ISA 88.00.05-Draft programming rules. See more details in Make2Pack [Ref. No. S88-5]. The unit/machine will communicate to other systems using the PackML interface PackTags. Full implementation of the PackML interface is integrated with the unit/machine program code.

6. THE PACKML INTERFACE STATE MODEL

6.1 THE SYNTAX OF THE PACKML STATE MODEL

The PackML Interface State model is based on two main elements:

- Commands
 - A trigger that moves the unit/machine from one state to another (for example a pushbutton on the unit/machine or an external command sent via the network)
- States
 - o Acting states (a state where the unit/machine performs an action)
 - Waiting states (a stable situation for the unit/machine). A wait state needs a command to enter the next state.




Figure 8 The syntax of the PackML State Model

6.2 THE PACKML INTERFACE STATE MODEL

The PackML Interface State Model is a state model that represents the unit/machine states in a standardized manner. The interface description is based on a state model, a state description and related control commands. Figure 9 is the interface state diagram (ref. ISA TR88.00.02).

Ver. 1.00 Page 15 of 97

⁹ It should be noted that Integration Level "C" may or may not support the full use of Make2Pack (M2P) based upon the specific template provided by the Technology Provider. Additionally the Technology Providers could provide 2 templates for their OMAC PackML / TR88 template – one with Make2Pack and without Make2Pack!



Hint: It is recommended to implement all 17 of the PackML states in production mode. However Machine Supplier and End User may agree to a deviation from the 17 states.




Figure 9: The PackML Interface State Model

Table 1: The Interface State Model with different states represented by different patterns

Pattern	State	Description
	EXECUTE	Acting State - The unit/machine is in a stable acting state - unit/machine is producing.
	STOPPED IDLE COMPLETE	Wait State – A stable state used to identify that a unit/machine has achieved a defined set of conditions. In such a state the unit/machine is holding or maintaining a status until a command causes a transition to an Acting state. The unit/machine is powered and stationary.
	RESETTING STARTING SUSPENDING UNSUSPENDING COMPLETING HOLDING UNHOLDING ABORTING CLEARING STOPPING	Acting State – A state which represents some processing activity, for example ramping up speed. It implies the single or repeated execution of processing steps in a logical order, for a finite time or until a specific condition has been reached, for example within the Starting state the quality and validity of the received data is checked, before ramping up speed for execution.

Ver. 1.00 Page 16 of 97



Pattern	State	Description
	HELD ABORTED	Wait state – A state which represents an error state on the Unit which will generate an alarm or warning. In this state the unit/machine is not producing, until the operator made a transition to the EXECUTING state. The state holds the unit/machine operations while material blockage are cleared, or safe correction of an equipment fault before the production may be resumed.
	SUSPENDED	Wait State – In this state the unit/machine is not producing any products. It will either stop running or continue to cycle without producing until external process conditions return to normal, at which time the SUSPENDED state will transition to the UNSUSPENDING state, typically without any operator intervention.

6.3 COLOURS USED FOR THE PACKML STATE MODEL

Colours can be used to represent different states in the PackML Interface Model, however it was decided to put all the colour guidance in a separate document: PackML User Interface – HMI.

6.4 THE PACKML STATE MODEL FROM A UNIT/MACHINE PERSPECTIVE

The figure below shows "Operator" intervention using HMI pushbuttons¹⁰:



The four pushbuttons have been added to the state model, as shown in Figure 10, to assist in the clarification of the unit/machine HMI and the PackML State Model relationship.

Ver. 1.00 Page 17 of 97

¹⁰ The colour coding for pushbutton control devices used on machines can be defined according to standard IEC 60204-1: 1997, 'Safety of Machinery':

 $[\]bullet$ $\,$ The colours for START should be WHITE, GREY or BLACK with a preference for WHITE. GREEN is also permitted. RED shall not be used.

[•] The colour YELLOW/RED shall be used for emergency stop.

[•] The colours for STOP should be BLACK, GREY or WHITE with a preference for BLACK. RED is also permitted, but it is recommended that RED is not used near an emergency operation device. GREEN shall not be used.

[•] WHITE, GREY or BLACK are the preferred colours for push-buttons actuators that alternately act as START and STOP push-buttons. The colours RED, YELLOW or GREEN shall not be used.

WHITE, GREY or BLACK are the preferred colours for push-buttons that cause operation while they are actuated and cease the operation when they are released (e.g. hold-to-run). The colours RED, YELLOW or GREEN shall not be used.

[•] Reset push-buttons shall be BLUE, WHITE, GREY or BLACK. Where they also act as a STOP button, the colours WHITE, GREY or BLACK are the preferred with the main preference being BLACK. GREEN shall not be used.






Figure 10: Pushbuttons for operating 11 the machine from HMI.

Ver. 1.00 Page 18 of 97

 $^{^{11}}$ Operator intervention is required to make a transition from Aborted state to Clearing State. It requires a Clear command.



6.5 THE PACKML STATE MODEL FROM AN INTERNAL AND EXTERNAL PERSPECTIVE

Figure 11 shows the two different stop situations when the unit/machine is producing, a HELD situation and a SUSPEND situation:




Figure 11: The difference between HELD and SUSPEND in mode Production.

HOLDING HELD UNHOLDING These states shall be used when INTERNAL unit/machine conditions do not allow the unit/machine to continue producing. This happens when the unit/machine leaves EXECUTE due to internal conditions. Note that internal machine conditions are conditions inside the unit/machine and not from another machines on the production line.

The HELD state is typically used for routine machine conditions that requires minor operator servicing in order to continue production. The HOLDING state can be initiated automatically or by an operator and can easily be recovered from.

An example of this would be a unit/machine that requires an operator to periodically refill a glue dispenser or carton magazine and due to the machine design, these operations cannot be performed while the unit/machine is running. Since these types of tasks are part of production operations, it is not desirable to go through aborting or stopping sequences and because these functions are integral to the unit/machine they are not considered to be "external". While in the HOLDING state, the machine is typically brought to a controlled stop and then transitions to HELD upon state complete.

Hint: To be able to restart production correctly after the HELD state, all relevant process set-points and status information at the time of receiving

Ver. 1.00 Page 19 of 97



the HOLD command must be saved in the unit/machine controller when executing the HOLDING procedure.

Hint: An event that caused transition from EXECUTE to HOLDING may need to be reset in the UNHOLDING state.

SUSPENDING SUSPENDED UNSUSPENDING These states shall be used when EXTERNAL unit/machine conditions do not allow the unit/machine to continue processing. External process conditions are conditions outside the unit/machine but usually within the same integrated production line.

This happens, when the unit/machine leaves EXECUTE due to upstream or downstream conditions on the line. This is typically due to a blocked or starved event. This condition may be detected by a local machine sensor or based on a supervisory system external command. While in the SUSPENDING state, the unit/machine is typically brought to a controlled stop and then transitions to SUSPENDED upon state complete.

Hint: To be able to restart production correctly after the SUSPENDED state, all relevant process set-points at the time of receiving the SUSPEND command must be saved in the unit/machine controller when executing the SUSPENDING procedure.

Hint: An event that caused transition from EXECUTE to SUSPENDING may need to be reset in the UNSUSPENDING state.

6.6 THE PACKML STATE MODEL FROM A UNIT/MACHINE PARAMETER PERSPECTIVE – PRODUCTION ORDERS

Figure 12 illustrates the information exchange in relation to the individual states and PackTags types. The black boxes at the top of the figure indicate the information to be exchanged. The blue arrows represents data related to PackML Status Tags and the red arrows represent data related to PackML Command Tags. The green arrows indicate the information related to the PackML Admin Tags.

The communication of data to a unit/machine consists of the following types of data and the data is identified by PackTags types:

- Command Tags Used for control of the unit/machine.
- Status Tags Used to obtain status information from the unit/machine.
- Admin Tags Used to obtain performance information from the unit/machine.

Table 2 Data types and PackTag types

Data type	PackTag type
Unit/machine Mode & State	Status Tags
Warning & Alarms	Admin Tags
Stop Reasons - OEE data	Admin Tags
Command	Command Tags
Parameters (Control Recipe parameters)	Command Tags
	Status Tags

Ver. 1.00 Page 20 of 97



The control logic and synchronization of units is managed through Command Tags. Commands are used to request a change of the state of a unit. The commands can be triggered by either an internal unit/machine condition, the unit/machine HMI (pushbuttons), or they can be received from an external system.




Figure 12 The PackML State Model from a unit/machine parameter perspective

Hints: In the design of a PackML Interface State Manager it is recommended to specify which information and when the information is to be exchanged between the PackML Interface State Manager and the Supplier dependent Machine State Manager.

To make a simplification of the communication and mapping, it is recommended to specify when information can be sent and received between the two State Managers and in addition, to specify what information can be exchanged in the different states. For example, Command Tags Parameters are only exchanged between the PackML Interface State Manager and the Supplier dependent Machine State Manager in IDLE or STOPPED state. Normally, relevant unit/machine parameters can also be changed by operator.

Ver. 1.00 Page 21 of 97






Figure 13 PackML State Model from a Production Order¹² perspective

The PackML base state model has its origins in the batch industry (See Ref. No. S88-1), and the state model indicates the change in the execution of a Production Order (Batch).

There are two ways to bring the Production Order to an end:

- Through a Stop command: this means that the currently produced products can be used. The production order is stopped.
- Through an Abort command: this means that currently produced products may be destroyed. The production order is terminated.

Ver. 1.00 Page 22 of 97

_

 $^{^{12}}$ The Production Order is used, as it represents the handling of products within the unit/machine as defined within reference ISA-88.00.01.



7. PACKML EVENT STATE MANAGER

It is possible to create a matrix that allows Machine Suppliers to configure what types of unit/machine events will lead to a PackML Interface State Change and vice versa. This can be determined when a unit/machine should switch to a specific state in the PackML Interface State Model.

For example, when the unit/machine makes an internal state change and maps to the PackML interface states: HELD, STOPPED, SUSPENDED and ABORTED, the End Users may have different interpretations and requirements for the mapping. The tables in the following parts of Section 7 illustrate the mapping between the PackML Interface State Manager and an example Supplier dependent Machine State Manager. The blue colour and the left side of the tables represent the PackML Interface State and the grey colour and right side of the tables represent the Supplier dependent Machine State, matching the colour scheme in Figure 14. Below the tables a set of figures illustrates a possible mapping of all Acting PackML Interface States into example Supplier dependent Machine States. The Supplier dependent Machine State is illustrated with a standard PackML state model, however, be aware that the state model of a Machine Supplier might be rather different.




Figure 14: The mapping of PackML Interface State Manger and PackML different Machine State Manager (Supplier dependent or PackML)

Hint: The buyer and the seller of a machine have to agree on when the machine has to be in each PackML interfaces state. It is recommended to use a matrix with the PackML Interface States as one dimension and then the current machine dependent machine states as the second dimension of the table. Mark all possible situations for being in the different PackML Interface states. See more details of a sample matrix in section 7.11

Ver. 1.00 Page 23 of 97



7.1 RESETTING

Table 3 Interpretation of the Resetting state

PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine State	Machine State description (Supplier dependent Machine State Manager)
RESETTING	The PackML interface RESETTING state will start the resetting process, which typically causes the unit/machine to clear data and to place the unit/machine in an IDLE state, where unit/machine components are energized waiting for a Start command. By resetting the Unit, the machine parameters will be cleared and the unit/machine is ready for new machine parameters. For example, the operator has changed tooling and by activating the Resetting process the operator have indicated that the machine is ready for production. Actions to be taken during RESETTING are to be specified by the Machine Supplier and End User.	Resetting	This state is the result of a RESET command from the STOPPED or COMPLETE state. Faults and stop causes are reset. RESETTING will typically cause safety devices to be energized and place the machine in the IDLE state where it will wait for a START command. RESETTING will typically reset alarms caused by actuated safety devices after the unit/machine has been reset. No hazardous motion should happen in this state. This acting state is triggered by a reset request Machine movement such as "re-homing" after a stop may occur in this state.

Ver. 1.00 Page 24 of 97

-

¹³ It is essential that the clearing of data is carried out at the right time for the Supplier dependent Machine State Manager to insure that the unit/machine does not physical start with the tooling and components for the wrong production order.



PACKML INTERFACE (RESETTING)
The Production order/Batch is being Reset, and a new Production order/Batch can be started.




Figure 15 Reset mapping¹⁴ between the PackML Interface State Model and the Machine control State model.

Ver. 1.00 Page 25 of 97

 $^{^{14}}$ A reset on machine/unit is not an "end of a Production Order" on the Supervisory Control Level and the other units in a line. Downstream units may still be executing the Supervisory Control Level production order.



7.2 STARTING

Table 4 Interpretation of the Starting state

PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine State	Machine State description (Supplier dependent Machine State Manager)
STARTING	This state provides the steps needed to be able to start the unit/machine and is triggered by a Start command. The starting logic will check the unit/machine parameters and move the unit/machine into the state EXECUTE if parameters has been accepted. The starting logic will ramp up speed, pressure, etc. to be ready for production. However, if the parameters are not valid, the starting logic will move the unit/machine into the STOPPING state and the unit/machine will end in STOPPED state. If the machine is not able to complete the Starting state process (internal error), the unit/machine will enter the STOPPING state and end in STOPPED state. Actions to be taken during STARTING are to be specified by the Machine Supplier and End User.	Starting	The machine completes the steps needed to start. This state is entered as a result of a Start command (local or remote). Following this command, the machine will begin to "execute". As a result of requesting a starting request to the EXECUTE state.

Ver. 1.00 Page 26 of 97



PACKML INTERFACE (STARTING)

The Production order/Batch is being started.




Figure 16 Starting mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 27 of 97



7.3 EXECUTE

Table 5 Interpretation of the Execute state

PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine State	Machine State description (Supplier dependent Machine State Manager)
EXECUTE	The unit/machine is running with all conditions met, defined by the selected MODE and / or recipe selected.	Execute	When the machine is processing materials it is in the EXECUTE state. Different machine modes will result in specific types of EXECUTE activities. For example, if the machine is in the "Production" mode, the EXECUTE will result in products being produced. The machine is producing product at the desired set speed. HINT: It is desirable to store set speed as a control recipe parameter within a product "recipe" to avoid speed losses due to unnecessary blocking and starvation.

Ver. 1.00 Page 28 of 97



PACKML INTERFACE (EXECUTE) The Production order/Batch is being executed.




Figure 17 Execute mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 29 of 97



7.4 HOLDING

Below are three machine control scenarios that can bring the PackML Interface State Model into the HOLDING state. The unit/machine can be in the HOLDING state, because of one of the following reasons:

- 1) Minor issue caused by a hold situation on the Unit/Machine
- 2) A stop of the Unit/Machine which does not prevent continuing the current production order
- 3) Or a major issue (ABORTING) that requires a Unit/Machine safety stop but does not prevent continuing the current production order

Normally, a unit/machine only supports one of the three scenarios.

Table 6 Interpretation of the Holding state

PackML	PackML Interface	Machine	Machine State description
Interface	description	State	(Supplier dependent Machine State Manager)
State	(PackML Interface		
	State Manager)		
HOLDING	The HOLDING	Holding ¹⁶	This state is to be used when INTERNAL (inside this
	logic brings the		unit/machine and not from another machine on the
	unit/machine to a		production line) machine conditions do not allow the machine
	stop or to a state		to continue producing, and the machine leaves EXECUTE due
	which represents		to internal conditions, but does not prevent continuing the
	HELD for the		current production order.
	particular Unit.		This is typically used for routine machine conditions that
	This is an internal		requires minor operator servicing to continue production. This
	control logic that		state can be initiated automatically or by an operator and can
	is executed when		easily be recovered from. An example of this would be a
	an error ¹⁵ occurs		machine that requires an operator to periodically refill a glue
	on the		dispenser or carton magazine and due to the machine design,
	unit/machine or		these operations cannot be performed while the machine is
	an operator		running. Since these types of tasks are normal production
	initiates a Hold		operations, it is not desirable to go through aborting or
	command from		stopping sequences, and because these functions are integral
	unit/machine		to the machine they are not considered to be "external".
	HMI. The Holding		While in the HOLDING state, the machine is typically brought
	control logics		to a controlled stop and then transitions to HELD upon state
	change the		complete. To be able to restart production correctly after the
	unit/machine		HELD state, all relevant process set-points and return status of
	from the Holding		the procedures at the time of receiving the HOLD command
	state to the HELD		must be saved in the machine controller when executing the
	state.		HOLDING procedure.

Ver. 1.00 Page 30 of 97

¹⁵ Not all machine errors will cause the machine to transition to Holding state. For example if an error does not influence the production on the unit/machine, the unit/machine should not be put into the PackML interface state HOLDING. The OEMs can determine in a table, which unit/machine errors and events should put the unit/machine into a certain PackML Interface State. The errors and events should be mapped to alarm and warning information.

 $^{^{16}}$ The mapping between the PackML Interface States and an example Supplier dependent Machine State Manager is defined within section 7.11.



PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine State	Machine State description (Supplier dependent Machine State Manager)
		Stopping ¹⁶	The machine is powered and stationary after completing the stopping state, but can continue the current production order after the stop condition is corrected. All communications with other systems are functioning, if applicable. As a result of requesting a Controlled stop to a stopped state.
		Aborting ¹⁶	The aborting state can be entered at any time in response to an abort command or on the occurrence of a machine fault. The aborting logic will bring the machine to a rapid safe stop, but can continue the current production order after the abort condition is corrected.


Ver. 1.00 Page 31 of 97



PACKML INTERFACE (HOLDING from internal hold)

The reason for moving a unit/machine into the HOLDING state can be:

1) Minor issue caused by a hold situation on the Unit/Machine



MACHINE CONTROL

Supplier dependent Machine State Manager



The Unit/Machine can stop because of a minor error and enter the unit/machine state Holding.

Figure 18 Hold mapping between the PackML Interface State Model and the Machine control State model


Ver. 1.00 Page 32 of 97



PACKML INTERFACE (HOLDING from internal stop)

The reason for moving a unit/machine into the HOLDING state can be:

2) A stop of the Unit/Machine



MACHINE CONTROL

Supplier dependent Machine State Manager



The Unit/Machine can stop because the operator stops the unit and the unit/machine enter the machine state Stopping.

Figure 19 Stopping mapping between the PackML Interface State Model and the Machine control State model


Ver. 1.00 Page 33 of 97



PACKML INTERFACE (HOLDING from internal abort)

The reason for moving a unit/machine into the HOLDING state can be:

3) Or a major issue (ABORTING) that requires a safety stop



MACHINE CONTROL

Supplier dependent Machine State Manager



The Unit/Machine can stop because the operator pressed an Estop and the unit/machine enter the machine state Aborting.

Figure 20 Aborting mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 34 of 97



7.5 Unholding

The UNHOLDING scenarios are related to the way that the unit/machine is entering the HOLDING state. The HOLDING state has three different scenarios and therefor, there are also three scenarios to the UNHOLDING process.

- 1) UNHOLDING can be carried out from the Machine Control just by restarting (Unhold) the unit/machine.
- 2) The Machine Control system was original stopped, and needs to be restarted on the same Production Order.
- 3) The Machine Control system was original E-stopped and needs to be cleared and restarted on the same Production Order.

Table 7 Interpretation of the UNHOLDING state


PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine States	Machine State description (Supplier dependent Machine State Manager)
UNHOLDING	The UNHOLDING state is a response to an Operator command to resume production. The control logics in the UNHOLDING state prepares the unit/machine to re-enter the normal EXECUTE state. The UNHOLDING logic will ramp up speed, pressure, etc. to be ready for	Unholding	Refers to HOLDING for when this state is used. A machine will typically enter into UNHOLDING automatically when INTERNAL conditions, material levels, for example, return to an acceptable level. If an operator has been required to perform minor servicing to replenish materials or make adjustments, then the UNHOLD command may be initiated by the operator.
	production.	Reset Idle Starting	The operator needs to handle the actions on the Machine Control panel (HMI) to return to the EXECUTE state. The operator has made a controlled stop of the unit/machine, and has to restart on the same Production Order after this situation.
		Clearing Stopped Reset Idle Starting	The operator has originally activated the safety circuit and the unit/machine is making a fast stop. The operator needs to clear the safety circuit, and handle the actions on the Machine Control panel (HMI) to return to the EXECUTE state. The operator has made an E-stop of the unit/machine, and has to clear E-stop circuits and restart after this situation on the same Production Order

Ver. 1.00 Page 35 of 97



PACKML INTERFACE (UNHOLDING from unholding)

The execution of a Production order/Batch is UNHOLDING because of problem on the unit/machine is fixed. Normally a minor problem that has been solved. The Machine Controller has not been stopped.



MACHINE CONTROL

Supplier dependent Machine State Manager



The Unit/Machine can start by UN-HOLDING because of a minor error and enters the unit/machine state Execute.


Figure 21 Unhold mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 36 of 97



PACKML INTERFACE (UNHOLDING from resetting, idle, starting)

The execution of a Production order/Batch is UNHOLDING because of problem on the unit/machine is fixed. The Machine Controller have been stopped and needs to be restarted.



MACHINE CONTROL

Supplier dependent Machine State Manager



The Unit/Machine can start when the operator has RESET the unit/ machine and thereafter pressed Start. The Unit will then enter the unit/machine Execute State.


Figure 22 Resetting mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 37 of 97



PACKML INTERFACE (UNHOLDING from clear, stopped, ...)

The execution of a Production order/Batch is UNHOLDING because of problem on the unit/machine is fixed. The Machine Controller have been E-stopped and needs to be cleared and restarted.



MACHINE CONTROL

Supplier dependent Machine State Manager

Clear Stopped Reseting Idle Starting The Unit/Machine can start when the operator has cleared the E-stop, reset the unit/machine and thereafter pressed Start. The unit/machine will then enter the Execute State.

Figure 23 Clear mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 38 of 97



7.6 Suspending

Below are two machine control scenarios that can bring the PackML Interface State Model into the SUSPENDING state. The unit/machine can be in the SUSPENDING state, because of one of the following reasons:

- 1) Starvation or saturation (Blockage) of material upstream or downstream.
- 2) Operator has stopped the machine control because of an external condition.

Table 8 Interpretation of the SUSPENDING state

PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine State	Machine State description (Supplier dependent Machine State Manager)
SUSPENDING	This SUSPENDING state is required prior to the SUSPENDED wait state, and prepares the unit/machine for e.g. stop ironing, stop cutting, stop debagging, etc. The unit/machine may be running at a relevant set point speed, but there is no product being send to the next unit/machine downstream. ¹⁷ The Machine Supplier and End User must specify the special conditions that have to take place when the units enter the Suspending and SUSPENDED state. Does the unit/machine fill up its internal product buffers or does the unit/machine stop immediately. The actions to be taken when the unit/machine enters the Suspending state are to be defined. Suspending is the result of starvation of material within the in-feeds or a result of saturation related out-feed blockage that prevents the unit/machine from Executing continued steady production. During the controlled sequence of Suspending the unit/machine will transition to a SUSPENDED state.	Suspending	This state shall be used when external process conditions (outside this unit/machine but usually on the same integrated production line) do not allow the machine to continue producing. Usually when the machine leaves EXECUTE due to upstream or downstream conditions on the line. For example, the unit/machine moves from EXECUTE if either upstream equipment cannot supply material or downstream equipment cannot receive material. This condition may be detected by a local machine sensor or based on a supervisory system external command. While in the SUSPENDING state, the machine is typically brought to a controlled stop and then transitions to SUSPENDED upon state complete. To be able to restart production correctly after the SUSPENDED state, all relevant process set-points and return status of the procedures at the time of receiving the SUSPEND command must be saved in the machine controller when executing the SUSPENDING procedure.
SUSPENDING	The SUSPENDING state might be forced by the operator via the external interface, such as when the operator needs to have a break.	Stopping	The machine is powered and stationary after completing the Stopping state. All communication with other systems are functioning, if applicable. As a result of requesting a Controlled Stop to the Stopped state.


 $^{^{17}}$ What is happing at specific unit/machine have to be defined, because this is unit/machine specific. Some unit/machines may not stop with open products.

Ver. 1.00 Page 39 of 97



PACKML INTERFACE (SUSPENDING from suspending)

The execution of a Production order/Batch is SUSPENDING because of problem on units outside the current unit/machine, that results in a starvation or saturation situation for the current unir/machine.



MACHINE CONTROL

Supplier dependent Machine State Manager The Unit/Machine can stop because of external issues, such as starvation or blockage of products.


Figure 24 Suspending mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 40 of 97



PACKML INTERFACE (SUSPENDING from stopping)

The execution of a Production order/Batch is SUSPENDING because the operator has ordered a stop. For example to take a short break.



MACHINE CONTROL




Figure 25 Stopping mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 41 of 97



7.7 Unsuspending

The unsuspending scenarios are related to the way that the unit/machine has entered the UNSUSPENDED state. The SUSPENDING state has two different scenarios and therefor, there are also two scenarios in the UNSUSPENDING process.

- 1) Automatic change on Machine Control level, because the sensors indicating starvation or saturation (blockage) of material upstream or downstream are no longer active.
- 2) The operator wants to restart the unit/machine.

Table 9 Interpretation of the UNSUSPENDING state


PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine State	Machine State description (Supplier dependent Machine State Manager)
UNSUSPENDING	This state is a result of a unit/machine generated request from SUSPENDED state to go back to the EXECUTE state or an Unsuspend command via the external interface. This state is done prior to the EXECUTE state, and prepares the unit/machine for the EXECUTE state. The actions of this state may include ramping up speeds, turning on vacuums, and the re-engagement of clutches. The unit/machine is not allowed to change state to EXECUTE unless that the external command has been set equal toUnsuspend. The actions to be taken when the unit/machine enters the UNSUSPENDING state are to be defined by the Machine Supplier and End User.	Unsuspending	Refer to SUSPENDING for when this state is used. This state is a result of process conditions returning to normal. The UNSUSPENDING state initiates any required actions or sequences necessary to transition the machine from SUSPENDED back to EXECUTE. To be able to restart production correctly after the SUSPENDED state, all relevant process set-points and return status of the procedures at the time of receiving the SUSPEND command must be saved in the machine controller when executing the SUSPENDING procedure. The machine moves from SUSPENDED if either upstream equipment or downstream equipment can receive product again. For example, a signal may come from an external Line Controller or sensors when any line buffering becomes clear and the machine can start producing again.
UNSUSPENDING		Reset Idle Starting	The operator has handled the actions on the Machine Control panel (HMI) necessary to return to the EXECUTE state. The operator has made a controlled stop of the unit/machine, and has restarted.

Ver. 1.00 Page 42 of 97



PACKML INTERFACE (UNSUSPENDING from unsuspending)

The execution of a Production order/Batch is UN-SUSPENDING because of problem on units outside the current unit/machine are fixed.



MACHINE CONTROL

Supplier dependent Machine State Manager



The Unit/Machine can start because the external issues were resolved. The starvation or blockage of products has ended.


Figure 26 Unsuspend mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 43 of 97



PACKML INTERFACE (UNSUSPENDING from idle, ...)

The execution of a Production order/Batch is UNSUSPENDED because the operator is ready to restart production. The Machine Controller have been stopped and needs to be restarted.



MACHINE CONTROL

Supplier dependent Machine State Manager



The Unit/Machine can start when the operator has reset the unit/ machine and thereafter pressed Start. The Unit will then enter the unit/machine Execute State.

Figure 27 Resetting mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 44 of 97



7.8 Completing

The Completing is related to the way in which the unit/machine is able to stop the production of a Production order.

Table 10 Interpretation of the COMPLETING state

PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine State	Machine State description (Supplier dependent Machine State Manager)
COMPLETING ¹⁸	This state provides the steps needed to complete the job usually as a result of product counter reaching a limit in the unit. The unit/machine will make available machine parameters back to the external system. The machine parameters can be obtained by the external system to get information about manual changed or corrected data on the unit/machine during executing. The Machine Supplier and End User have to specify the special conditions that have to take place when the unit/machine enters the COMPLETING and COMPLETE state. For example, does the unit/machine empty its internal product buffers, or does the unit/machine stop immediately with products within the unit. Actions to be taken during COMPLETING are to be specified by the Machine Supplier and End User.	Completing	This state is an automatic response from the EXECUTE state when the specified number of products have been processed. Normal operations have run to completion, i.e. processing of material at the infeed will stop. For example, this state could also be issued by the operator on the Machine Control by pressing an HMI push button.


Ver. 1.00 Page 45 of 97

 $^{^{18}}$ In the case that the operator wants to force "Finalize" or "Complete" the production. It is not possible to enter the COMPLETE state from an external system. The operator has to issue a Stop command to the unit/machine. This gives the operator the flexibility to stop the production at a certain amount of products through an external system.



PACKML INTERFACE (COMPLETING from completing)

The execution of a Production order/Batch is COMPLETING because the number of products to produce has been reached.



MACHINE CONTROL

Supplier dependent Machine State Manager The Unit / Machine can complete



The Unit/Machine can complete production because the number of products produced for the specific production order has been reached.

 $\begin{tabular}{ll} Figure~28~Completing~mapping~between~the~PackML~Interface~State~Model~and~the~Machine~control~State\\ model \end{tabular}$

Ver. 1.00 Page 46 of 97



7.9 Stopping

The purpose of the STOPPING state is to stop the production of a production order from a Supervisory control system or when the operator wants to stop the production order at a unit/machine.

Table 11 Interpretation of the STOPPING state

PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine State	Machine State description (Supplier dependent Machine State Manager)
STOPPING	This state executes control logic which brings the unit/machine to a controlled stop as reflected by the STOPPED state. The unit/machine can make available machine parameters back via the External interface. The machine parameters can be used to get information about manual changes and corrections on the unit/machine during executing. The Machine Supplier and End User must specify the special conditions that have to take place, when the units enters the STOPPING and STOPPED state. For example, does the unit/machine empty its internal product buffers, or does the unit/machine stop immediately.	Stopping	This state is entered in response to a STOP command. In this state the machine executes the logic which brings it to a controlled stop as reflected by the STOPPED state. Normal STARTING of the machine cannot be initiated unless RESETTING had taken place. As a result of completing a controlled stop the unit/machine will transition to the STOPPED state.

Ver. 1.00 Page 47 of 97



PACKML INTERFACE (STOPPING from stopping) The execution of a Production order/Batch is STOPPING because the operator has

The execution of a Production order/Batch is STOPPING because the operator has stopped the production order/Batch.




Figure 29 Stopping mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 48 of 97



7.10 Aborting

Table 12 Interpretation of the ABORTING state

PackML Interface State	PackML Interface description (PackML Interface State Manager)	Machine State	Machine State description (Supplier dependent Machine State Manager)
ABORTING	The ABORTING state can be entered at any time as a response to an Abort command. The aborting logic will bring the unit/machine to a rapid safe stop. The Aborting logic will provide the necessary actions to move the unit/machine into the ABORTED State. The actions to be taken when the unit/machine enters the Aborting state are to be defined by the Machine Supplier and End User.	Aborting ¹⁹ Stopping	The ABORTING state can be entered at any time in response to the ABORT command or on the occurrence of a machine fault. The aborting logic will bring the machine to a rapid safe stop. Aborting is a result of e-stop button pushed or a machine fault that needs a fast stop of the unit/machine. This state is entered in response to a STOP command. While in this state the machine executes the logic which brings it to a controlled stop as reflected by the unit/machine stopped state. Normal starting of the machine cannot be initiated unless PackML RESETTING had taken place.

Ver. 1.00 Page 49 of 97

 $^{^{19}}$ The products produced before the Aborting, are in the packaging world, normally not destroyed. The aborted state indicate that the production order is finished and cannot be started again.



PACKML INTERFACE (ABORTING from stopping)

The execution of a Production order is ABORTED because the operator has terminated the production order. There are two different ways to map to the ABORT state:

- 1) The Unit/Machine maps a stopped state to the PackML ABORTING State or
- 2) The Unit/Machine maps the aborted state to the PackML ABORTING State.




Figure 30 Stopping mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 50 of 97



PACKML INTERFACE (ABORTING from aborting)

The execution of a Production order is ABORTED because the operator has terminated the production order. There are two different ways to map to the ABORT state:

- 1) The Unit/Machine maps a stopped state to the PackML ABORTING State or
- 2) The Unit/Machine maps the aborted state to the PackML ABORTING State.





Figure 31 Aborting mapping between the PackML Interface State Model and the Machine control State model

Ver. 1.00 Page 51 of 97



7.11 MAPPING TABLE

As illustrated below, Table 13 gives an overview of the mapping possibilities between the PackML Interface States and a set of example Supplier dependent Machine States. The example Supplier dependent Machine State model is depicted in Figure 32.



LTR Local to Remote control RTL Remote to Local control (e.g. error) Upload Send Information and data Downlaod Receive information and data Clear Erase data Select Create executable program Deselect Delete executable program Start Start the execution of a program Finished End of program execution Pause Stop for a period the program execution Continue Restart the program execution Reset Reset the program execution Kill Pull out the program

Figure 32 Example supplier dependent Machine State model

The mapping process determines which Supplier dependent Machine states and commands correspond to PackML States and commands. The state model above shows several states and a lot of state transactions that can be mapped against the PackML acting states (White coloured boxes on the PackML state model diagram), as shown in Table 13.

Ver. 1.00 Page 52 of 97



Table 13 An example mapping table between PackML Interface States and Machine States

			Supplier dependent Machine State & transitions																	
		Not ready (Manual intervention required)	LTR – Local to Remote control	RTL – Remote to local control (E.g. error)	ldle	Download (Not supported by PackML)	Clear	Loaded	Select (Not supported by PackML)	Deselect (Not supported by PackML)	Ready	Start	Finished	Running	Pause	Continue	НоІд	Reset	Kill	Upload (Not supported by PackML)
	STOPPED	Х																		
	Reseting		С				С													
	IDLE				Χ			Χ												
	Starting										Χ	С								
	EXECUTE													Χ						
ate	Holding			С																
e Sta	HELD	Х																		
.tac	Unholding		С																	
nter	Suspending														С					
٦ ا	SUSPENDED																Χ			
PackML Interface State	Unsuspending															С				
Ą	Completing												С							
	COMPLETE													Χ						
	Aborting			С															С	
	ABORTED	Χ																		
	Clearing		С																	
	Stopping			С														С		

X = State, C = Command (Acting state)

Hint: The Machine Supplier and End User have to agree on when the machine is to be in the different PackML interfaces states. It is recommended to make a matrix such as illustrated in Table 13 with the PackML Interface States as one dimension of the table and the current machine dependent machine states as the second dimension of the table. Mark all the possible situations for the different PackML Interface states.

Hint: During the specification of a specific unit/machine, use a version of Table 13, and fill in the specific Supplier dependent Machine State & transitions.

Ver. 1.00 Page 53 of 97



7.12 Mapping Alarms to event triggers to PackML

It is possible to create a matrix that allows a Machine Supplier to configure which types of alarms and events that will lead to a PackML state change. It can be used to specify when a machine should switch to the states in the PackML state model. See Table 14 as an example mapping table.

It is especially useful to document when the unit/machine has to move to HELD, STOPPED, SUSPENDED and ABORTED states, because the End Users sometimes have different interpretations and expectations of when the different states should be entered.

Table 14: Error and event triggers relation to PackML state management table

Events /	State change ID	Reaction for Machine Control	Reaction for PackML Interface
Alarms	= Commands		state manager
1	8	Abort	ABORTING
2	8	Abort	ABORTING
3	4	Hold – Error on material	HOLDING
4	4	Hold – Error on glue	HOLDING
5	3	Stop – Drive failure	ABORTING
6	3	Stop – Sensor failure	HOLDING
7	6	Suspend - Blocked	SUSPENDING
8	6	Suspend – Queue	SUSPENDING
9	20	Pop-up information on HMI –	No state change
		Executing state	
10	20	Pop-up information on HMI –	No state change
		Executing state	

Hint: During the specification of a specific unit/machine, is it recommended to use and empty version of Table 14, and to fill in the specific Supplier dependent Machine alarms and warnings and the PackML Interface State Manager action.

Ver. 1.00 Page 54 of 97



8. PACKML CONTROL COMMAND DEFINITIONS

The Control Command provides the state commands to drive state changes in the PackML Interface State Model (see Figure 9: The PackML Interface State Model). The processing of the command in the unit/machine Control System may be combined with remote or local unit/machine conditions to drive the interface state model from a Wait state to an Acting state. The unit/machine shall always respond to a command²⁰, but not all commands will cause a PackML state change.

8.1 PACKML COMMANDS

The Control Command can be set by the unit/machine HMI or remote set via the PackML interface. The column "Issued" in Table 15, describes who is able to issue the command.

The Control Commands shall be exposed as an Integer, the specific command values are given in 8.2.

Command Issued Comments E-stop On or by Ву External unit/ machine²¹ interface Start YES The start command will move the unit/machine into the YES Starting state. The start command will finally put the unit/machine into the EXECUTE state. If an error occurs the unit/machine will be put into STOPPED or ABORTED. An external system is allowed to give the Start command when the unit/machine is in Production Mode and IDLE State. Starting the unit/machine from an external system, when the parameters were downloaded in STOPPED or IDLE state, will automatic start the unit, because the unit/machine is already locally approved for production by operator (See reset command). (*) Start on the unit/machine itself can be used if there is no external system. Hold YES The Hold command can be executed by the unit/machine when an internal unit/machine fault is detected or by an operator command on the unit/machine during Production. The Hold command changes the unit/machine from the EXECUTE state to the HOLDING state. The Hold command offers the operator a safe way to

Table 15: Control internal, external and e-stop commands

intervene manually in the process, for example removing

Ver. 1.00 Page 55 of 97

²⁰ If a command is not valid in relation to the current state, the unit/machine should not react, but should give a warning. For example a start command is send to a unit in state STOPPED, and then the unit/machine has to respond by rejecting the command.

²¹ The column "Issued On or by unit/ machine" indicates that the operator can, from the HMI or via ahardware push button at the machine, initiate the command. The column also indicates that the unit itself can initiate the command. For example, an Unsuspend command does not have to come from the operator.



Command	Issued			Comments
	On or by unit/ machine ²¹	By External interface	E-stop	
				broken material from the in-feed, or opening a safe door and removing cardboard. The configuration of safe stops are not defined within this guideline.
Unhold	YES			The Unhold command releases the HOLD state and moves the unit/machine to the UNHOLDING state and then back to EXECUTE state. The Unhold command is a response to an Operator command to resume the production after an error/fault on the unit indicated by an alarm or warning. For example, when the operator has cleared material blockage. An Unhold command is always required from the operator and can never be initiated automatically by the unit.
Suspend	YES	YES		The Suspend command from the unit/machine is the result of starvation of material within the in-feeds, or a result of saturation related out-feed blockage that prevents the unit/machine from Executing continued steady production, or on operator command. A unit/machine that is already in SUSPENDED state and receives an external Suspend command, will only change the stop reason. A Suspend command may come as the result of upstream or downstream problems outside the unit/machine itself.
Unsuspend	YES	YES		The Unsuspend command releases the unit/machine from SUSPENDED state and moves the unit/machine to the UNSUSPENDING state and finally to the EXECUTE state. The Unsuspend command is initiated by the unit when the Downstream and Upstream units are ready to execute, or when the an external system issues an Unsuspend.
State Completed (SC) from any acting states	YES			The State Completed (SC) is an internal unit/machine action/command, which moves the unit/machine itself to the next state. The SC is activated when the appropriate unit/machine conditions are reached.
State Completed (SC) from EXECUTE state Complete	YES			The State Completed (Complete) is an internal unit/machine command, which moves the unit/machine from the EXECUTE state to the COMPLETING state and finally the COMPLETE state. The SC could be a unit/machine condition where the product counter is reached. This means the production order is complete.

Ver. 1.00 Page 56 of 97



Command	Issued			Comments
	On or by unit/ machine ²¹	By External interface	E-stop	HINT: The unit/machine can be forced via the external interface with a Stop command to complete the order, and if required empty its output buffer for products.
Stop	YES	YES		The Stop command will start the execution of logic which brings the unit/machine to the STOPPING state and finally to the STOPPED state. The operator can stop the unit/machine via the external interface or on the unit/machine HMI. The unit/machine will stop and make available parameter data via the PackML interface. The Stop command can be initiated from any state except
				ABORTED, ABORTING, CLAERING, STOPPING and STOPPED. This means, that the Stop command can be initiated within the grey area in the PackML interface state model (see Figure 9: The PackML Interface State Model). To finish production, an external Stop command can be sent to the unit, when the unit/machine is in EXECUTE, HELD, SUSPENDED, COMPLETE, or IDLE state and the unit/machine is in Production Mode.
Reset ²²	YES			The Reset command is activated by the operator on the unit/machine HMI. The operator has to initiate on the unit/machine that is ready for production and move the unit/machine into the IDLE state via the RESETTING state. The operator has to check that all safety issues are satisfied, and the unit/machine conditions are ready for production. The unit/machine can either be in the STOPPED or COMPLETE state when the Reset command is processed.
Abort			YES	The Abort command is to be handled automatically when the E-stop is activated on the Unit. The abort command can be executed at any state (see Figure 9 – the light grey and dark grey), and will change the unit/machine to the Aborting state and to the transitional state ABORTING and the secure state ABORTED. Operation of the emergency stop will cause the unit/machine to be tripped by its safety system and send an Abort command. It is to be determined, which technical solutions

 $^{^{22}}$ The Reset command is required to ensure that the unit/machine is safe to start from remote.

Ver. 1.00 Page 57 of 97



Command	Issued			Comments
	On or by	Ву	E-stop	
	unit/	External		
	machine ²¹	interface		
				that ensures the unit/machine to move and remain in ABORTED state.
Clear	YES			The clear command is used when the unit/machine has been stopped by an Abort command. The Clear command is activated on the unit/machine HMI to clear faults that may have occurred when ABORTING and were presented in the ABORTED state before proceeding to a CLEARING state and then the STOPPED state.

Ver. 1.00 Page 58 of 97



8.2 Specification of commands on unit HMI and from External system

The Machine Supplier should fill out the table below to identify what commands are possible to activate from unit HMI or External system via interface.

Table 16 Defined Commands

Command	PackML	Implemented on Unit					
	Tag	External	Unit push buttons	E-stop	Name on		
	Value	interface	and HMI		unit HMI		
No command	0	Optional	YES		N/A		
Reset	1	Optional	YES		Reset		
Start	2	Optional	YES		Start		
Stop	3	Optional	YES		Stop		
Hold	4	Optional	YES		N/A		
Unhold	5	Optional	YES		Restart		
Suspend	6	YES	YES		N/A		
Unsuspend	7	YES	YES		N/A		
Abort	8	Optional		YES	E-Stop		
Clear	9	Optional	YES		Reset E-Stop		

Hint: During the specification of a specific unit/machine, is it recommend use an empty version of Table 16, and fill in the specific Supplier dependent Machine commands and equivalent HMI names.

9. PACKML INTERFACE STATE DEFINITION

The Interface unit/machine State defines the current condition of a Unit. An Interface unit/machine State is expressed as the overall state for the unit/machine as seen through the HMI or external control system. The unit/machine could contain several internal controllers (PLC's or Drive controllers) but from the PackML point of view, the unit/machine will be seen as a single Unit.

The State is to be exposed as an Integer value as shown in Table 17 Fejl! Henvisningskilde ikke fundet..

When a unit/machine is powered on it will start in the STOPPED state.

Ver. 1.00 Page 59 of 97



Table 17: Interface unit/machine state definitions

State name	PackML	Description
	Tag Value	
IDLE	1	This is a state which indicates that Resetting is complete. The unit/machine is ready for new production and machine parameters can be received. If an error occurs on the unit, the unit/machine will enter the STOPPING state and end in STOPPED state. In the IDLE state the unit/machine is approved for safety issues and ready for production. The unit/machine can allow, in the IDLE state, a remote Start command from external system. It is to end User responsibility to ensure that company safety is followed for external
		Start commands.
STARTING STARTING	3	This state provides the steps needed to start the unit/machine and is a result of a Start command. The starting logic will load the unit/machine parameters into the Machine Control and move the unit/machine into the EXECUTE state if parameters were loaded correctly. The starting logic will ramp up speed, pressure, etc. to be ready for production. Otherwise, if there were errors in the loaded data, the starting logic will move the unit/machine into the STOPPING state and the unit/machine will end in STOPPED state. The unit/machine is not allowed to change state to EXECUTE unless the Start command is received. If an error occurs on the unit, the unit/machine will enter the STOPPING state and end in the STOPPED state.
		Actions to be taken during the STARTING state are to be specified by the Machine Supplier and End User.
EXECUTE	6	Once the unit/machine is producing materials it is in the EXECUTE state. The machine / unit/machine is running with all conditions met, as defined by the selected MODE and / or recipe selected.
COMPLETING	16	This state provides the steps needed to complete the job, such as the result of a product counter value has been reached in the unit. Corrected parameters (Recipe Control Parameters) on the unit/machine by the operator can be made available to the external system. The machine parameters can be used by the external system to get information about manual changed or corrected data on the unit/machine during execution. The Machine Supplier and End User have to specify the special conditions that have to take place, when the unit/machine enters the COMPLETING and COMPLETE state. For example, does the unit/machine empty its internal product buffers, or does the unit/machine stop immediately with products within the unit. Actions to be taken during the COMPLETING state will be specified by the Machine Supplier and End User.

Ver. 1.00 Page 60 of 97



State name	PackML Tag Value	Description			
COMPLETE	17	The unit/machine has finished the COMPLETING state and is now waiting for a Reset command before transitioning to the Resetting state. The unit/machine is powered and all data is still represented within the unit. The unit/machine is ready to be reset.			
RESETTING	15	The RESETTING state will start the resetting process, which typically cause the unit/machine to clear data and to place the unit/machine in an IDLE state, where the unit/machine components are energized waiting for a Start command. By resetting the Unit, the data (recipe & parameters) is cleared and the unit/machine is ready for new machine parameters. For example, the operator may have changed tooling and by activating the Resetting process the operator has indicated that the machine is ready for production. Actions to be taken during Resetting will be specified by the Machine Supplier and End User.			
HOLDING	10	The HOLDING logic brings the unit/machine to a controlled stop or to a state which represents HELD for the particular Unit. This is internal control logic that is executed when an error/fault occurs on the unit/machine or an operator initiates a Hold command from unit/machine HMI. The Holding control logics changes the unit/machine from the HOLDING state to the HELD state. The E-stop is an exception, which are handled separately and not part of the Holding logic. See state Aborting and ABORTED.			
HELD	11	The HELD state holds the Unit's operation while material blockages are cleared or enables the safe correction of an equipment fault before the production may be resumed. To be able to restart production correctly after the HELD state, all relevant process set-points and return status of the procedures at the time of receiving the Hold Command must be saved in the unit/machine controller when executing the Holding procedure.			
UNHOLDING	12	The UNHOLDING state is a response to an operator command to resume production. The control logic in the UNHOLDING state prepares the unit/machine to re-enter the normal EXECUTE state. The Unholding logic will ramp up speed, pressure, etc. to be ready for production.			
SUSPENDING 13 SUSPENDING		This SUSPENDING state is required prior to the SUSPENDED wait state, and prepares the unit/machine to suspend, for example it may stop ironing, stop cutter, stop debagger, etc. The unit/machine may be running at a relevant set point speed, but there is no product being produced for the next unit/machine downstream. During the controlled sequence of Suspending the unit/machine will transition to a SUSPENDED state.			

Ver. 1.00 Page 61 of 97



State name	PackML Tag Value	Description
		The Machine Supplier and End User must specify the special conditions that have to take place when the units enter the SUSPENDING and SUSPENDED state. For example, does the unit/machine fill up its internal product buffers, or does the unit/machine stop immediately. Suspending is the result of starvation of material within the in-feeds or a result of saturation related out-feed blockage that prevents the unit/machine from Executing continued steady production. The SUSPENDING state might be forced by the operator via the external interface, when the operator needs to have a break or suspends due to external events.
SUSPENDED	5	The SUSPENDED state can be reached as a result of external process conditions. In the SUSPENDED state the unit/machine is waiting for external process conditions to return to normal and then transition to UNSUSPENDING State and then the normal EXECUTE state.
UNSUSPENDING UNSUSPENDING	14	This state is a result of a unit/machine generated request from the SUSPENDED state to go back to the EXECUTE state or an Unsuspend command via the external interface. This state is done prior to EXECUTE state, and prepares the unit/machine for the EXECUTE state. The actions of this state may include ramping up speeds, turning on vacuums, and the re-engagement of clutches. The actions to be taken when the unit/machine enters the UNSUSPENDING state are to be defined by the Machine Supplier and End User.
Stopping STOPPING	7	This state executes control logic which brings the unit/machine to a controlled stop as reflected by the STOPPED state. The Machine Supplier and End User must specify the special conditions that have to take place when the unit/machine enter the Stopping and STOPPED state. For example, does the unit/machine empty its internal product buffers, or does the unit/machine stop immediately.
STOPPED	2	The unit/machine is powered and stationary after completing the STOPPING state. All communication with other systems is functioning. The unit/machine is powered and all parameters is still represented within the unit. The unit/machine is ready to be reset. Normal Starting of the unit/machine cannot be initiated unless Resetting had taken place.
Aborting	8	The ABORTING state can be entered at any time as a response to an Abort command. The Aborting logic will bring the unit/machine to a

Ver. 1.00 Page 62 of 97



State name	PackML	Description		
	Tag Value			
ABORTING		rapid safe stop. The Aborting logic will provide the necessary actions to move the unit/machine into the ABORTED State. The actions to be taken when the unit/machine enters the ABORTING state are to be defined by the Machine Supplier and End User.		
ABORTED	The unit/machine in this state has to maintain unit/machin information. The unit/machine can only exit the ABORTED state after an			
Clearing CLEARING	1	Within the CLEARING state the operator clears the safety system and moves the unit/machine into the STOPPED state. The unit/machine clears faults that may have occurred when Aborting and are presented in the ABORTED state before proceeding to a STOPPED state.		
		The unit/machine will make available machine parameters to the external system. The machine parameters are available in order to get information about eventual manual changes and corrections of data on the Unit.		
		The actions to be taken when the unit/machine enters the CLEARING state are to be defined by Machine Supplier and End User.		

Ver. 1.00 Page 63 of 97



10. Unit control modes

A unit/machine can be in different modes, for example Production, Maintenance, Manual, Clean, Jog Mode, etc.

A Unit control mode is an ordered subset of states and commands that determines the strategy to be carried out by the unit/machine process.

This means that the PackML interface State Model above may be represented differently in different modes. The PackML Interface State Model must be implemented fully for Production mode, and can be partly implemented for manual and maintenance mode. In the Manual mode all communication with external systems that can manipulate the unit/machine are disabled. Within Manual mode the operator can take over control of the unit via the unit HMI without a connection to an external system.

The Machine Supplier must specify which modes besides Production, Manual and Maintenance are available.

The Unit Control modes shall be exposed as an Integer, as defined in Table 18.

It is up to the Machine Supplier and End User to define the starting mode after power on, foe example STOPPED or IDLE.

Table 18 Mandatory and optional Unit/machine modes

PackML Tag Value	Mode	PackML State Model	Restricted Access	Use		
1	PRODUCTION	Mandatory	Primary Mode used for all production activities, All PackML model states will be utilized. PackTags are a and reporting. The unit/machine executes relevant in response to commands which are mainly coming External Systems, or entered directly by the operator			
2	MAINTENANCE	Optional	YES	Used for routine preventive Maintenance or planned maintenance. Shall be utilized to document planned maintenance occurrence and duration. This mode allows authorized personnel to run the unit/machine independent of other systems. This mode would typically be used for fault finding, machine trials, or testing operational improvements. For example: The cleaning of a print head is maintenance.		
3	MANUAL	Optional	YES	Used for fault diagnosis of unplanned technical intervention. HINT: In Manual Control mode, it is not necessary to implement all PackML states.		

Examples of user defined PackML Modes

Further Unit Control Modes might be available on the unit/machine, but the unit need not follow the PackML Interface State Model in these other Unit Control Modes .

Ver. 1.00 Page 64 of 97



4	CHANGE OVER	Optional	NO	Can be used specifically for format or recipe change over, includes "cleaning" operations.			
5	CLEAN	Optional	NO	Can be used for Routine Cleaning requirements example: as specified by factory maintenance procedures.			
6	SET UP	Optional	Optional restriction	Can be used for set up or adjustments example: mechanical adjustments and testing			
7	EMPTY OUT ²³	Optional	NO	Would be used to empty out machine example: end of a block of shifts prior to factory weekend shut down, empty out resident product within the machine that could be sent to finished product and minimize part finished "rework".			
To be defined	OEM specific	Optional	YES	Would be used for OEM ONLY, all settings that are required for the machine, and likely NEVER be needed b any customer.			
To be defined	÷.	Optional	?	?			

Hint: The mode change²⁴ only takes place, when the unit/machine is in STOPPED state. This means that exit and enter modes are in STOPPED state. The mode change will not make any change in PackML state. Therefore, a unit/machine in production mode and stopped state will enter for example Maintenance mode in STOPPED state. The mode change can also happen in ABORTED state, when entering Manual mode. The exit to Manual mode, is with restrictions because of safety issues.

Ver. 1.00 Page 65 of 97

²³ The mode change to mode EMPTY OUT might require a change in the EXECUTE state. This mode change can be done manual by operator or automatically by the unit/machine when it reaches the end of production order.

 $^{^{24}}$ According to ISA-TR88.00.02-2015 is it allowed to change mode in all PackML wait states.






Figure 33 Recommended PackML states in which mode changes can be made

11. PACKTAGS

PackTags provide a uniform set of naming conventions for data elements used in the base state model. PackTags are named data elements used for open architecture, interoperable data exchange in automated machinery. This document includes the End Users minimum set of the data elements and their data types, defined in Table 19. PackTags are useful for communication between machines, as well as for exchange of data between machines and higher-level information systems.

Hint: Use the Pascal Case where the first letter of each word in an identifier is capitalized for readability. In order to ensure inter-operability with all systems, IEC 61131 is not case sensitive and therefore, it is recommended that the Pascal Case format is followed. Optionally, underscores ("_") may also be used in place of the "dot" notation for legacy systems that do not support structured tagnames.

The table below indicates the minimum set of PackTags that the End Users recommend Machine Suppliers to implement. Of course, it is allowed for Machine Suppliers to implement additional PackTags. The minimum set of PackTags required are indicated in the column "End user Minimum tags".

Ver. 1.00 Page 66 of 97



Table 19: Minimum PackTags²⁵

PackTag type	PackTag	Example of End user term	Datatype	TR 88.00.02 Minimum tags	End user Minimum tags
Status	StateCurrent	State	INT(32)	Х	Х
Status	UnitModeCurrent	Mode	INT(32)	Х	Х
Status	MachSpeed	Nominal Speed	REAL	Х	Х
Status	CurMachSpeed	Current Speed	REAL	Х	Х
Status	EquipmentInterlock.Blocked	Blockage	BIT	Х	Х
Status	EquipmentInterlock.Starved	Starvation	BIT	Х	Х
Status	Parameter [#]	Machine data/parameter	Array Structure		Х
Status	Parameter[#].ID	Parameter ID	INT(32)		Х
Status	Parameter[#].Name	Name of parameter	STRING		Х
Status	Parameter[#].Unit	Unit of measure	STRING[5]		Х
Status	Parameter[#].Value	Value of parameter	User Defined		Х
Status	RemoteInterface.Parameter[#]	Additional production data	Structure		Х
Status	RemoteInterface.Parameter[#].ID	Parameter ID	INT(32)		Х
Status	RemoteInterface.Parameter[#].Name	Name of parameter	STRING		Х
Status	RemoteInterface.Parameter[#].Unit	Unit of measure	STRING[5]		Х
Status	RemoteInterface.Parameter[#].Value	Value of parameter	REAL		Х
Admin	Warning[#]	Warning	Array Structure		Х
Admin	Warning[#].Trigger	Trigger	Bool		Х
Admin	Warning[#].ID	ID	Int (32bit)		Х
Admin	Warning[#].Value	Value	Int (32bit)		Х
Admin	ProdDefectiveCount	OEE.Bad count	INT(32)	Х	Х
Admin	ProdProcessedCount	OEE.Total count	INT(32)	Х	Х
Admin	StopReason.ID	Event and stop reason	INT(32)	Х	Х
Admin	StopReason.Value	Detailed Error Information	INT(32)		Х
Command		Command	INT(32)	Х	Х
Command	Parameter [#]	Machine data/parameter	Array Structure		Х
Command	Parameter[#].ID	Parameter ID	INT(32)		Х
Command	Parameter[#].Name	Name of parameter	STRING		Х
Command	Parameter[#].Unit	Unit of measure	STRING[5]		Х
Command	Parameter[#].Value	Value of parameter	User Defined		Х
Command	RemoteInterface.Parameter [#]	Additional Production data	Array Structure		Х
Command	RemoteInterface.Parameter[#].ID	Parameter ID	INT(32)		Х
Command	RemoteInterface.Parameter[#].Name	Name of parameter	STRING		Х
	RemoteInterface.Parameter[#].Unit	Unit of measure	STRING[5]		Х
	RemoteInterface.Parameter[#].Value	Value of parameter	REAL		Х
	UnitMode	Mode	INT(32)	Х	Х
Command	UnitModeChangeRequest	Change mode	BOOL	Х	Х
	MachSpeed ²⁶	Mach Speed	REAL	Х	Х
	CmdChangeRequest	Change command	BOOL	X	Х

X = Supported.

Ver. 1.00 Page 67 of 97

 $^{^{25}}$ ANSI/ISA 88.00.02-2015 is the reference for all PackTags.

²⁶ In case the unit/machine is able to run different products with different sizes of primary packages within one line, the calculation and view of MachSpeed needs to be part of the Machine Recipe Parameters, to help the operator to understand the machine and its speed. The reason is that the speed of e.g. a small feeding system may change because the primary package size changes.



11.1 DESCRIPTION AND DEFINITION OF PACKTAGS

See details about the PackTags in the reference ANSI/ISA-TR88.00.02-2015, $Machine\ and\ unit/machine\ States$, $An\ Implementation\ example\ of\ ANSI/ISA-88.00.01$.

Ver. 1.00 Page 68 of 97



12. Example of Unit Controller Functionality

The elements in this section illustrates eight main functions for the Unit Controller functionality:

- 1. Prepare unit/machine (Prepare for production)
- 2. Start unit/machine (Start production)
- 3. Stop unit/machine (Stop production)
 - a. Stop unit/machine (Stop production)
 - b. Complete unit/machine (Complete production)
- 4. Pause on unit/machine
- 5. Stop and restart unit/machine
- 6. Download new machine parameters (Order change)
- 7. Error and warnings on unit/machine
- 8. Safety circuit activated

The illustrations below are based on one unit, with material flows from upstream units and to downstream units.

12.1 SYNTAX AND SYMBOLIC DESCRIPTION

Below is an illustration of the syntax and symbolic used in the use case scenarios.




Figure 34: syntax and symbolic for use case scenarios

Ver. 1.00 Page 69 of 97



12.2 Prepare unit/machine

The operator indicates that the unit that it is ready for production and moves the unit into the IDLE state via Resetting state. The operator has to check that all safety issues are satisfied and that the unit conditions are ready for production.

Prepare unit/machine




Figure 35: Prepare unit/machine for production




Figure 36: The states in the PackML statemodel in focus for Prepare unit/machine

Ver. 1.00 Page 70 of 97



12.3 START UNIT/MACHINE

The operator starts the unit/machine for production from the unit panel/HMI or from an external system. When the operator starts the selected program on the unit/machine, the parameters are loaded into the unit. The unit/machine parameters can either be typed in on the unit/machine panel/HMI or the parameters can be downloaded to the unit/machine from an external system.

The operator or the external system starts the unit/machine according to the PackML standard.




Figure 37: Start unit/machine from unit panel/HMI

Ver. 1.00 Page 71 of 97






Figure 38: Start unit/machine from external system




Figure 39: The states in the PackML statemodel in focus for Start unit/machine

Ver. 1.00 Page 72 of 97



12.4 STOP UNIT/MACHINE FROM UNIT PANEL/HMI

The unit can move to the COMPLETE state when the product counter reaches the designated value in the machine parameters. The unit will complete processing, empty, and stop producing products and then enter the COMPLETE state.

Hint: It can be necessary to define what is going to happen at the unit if there is remaining products on the inlet/infeed when the unit is completing.

Hint: The Machine Supplier and End User of a unit/machine need to define if a unit/machine needs to be stopped after a completion of a production order (product counter reached according to a production order). It may depend on when the unit/machine parameters are downloaded or typed into the unit/machine by operator.

Hint: A unit/machine in suspended state because of starvation can only complete the production order by a stop command from the operator – either on the unit/machine itself or from the supervisory control system.




Figure 40: Completion from unit

Ver. 1.00 Page 73 of 97






Figure 41: The states in the PackML statemodel in focus for Completion from unit

12.5 STOP UNIT/MACHINE FROM EXTERNAL SYSTEM


An external system can continuously acquire the number of produced products from the units. The external system also knows the number of products in the process. The external system can compare the number of produced products with the parameter value received from production order data. When the number of products equals the parameter value (100%), then the external system can send a message to the operator.

The operator can stop the unit or the production can be stopped from the external system. The unit will stop, enter the STOPPING state, empty out (if necessary) and stop production and enter the STOPPED state. When the unit stops and has completed the production, the unit/machine parameters can be uploaded into the external system.

Hint: It can be necessary to decide what is going to happen at the unit if there are remaining products on the inlet/infeed, when the unit is stopping.

Ver. 1.00 Page 74 of 97





Unit 1 is Stopping and if required sends the current unit/machine parameters to External System. When the state actions are complete the unit/machine performs a State Completed (SC) and enters into state STOPPED.

Figure 42: Completion from External system




Figure 43: The states in the PackML statemodel in focus for Stop Order from External System

Ver. 1.00 Page 75 of 97



12.6 OPERATOR BREAK AND PAUSE ON UNIT/MACHINE

The operator decides to make a temporary stop and the unit/machine is suspended. Suspension of a unit/machine is typically used for shorter breaks or meetings.

The external system can suspend the unit.

Hint: The machine Supplier and End User need to decide what is going to happen with the OEE parameters in the unit.

The StopReason for the unit stop is to be generated directly in the units, and is sent unchanged to the external system.

It is also to be defined if the products can remain in the unit or the unit has to empty out.




Figure 44: Operator break from External System

Ver. 1.00 Page 76 of 97






Figure 45: The states in the PackML state model in focus for Operator break from External System²⁷

12.7 RESUME UNIT/MACHINE AFTER BREAK FROM EXTERNAL SYSTEM

The operator restarts (unsuspend) the unit/machine. The External system unsuspends the unit by sending an Unsuspend command. The unit/machine will enter the EXECUTE state.

Ver. 1.00 Page 77 of 97

 $^{^{\}rm 27}$ The unit/machine Supplier dependent Machine State mode is able to be Stopped.






Figure 46: Resume unit/machine after break




Figure 47: The states in the PackML statemodel in focus for resume unit/machine after break

12.8 STOP UNIT FROM UNIT PANEL/HMI

The operator stops the unit/machine by pressing Stop on the panel/HMI on the unit/machine. When the operator want to start the unit, the operator has to reset the unit, and make the unit ready for production. The illustration below illustrates that an error condition has required that the operator stops the unit. Normally, when an error occurs on the unit, the unit will enter the HELD state. As an example, this could happen in a situation, where the unit is running without the correct packaging material.

Ver. 1.00 Page 78 of 97






Figure 48: Stop unit from unit




Figure 49: The states in the PackML state model in focus for Stop Unit

Ver. 1.00 Page 79 of 97



12.9 ABORT UNIT/MACHINE

The operator press E-stop on a unit/machine. The operator fixes what may be wrong on the unit/machine. It is not recommended to use E-stop to make a stop on a unit because the E-stop is not a controlled stop, as is done in stopping or holding. When the E-stop issue is corrected the operator clears the safety circuit, and resets the unit/machine, and finally makes the unit ready for execute production.

Unit Unit 3 External system monitors unit states. State=Any state Unit 1 Operator open safety door or presses E-stop on Unit 1. E-stop The unit performs an Abort command. **Abort command** Unit 1 State=Aborting Unit 1 is aborting and when the state actions are SC complete the unit performs a State Completed Unit 1 (SC) and enters into state ABORTED. State = ABORTED Operator fix problem on Fix problem Unit 1. Operator Clear safety **Clear Safety** circuit on Unit 1 circuit Clear command Unit 1 State=CLEARING Unit 1 Operator reset Unit 1 by State = STOPPED pressing a "RESET" button on **Press RESET** Unit 1. The unit performs a button Reset command. Reset command Unit 1 Unit 1 Unit 1 is Resetting and when the state actions State = RESETTING are complete the unit performs a State Unit 1 Completed (SC) and enters into state IDLE. State = IDLE

Figure 50: Abort Unit

Ver. 1.00 Page 80 of 97






Figure 51: The states in the PackML state model in focus for Aborting and resetting Production

12.10 RE-START UNIT FROM UNIT PANEL/HMI AFTER STOP OR ABORT

It is possible to restart the unit from the unit panel/HMI.

Below is illustrated the situation when the operator starts the unit from the unit panel/HMI. The operator presses start on the unit. The unit restores parameters and it will enter the EXECUTE state.




Figure 52 Re-start unit from unit after stop or abort

Ver. 1.00 Page 81 of 97






Figure 53: The states in the PackML state model in focus for Re-start unit from unit panel/HMI.

12.11 RE-START UNIT FROM EXTERNAL SYSTEM AFTER STOP OR ABORT

It is also possible to restart the unit from the External System.




Figure 54: Re-start Unit after stop or abort

Ver. 1.00 Page 82 of 97






Figure 55: The states in the PackML state model in focus for re-start Unit from external supervisory system.

12.12 ALARM AND WARNING ON UNIT

The data flow for an alarm is shown on Figure 58. All alarm and warning data sent from the unit must be defined and described, if an external system needs to use the alarm and warning data for HMI or Historian purpose.

The operator can be directed to a unit/machine to a situation, were an alarm or warning is activated. Depending on the situation the unit/machine has to perform certain actions. The actions to be taken can be defined in an event state management table. See more in section 12.12.1. The reason for the event state management table, as shown in Table 20, is the possibility to handle different interpretations of alarms and warnings between different End Users. End Users may not all agree on what is an alarm and a warning, therefore a table gives the flexibility to Machine Suppliers to map to current End Users requirements.

For example the End Users definitions could be as follows:

Internal Event:

- Unit/machine alarm e.g. drive failure
- Unit/Machine warnings e.g. Missing packaging material

Configure internal Events in categories:

- Safety related Event: Alarm
- Non Safety related events: Alarms and Warnings (technical)
- Material related Event: Alarm and Warning

Ver. 1.00 Page 83 of 97



12.12.1 PackML alarm and event state management table

It is possible to create a table that allows Machine Suppliers to configure which types of alarms and events will lead to a state change. It can be used to document when a machine should switch to the states in the PackML state model. It is especially useful when the unit has to jump to HELD, STOPPED, SUSPENDED and ABORTED, because the End Users sometimes have different interpretations and expectations of when the different states should be entered.

Alarm / Event	State change ID = Commands	Reaction
1	8	Abort
2	8	Abort
3	4	Held – Error on material
4	4	Held – Error on glue
5	3	Stop – Drive failure
6	3	Stop – Sensor failure
7	6	Suspend - Blocked
8	6	Suspend – Queue
9	20	Pop-up information on HMI – Executing state
10	20	Pop-up information on HMI – Executing state

Table 20: Example Alarm/Event state management table

External system monitors unit states.




Figure 56: Alarm on unit

Ver. 1.00 Page 84 of 97



The data flow for warnings is shown below.

Hint: All warning data sent from the unit must be defined if the external system needs to use the alarm data.




Figure 57: Warning on unit

Note: Alarms and warnings can be sent in any PackML state, therefore all PackML states are in focus.




Figure 58: The states in the PackML statemodel in focus for alarm and warning handling

Ver. 1.00 Page 85 of 97



12.13 BACKGROUND TASK: OEE

This example illustrates the data flow of raw data for OEE calculations. The unit generates the data, which is made available to the external system using the PackTags: StopReason.Value, ProdDefectiveCount, ProdProcessedCount.

In this situation the unit/machine only sends OEE parameters as PackTags and all calculation of OEE KPIs are performed by an external system for OEE analysis.




Figure 59: Background task - OEE

Note: OEE data can be sent in any PackML state, therefore all PackML states are in focus.




Figure 60: The states in the PackML statemodel in focus for Background Task: OEE

Ver. 1.00 Page 86 of 97



12.14 BACKGROUND TASK: MODE & STATE

In this example the PackML state and mode is available from a unit. The external system can collect the state and mode from the unit and can use it generate an overview of the unit or an entire line of units.




Figure 61: Change mode or state, and the unit will send Mode & State information




Figure 62: Send Mode & State information

Note: State and Mode can be send in any PackML state, therefore all PackML states are in focus.

Ver. 1.00 Page 87 of 97






Figure 63: The states in the PackML statemodel in focus for mode & state reporting

Ver. 1.00 Page 88 of 97



12.15 Suspend: Starvation or Saturation

In this example, a product queue guard on a unit detects starvation or saturation (blockages, queue) and the unit enters the SUSPENDED state.




Figure 64: Suspend Production because of starvation or saturation




Figure 65: The states in the PackML state model in focus for Suspending Production

Ver. 1.00 Page 89 of 97



12.16 Unsuspend

When the queue guard on a unit no longer detects starvation or saturation (blockages, queue) it unsuspends to return to the EXECUTE state.




Figure 66: Re-start Production after suspension




Figure 67: The states in the PackML statemodel in focus for Unsuspending production.

Ver. 1.00 Page 90 of 97



13. Reference information

13.1 DEFINITIONS AND ABBREVIATIONS

Table 21 List of definitions and abbreviations

Abbreviation	Description	Explanation
FAT	Factory Acceptance Testing	Test of the unit/machine being carried out before delivery.
		The test is carried out to ensure that delivery is in
		accordance with stated requirements.
FMEA	Failure Mode and Effect	A FMEA is often the first step of a system reliability study. It
	Analysis	involves reviewing of as many components, assemblies, and
		subsystems as possible to identify failure modes, and their
		causes and effects.
HMI	Human Machine Interface	Human machine interface is the part of the unit/machine
		that handles the human to machine interactions.
I/O test	Input / Output test	I/O test is a test of electrical connection at place of
		installation.
ISA	The International Society of	ISA is a non-profit technical society for engineers,
I	Automation	technicians, businesspeople, educators and students, who
I		work, study or are interested in industrial automation and
		pursuits related to it.
SCS	Supervisory Control System	Manufacturing Execution System (MES)
		System software to integrate customer orders in the ERP
		system and to program sequences for SCADA and PLC
		systems.
		Supervisory Control and Data Acquisition (SCADA)
		The SCADA system normally log data from units/machines
		and monitors the unit status. The SCADA is often a HMI for
		a set of units/machines put together in a Production Line.
		Line Controller (LC)
		Line Controller can be part of a Supervisory Control System.
		A Line Controller controls a number of Units in a line.
		The Supervisory Control System could be a PLC or part of
		existing PLC, PC or Server.
OEE	Overall Equipment	OEE measurement is commonly used as a key performance
	Effectiveness	indicator (KPI) in conjunction with manufacturing efforts to
		provide an indicator of success.
OEM	Original Equipment	OEM are manufacturing products or components bought by
	Manufacturer	another company and sold under the purchasing company's
		brand or company name.
OMAC	Organization for Machine	OMAC is the organization for automation and
	Automation and Control	manufacturing professionals that is dedicated to supporting
		the machine automation and operation needs of
		manufacturing.
PackML	Packaging Machine	The primary objective of PackML is to bring a common
	Language	"look and feel" and operational consistency to all machines.

Ver. 1.00 Page 91 of 97



Abbreviation	Description	Explanation	
PackML GW	PackML Gateway	A gateway that represents the PackML Interface State	
		Manager and maps to the existing Machine State Manager	
		of a specific machine (unit/machine).	
PackML SDS PackML Software Design Function specification for a unit/machi		Function specification for a unit/machine, that specifies the	
	Specification	behaviour of a unit/machine and specifies the Interface to	
		the unit/machine from a PackML prospective.	
PackTags	PackML data identifier	PackTags are data elements that have been defined by the	
		OMAC Packaging Workgroup to facilitate easy data	
		exchange between packaging machines.	
PLC Programmable Logic A computer controlling instruments, mo		A computer controlling instruments, motors, valves, etc.	
	Controller		
SAT	Site Acceptance Testing	Test of the unit/machine being carried out on the site	
		where it is installed. The test is carried out to ensure that	
		delivery is in accordance with stated requirements.	
TR 88.00.02	Technical Report	Technical Report is an informative document on S88	
		implementation on discrete machines – It is the	
		specification of PackML.	

13.2 REFERENCES

Table 22 List of references

Ref. no.	Document
[S88-1]	ANSI/ISA-88.00.01-2010, Batch Control, Part 1: Models and Terminologies.
[TR88]	ANSI/ISA-TR88.00.02-2015, Machine and unit/machine States, An Implementation example of ANSI/ISA-88.00.01.
[S88-5]	ISA/DRAFT-88.00.05-2013, Working Draft 08, Batch Control, Part 5: Implementation Models & Terminologies for Modular Equipment Control.

Ver. 1.00 Page 92 of 97



13.3 List of People involved in Preparation of the Guideline

The following people served as active participants in preparation of this technical report:

Table 23 List of people involved in the preparation of this technical report

Name	Surname	Company
Joachim	Bergmeyer	A+F Automation
Engelbert	Freiberger	Alpma
Jürgen	Wegscheider	Alpma
Arne	Svendsen	Arla Foods
Claus	Norup	Arla Foods
Enrico	Paolucci	B&R
Lazarus	Patsakas	B&R
Miodrag	Veselic	B&R
Sari	Germanos	B&R
Rob	Rawlyk	Beckhoff
Pascal	Witprächter	Bosch
Wolfgang	Martin	Bosch
Carl	Bostrom	Bosch Rexroth
Thomas	Haberkorn	Bosch Rexroth
Imbriaco	Giacomo	Coesia Engineering Center
Peder	Stocklund	Coloplast
Arthur C.	Smith	Coming
Emilian	Axinia	COPA-DATA
Van Dam	Maarten	COPA-DATA
Pierre	Henri	Danone Engineering Worldwide
Pasquali	Stefano	Gebo Cermex.
Fabian	Elsässer	Harro Höfliger
Manfred	Zoehrer	Haas Food Equipment
Karsten	Vollmer	KHS
Andreas	Gschrey	Krones
Christian	Rott	Krones
Uwe	Keiter	Lenze
Christoph	Riedmann	Lti-motion
Frank	Polky	Mars
Lee	Smith	Mettler Toledo
Heinz-Hermann	Bruemmer	Meurer
Jochen	Schohaus	Meurer
Malte	Schlüter	Mitsubishi
Claus	Botzenhardt	Multivac
Fabrice	Bertin	Nestlé

Ver. 1.00 Page 93 of 97



Name	Surname	Company
Geoff	Gooding	Nestlé
Jean-Claude	Pourchet	Nestlé
Kris	Matlock	Nestlé
Markus	Gehrke	Nestlé
Peter	Jarlvik	Norden Machinery
Carlos	Ruiz	Omron
Josep	Lario	Omron
Adal	Tecleab	P&G
Jason	Debruler	P&G
Jim	Blundy	P&G
Paul	Southman	P&G
Jay	Joyner	P&G
Mark	Ruberg	Pro Mach
Gord	Davison	Pro Mach
Gunther	Saelzer	Rockwell Automation
Christian	Chatel	Schneider Electric
Rainer	Beudert	Schneider Electric
Anthony	Esnault	Serac
Carsten	Nøkleby	SESAM-World
Michel-René	Kübler	SEW-EURODRIVE
Heiko	Soehner	Siemens
Kim	Meyer-Jacobsen	Siemens
Mike	Pieper	Siemens
Uwe	Zell	SIG Combibloc
Thomas	Rummel	Softing
Filippo	Sarafini	Tetra Pak
Heinrich	Iben	Tetra Pak
Kasper Korsholm	Christiansen	Velux
Ole	Riis	Velux
David	Tobon	Yaskawa

Ver. 1.00 Page 94 of 97



13.4 Support

The preparation of this document is supported by **Mitsubishi Electric**, **Arla Foods** and **SESAM-World**.

13.5 THE AUTHOR

Carsten Nøkleby is a senior consultant with focus on Automation and Production IT. The consulting jobs are done for customers like Arla Foods, Tetra Pak, Novo Nordisk, Nestlé, Grundfos, Velux, Baader & Linco and many more. The consulting is related to strategic and tactical issues related to the introduction computers and new business processes on the factory floor. The technical systems handled by Carsten Nøkleby are PLC, SCADA, DCS and MES.

Carsten Nøkleby is responsible for running the Industrial networks SESAM Sverige and SESAM Danmark with approx. 3.000 members. The network has its focus on distributing knowledge between the members. The main focus in on Automatization and Digitalization of manufacturing processes.

Carsten Nøkleby made a Ph.D. Thesis in 1992 at the Technical University of Denmark. The title was "Structure and Information for a flexible assembly cell – Issues in the analysis, design and implementation of virtual manufacturing devices for remote controlled application processes".

The visionary

I have always worked with the Smart Industry applications. From the old days we called it Computer Integrated Manufacturing during my Ph.D. What we see today is more emphasis on integration of people, machinery, equipment and products. The internet is here and IoE is the future. The potential of combining existing and new technology with business processes and culture will make the change in the manufacturing environment.

Ver. 1.00 Page 95 of 97



14. VERSION HISTORY

Table 24 Version log

Date [YYYY-MM-DD]	Initials	Description	Version
2015-12-10	CAN	First version – Input from OMAC workshops in 2015	01A
2016-03-11	CAN	Second version – Document rewritten based on the definition of terminology and scope defined by the OMAC working group	02A
		 Claus Norup, Arla Foods Arne Svendsen, Arla Foods and OMAC Kris Matlock (Nestlé) Pascal Witprächtiger, Bosch Packaging Uwe Keiter, Lenze and OMAC Malte Schlüter, Mitsubishi Electric 	
2016-03-18	CAN	Sections added:	02B
2010 03 10	C/ IIV	 Understand and define a Unit The PackML Interface State Model List of participants 	025
2016-03-22	CAN	Review comments from Uwe Keiter and Claus Norup Section added: Section 6.1 The syntax of the PackML State Model Section 7 PackML Event State Manager Section 8 PackML Control Command definitions Section 9 PackML Interface State definitions	02C
2016-04-08	CAN	 unit/machine control modes PackTags Overview of use case scenarios 	02D
2016-04-21	CAN	Final version for review of whole reference group	02E
2016-06-23	CAN	All 262 received review comments are put into the document.	03A 03B
		 All figures are made neutral and the HMI part is presented in a separate section. All the comments on the workshop 21st and 22nd June at Arla Foods Copenhagen. 	03K
2016-08-01	CAN	The document have been review by Sofie Ambrosius, Arla Foods.	03L
2016-08-03	CAN	Minor details changed, e.g. participationlist and mapping alarms to event triggers to PackML	03M
2016-08-04	CAN	Review and minor details are changed.	03N
2016-08-05	CAN	Final version for 2 nd review	03O 03P
2016-10-13	CAN	Review comments are included. The comments are from the companies: Alpma, Arla Foods, BoschRexRoth, COPA-DATA, Corning, Krones, Mettler-Toledo, Nestlé, SEW-Eurodrive and Siemens.	03Q 03Y
2016-11-02	CAN/DB	Linguistic review by Dennis Brandl, BR&L Consulting	1.00

Ver. 1.00 Page 96 of 97



Ver. 1.00 Page 97 of 97