Step 1. Download
Download Quartus Prime software Lite edition (free version)

https://www.altera.com/downloads/download-center.html

* Altera Account has to be created
* software size 5 GB but requires around 15 GB space in computer(both Linux or Windows)

Step 2. INSTALL

Install with default settings (make sure Cyclone IV is checked while installing)

Step 3.

For Linux - 64 bit users
Type following commands in the terminal (this will be required for Modelsim)

```
sudo apt-get install libxft2
sudo apt-get install libxft2:i386
sudo apt-get install libcurses5
sudo apt-get install libcurses5:i386
sudo apt-get install libxtst6
sudo apt-get install libsm6:i386
sudo apt-get install libxtst6:i386

sudo dpkg --add-architecture i386
sudo apt-get update
sudo apt-get install build-essential
sudo apt-get install gcc-multilib g++-multilib lib32z1 lib32stdc++6 lib32gcc1 \
expat:i386 fontconfig:i386 libfreetype6:i386 libexpat1:i386 libc6:i386 libgtk-3-0:i386 \
libcanberra0:i386 libpng12-0:i386 libice6:i386 libsm6:i386 libncurses5:i386 zlib1g:i386 \
libx11-6:i386 libxau6:i386 libxdmcp6:i386 libxext6:i386 libxft2:i386 libxrender1:i386 \
libxt6:i386 libxtst6:i386
```

*some of them might not install but that's fine

Step 4. Drivers Installation

Linux users

Make a file named - "51-usbblaster.rules"
and paste the following lines

```
# For Altera USB-Blaster permissions.

# USB-Blaster II
SUBSYSTEM=="usb", ENV{DEVTYPE}=="usb_device", ATTRS{idVendor}=="09fb", ATTRS{idProduct}=="6010", MODE="0666", SYMLINK+="usbblaster2/%k"
SUBSYSTEM=="usb", ENV{DEVTYPE}=="usb_device", ATTRS{idVendor}=="09fb", ATTRS{idProduct}=="6810", MODE="0666", SYMLINK+="usbblaster2/%k"

# USB-Blaster
SUBSYSTEM=="usb", ENV{DEVTYPE}=="usb_device", ATTRS{idVendor}=="09fb", ATTRS{idProduct}=="6001", MODE="0666", SYMLINK+="usbblaster/%k"
SUBSYSTEM=="usb", ENV{DEVTYPE}=="usb_device", ATTRS{idVendor}=="09fb", ATTRS{idProduct}=="6002", MODE="0666", SYMLINK+="usbblaster/%k"
SUBSYSTEM=="usb", ENV{DEVTYPE}=="usb_device", ATTRS{idVendor}=="09fb", ATTRS{idProduct}=="6003", MODE="0666", SYMLINK+="usbblaster/%k"
```

then go to the directory where you created the file and type this command in the terminal

```
sudo cp -r 51-usbblaster.rules /etc/udev/rules.d
```

and then Reload drivers:

```
sudo udevadm control --reload
```

Windows Users

a. Plug the USB-Blaster II cable into your PC.

b. Open the **Device Manager**, and right-click on the **Unknown device** under the **Other devices** branch.

c. Select **Update Driver Software**.

d. Select **Browse my computer for driver software**.

e. Enter the location of the Quartus Prime software USB-Blaster driver files directory (<***Path to Quartus Prime installation***>***drivers******usb-blaster***) in the **Search for driver software in this location** field.

f. Click **Next**.

g. Click **Install** in the **Would you like to install this device software?** Windows security dialog box.

h. Close the **Update Driver Software - Altera USB-Blaster (Unconfigured)** successful installation notification. The Device Manager now shows a new branch called **JTAG cables** with an **Altera USB-Blaster (Unconfigured)** node.

i. Open the Quartus Prime Programmer. Within a few seconds, the **JTAG cables** branch displays two nodes: **Altera USB-Blaster (JTAG interface**) and **Altera-USB Blaster II (System Console interface)**.