Alexa Command Set

Startup

- Ask Extron to startup
- Ask Extron to start the system

Shutdown

- Ask Extron to shutdown
- Ask Extron to shut down the system

Input / Output (Show)

Inputs include (computer, PC, laptop, bluray, DVD, Document Camera, Share Link, Apple TV, Air Media, HDMI, DisplayPort, VGA)

Outputs include (main, left, right, center, both, all)

- Ask Extron to show the {source} input # Defaults to main output
- Ask Extron to show the {source} connection # Defaults to main output
- Ask Extron to show the {source} input on the {output} screen
- Ask Extron to show the {source} connection on the {output} screen
- Ask Extron to show the {source} input on the {output} display
- Ask Extron to show the {source} connection on the {output} display
- Ask Extron to show the {source} input on the {output} monitor
- Ask Extron to show the {source} connection on the {output} monitor

Video Freeze (Set)

- Ask Extron to set video Freeze to {on/off}
- Ask Extron to set the video Freeze to {on/off}

Video Mute (Set)

- Ask Extron to set video Mute to {on/off}
- Ask Extron to set the video Mute to {on/off}

Shades (Set)

- Ask Extron to set shades to {up / down}
- Ask Extron to set the shades to {up / down}

Lighting (Set)

Light levels (Preset 1, Preset 2, Preset 3, Preset 4, On, Off, Low, Medium, High, Presentation)

- Ask Extron to set lights to {light level}
- Ask Extron to set the lights to {light level}
- Ask Extron to turn the lights on
- Ask Extron to turn the lights off

Volume (Set)

Audio Channels (Main, Program, Microphone, Left, Right)

Integer (0 – 100)

- Ask Extron to set {audio channel} volume to {integer} percent
- Ask Extron to set the {audio channel} volume to {integer} percent
- Ask Extron to set {audio channel} volume level to {integer} percent
- Ask Extron to set the {audio channel} volume level to {integer} percent

Volume (Adjust) Changes in 3% increments

Audio Channels (Main, Program, Microphone, Left, Right)

- Ask Extron to adjust {audio channel} volume {up / down}
- Ask Extron to adjust the {audio channel} volume level {up / down}
- Ask Extron to adjust {audio channel} volume {up / down}
- Ask Extron to adjust the {audio channel} volume level {up / down}

Volume (Mute)

Audio Channels (Main, Program, Microphone, Left, Right)

- Ask Extron to set {audio channel} mute to {On / Off}
- Ask Extron to set the {audio channel} mute to {On / Off}
- Ask Extron to set {audio channel} audio mute to {On / Off}
- Ask Extron to set the {audio channel} audio mute to {On / Off}

Transports (Press)

Transports (Play, Pause, Stop, Rewind, Fast Forward, Skip Back, Skip Forward, Eject)

- Ask Extron to press {Transport}
- Ask Extron to press {Transport} button