

Digital Inputs

9V Batt +

Speaker Out here

Norm Op Mode

Prog Mode

PROG.JMP

SCK	5V
MOSI	RESET
GND	MISO

JP5*

TP13 TP14 TP17 TP18 TP19

TP1

POT3

TP1

TP2

TP3

TP4

TP5

TP6

TP7

TP8

TP9

TP10

TP11

TP12

TP13

TP14

TP15