WS63V100 CoAP

开发指南

文档版本 02

发布日期 2024-06-27

前言

概述

CoAP,即 Constrained Application Protocol(受限应用协议),是一种专为受限环境(如物联网设备)设计的轻量级网络协议。它旨在提供一种简单和有效的方式,使受限设备能够进行互联网通信。本文档介绍了基于 libcoap 的 CoAP 功能开发实现示例,以及基于 lwIP(A Lightweight TCP/IP stack)协议栈对 libcoap 某些接口进行线程安全封装后的接口说明。

产品版本

与本文档相对应的产品版本如下。

产品名称	产品版本
WS63	V100

读者对象

本文档主要适用于以下对象:

- 软件开发工程师
- 技术支持工程师

符号约定

在本文中可能出现下列标志,它们所代表的含义如下。

2024-06-27

符号	说明
▲ 危险	表示如不避免则将会导致死亡或严重伤害的具有高等级风险的危害。
↑ 警告	表示如不避免则可能导致死亡或严重伤害的具有中等级风险的危害。
<u> 注意</u>	表示如不避免则可能导致轻微或中度伤害的具有低等级风险的危害。
须知	用于传递设备或环境安全警示信息。如不避免则可能会导致设备 损坏、数据丢失、设备性能降低或其它不可预知的结果。 "须知"不涉及人身伤害。
□ 说明	对正文中重点信息的补充说明。 "说明"不是安全警示信息,不涉及人身、设备及环境伤害信息。

修改记录

文档版本	发布日期	修改说明
02	2024-06-27	• 更新 "1.1 概述" 的接口说明。
		• 更新 "2.1.1 资源配置" 的配置说明。
		• 更新 "2.2 代码示例" 的代码样例。
01	2024-04-10	第一次正式版本发布。
00B01	2024-03-15	第一次临时版本发布。

2024-06-27 ii

目录

前言	i
1 API 接口说明	1
1.1 概述	
2 开发指南	
2.1 开发约束	
2.1.1 资源配置	2
2.2 代码示例	2
2.2.1 服务器	2
222 安白農	F

1 API 接口说明

1.1 概述

1.1 概述

CoAP 使用开源库 libcoap 提供基础功能支持,基于 CoAP 的业务实现请调用 libcoap 接口。对于开源库自身提供的 API 的使用说明请参见开源 API 接口说明信息,对于当前提供的 libcoap 适配的 lwip 协议栈,开源提供以下接口:

● coap_new_context 创建 coap 上下文

● coap_free_context 释放或销毁 coap 上下文

● coap_check_notify 检查是否需要发送通知

● coap_send 发送 coap 消息

● coap_send_ack 发送 coap ack

● coap_send_error 发送 coap error

● coap_send_message_type 定义发送的 coap 消息类型

2024-06-27

2 开发指南

- 2.1 开发约束
- 2.2 代码示例

2.1 开发约束

2.1.1 资源配置

当前 libcoap 中使用的资源是在 lwip 中预分配的,资源包括支持的节点个数。 context/endpoint/session/pdu/resource 等个数的限制。请开发者根据需要支持的实际场景进行合理配置。具体配置的值在

open_source/libcoap/libcoap/examples/lwip/config/lwippools.h 文件中进行设置,以宏的形式给出,开发者可以在该文件中进行适配修改。使用这些资源会使 lwip 预分配的内存池变大,增大的 RAM 的 size,故代码中默认没有开启这些资源的预配置,需要修改 build/cmake/open_source/libcoap.cmake 中全局宏定义为:

```
set(PUBLIC_DEFINES

MEMP_USE_CUSTOM_POOLS=1
)
```

2.2 代码示例

2.2.1 服务器

以下为服务端开放 get 与 post 方法示例代码:

#include "lwip/netifapi.h"

```
#include "lwip/sockets.h"
#include "lwip/netifapi.h"
#include "lwip/sockets.h"
#include "coap3/coap.h"
#include "osal debug.h"
#include "osal task.h"
#define SERVER PORT 5683
static int quit = 0;
static void hello_handler(coap_resource_t *resource, coap_session_t *session,
              const coap pdu t *request, const coap string t *query,
              coap_pdu_t *response)
    unsigned char buf[3];
    const char *response data = "Hello World!";
    char coap_msg[64] = \{0\};
    size_t len = 0;
    u32_t cnt;
    unsigned char *data = NULL;
    (void)resource;
    (void)query;
    if (coap_get_data(request, &len, (const uint8_t **)&data)) {
        if (len < 6) {
            osal_printk("[%s][%d] len %d\n", __FUNCTION__, __LINE__, len);
            (void)snprintf_s(coap_msg, sizeof(coap_msg), sizeof(coap_msg)-1, "%s",
response_data);
             quit = 1;
        } else {
             memcpy(coap_msg, data, 4);
            (void)snprintf_s(coap_msg + 4, sizeof(coap_msg) - 4, sizeof(coap_msg) - 5, "%s",
response_data);
            cnt = ntohl(*((u32_t *)data));
             len -= 4;
             data += 4;
            osal_printk("[%s][%d] <%u> len : %d, data : %.*s\n", __FUNCTION__, __LINE__, cnt,
len, len, data);
             quit = 1;
        }
    }
    response->code = COAP_RESPONSE_CODE(205);
    coap_add_option(response, COAP_OPTION_CONTENT_TYPE, coap_encode_var_safe(buf,
sizeof(buf),
```

```
COAP_MEDIATYPE_TEXT_PLAIN), buf);
    coap_add_data(response, 4 + strlen(coap_msg + 4), (unsigned char *)coap_msg);
}
int server_main_task(void *p_data)
{
    coap address t serv addr;
    coap address init(&serv addr);
    serv_addr.port = SERVER_PORT;
    ipaddr_aton("192.168.3.68", &(serv_addr.addr)); /* 服务端ip地址 */
    coap_context_t *ctx = coap_new_context(&serv_addr);
    if (!ctx) {
        osal_printk("coap_new_context ctx = NULL\n");
        return 0;
    }
    coap resource t*hello resource = coap resource init(coap make str const("hello"), 0);
    if (hello resource == NULL) {
        osal_printk("hello_resource = NULL\n");
    }
    coap_register_handler(hello_resource, COAP_REQUEST_GET, hello_handler);
    coap_register_handler(hello_resource, COAP_REQUEST_POST, hello_handler);
    coap_add_resource(ctx, hello_resource);
    /*Listen for incoming connections */
    osal_printk("Server listening for connections\n");
    while (!quit) { /* 根据需求改变停止条件 */
        osal msleep(1000);
        uapi_watchdog_kick();
    osal_printk("Process terminated\n");
    return 0:
int server_main(void)
    osal task *coap server thread = osal kthread create(server main task, NULL, "coap server",
0x1200);
    if (coap server thread == NULL) {
        osal_printk("create server_main_task kthread failed\n");
        return -1;
    }
```

```
osal_kthread_set_priority(coap_server_thread, 20);
return 0;
}
```

客户端用 post 方法获取 response 结果如下图:

^Croot@huawei-ThinkCentre-M920t-N000:~/coap_test/libcoap-4.1.1/examples# ./coap-client -m post -e "1234" coap://192.168.3.68:5683/hellov:1 t:0 tkl:0 c:2 id:30637
Hello World!

2.2.2 客户端

以下为客户端以 get 方法获取服务端响应的示例代码:

```
#include "lwip/netifapi.h"
#include "lwip/sockets.h"
#include "coap3/coap.h"
#include "osal debug.h"
#define SERVER_PORT 5683
#define PAYLOAD SIZE 60
#define MICE_URI "/"
static coap context t*g ctx = NULL;
static coap_response_t mice_handler(coap_session_t *session, const coap_pdu_t *sent, const
coap_pdu_t *received,
    const coap_mid_t mid)
    unsigned char *data;
    size t data len;
    if (COAP_RESPONSE_CLASS(received->code) == 2) {
        if (coap_get_data(received, &data_len, (const uint8_t **)&data)) {
            osal_printk("Reply OK. TID %d msgID %d\n", mid, ntohs(received->mid));
            osal_printk("Payload***[%s]***\n", data);
    } else {
        osal printk("code error");
        osal_printk("Mice unsuccessful, code: %hu \n", received->code);
    }
static void coap_recv_client(void *arg, struct udp_pcb *upcb, struct pbuf *p, const ip_addr_t *addr,
u16_t port)
    coap_session_t *session = arg;
    coap_pdu_t *pdu = coap_new_pdu(COAP_MESSAGE_CON, COAP_REQUEST_GET,
```

```
session);
    memset_s(pdu, sizeof(coap_pdu_t), 0, sizeof(coap_pdu_t));
    pdu->max_hdr_size = COAP_PDU_MAX_UDP_HEADER_SIZE;
    pdu-pbuf = p;
    pdu->token = (uint8_t *)p->payload + pdu->max_hdr_size;
    pdu->alloc size = p->tot len - pdu->max hdr size;
    coap pdu clear(pdu, pdu->alloc size);
    if (!coap pdu parse(COAP PROTO UDP, p->payload, p->len, pdu)) {
        return;
    }
    coap_dispatch(g_ctx, session, pdu);
    (void)pbuf free(p);
    pdu->pbuf = NULL;
    coap delete pdu(pdu);
    udp_remove(session->sock.pcb);
    if (g_ctx!= NULL) {
        coap_free_context(g_ctx);
        g ctx = NULL;
    }
    coap_session_release(session);
void snd_msg(void)
    osal printk("-----method get msg-----\n");
    coap pdu t*request = coap pdu init(COAP MESSAGE CON, COAP REQUEST GET,
coap_new_message_id(g_ctx->sessions),
        coap session max pdu size(g ctx->sessions));
    if (request == NULL) {
        osal_printk("request init error");
        return:
    }
    coap uri turi;
    coap_split_uri((const uint8_t *)MICE_URI, strlen(MICE_URI), &uri);
    coap_add_option(request, COAP_OPTION_URI_PATH, uri.path.length, uri.path.s);
    char *request_data = (char *)malloc(64);
    if (request data == NULL) {
        osal_printk("[%s][%d]: malloc error\n", __FUNCTION__, __LINE__);
        return;
    (void)snprintf s(request data + 4, sizeof(request data) - 4, sizeof(request data)-5, "%s",
"testcoap");
```

```
coap_add_data(request, 4 + strlen((const char *)(request_data+4)), (unsigned char
*)request_data);
    free(request_data);
    if (coap_send(g_ctx->sessions, request) < 0) {
        osal_printk("[%s][%d]: coap send error\n", __FUNCTION__, __LINE__);
    }
    return;
void snd continuous(char *address, int port)
    if (g ctx == NULL) {
        osal_printk("snd_continuous 1\r\n");
        coap address t src addr;
        coap address init(&src addr);
        ip addr set any(false, &(src addr.addr));
        src_addr.port = port;
        g_ctx = coap_new_context(NULL);
        if (g_ctx == NULL) {
            osal_printk("new context error\n");
            return;
        }
        coap_context_set_keepalive(g_ctx, 60);
        coap_address_t dst_addr;
        coap address init(&dst addr);
        ipaddr aton(address, &(dst addr.addr));
        dst_addr.port = port;
        coap session t *session = coap new client session(g ctx, NULL, &dst addr,
COAP PROTO UDP);
        if (session == NULL) {
            osal_printk("----session is null\n");
            return;
        }
        session->sock.pcb = udp_new_ip_type(IPADDR_TYPE_ANY);
        if (session->sock.pcb == NULL) {
            osal printk("coap new endpoint: udp new fail\n");
            return:
        }
        session->sock.pcb->netif_idx = NETIF_NO_INDEX;
        udp recv(session->sock.pcb, coap recv client, session);
        if (udp_bind(session->sock.pcb, &(src_addr.addr), 0)) {
             osal printk("-----udp bind error\n");
             udp remove(session->sock.pcb);
```

```
return;
        }
        /* register mice handler */
        coap_register_response_handler(g_ctx, mice_handler);
    }
    snd_msg();
}
int coap_client(void)
    osal_printk("client_main start\n");
    int port = 5683; /* coap服务端口 */
    char *address = "192.168.3.65"; /* 服务端ip地址 */
    osal_printk("Start on port %d, connect to %s\n", port, address);
    osal_printk("Client started\n");
    osal_printk("\r\nsnd_continuous\r\n");
    snd_continuous(address, port);
    return 0;
```

服务端的响应如下图:

```
AT+COAPTEST

client_main start

Start on port 5683, connect to 192.168.3.65

client started

snd_continuous

snd_continuous 1
-----method get msg-----

OK

OK

Reply OK. TID 43415 msgID 38825

Payload***[This is a test server made with libcoap (see http://libcoap.sf.net)

Copyright (C) 2010--2013 Olaf Bergmann <bergmann@tzi.org>

]***
```

2024-06-27