

TAG DESCRIPTION TABLE

38784STD-BV9a

20 March 2015

abbrsect

Abbreviation Section

Description: Identifies the paragraph used to define abbreviations/acronyms and the associated list.

Source paragraph: 4.3.4 and 4.5.9 (MIL-STD-38784)

Content Model: (([title](#), [warning*](#), [caution?](#), [note?](#), ([para](#), [note?](#))?, ([step1](#), [step1+](#))?, [subpara1*](#))?, ([abbrtitle?](#), [acronymlist](#)))

Parents: [foreword](#), [intro](#), [preface](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

abbrtitle

Abbreviation Title

<i>Description:</i>	Identifies the title for the list of acronyms and abbreviations.
<i>Source paragraph:</i>	4.3.4 and 4.5.9 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(figure table foldout objmedia)
<i>Parents:</i>	abbrsect
<i>Entities used in this element:</i>	chgatt , delstat , exclus , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

acronym

Acronym

<i>Description:</i>	Identifies the first time an acronym or abbreviation is used in a chapter. The def part of the acronym is used to define the acronym/abbreviation, while the term part of the acronym contains the actual acronym/abbreviation. Within the text, the term portion will be surrounded with parenthesis.
<i>Source paragraph:</i>	4.3.4 and 4.5.9 (MIL-STD-38784)
<i>Content Model:</i>	(def, term) -(acronym figure table foldout objmedia)
<i>Parents:</i>	abbrtitle, activity, address, applicabil, apptitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, llink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcoe, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdlocation, tpdno, typedes, typeno, underline, vollepgchg, volleppage, volnot, volnum
<i>Excluded in:</i>	acronym, acronymlist
<i>Entities used in this element:</i>	chgatt, delstat, exclus, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

acronymlist

Acronym/Abbreviation List

<i>Description:</i>	Identifies the list of acronyms and abbreviations.
<i>Source paragraph:</i>	4.3.4 and 4.5.9 (MIL-STD-38784)
<i>Content Model:</i>	(acronymrow+ (term, def)+) -(acronym figure table foldout objmedia)
<i>Parents:</i>	abbrsect
<i>Entities used in this element:</i>	chgatt, delstat, exclus, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	2.5in	Allows the author to define the width of the right column, which typically contains the definitions of the acronym/abbreviation.
ltermwidth	NUTOKEN	1in	Allows the author to define the width of the left column, which typically contains the acronym/abbreviation.
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

acronymrow

Acronym/Abbreviation List Row

Description: Identifies a set of term and definition for an acronym/abbreviation list.

Source paragraph: 4.3.4 and 4.5.9 (MIL-STD-38784)

Content Model: (term, def)

Parents: acronymlist

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

activity

Reporting Activity

Description: Identifies the activity submitting a technical publication deficiency report list.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [tpdrrow](#), [tpdrtbl](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

address

Change Instruction Sheet Name/Address

Description: Identifies the name and address of the activity responsible for preparation of the change instruction sheet.

Source paragraph: 4.7.3.10.2 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginsst](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

appendix

Appendix

Description: Identifies an appendix of the manual.

Source paragraph: 4.2.9.6 (MIL-STD-38784)

Content Model: (title, para0+) +(ftnote | figure | table | foldout | objmedia)

Parents: rear

Entities used in this element: [append](#), [bodyatt](#), [chapatt](#), [chgatt](#), [delstat](#), [inclus](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

applic

Applicability/Effectivity Definition Entry

Description: Defines applicability/effectivity markings.

Source paragraph: 4.3f and 4.5.9 (MIL-STD-38784)

Content Model: ([term](#), [def](#))

Parents: [applicdef](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#REQUIRED	Allows the author to generate a unique ID for use when referencing this element.
flagnote	NUMBER	1	Set this attribute equal to "1" to use flagnotes (TV Screens) to display Effectivity.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

applicabil

Applicability/Effectivity

Description: Identifies a portion of text as being applicable to a specific model, serial number, part number, etc. Use of this element will cause the applicability/effectivity markings defined in the applicability definition ([applicdef](#)) to appear at that point in running text.

Source paragraph: 4.3f (MIL-STD-38784)

Content Model: (([#PCDATA](#) | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([applicabil](#) | [figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [appltite](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrctcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Excluded in: [applicabil](#), [extapplicabil](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
applicref	IDREFS	#REQUIRED	Allows the author to assign an applicability/effectivity reference to this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

applicdef

Applicability/Effectivity Definition

Description: Identifies the paragraph used to define applicability/effectivity markings, and the associated list.

Source paragraph: 4.3f (MIL-STD-38784)

Content Model: (([title](#), [warning*](#), [caution?](#), [note?](#), ([para](#), [note?](#))?), ([step1](#), [step1+](#))?, [subpara1*](#))?, ([appltite?](#), [applichd?](#), [applic+](#)))

Parents: [foreword](#), [intro](#), [preface](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	2.5in	Allows the author to define the width of right column, which typically contains the applicability/effectivity definition. This attribute is not currently supported by the FOSI.
ltermwidth	NUTOKEN	1in	Allows the author to define the width of the left column, which typically contains the applicability/effectivity. This attribute is not currently supported by the FOSI.

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcp	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

applichd

Applicabilty/Effectivity List Column Headings

Description: Defines the column headings used for the applicability/effectivity list.

Source paragraph: 4.3f (MIL-STD-38784)

Content Model: ([term](#), [def](#))

Parents: [applicdef](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

appltile

Applicability/Effectivity Title

Description: Identifies the title for the applicability/effectivity list.

Source paragraph: 4.3f (MIL-STD-38784)

Content Model: (([PCDATA](#) | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#)+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [applicdef](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

Attribute	Type	Default	Description
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

authnot

Authority Notice

Description: Identifies the authority notice at the bottom of the title page.

Source paragraph: 4.5.1.15 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

auxfront

Auxillary Front Matter

Description: Identifies the front matter that appears in second and subsequent volumes.

Source paragraph: 4.2.9.1 (MIL-STD-38784)

Content Model: (warnpage?, idinfo, chginssht?, (lep | vollep), verstat?, tpd?, chgrec?, (contents | volcontents), (illuslist | voliilluslist)?, (tablelist | vtablelist)?, (foreword | preface | intro)?, safesum?) +(fnote)

Parents: volume

Entities used in this element: auxfrnt, chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

bindByCoords

Bind By Coordinates

Description: Identifies coordinates on a graphic that may be used for referencing. This element is not currently supported by the FOSI.

Source paragraph: None

Content Model: (xref*)

Parents: graphic

Entities used in this element: cgmatts, chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
coords	CDATA	#REQUIRED	A list of the coordinates identifying the region on the graphic.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
title	CDATA	#IMPLIED	Label/Screen tip of hotspot.
descript	CDATA	#IMPLIED	Description of graphical hotspot.
visibility	(visible hidden)	visible	Indicates if an object is visible or not. A non-visible object behaves like a non-interactive object (i.e., it cannot be clicked or highlighted).
interactivity	(interactive none)	none	Indicates if an object may receive mouse events. When this attribute is set to "none", events for this object are disabled.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

bindByld

Bind By ID

<i>Description:</i>	Identifies by ID a region in a Computer Graphics Metafile (CGM) that may be used for referencing. This element is not currently supported by the FOSI.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	(xref*)
<i>Parents:</i>	graphic
<i>Entities used in this element:</i>	cgmatts , chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
objectid	CDATA	#REQUIRED	The name of the ID identifying the region on the CGM.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
title	CDATA	#IMPLIED	Label/Screen tip of hotspot.
descript	CDATA	#IMPLIED	Description of graphical hotspot.
visibility	(visible hidden)	visible	Indicates if an object is visible or not. A non-visible object behaves like a non-interactive object (i.e., it cannot be clicked or highlighted).
interactivity	(interactive none)	none	Indicates if an object may receive mouse events. When this attribute is set to "none", events for this object are disabled.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

bindByName

Bind By Name

<i>Description:</i>	Identifies by name a region on a CGM that may be used for referencing. This element is not currently supported by the FOSI.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	(xref*)
<i>Parents:</i>	graphic
<i>Entities used in this element:</i>	cgmatts , chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
apstargetname	CDATA	#REQUIRED	The name of the region on the CGM.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
title	CDATA	#IMPLIED	Label/Screen tip of hotspot.
descript	CDATA	#IMPLIED	Description of graphical hotspot.
visibility	(visible hidden)	visible	Indicates if an object is visible or not. A non-visible object behaves like a non-interactive object (i.e., it cannot be clicked or highlighted).
interactivity	(interactive none)	none	Indicates if an object may receive mouse events. When this attribute is set to "none", events for this object are disabled.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

body

Body

Description: Identifies the portion of the manual where chapters are used, exclusive of front matter and appendices, indexes, etc.

Source paragraph: 3.2.38 and 4.2.9.3 (MIL-STD-38784)

Content Model: (chapter, ((chapter+, [ipbchap?](#)) | [ipbchap](#)), [ddchapter?](#)) +([fnote](#))

Parents: [doc](#), [volume](#)

Entities used in this element: [bodyele](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
numcols	(1 2)	#REQUIRED	Allows the author to define the page format as one or two columns for this section of the manual.

brk

Break

Description: This element is used to indicate that a column, line, or page break should be forced at that point. This element is included to allow the author flexibility in composing the manual in accordance with this specification.

Source paragraph: None

Content Model: EMPTY

Included in: [doc](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
type	(col line npg)	line	Allows the author to define what type of break will occur when the brk element is used - column, line, or page.

caution

Caution

Description: Identifies a CAUTION in the manual.

Source paragraph: 4.3.10 (MIL-STD-38784)

Content Model: (para*) -(randlist | deflist | seqlist | figure | table | foldout | objmedia | warning | caution)

Parents: [abbrsect](#), [applicdef](#), [dddesc](#), [ddindex](#), [entry](#), [ipbesdsdesc](#), [ipbfinding](#), [ipbhcidesc](#), [ipbmfriest](#), [ipbmodelcover](#), [ipbpartstd](#), [ipbquickchgexpl](#), [ipbserialization](#), [ipbshtnoexpl](#), [ipbsmassem](#), [ipbsmrexpl](#), [ipbuseonexpl](#), [lrp](#), [para0](#), [ratddesc](#), [step1](#), [step2](#), [step3](#), [step4](#), [subpara1](#), [subpara2](#), [subpara3](#), [subpara4](#), [subpara5](#), [subpara6](#), [subpara7](#), [subpara8](#), [symsect](#), [tctolist](#), [tmimprep](#)

Included in: [safesum](#)

Excluded in: [caution](#), [note](#), [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [list](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

change

Changed Information

Description: Identifies material that has been changed. In order to add material, the type attribute should be set to "add", and the change element should surround the added material. In order to delete material where a complete history of all changes to the document are being preserved, the type attribute should be set to "delete" and the change element should surround the deleted material. If all changes are not being preserved, change the material and surround it with a change element, setting the type attribute to "add".

Source paragraph: 4.7.3.9 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvi](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [exclus](#), [secur](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
level	NMTOKEN	#REQUIRED	Defines the change level for the modification.
change	(add delete)	add	Defines the type of change - addition or deletion of text.
mark	NUMBER	1	Allows the author to define if a change mark will appear for this change. Setting this attribute to "1" will produce a change bar on the page and "0" will suppress it.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

chapter

Chapter

Description: Identifies a chapter.

Source paragraph: 4.2.9.3 (MIL-STD-38784)

Content Model: ([title](#), (([section](#), ([note](#)?, [section](#))+) | [para0](#)+)) +(figure | table | foldout | objmedia)

Parents: [body](#), [body](#)

Entities used in this element: [bodyatt](#), [chap](#), [chapatt](#), [chgatt](#), [delstat](#), [inclus](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

Attribute	Type	Default	Description
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

chgdate

Change Date

Description: Identifies the date of the latest change.

Source paragraph: 4.5.1.17 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [text](#)

chghistory

Change History

Description: Identifies the beginning of the change history dates. The first date in the chghist is the original date and subsequent dates are change 1, change 2, etc.

Source paragraph: 4.5.3.1 (MIL-STD-38784)

Content Model: ([chghinfo](#)*)

Parents: [idinfo](#)

chginfo

Change Information

<i>Description:</i>	Container element to identify the change information contained in the change history of the document.
<i>Source paragraph:</i>	4.5.3.1 (MIL-STD-38784)
<i>Content Model:</i>	(chgtxt? , date)
<i>Parents:</i>	chghistory

chginsst

Change Instruction Sheet

<i>Description:</i>	Identifies the change instruction sheet.
<i>Source paragraph:</i>	4.7.3.10.2 (MIL-STD-38784)
<i>Content Model:</i>	(chgnum , address , date , prtitle , effdatenot? , discl? , distrib , expcont? , destr? , chgpara+ , chglst , sigblock?)
<i>Parents:</i>	auxfront , front
<i>Entities used in this element:</i>	chgst

chglst

Change List

<i>Description:</i>	Identifies the Remove Pages and Insert Pages columns on the change instruction sheet.
<i>Source paragraph:</i>	4.7.3.10.2 (MIL-STD-38784)
<i>Content Model:</i>	(tabmat (removepg , insertpg)+)
<i>Parents:</i>	chginsst

chgnum

Change Number/Letter

<i>Description:</i>	Identifies the latest change number/letter.
<i>Source paragraph:</i>	4.2.1.4.2.3, 4.5.1.17, and 4.7.3.1 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	chginsst , idinfo
<i>Entities used in this element:</i>	text

chgpara

Change Paragraph

<i>Description:</i>	Identifies change instructions which precede the change list on the change instruction sheet.
<i>Source paragraph:</i>	4.7.3.10.2 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	chginsst
<i>Entities used in this element:</i>	text

chgrec

Change Record

<i>Description:</i>	Identifies the change record page. This page will be an empty table whose contents will be completed by the person filing the change pages in the manual. The change record page will be automatically generated by the FOSI.
<i>Source paragraph:</i>	4.5.5 (MIL-STD-38784)
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	auxfront , front

chgtxt

Change Text

Description: This element is optional and is used to provide an alpha representation of the current change level. This element will only be used by those branches of the Armed Services that require alpha change levels. For all other users, this element should not be used.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginfo](#)

Entities used in this element: [text](#)

clink

Contextual Link

Description: One of several HyTime elements. Can be used in any situation similar to the xref or extref element. This element will reference any [nameloc](#) declared.

Source paragraph: None

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [superseded](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
HyBase	NAME	#FIXED hylink	Used in combination with HyTime to establish a contextual link.
HyBnames	CDATA	#FIXED "refsub linkend"	Used in combination with HyTime to establish a contextual link.
anchrole	CDATA	#FIXED "refmark refsub #LIST"	Used in combination with HyTime to establish an anchor role for contextual links.
anchcstr	NAMES	"self required"	Used in combination with HyTime to establish the type of anchor string defined for a contextual link.
linkend	CDATA	#IMPLIED	References a linkend declared within a nameloc element. Other attributes are not included at this time as they are not applicable during a period of alpha testing and will be added to the TDT as the options are explored and implemented.

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

cntentry

Table of Contents Entry

Description: Identifies an entry for a manually tagged Table of Contents.

Source paragraph: 4.5.6 (MIL-STD-38784)

Content Model: ([label](#), [title](#), [pageno](#))

Parents: [contents](#), [volcontents](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
inlevel	NUMBER	#IMPLIED	Identifies the indenture level of the entry.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

cogact

Cognizant Field Activity

Description: Identifies the Cognizant Field Activity on the title page and is included in the distribution statement. This is a Navy requirement.

Source paragraph: 4.5.1.11 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

colspec

Column Specification

Description: Defines a column in a table. Each column must have a column specification. The column specification defines the width of the column and an optional name used when the column is starting or ending a horizontal span or referenced in a table entry. Column specifications in a table group apply to the table heading (boxheads) and the table body. The table heading can redefine the column specifications if needed, however, the table body must use the column specifications defined in the table group.

Source paragraph: 4.2.7 (MIL-STD-38784)

Content Model: EMPTY

Parents: [entrytbl](#), [tfoot](#), [tgroup](#), [thead](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
colname	NMTOKEN	#IMPLIED	Allows the author to define a column name.
colnum	NUMBER	#IMPLIED	Allows the author to define a column number.
align	(left right center justify char)	#IMPLIED	Defines the horizontal alignment of text within a cell.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column. This attribute should be used when the align attribute is set to "char".
leftmar	NUTOKEN	#IMPLIED	Defines the left margin for each cell in the column.
rightmar	NUTOKEN	#IMPLIED	Defines the right margin for each cell in the column.
topmar	NUTOKEN	#IMPLIED	Defines the top margin for each cell in the column.
botmar	NUTOKEN	#IMPLIED	Defines the bottom margin for each cell in the column.
mindepth	NUTOKEN	#IMPLIED	Allows the author to define a minimum depth if desired.
colwidth	CDATA	#IMPLIED	Allows the author to define the width of the column.
colsep	NUMBER	#IMPLIED	Allows the author to include a vertical line to separate columns. Setting this attribute equal to "1" will generate column separators.
rowsep	NUMBER	#IMPLIED	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

contents

Table of Contents

<i>Description:</i>	Identifies the table of contents. For Army documents, the table of contents consists of chapter and section titles. For all other services, the table of contents consists of chapter, section, and paragraph titles. If an alphabetical index is used, the table of contents consists of chapter, section, primary paragraph, and first subordinate paragraph titles. This information is automatically generated by the FOSI.
<i>Source paragraph:</i>	4.5.6 (MIL-STD-38784)
<i>Content Model:</i>	((cntentry * #PCDATA)*)-(note)
<i>Parents:</i>	auxfront , front
<i>Entities used in this element:</i>	chgatt , cntnt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

contractno

Contract Number

<i>Description:</i>	Identifies the contract number on the title page.
<i>Source paragraph:</i>	4.5.1.4 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat fnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+)

Parents: [idinfo](#)

Entities used in this element: [secur](#), [text](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

copyright

Copyright Notice

Description: Identifies the copyright notice on the title page.

Source paragraph: 4.1.2 and 4.5.1.14 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

dataiden

Data Identification

Description: May be used to identify specific types of data (e.g. hazardous materials, special tools, etc.). Use of this element does not affect the formatted output, but is intended to be used in database functions and data searches.

Source paragraph: None

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([dataiden](#) | [figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Excluded in: [dataiden](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
type	CDATA	#REQUIRED	Defines the type of data being used in the database functions and database searches.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

date

Date

Description: Identifies a date.

Source paragraph: 4.5.1.17 and 4.5.9.4b (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [chginfo](#), [chginsst](#), [ratdentry](#), [tctorow](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

dateinc

Date Incorporated

Description: Identifies the date the information affected by the directive or engineering change proposal was incorporated into the manual. This appears in the "Date Inc." column in the record of applicable technical directives table.

Source paragraph: 4.5.9.4d (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ratdentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ddchapter

Difference Data Chapter

Description: Identifies the difference data chapter.

Source paragraph: 4.7.3.3 (MIL-STD-38784)

Content Model: ([dddesc](#), ([ddindex](#), [ddsheets](#))+) ?) +(figure | table | foldout | objmedia)

Parents: [body](#)

Entities used in this element: [bodyatt](#), [chapatt](#), [chgatt](#), [ddchap](#), [delstat](#), [inclus](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
numcols	(1 2)	1	Allows the author to define the page format as one or two columns for this section of the manual.
paranumbers	NUMBER	0	Setting this attribute equal to "1" will label the paragraphs in the difference data chapter.

dddesc

Difference Data Description

Description: Identifies the lead-in information for the difference data chapter.

Source paragraph: 4.7.3.3 (MIL-STD-38784)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)

Parents: [ddchapter](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.

Attribute	Type	Default	Description
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ddindex

Difference Data Index

Description: Identifies the lead-in information for the difference data index and its associated list.

Source paragraph: 4.7.3.3.1 (MIL-STD-38784)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*, dlist)

Parents: ddchapter

Entities used in this element: bodyatt, chgatt, delstat, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ddlist

Difference Data List

Description: Identifies the listing of part numbers to corresponding difference data sheets.

Source paragraph: 4.7.3.3 (MIL-STD-38784)

Content Model: ([partno](#), [pageno](#))*

Parents: [ddindex](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ddsheets

Difference Data Sheet

Description: Identifies a difference data sheet.

Source paragraph: 4.7.3.3 (MIL-STD-38784)

Content Model: (([nomen](#), ([partno](#)+ | [modelno](#)+ | [typedes](#)+)), [para0](#)*)

Parents: [ddchapter](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

def

Definition

Description: Identifies a definition in a list. Each definition has an associated term.

Source paragraph: 4.3.4 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [acronym](#), [acronymlist](#), [acronymrow](#), [applic](#), [applchd](#), [defhd](#), [deflist](#), [glosslist](#), [glossrow](#), [ipbuseoncodelist](#), [symrow](#), [symsect](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

defhd

Definition List Column Headings

Description: Identifies the column headings for a definition list.

Source paragraph: 4.3.4 (MIL-STD-38784)

Content Model: ([term](#), [def](#))

Parents: [deflist](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

deflist

Definition List

Description: Identifies a two-column definition list. This element can be used when a listing is needed to define particular terms.

Source paragraph: 4.3.4 (MIL-STD-38784)

Content Model: ([title?](#), [defhd?](#), ([term](#), [def](#))⁺)

Parents: [entry](#), [fnote](#), [para](#)

Excluded in: [caution](#), [note](#), [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	1.9in	Allows the author to set the width of the right column.
ltermwidth	NUTOKEN	0.7in	Allows the author to set the width of the left column.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

destr

Destruction Notice

Description: Identifies the destruction notice on the title page.

Source paragraph: 4.5.1.13 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [text](#)

discl

Disclosure Notice

Description: Identifies the disclosure notice on the title page.

Source paragraph: 4.5.1.10 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [text](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
disclos1	CDATA	#IMPLIED	Identifies which type of disclosure notice will appear on the title page. Use of this attribute will generate an alternate disclosure notice as opposed to the notice generated by the FOSI.

distrib

Distribution Statement

Description: Identifies the distribution statement.

Source paragraph: 4.5.1.11 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [text](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
type	(A B C D E F X)	#REQUIRED	Identifies and displays the type of distribution statement per STINFO requirements.

doc

Document

Description: Identifies the entire document and is the top level element.

Source paragraph: 4.1.7 (MIL-STD-38784)

Content Model: (([volume](#), [volume](#)+) | ([front](#), [body](#), [rear](#)?)) +([pgbrk](#) | [brk](#) | [subjinfo](#) | [line](#) | [modreq](#) | [location](#) | [note](#))

Entities used in this element: [doc](#), [docatt](#), [pubatts](#), [secur](#), [service](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
service	(AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD FRN)	#REQUIRED	Identifies which branch of the service. If no branch is suitable, the author should choose "FRN" and manually fill in the appropriate branch using the FRN attribute.
FRN	CDATA	#IMPLIED	Allows the author to manually enter the branch. This will be displayed on the "A" page of the LEP. This should only be used when the service attribute is set to "FRN".
docid	CDATA	#IMPLIED	Allows the author to define an identification number for the document.
docstat	(revision change prelim draft formal)	prelim	Allows the author to stipulate what form the manual is in.
verstatpg	(ver unver)	unver	Allows the author to stipulate a verified or unverified manual. Use of this attribute will trigger the generation of the verification status page and the temporary file - vsmatter.dat. See the accompanying readme.txt file on verification status for more details.
index	NUMBER	0	Indicates whether an index is included in the manual. This attribute should be set to "1" when an index is present. Use of this attribute will affect the level of detail in the table of contents.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. For proper formatting on foldout pages, the caveat should be preceded and succeeded with enough "spaces" to occupy the same length as the security classification.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
controlno	CDATA	00000000	System generated attribute value included for compliance with the JCALS menu structure.
cycle	CDATA	new	System generated attribute value included for compliance with the JCALS menu structure.
chglevel	NUMBER	#IMPLIED	System generated attribute value included for compliance with the JCALS menu structure.
initlabel	NUMBER	#IMPLIED	System generated attribute value included for compliance with the JCALS menu structure.

Attribute	Type	Default	Description
initpage	NUMBER	1	System generated attribute value included for compliance with the JCALS menu structure.
docno	CDATA	#IMPLIED	System generated attribute value included for compliance with the JCALS menu structure.
highguid	NUMBER	0	System generated attribute value included for compliance with the JCALS menu structure.
labelstyle	CDATA	FAN	System generated attribute value included for compliance with the JCALS menu structure.
HyTime	NAME	#FIXED "HyDoc"	Used to alert the processing system that this is a HyTime compliant document. This attribute is only required and/or effective with a HyTime aware processor.

doctype

Document Type

Description: Identifies the type of manual on the title page (e.g. maintenance instructions, illustrated parts breakdown, inspection manual, etc.).

Source paragraph: 4.5.1.3.2 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

downgrd

Downgrade Notice

Description: Identifies the classification downgrade notice on the title page.

Source paragraph: 4.4 (MIL-STD-38784)

Content Model: ([phrase](#) | [oadr](#))

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ecpno

Engineering Change Proposal (ECP) Number

Description: Identifies the ECP Number in the record of applicable technical directives.

Source paragraph: 4.5.9.4 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ratdentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

effdatenot

Effective Date Notice

Description: Identifies the effective date notice on the title page.

Source paragraph: 4.5.1.8 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

emphasis

Emphasis

Description: Identifies portions of text to be highlighted (e.g. italic, bold, etc.). This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: None

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺ -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersd](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
type	(u b b u i b i q q a x o sup sub ui)	#REQUIRED	Displays different types of emphasis. Set this attribute equal to "u" for underline, "b" for bold, "bu" for bold/underline, "i" for italics, "bi" for bold/italics, "q" for quotes, "qa" for quote alternate (currently unsupported), "x" for box, "o" for overscore, "sup" for superscript, "sub" for subscript, and "ui" for underline/italics.
fontsize	NUTOKEN	#IMPLIED	Allows the author to set the font size which will be applied to the text within the emphasis element.
color	(black white red orange yellow green blue violet brown gray)	#IMPLIED	Allows the author to set the color which will be applied to the text within the emphasis element.

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

entry

Table Entry

Description: Identifies a table entry (cell).

Source paragraph: 4.2.7 (MIL-STD-38784)

Content Model: (((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+ | [randlist](#) | [deflist](#) | [seqlist](#) | [warning](#) | [caution](#) | [note](#))+)

Parents: [row](#)

Entities used in this element: [chgatt](#), [delstat](#), [entry](#), [entryatt](#), [list](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
colname	NMTOKEN	#IMPLIED	Allows the author to specify the name of the column to use.
spanname	NMTOKEN	#IMPLIED	Allows the author to define a span name.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
morerows	NUMBER	0	Allows the author to define a vertical span on entries within a table.
colsep	NUMBER	#IMPLIED	Allows the author to include a vertical line to separate columns. Setting this attribute equal to "1" will generate column separators.
rowsep	NUMBER	#IMPLIED	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
rotate	NUMBER	0	Set this attribute equal to "1" to rotate the contents of the entry 90 degrees.
valign	(top middle bottom)	#IMPLIED	Defines the vertical alignment of text within a cell.
align	(left right center justify char)	#IMPLIED	Defines the horizontal alignment of text within a cell.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column. This attribute should be used when the align attribute is set to "char".
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

entrytbl

Entry Table

Description: Identifies a table within a table entry. This element allows a table cell to be divided into a sub-table, with its own set of rows, columns, and entries. Use of this element basically allows the author to create a table within a table.

Source paragraph: 4.2.7 (MIL-STD-38784)

Content Model: (colspec*, spanspec*, thead?, tbody) -(entrytbl)

Parents: row

Excluded in: entrytbl, tfoot, thead

Entities used in this element: chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
cols	NUMBER	#REQUIRED	Allows the author to define the number of columns.
colname	NMTOKEN	#IMPLIED	Allows the author to specify the name of the column to use.
spanname	NMTOKEN	#IMPLIED	Allows the author to define a span name.
colsep	NUMBER	#IMPLIED	Allows the author to include a vertical line to separate columns. Setting this attribute equal to "1" will generate column separators.
rowsep	NUMBER	#IMPLIED	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
align	(left right center justify char)	#IMPLIED	Defines the horizontal alignment of text within a cell.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column. This attribute should be used when the align attribute is set to "char".
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

esds

Electrostatic Discharge Sensitive (ESDS)

Description: Identifies ESDS parts. Use of this element will cause the ****ESD**** symbol to appear at that point in the running text. This element should only be used in running text, e.g. to display the ****ESD**** symbol in a paragraph. The esds attribute should be used to place the ****ESD**** symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.4 (MIL-STD-38784)

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersd](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

expcont

Export Control Notice

Description: Identifies the export control notice on the title page. Note that the export control notice entity (&expcontnot;) may be used in place of entering the text manually.

Source paragraph: 4.5.1.12 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) +(underline)

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [text](#)

extapplicabil

External Applicability/Effectivity

Description: Identifies a portion of text as being applicable to a specific model, serial number, part number, etc. Use of this element will cause the applicability/effectivity markings to appear at that point in running text.

Source paragraph: 4.3f (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+ -([applicabil](#) | [extapplicabil](#) | [figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretnidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Excluded in: [extapplicabil](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
targetdoc	CDATA	#REQUIRED	Identifies the external document that you are referencing. This value should equal an ID specified in the List of Related Publications. For implementing external references in digital data, this ID must equal the ID of the external document.
targetid	CDATA	#IMPLIED	Provides the ID for the element being referenced in the external document. The value of this attribute should equal the ID of an element in the referenced document.
displayvalue	CDATA	#IMPLIED	Allows the author to add additional, unique information for purposes of referencing an external document. This attribute should be used for providing paragraph titles, system numbers, task numbers and for author-generated TO numbers where applicable.
HyTime	NAME	#FIXED "clink"	Used in combination with HyTime to establish a contextual link.
HyNames	NAMES	#FIXED "linkend xrefid"	Used in combination with HyTime to establish a contextual link.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

extref

External Reference

Description: Generates a reference to an external document.

Source paragraph: 4.3.1m (MIL-STD-38784)

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typesdes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
targetdoc	CDATA	#REQUIRED	Identifies the external document that you are referencing. This value should equal an ID specified in the List of Related Publications. For implementing external references in digital data, this ID must equal the ID of the external document.
targetid	CDATA	#IMPLIED	Provides the ID for the element being referenced in the external document. The value of this attribute should equal the ID of an element in the referenced document.
displayvalue	CDATA	#IMPLIED	Allows the author to add additional, unique information for purposes of referencing an external document. This attribute should be used for providing paragraph titles, system numbers, task numbers and for author-generated TO numbers where applicable.
HyTime	NAME	#FIXED "clink"	Used in combination with HyTime to establish a contextual link.
HyNames	NAMES	#FIXED "linkend xrefid"	Used in combination with HyTime to establish a contextual link.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

fc

Fracture Critical Parts (FCP)

Description: Identifies fracture critical parts. Use of this element will cause the **FCP** symbol to appear at that point in the running text. This element should only be used in running text, e.g. to display the **FCP** symbol in a paragraph. The fcp attribute should be used to place the **FCP** symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.5 (MIL-STD-38784)

Content Model: EMPTY

Parents: abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecprno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlst, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcoe, ipbssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdlocation, tpdno, typedes, typeno, underline, vollepg, volleppage, volnot, volnum

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltpe	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

fig

Figure Number

Description: Identifies the figure number within the list of illustrations when the list of illustrations is manually tagged.

Source paragraph: 4.5.7 (MIL-STD-38784)

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Parents: illistrow, illuslist, volilluslist

Entities used in this element: chgatt, delstat, status, text, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

figure

Figure

<i>Description:</i>	Identifies an illustration.
<i>Source paragraph:</i>	4.2.8 (MIL-STD-38784)
<i>Content Model:</i>	(title, (((subfig subfigfo), (subfig subfigfo)+) ((graphic, legend?) tabdisplay)+)) -(figure table foldout objmedia)
<i>Parents:</i>	ipbplgrp
<i>Included in:</i>	appendix, chapter, ddchapter, foreword, intro, ipbfwordchap, preface, safesum
<i>Excluded in:</i>	abbrtitle, acronym, acronymlist, applicabil, apptitle, caution, change, dataiden, date, dateinc, def, ecpno, emphasis, extapplicabil, figure, foldout, ftnote, item, modelno, nomen, note, objmedia, partno, prentry, remarks, secentry, serno, symtitle, tabdisplay, table, tabmat, tctono, term, title, tmidno, topic, typedes, typeno, underline, warning
<i>Entities used in this element:</i>	bodyatt, chgatt, delstat, exclus, fig, figatts, secur, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
pgwide	NUMBER	1	Set this attribute equal to "1" to have the figure fill the entire width of the page.
orient	(port land land2)	port	Defines the orientation of the figure, either portrait or landscape. Setting this attribute equal to "land2" will rotate the figure and the figure title.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
legend	NUMBER	0	Set this attribute equal to "1" when a legend is tagged as part of the figure.
nxtpg	NUMBER	0	Set this attribute equal to "1" to indicate the legend should appear on the next page after the graphic.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

foldout

Foldout

<i>Description:</i>	Identifies a foldout.
<i>Source paragraph:</i>	4.2.4.1 (MIL-STD-38784)
<i>Content Model:</i>	(title, (((subfig subfigfo), (subfig subfigfo)+) ((graphic, legend?) tabdisplay)+)) -(figure table foldout objmedia)
<i>Parents:</i>	foldsect
<i>Included in:</i>	appendix, chapter, ddchapter
<i>Excluded in:</i>	abbrtitle, acronym, acronymlist, applicabil, appltile, caution, change, dataiden, date, dateinc, def, ecpno, emphasis, extapplicabil, figure, foldout, ftnote, item, modelno, nomen, note, objmedia, partno, prentry, remarks, secentry, serno, symtitle, tabdisplay, table, tabmat, tctono, term, title, tmidno, topic, typedes, typeno, underline, warning
<i>Entities used in this element:</i>	bodyatt, chgatt, delstat, exclus, fig, figatts, secur, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
pgstyle	(11x17 11x20.5 11x24 11x27.5 11x31 11x34.5 11x38 11x41.5 11x45)	#IMPLIED	Defines the page size for the foldout.
blankapron	NUMBER	1	Set this attribute to "1" to indicate that the foldout will have a blank apron, and to "0" to indicate that the foldout will not have a blank apron.
pgwide	NUMBER	1	Set this attribute equal to "1" to have the figure fill the entire width of the page.
orient	(port land land2)	port	Defines the orientation of the figure, either portrait or landscape. Setting this attribute equal to "land2" will rotate the figure and the figure title.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
legend	NUMBER	0	Set this attribute equal to "1" when a legend is tagged as part of the figure.
nxtpg	NUMBER	0	Set this attribute equal to "1" to indicate the legend should appear on the next page after the graphic.

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

foldsect

Foldout Section

Description: Identifies the area where foldouts are placed when they are included at the end of the manual. This element is not marked as a chapter or section, but is merely a placeholder for the foldouts.

Source paragraph: 4.2.4.1d (MIL-STD-38784)

Content Model: (foldout+) -(note)

Parents: rear

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

foreword

Foreword

Description: Identifies the foreword of the manual. This element is identical to the preface and introduction elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: (para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp | tclist | ratddesc | tmimprep)*) +(figure | table)

Parents: auxfront, front

Entities used in this element: chgatt, delstat, fpi, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

front

Front

Description: Identifies the front matter of the manual.

Source paragraph: 4.5 (MIL-STD-38784)

Content Model: (warnpage?, idinfo, chginsst?, (lep | volle), verstat?, tldr?, chgrec?, (contents | volcontents), (illuslist | voliilluslist)?, (tablelist | vtablelist)?, (foreword | preface | intro), safesum?) +(ftnote)

Parents: doc, volume

Entities used in this element: frnt, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
t2page	NUMBER	0	Set this attribute equal to "1" to generate a T-2 page (second title page).
numcols	(1 2)	#REQUIRED	Allows the author to define the page format as one or two columns for this section of the manual.

ftnote

Footnote

<i>Description:</i>	Identifies footnotes to paragraphs and tables. The footnote appears on the same page that the corresponding footnote reference (<ftnref>) occurs. Only the footnote whose id matches the xrefid specified in the footnote reference will appear. Footnotes to text will be displayed at the bottom of the page where the footnote is referenced.
<i>Source paragraph:</i>	4.2.2.2.3 and 4.3.1n (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+ -(ftnote ftnref figure table foldout objmedia)
<i>Included in:</i>	appendix , auxfront , body , front
<i>Excluded in:</i>	ftnote
<i>Entities used in this element:</i>	chgatt , delstat , exclus , list , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#REQUIRED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ftnref

Footnote Reference

<i>Description:</i>	Identifies a reference to a footnote. This element will cause the footnote number/symbol/letter to appear at the point in the text where used, and will cause the footnote number/symbol/letter and the footnote text to appear at the bottom of the page.
<i>Source paragraph:</i>	4.3.1n (MIL-STD-38784)

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Excluded in: [ftnote](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
mark	(num sym alpha)	num	Indicates the type of symbol or mark used to indicate a footnote.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

glossary
Glossary

Description: Identifies the glossary of the manual.

Source paragraph: 4.2.9.7 (MIL-STD-38784)

Content Model: (([letter?](#), [glosslist](#))+) -([note](#))

Parents: [rear](#)

Entities used in this element: [chgatt](#), [delstat](#), [glossry](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

glosslist

Glossary List

Description: Identifies the glossary list of definitions and terms.

Source paragraph: 4.2.9.7 (MIL-STD-38784)

Content Model: (glossrow+ | (letter?, (term, def))+)

Parents: [glossary](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

glossrow

Glossary List Row

Description: Identifies a row in the glossary list.

Source paragraph: 4.2.9.7 (MIL-STD-38784)

Content Model: (letter?, (term, def))

Parents: [glosslist](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

graphic

Graphic

Description: Identifies a graphic within a figure, or a graphic within running text or tables. If used within running text, no figure number or title will be generated.

Source paragraph: None

Content Model: ([bindById](#) | [bindByName](#) | [bindByCoords](#))*

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [appltile](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [figure](#), [foldout](#), [fnote](#), [hazmat](#), [icon](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subfig](#), [subfigfo](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [graphatt](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
boardno	ENTITY	#REQUIRED	Allows the author to place the name of the graphic entity here.
graphsty	NMTOKEN	#IMPLIED	Defines the graphic style.
llcordra	CDATA	#IMPLIED	Lower left world coordinates (1,1). If the scalefit attribute is set to "0" and the reprowid attribute is not specified, the default is lower left.
rucordra	CDATA	#IMPLIED	Upper right world coordinates (10000,10000). If the scalefit attribute is set to "0" and the reprodep is not specified, the default is upper right.
reprowid	NUTOKEN	#IMPLIED	Specifies the horizontal dimension (width) of a graphic bounding box.
reprodep	NUTOKEN	#IMPLIED	Specifies the vertical dimension (depth or height) of a graphic bounding box.
hscale	NUMBER	#IMPLIED	Allows the author to set the percentage of horizontal scaling for the graphic.
vscale	NUMBER	#IMPLIED	Allows the author to set the percentage of vertical scaling for the graphic.
scalefit	NUMBER	#IMPLIED	Set this attribute equal to "1" to scale the graphic to fit the graphic bounding box set by the reprodep and reprowid attributes. This attribute has no affect if the hscale and vscale attributes are used.
hplace	(left right center)	#IMPLIED	Allows the author to set the horizontal placement of the graphic.
vplace	(top middle bottom)	#IMPLIED	Allows the author to set the vertical placement of the graphic. This attribute is not currently supported by the FOSI.

Attribute	Type	Default	Description
coordst	CDATA	#IMPLIED	Specifies the coordinate to start graphic.
coordend	CDATA	#IMPLIED	Specifies the coordinate to end graphic.
color	NUMBER	0	Allows the author to choose the graphic color.
icon	(yes no)	no	Allows the author to specify whether the graphic is full size or an icon. Setting this attribute equal to "yes" will eliminate the textbrk surrounding the graphic which should make the graphic render inline with the text.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

hazmat

Hazardous Material Name

Description: Identifies the hazardous material name used with a hazardous material warning icon.

Source paragraph: 4.3.10.1 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [icon](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

hci

Hardness Critical Item (HCI)

Description: Identifies hardness critical items. Use of this element will cause the ****HCI**** symbol to appear at that point in the running text. This element should only be used in running text, e.g. to display the ****HCI**** symbol in a paragraph. The hci attribute should be used to place the ****HCI**** symbol between a paragraph/step number and text.

Source paragraph: None

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

hcp

Hardness Critical Process (HCP)

Description: Identifies hardness critical processes. Use of this element will cause the ****HCP**** symbol to appear at that point in the running text. This element should only be used in running text, e.g. to display the ****HCP**** symbol in a paragraph. The hcp attribute should be used to place the ****HCP**** symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.3 (MIL-STD-38784)

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcoe](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

icon

Hazardous Material Warning Icon

Description: Identifies the hazardous material warnings. The hazardous material warning consists of a graphic(s) (e.g fire icon, poison icon, etc.), the hazardous material name, and the sequence number which identifies the order in which the hazardous material warnings are included in the safety summary.

Source paragraph: 4.3.10.1 and Appendix A (MIL-STD-38784)

Content Model: ([graphic+](#), [hazmat+](#), [seqno](#))

Parents: [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [icon](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

idinfo

Identification Information (Title Page)

<i>Description:</i>	Identifies the title page and cover (if used) of the manual.
<i>Source paragraph:</i>	4.5.1 (MIL-STD-38784)
<i>Content Model:</i>	(tmidno +, (chgnum , chgdate)?, chghistory , pretmidno *, volnum ?, revnum ?, doctype , maintlvl ?, prtitle , subtitle ?, (mfr +, contractno +)?, seal ?, superseded ?, suppl *, effdatenot ?, volnot ?, discl ?, distrib , expcont ?, destr ?, copyright *, cogact ?, moveddata ?, authnot , downgrd ?, pubdate)
<i>Parents:</i>	auxfront , front
<i>Entities used in this element:</i>	idinf

ilink

Independent Link

<i>Description:</i>	One of several HyTime elements. Used in a situation of indirection where a specific ID is not declared in an external document and must be declared using nameloc and nmlist elements.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) +)
<i>Parents:</i>	abbrtitle , activity , address , applicabil , apptitle , authnot , change , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , figno , ftnote , hazmat , ilink , insertpg , internatlstd , ipbcage , ipbfigindex , ipbfigureno , ipbpartnosym , ipbrefdes , ipbsmrcline , ipbssn , ipbunits , ipbuseoncode , item , label , lepchg , leppage , letter , line , maintlvl , mfr , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , phrase , pretmidno , prindex , pubdate , remarks , removepg , revnum , secindex , seqno , serno , sigblock , subject , subtitle , superseded , suppl , symtitle , tabno , tctono , term , tfnid , title , tmidno , topic , tpdrlocation , tpdrno , typedes , typeno , underline , volleppchg , volleppage , volnot , volnum
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
anchrole	CDATA	#REQUIRED	Defines the anchor role assumed by the independent link. Used in combination with HyTime.
linkends	IDREFS	#REQUIRED	References the linkends declared within a nameloc element. Other attributes are not included at this time as they are not applicable during a period of alpha testing and will be added to the TDT as the options are explored and implemented.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

illistrow

List of Illustrations Row

Description: Identifies a row from the list of illustrations when the list of illustrations is tagged manually.

Source paragraph: 4.5.7 (MIL-STD-38784)

Content Model: (figno, title, pageno)

Parents: [illuslist](#), [volilluslist](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

illuslist

List of Illustrations

Description: Identifies the list of illustrations in the manual. This information is automatically generated by the FOSI. If this element is not used, no list of illustrations will appear in the manual.

Source paragraph: 4.5.7 (MIL-STD-38784)

Content Model: (illistrow* | (figno, title, pageno)*)-(note)

Parents: [auxfront](#), [front](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.

index

Index

Description: Identifies the index.

Source paragraph: 4.2.9.8 (MIL-STD-38784)

Content Model: (indexrow+ | (letter?, (preentry, secentry*))+) -(note)

Parents: rear

Entities used in this element: chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.
type	(parano pageno both)	parano	Allows the author to determine whether paragraph, figure, and table numbers are used, or page numbers are used, or both page numbers and paragraph numbers are used for the index.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

indexrow

Index Row

Description: Identifies a row in the index when the index is tagged manually.

Source paragraph: 4.2.9.8 (MIL-STD-38784)

Content Model: (letter?, (preentry, secentry*))

Parents: [index](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

insertpg

Insert Page Column Entry

Description: Identifies an entry within the Insert Page column on the change instruction sheet.

Source paragraph: 4.7.3.10.2 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chglist](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

internatlst

International Standardization Agreement Note

Description: Identifies the international standardization agreement note. The paragraph number and title, of this note will be automatically generated by the FOSI.

Source paragraph: 4.5.9.1 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [foreword](#), [intro](#), [preface](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

intro

Introduction

Description: Identifies the introduction of the manual. This element is identical to the preface and foreword elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: ([para0](#), ([para0](#) | [applicdef](#) | [symsect](#) | [abbrsect](#) | [internatlst](#) | [lrp](#) | [tctolist](#) | [ratddesc](#) | [tmimprep](#))^{*}) ⁺([figure](#) | [table](#))

Parents: [auxfront](#), [front](#)

Entities used in this element: [chgatt](#), [delstat](#), [fpi](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbcage

Commercial and Government Entity (CAGE)

<i>Description:</i>	Identifies the design activity or government agency whose number appears in the part number column of the maintenance parts list.
<i>Source paragraph:</i>	3.6.7.3 (MIL-PRF-38807)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	ipbcagecodes , ipbpl0 , ipbpl1 , ipbpl2 , ipbpl3 , ipbpl4 , ipbpl5 , ipbpl6 , ipbpl7
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbcagecodes

Commercial and Government Entity (CAGE) Codes

<i>Description:</i>	Identifies one or more CAGE codes.
<i>Source paragraph:</i>	3.6.7.3 (MIL-PRF-38807)
<i>Content Model:</i>	(ipbcage ⁺) ⁺ (tfoot ftnref)
<i>Parents:</i>	ipbpl0 , ipbpl1 , ipbpl2 , ipbpl3 , ipbpl4 , ipbpl5 , ipbpl6 , ipbpl7

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbchap

Illustrated Parts Breakdown (IPB) Chapter

Description: Identifies the IPB chapter in a combined manual.

Source paragraph: 4.11 (MIL-STD-38784)

Content Model: ([ipbfwordchap](#), [ipbpl](#), [ipbnumindx?](#), [ipbrfdsindx?](#))

Parents: [body](#), [body](#)

Entities used in this element: [bodyatt](#), [chapatt](#), [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbdesc

Part Description

Description: Identifies the description of each part listed in the maintenance parts list.

Source paragraph: 3.6.7.4 (MIL-PRF-38807)

Content Model: ([nomen](#), [ipbrefdes*](#), [ipbsssn*](#), [remarks?](#))

Parents: [ipbpl0](#), [ipbpl1](#), [ipbpl2](#), [ipbpl3](#), [ipbpl4](#), [ipbpl5](#), [ipbpl6](#), [ipbpl7](#)

Entities used in this element: [chgatt](#), [delstat](#), [descatts](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
attachpart	NUMBER	0	Setting this attribute equal to "1" will display "(AP)" following the description.
kit	NUMBER	0	Setting this attribute equal to "1" will display "(Repair kits available)" following the description.
quickchgexpl	NUMBER	0	Setting this attribute equal to "1" will display "(QCU available)" following the description.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbesdsdesc

Illustrated Parts Breakdown (IPB) Electrostatic Discharge Sensitive (ESDS)

Description: Identifies the ESDS in the IPB foreword.

Source paragraph: 3.5.11 (MIL-PRF-38807)

Content Model: ([title](#), [warning*](#), [caution?](#), [note?](#), ([para](#), [note?](#))?, ([step1](#), [step1+](#))?, [subpara1*](#))

Parents: [ipbfwordchap](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcp	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbfigindex

Figure and Index Number

Description: Identifies the figure and index numbers in the maintenance parts list, the reference designator index and the numerical index. The contents of this element appears second in the Figure & Index/Sheet No column of the maintenance parts list.

Source paragraph: 3.6.7.1, 3.7.2.2, and 3.8.2.2 (MIL-PRF-38807)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [ipbnumgrp](#), [ipbnumgrprow](#), [ipbpl0](#), [ipbpl1](#), [ipbpl2](#), [ipbpl3](#), [ipbpl4](#), [ipbpl5](#), [ipbpl6](#), [ipbpl7](#), [ipbrfdsggrp](#), [ipbrfdsgrprow](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
shown	NUMBER	1	Setting this attribute equal to "0" will display a dash in the figure/index column and "Not Illustrated" at the bottom of the maintenance parts list.
follows	NUMBER	0	Setting this attribute equal to "1" will display an "F" and the preceding figure number and index number in the figure/index column.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbfigureno

Figure and Index Number

Description: Identifies the figure and index numbers in the maintenance parts list, the reference designator index and the numerical index. The contents of this element appears first in the Figure & Index/Sheet No column of the maintenance parts list.

Source paragraph: 3.6.7.1, 3.7.2.2, and 3.8.2.2 (MIL-PRF-38807)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [ipbpl0](#), [ipbpl1](#), [ipbpl2](#), [ipbpl3](#), [ipbpl4](#), [ipbpl5](#), [ipbpl6](#), [ipbpl7](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbfinding

Finding Part Numbers, Illustrations, Descriptions

Description: Identifies how to find part numbers, illustrations, and descriptions in the illustrated parts breakdown chapter in a combined manual.

Source paragraph: 3.5.3 (MIL-PRF-38807)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)

Parents: [ipbfwordchap](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbfwordchap

Illustrated Parts Breakdown (IPB) Foreword

Description: Identifies the foreword of the IPB chapter.

Source paragraph: 3.5 (MIL-PRF-38807)

Content Model: (([para0+](#), [ipbmodelcover](#), [ipbserialization?](#), [ipbfinding?](#), [ipbsimassem?](#), [ipbquickchgexpl?](#), [ipbshtnoexpl?](#), [ipbuseonexpl](#), [ipbsmrexpl](#), [ipbhcidesc?](#), [ipbesdsdesc?](#), [ipbpartstd](#), [ipbmfrlst?](#), [para0*](#))) +(figure | table)

Parents: [ipbchap](#)

Entities used in this element: [bodyatt](#), [chapatt](#), [chgatt](#), [delstat](#), [ipbforwd](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.

Attribute	Type	Default	Description
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbgroup10

Group 10

Description: Used to create a space beneath every tenth listing in the reference designator index and numerical index.

Source paragraph: 3.7.2, 3.8.2 (MIL-PRF-38807)

Content Model: EMPTY

Included in: [ipbnumindx](#), [ipbrfdsindx](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbhcidesc

Illustrated Parts Breakdown (IPB) Hardness Critical Items (HCI)

Description: Identifies the HCI in the IPB foreword.

Source paragraph: 3.5.10 (MIL-PRF-38807)

Content Model: (title, [warning*](#), [caution?](#), [note?](#), (para, [note?](#))?, (step1, step1+)?, subpara1*)

Parents: [ipbfwordchap](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbmfrlist

Illustrated Parts Breakdown (IPB) Manufacturer List

Description: Identifies the manufacturer list in the IPB foreword.

Source paragraph: 3.5.13 (MIL-PRF-38807)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)

Parents: ipbfwordchap

Entities used in this element: bodyatt, chgatt, delstat, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbmodelcover

Illustrated Parts Breakdown (IPB) Model(s) Covered

Description: Identifies the model(s) covered by the manual in the IPB foreword.

Source paragraph: 3.5.1 (MIL-PRF-38807)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)

Parents: ipbfwordchap

Entities used in this element: bodyatt, chgatt, delstat, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbnumgrp

Illustrated Parts Breakdown (IPB) Numerical Group

Description: Container element for the IPB numerical index.

Source paragraph: 3.7 (MIL-PRF-38807)

Content Model: (([ipbnumgrprow+](#) | ([partno](#), [ipbfigindex](#))+))

Parents: [ipbnumindx](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbnumgrprow

Illustrated Parts Breakdown (IPB) Numerical Group Row

Description: Identifies a row in the IPB numerical index when the numerical index is tagged manually.

Source paragraph: 3.7 (MIL-PRF-38807)

Content Model: (partno, ipbfigindex)

Parents: [ipbnumgrp](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbnumindx

Illustrated Parts Breakdown (IPB) Numerical Index

Description: Identifies the numerical index in the IPB chapter.

Source paragraph: 3.7 (MIL-PRF-38807)

Content Model: (ipbnumgrp) -(note) +(ipbgroup10)

Parents: [ipbchap](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
cols	(2 3)	3	Defines the number of columns desired for the numerical index table.
autobuild	NUMBER	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.

Attribute	Type	Default	Description
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpartnosym

Illustrated Parts Breakdown (IPB) Part Number Symbol

Description: Identifies the part number symbol that appears in the part number column of the IPB.

Source paragraph: 3.6.9.9 (MIL-PRF-38807)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [ipbpl0](#), [ipbpl1](#), [ipbpl2](#), [ipbpl3](#), [ipbpl4](#), [ipbpl5](#), [ipbpl6](#), [ipbpl7](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpartstd

Illustrated Parts Breakdown (IPB) Parts Standardization

Description: Identifies a required paragraph in the IPB foreword.

Source paragraph: 3.5.12 (MIL-PRF-38807)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)

Parents: ipbfwordchap

Entities used in this element: bodyatt, chgatt, delstat, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl

Illustrated Parts Breakdown (IPB) Maintenance Parts List

Description: Identifies the second section in the IPB chapter.

Source paragraph: 3.6 (MIL-PRF-38807)

Content Model: (ipbplgrp+) +(ipbplbrk)

Parents: ipbchap

Entities used in this element: bodyatt, chapatt, chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl0

Illustrated Parts Breakdown (IPB) Part Listing - Indenture 0

Description: Identifies a part listing in the maintenance parts list that will have an indenture level of 0 in the description column.

Source paragraph: 3.6.7.4.1 (MIL-PRF-38807)

Content Model: ((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrpcodes)+)+, ipbpl1*)

Parents: ipbpl0tbl

Entities used in this element: bodyatt, chgatt, delstat, mpl, mplatts, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
sepmanual	NUMBER	0	Setting this attribute equal to "1" identifies the maintenance parts list table as being in a separate manual.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
shown	NUMBER	1	Setting this attribute equal to "0" will display a dash in the figure/index column and "Not Illustrated" at the bottom of the maintenance parts list.
attachpart	NUMBER	0	Setting this attribute equal to "1" will display "(AP)" following the description.
marking	NUMBER	0	Setting this attribute equal to "1" indicates the part is a marking (decalcomanias, metalcals, vinyl film markings, etc.).
kit	NUMBER	0	Setting this attribute equal to "1" will display "(Repair kits available)" following the description.
quickchgexpl	NUMBER	0	Setting this attribute equal to "1" will display "(QCU available)" following the description.

ipbpl0tbl

Illustrated Parts Breakdown (IPB) Parts List Table

Description: Identifies the maintenance parts list table.

Source paragraph: 3.6.7 (MIL-PRF-38807)

Content Model: (ipbpl0+, ipbuseonodelist?) +(tfndisplay | note)

Parents: [ipbplgrp](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
numsmrcols	(1 2 3 4 5)	1	Identifies the number of SMR columns to be used in a multi-service manual. Must be used in conjunction with the service attribute on the ipbsmrcline element to get multiple columns to appear.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl0tblfoot

Illustrated Parts Breakdown (IPB) Parts List Table Footnote

Description: This is a placeholder for the FOSI generated "Not Illustrated" footnote.

Source paragraph: 3.6.7.2 and Figure 3 (MIL-PRF-38807)

Content Model: EMPTY

Parents: [ipbplgrp](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl1

Parts List - Indenture 1

Description: Identifies a part listing in the maintenance parts list that will have an indenture level of 1 in the description column.

Source paragraph: 3.6.7.4.1 (MIL-PRF-38807)

Content Model: ((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmr codes)+), ipbpl2*)

Parents: ipbp10

Entities used in this element: bodyatt, chgatt, delstat, mpl, mplatts, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
sepmanual	NUMBER	0	Setting this attribute equal to "1" identifies the maintenance parts list table as being in a separate manual.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
shown	NUMBER	1	Setting this attribute equal to "0" will display a dash in the figure/index column and "Not Illustrated" at the bottom of the maintenance parts list.
attachpart	NUMBER	0	Setting this attribute equal to "1" will display "(AP)" following the description.
marking	NUMBER	0	Setting this attribute equal to "1" indicates the part is a marking (decalcomanias, metalcals, vinyl film markings, etc.).
kit	NUMBER	0	Setting this attribute equal to "1" will display "(Repair kits available)" following the description.
quickchgexpl	NUMBER	0	Setting this attribute equal to "1" will display "(QCU available)" following the description.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl2

Illustrated Parts Breakdown (IPB) Part Listing - Indenture 2

Description: Identifies a part listing in the maintenance parts list that will have an indenture level of 2 in the description column.

Source paragraph: 3.6.7.4.1 (MIL-PRF-38807)

Content Model: ((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrpcodes)+)+, ipbpl3*)

Parents: ipbpl1

Entities used in this element: bodyatt, chgatt, delstat, mpl, mplatts, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
sepmanual	NUMBER	0	Setting this attribute equal to "1" identifies the maintenance parts list table as being in a separate manual.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
shown	NUMBER	1	Setting this attribute equal to "0" will display a dash in the figure/index column and "Not Illustrated" at the bottom of the maintenance parts list.
attachpart	NUMBER	0	Setting this attribute equal to "1" will display "(AP)" following the description.
marking	NUMBER	0	Setting this attribute equal to "1" indicates the part is a marking (decalcomanias, metalcals, vinyl film markings, etc.).
kit	NUMBER	0	Setting this attribute equal to "1" will display "(Repair kits available)" following the description.
quickchgexpl	NUMBER	0	Setting this attribute equal to "1" will display "(QCU available)" following the description.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl3

Illustrated Parts Breakdown (IPB) Part Listing - Indenture 3

Description: Identifies a part listing in the maintenance parts list that will have an indenture level of 3 in the description column.

Source paragraph: 3.6.7.4.1 (MIL-PRF-38807)

Content Model: ((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrpcodes)+)+, ipbpl4*)

Parents: ipbpl2

Entities used in this element: bodyatt, chgatt, delstat, mpl, mplatts, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
sepmanual	NUMBER	0	Setting this attribute equal to "1" identifies the maintenance parts list table as being in a separate manual.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
shown	NUMBER	1	Setting this attribute equal to "0" will display a dash in the figure/index column and "Not Illustrated" at the bottom of the maintenance parts list.
attachpart	NUMBER	0	Setting this attribute equal to "1" will display "(AP)" following the description.
marking	NUMBER	0	Setting this attribute equal to "1" indicates the part is a marking (decalcomanias, metalcals, vinyl film markings, etc.).
kit	NUMBER	0	Setting this attribute equal to "1" will display "(Repair kits available)" following the description.
quickchgexpl	NUMBER	0	Setting this attribute equal to "1" will display "(QCU available)" following the description.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl4

Illustrated Parts Breakdown (IPB) Part Listing - Indenture 4

Description: Identifies a part listing in the maintenance parts list that will have an indenture level of 4 in the description column.

Source paragraph: 3.6.7.4.1 (MIL-PRF-38807)

Content Model: ((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrpcodes)+)+, ipbpl5*)

Parents: ipbp13

Entities used in this element: bodyatt, chgatt, delstat, mpl, mplatts, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
sepmannual	NUMBER	0	Setting this attribute equal to "1" identifies the maintenance parts list table as being in a separate manual.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
shown	NUMBER	1	Setting this attribute equal to "0" will display a dash in the figure/index column and "Not Illustrated" at the bottom of the maintenance parts list.
attachpart	NUMBER	0	Setting this attribute equal to "1" will display "(AP)" following the description.
marking	NUMBER	0	Setting this attribute equal to "1" indicates the part is a marking (decalcomanias, metalcals, vinyl film markings, etc.).
kit	NUMBER	0	Setting this attribute equal to "1" will display "(Repair kits available)" following the description.
quickchgexpl	NUMBER	0	Setting this attribute equal to "1" will display "(QCU available)" following the description.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl5

Illustrated Parts Breakdown (IPB) Part Listing - Indenture 5

Description: Identifies a part listing in the maintenance parts list that will have an indenture level of 5 in the description column.

Source paragraph: 3.6.7.4.1 (MIL-PRF-38807)

Content Model: ((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrpcodes)+)+, ipbpl6*)

Parents: ipbpl4

Entities used in this element: bodyatt, chgatt, delstat, mpl, mplatts, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
sepmanual	NUMBER	0	Setting this attribute equal to "1" identifies the maintenance parts list table as being in a separate manual.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
shown	NUMBER	1	Setting this attribute equal to "0" will display a dash in the figure/index column and "Not Illustrated" at the bottom of the maintenance parts list.
attachpart	NUMBER	0	Setting this attribute equal to "1" will display "(AP)" following the description.
marking	NUMBER	0	Setting this attribute equal to "1" indicates the part is a marking (decalcomanias, metalcals, vinyl film markings, etc.).
kit	NUMBER	0	Setting this attribute equal to "1" will display "(Repair kits available)" following the description.
quickchgexpl	NUMBER	0	Setting this attribute equal to "1" will display "(QCU available)" following the description.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl6

Illustrated Parts Breakdown (IPB) Part Listing - Indenture 6

Description: Identifies a part listing in the maintenance parts list that will have an indenture level of 6 in the description column.

Source paragraph: 3.6.7.4.1 (MIL-PRF-38807)

Content Model: ((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrpcodes)+)+, ipbpl7*)

Parents: ipbpl5

Entities used in this element: bodyatt, chgatt, delstat, mpl, mplatts, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
sepmanual	NUMBER	0	Setting this attribute equal to "1" identifies the maintenance parts list table as being in a separate manual.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
shown	NUMBER	1	Setting this attribute equal to "0" will display a dash in the figure/index column and "Not Illustrated" at the bottom of the maintenance parts list.
attachpart	NUMBER	0	Setting this attribute equal to "1" will display "(AP)" following the description.
marking	NUMBER	0	Setting this attribute equal to "1" indicates the part is a marking (decalcomanias, metalcals, vinyl film markings, etc.).
kit	NUMBER	0	Setting this attribute equal to "1" will display "(Repair kits available)" following the description.
quickchgexpl	NUMBER	0	Setting this attribute equal to "1" will display "(QCU available)" following the description.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbpl7

Illustrated Parts Breakdown (IPB) Part Listing - Indenture 7

Description: Identifies a part listing in the maintenance parts list that will have an indenture level of 7 in the description column.

Source paragraph: 3.6.7.4.1 (MIL-PRF-38807)

Content Model: ((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrpcodes)+)+)

Parents: ipbpl6

Entities used in this element: bodyatt, chgatt, delstat, mpl, mplatts, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
sepmanual	NUMBER	0	Setting this attribute equal to "1" identifies the maintenance parts list table as being in a separate manual.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
shown	NUMBER	1	Setting this attribute equal to "0" will display a dash in the figure/index column and "Not Illustrated" at the bottom of the maintenance parts list.
attachpart	NUMBER	0	Setting this attribute equal to "1" will display "(AP)" following the description.
marking	NUMBER	0	Setting this attribute equal to "1" indicates the part is a marking (decalcomanias, metalcals, vinyl film markings, etc.).
kit	NUMBER	0	Setting this attribute equal to "1" will display "(Repair kits available)" following the description.
quickchgexpl	NUMBER	0	Setting this attribute equal to "1" will display "(QCU available)" following the description.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbplbrk

Illustrated Parts Breakdown (IPB) Parts List Break

Description: Allows the author to put a break in the maintenance parts list.

Source paragraph: None

Content Model: EMPTY

Included in: [ipbpl](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbplgrp

Illustrated Parts Breakdown (IPB) Parts List Group

Description: Container element for a figure and its associated parts list.

Source paragraph: 3.6 (MIL-PRF-38807)

Content Model: ([figure](#), [ipbpl0tbl](#), [ipbuseoncodelist?](#), [ipbpl0tblfoot?](#)) -([note](#))

Parents: [ipbpl](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbquickchgexpl

Illustrated Parts Breakdown (IPB) Quick Change Explanation

Description: Identifies the paragraph(s) in the IPB foreword which explain parts in kits and quick change units.

Source paragraph: 3.5.5 (MIL-PRF-38807)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)

Parents: ipbfwordchap

Entities used in this element: bodyatt, chgatt, delstat, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCl). All hardness critical items shall be identified by the **HCl** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.

Attribute	Type	Default	Description
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbrefdes

Illustrated Parts Breakdown (IPB) Reference Designator

Description: Identifies the first column of the reference designator index in the IPB.

Source paragraph: 3.8.2.1 (MIL-PRF-38807)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [ipbdesc](#), [ipbrfdsgpr](#), [ipbrfdsgprow](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbrfdsggrp

Illustrated Parts Breakdown (IPB) Reference Designator Group

Description: Container element for the reference designator index in the IPB.

Source paragraph: 3.8 (MIL-PRF-38807)

Content Model: ((ipbrfdsgrprow+ | (ipbrefdes?, ipbsssn?, ipbfigindex)+))

Parents: [ipbrfdsindx](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbrfdsgrprow

Illustrated Parts Breakdown (IPB) Reference Designator Group Row

Description: Identifies a row for the reference designator index in the IPB.

Source paragraph: 3.8 (MIL-PRF-38807)

Content Model: (ipbrefdes?, ipbsssn?, ipbfigindex)

Parents: [ipbrfdsggrp](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbrfdsindx

Illustrated Parts Breakdown (IPB) Reference Designator Index

Description: Identifies the reference designator index in the IPB chapter.

Source paragraph: 3.8 (MIL-PRF-38807)

Content Model: (ipbrfdsgpr) -(note) +(ipbgroup10)

Parents: ipbchap

Entities used in this element: bodyatt, chapatt, chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	NUMBER	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.
type	(refdes ssn both)	refdes	Defines whether the reference designator index includes reference designators, or SSSN, or both.
cols	(2 3)	3	Defines the number of columns for the reference designator index.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbserialization

Illustrated Parts Breakdown (IPB) Serialization

Description: Identifies the serialization paragraph(s) and serialization table in the IPB foreword.

Source paragraph: 3.5.2 (MIL-PRF-38807)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*, ipbsertable)

Parents: ipbwordchap

Entities used in this element: bodyatt, chgatt, delstat, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbserrow

Illustrated Parts Breakdown (IPB) Serialization Table Row

Description: Identifies a row in the serialization table in the IPB foreword.

Source paragraph: 3.5.2 (MIL-PRF-38807)

Content Model: ([nomen](#), [modelno](#), [serno](#))

Parents: [ipbsertable](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbsertable

Illustrated Parts Breakdown (IPB) Serialization Table

Description: Identifies the serialization table in the IPB foreword.

Source paragraph: 3.5.2 (MIL-PRF-38807)

Content Model: ([title?](#), ([ipbserrow](#)+ | ([nomen](#), [modelno](#), [serno](#))+))

Parents: [ipbserialization](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [secur](#), [status](#), [verified](#), [xatabatts](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
col1width	CDATA	1.75in	Specifies the value for the width of the first column.
col2width	CDATA	1.25in	Specifies the value for the width of the second column.
tabstyle	NMTOKEN	#IMPLIED	Describes the type of table.
frame	(top bottom topbot all sides none)	all	Defines the frame for the table.
colsep	NUMBER	1	Allows the author to include a vertical line to separate columns. Setting this attribute equal to "1" will generate column separators.
rowsep	NUMBER	0	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
orient	(port land1)	port	Defines orientation of table on the page, either portrait or landscape.
pgwide	NUMBER	1	Set this attribute equal to "1" to have the table fill the entire width of the page.
cellcont	(Continued Cont)	Continued	Specifies whether the table will display "Continued" or "Cont." when it continues on more than one page.
id	ID	#IMPLIED	Provides means to specify an ID number for the table.
footnotes	(page end)	#IMPLIED	Allows the author to specify whether table footnotes appear at the end of the table or at the end of the page.
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
leftind	CDATA	#IMPLIED	Specifies the left indent of the table in relationship to the page.
rightind	CDATA	#IMPLIED	Specifies the right indent of the table in relationship to the page.
leftmar	NUTOKEN	#IMPLIED	Specifies the left margin of the table.
rightmar	NUTOKEN	#IMPLIED	Specifies the right margin of the table.
topmar	NUTOKEN	#IMPLIED	Specifies the top margin of the table.
botmar	NUTOKEN	#IMPLIED	Specifies the bottom margin of the table.
mindepth	NUTOKEN	#IMPLIED	Specifies the minimum depth (height) of the table.
pgdeep	NUMBER	0	Setting this attribute equal to "1" will set the depth (height) of the table equal to the depth (height) of the page.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

ipbshtnoexpl

Illustrated Parts Breakdown (IPB) Sheet Number Explanation

Description: Identifies the paragraph(s) in the IPB foreword that explain sheet numbers.

Source paragraph: 3.5.7 (MIL-PRF-38807)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)

Parents: ipbfwordchap

Entities used in this element: bodyatt, chgatt, delstat, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbsimassemm

Illustrated Parts Breakdown (IPB) Similar Assemblies

Description: Identifies the paragraph(s) in the IPB foreword that explains the method used to list similar assemblies.

Source paragraph: 3.5.4 (MIL-PRF-38807)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)

Parents: ipbfwordchap

Entities used in this element: bodyatt, chgatt, delstat, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbsmrcode

Illustrated Parts Breakdown (IPB) Source, Maintenance, and Recoverability (SMR) Code

<i>Description:</i>	Identifies the SMR codes that appear in the SMR code column in the maintenance parts list.
<i>Source paragraph:</i>	3.6.7.7 (MIL-PRF-38807)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	ipbsmr codes
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
service	(army navy af marine cg)	af	Identifies which service the SMR code is applicable to in multi-service manuals. Must be used in conjunction with the numsmrcols attribute on the ipbpl0tbl element to get multiple columns to appear.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbsmrcodes

Illustrated Parts Breakdown (IPB) Source, Maintenance, and Recoverability (SMR) Codes

Description: Container element for the SMR codes that appear in the SMR code column in the maintenance parts list.

Source paragraph: 3.6.7.7 (MIL-PRF-38807)

Content Model: (ipbsmrcode)+

Parents: ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, ipbpl7

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbsmrexpl

Illustrated Parts Breakdown (IPB) Source, Maintenance, and Recoverability (SMR) code explanation.

Description: Identifies the paragraph(s) in the IPB foreword that explain the SMR codes.

Source paragraph: 3.5.9 (MIL-PRF-38807)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)

Parents: ipbfwordchap

Entities used in this element: bodyatt, chgatt, delstat, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcp	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbsssn

Illustrated Parts Breakdown (IPB) System, Subsystem, Sub-subsystem Number (SSSN)

Description: Identifies the SSSN in the reference designator index.

Source paragraph: 3.8.2.1 (MIL-PRF-38807)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [ipbdesc](#), [ipbrfdsgpr](#), [ipbrfdsgprow](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
showinftn	NUMBER	0	Setting this attribute equal to "1" will show the SSSN in the page footnote.
hidesssn	NUMBER	0	Setting this attribute equal to "1" will hide the SSSN.

ipbunits

Illustrated Parts Breakdown (IPB) Units

Description: Identifies the units that appear in the units per assembly column in the maintenance parts list.

Source paragraph: 3.6.7.5 (MIL-PRF-38807)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [ipbpl0](#), [ipbpl1](#), [ipbpl2](#), [ipbpl3](#), [ipbpl4](#), [ipbpl5](#), [ipbpl6](#), [ipbpl7](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbuseoncode

Illustrated Parts Breakdown (IPB) Usable on Code

Description: Identifies the useable on code that appears in the useable on code column in the maintenance parts list.

Source paragraph: 3.6.7.6 (MIL-PRF-38807)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [ipbpl0](#), [ipbpl1](#), [ipbpl2](#), [ipbpl3](#), [ipbpl4](#), [ipbpl5](#), [ipbpl6](#), [ipbpl7](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbuseonodelist

Illustrated Parts Breakdown (IPB) Usable on Code List

Description: Identifies the usable on code list that appears at the end of the maintenance parts list.

Source paragraph: 3.6.7.6 (MIL-PRF-38807)

Content Model: (term, def)+ +(note)

Parents: [ipbpl0tbl](#), [ipbplgrp](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ipbuseonexpl

Illustrated Parts Breakdown (IPB) Usable on Code Explanation

Description: Identifies the paragraph(s) in the IPB foreword that explain the definitions of the useable on codes.

Source paragraph: 3.5.8 (MIL-PRF-38807)

Content Model: (title, [warning*](#), [caution?](#), [note?](#), ([para](#), [note?](#))?, ([step1](#), [step1+](#))?, [subpara1*](#))

Parents: [ipbwordchap](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcp	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

item

Item

<i>Description:</i>	Identifies an item within a list.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(figure table foldout objmedia)
<i>Parents:</i>	randlist , seqlist
<i>Entities used in this element:</i>	chgatt , delstat , exclus , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

label

Label

<i>Description:</i>	Identifies the label for a manually tagged table of contents entry.
<i>Source paragraph:</i>	4.5.6 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+)
<i>Parents:</i>	cntentry

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

legend

Legend

Description: A tabular listing of an illustration's index numbers/letters and their meanings.

Source paragraph: 4.6.17 (MIL-STD-38784)

Content Model: ([tabmat](#))

Parents: [figure](#), [foldout](#), [subfig](#), [subfigfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

lep

List of Effective Pages (LEP)

Description: Identifies the list of effective pages for the manual.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ([lepcontents](#)) -([note](#))

Parents: [auxfront](#), [front](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
lepcount	NUMBER	0	Identifies the number of pages in the manual for a manually tagged LEP.

lepchg

List of Effective Pages (LEP) Change

Description: Identifies the change number that appears in the change number column in a manually tagged LEP entry.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [lepentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

lepcontents

List of Effective Pages (LEP) Contents

Description: Contains the entries for the LEP. The FOSI can automatically generate the LEP.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ([lepentry](#))⁺

Parents: [lep](#)

Entities used in this element: [lepcontents](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.

lepentry

List of Effective Pages (LEP) Entry

Description: Identifies an entry for a manually tagged LEP.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ([leppage](#), [lepchg](#))

Parents: [lepcontents](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

leppage

List of Effective Pages (LEP) Page

Description: Identifies the page numbers that appear in the page number column in a manually tagged LEP entry.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [lepentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

letter

Letter

<i>Description:</i>	Identifies the letter heading for the index and glossary.
<i>Source paragraph:</i>	4.2.9.7 and 4.2.9.8 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	glossary , glosslist , glossrow , index , indexrow
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

line

Line

<i>Description:</i>	This element is used to indicate that a column or line should be forced at that point.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Included in:</i>	doc
<i>Entities used in this element:</i>	chgatt , delstat , lineatt , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
prespace	CDATA	#IMPLIED	Allows the author to set the amount of space before/above the line used.
postspace	CDATA	#IMPLIED	Allows the author to set the amount of space after/below the line used.
quad	(left center right justify)	left	Specifies the quadding option for the line.
indent	CDATA	#IMPLIED	Specifies how much indentation is set on the line.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

location

Location (Not Used; Under Review)

Description: Identifies the placement of a floating object such as a figure, table or figure table.

Source paragraph: None

Content Model: EMPTY

Included in: [doc](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

Irp

List of Related Publications

Description: Identifies the list related publications.

Source paragraph: 4.5.9.2 (MIL-STD-38784)

Content Model: ((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)?, lrptable?)

Parents: foreword, intro, preface

Entities used in this element: bodyatt, chgatt, delstat, lrp, para0att, parazero, secur, status, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
ltermwidth	NUTOKEN	1.63in	Allows the author to set the width of the left column.
rtermwidth	NUTOKEN	1.9in	Allows the author to set the width of the right column.
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

Irpretry

List of Related Publications Entry

Description: Identifies an entry in the list of related publications. When the value of the id attribute is specified via the xrefid attribute of the extref element, the title of the publication appears. Please note: According to spec, only the tmidno and title elements may be used for the lrp. The partno, modelno, and typedes elements were left in only for backwards compatability and possible future expansion.

Source paragraph: 4.5.9.2 (MIL-STD-38784)

Content Model: (([partno](#) | ([modelno](#) | [typedes](#)))*[tmidno](#)+, [title](#))

Parents: [lrptable](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

Irptable

List of Related Publications Table

Description: Identifies the list of related publications table.

Source paragraph: 4.5.9.2 (MIL-STD-38784)

Content Model: ([lrpretry](#)*)

Parents: [lrp](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

maintlvl

Maintenance Level

<i>Description:</i>	Identifies the maintenance level of the manual (e.g. organizational, intermediate, depot, etc.) on the title page.
<i>Source paragraph:</i>	4.5.1.3.3 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hpc hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	idinfo
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mfr

Manufacturer

Description: Identifies the manufacturer of the equipment on the title page.

Source paragraph: 4.5.1.3.6 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

modelno

Model Number

Description: Identifies the model number of the equipment on the title page and on the difference data sheet.

Source paragraph: 4.5.1.3.4 and 4.7.3.3 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ddsheets](#), [ipbserrow](#), [ipbsertable](#), [lrpentry](#), [prttitle](#)

Entities used in this element: [exclus](#), [secur](#), [text](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

Attribute	Type	Default	Description
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

modreq

Modification Request (Not Used; Under Review)

Description: The modification request element identifies a marking which document editors may place into the document instance to indicate where modification should be made. This element is used only in the review process and will not be used during document composition.

Source paragraph: None

Content Model: ([mrinfo?](#), [mrmod](#), [mrrespns?](#))

Included in: [doc](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
xref	NMTOKEN	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
refpos	(prexref postxref xref)	xref	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
by	CDATA	#REQUIRED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
date	CDATA	#REQUIRED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
organiz	NMTOKEN	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
orgcat	NMTOKEN	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
cmntrcat	NMTOKEN	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
priority	(1 2 3 4 5)	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
category	NMTOKEN	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
topic	CDATA	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

movedata

Moved Data

Description: Provides a means to identify the type of information that will appear on the T-2 page when the title page overflows.

Source paragraph: 4.5.1 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mrchgtxt

Modification Request Change Text (Not Used; Under Review)

Description: Identifies the modification request change text used to indicate editorial changes during document production. This element is used only in the review process and will not be used during document composition.

Source paragraph: None

Content Model: ANY

Parents: [mrmod](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
chgloc	NUMBER	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
chglen	NUMBER	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
action	(insert delete replace)	replace	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.

mrngenmod

Modification Request General Modification (Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. This element is used only in the review process and will not be used during document composition.

Source paragraph: None

Content Model: ([mrpara](#) | [mrlist](#))⁺

Parents: [mrmod](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mrinfo

Modification Request Information (Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. This element is used only in the review process and will not be used during document composition.

Source paragraph: None

Content Model: ANY

Parents: [modreq](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mrinstr

Modification Request Instructions (Not Used; Under Review)

<i>Description:</i>	This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. This element is used only in the review process and will not be used during document composition.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	(mrpara mrlist) ⁺
<i>Parents:</i>	mrmod
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mritem

Modification Request Item (Not Used; Under Review)

<i>Description:</i>	This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. This element is used only in the review process and will not be used during document composition.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	((#PCDATA change tabmat fnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺
<i>Parents:</i>	mrlist
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mrlist

Modification Request List (Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. This element is used only in the review process and will not be used during document composition.

Source paragraph: None

Content Model: (mritem+)

Parents: [mrgenmod](#), [mrinstr](#), [mrreason](#), [mrrespns](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mrmod

Modification Request Modification (Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. This element is used only in the review process and will not be used during document composition.

Source paragraph: None

Content Model: (mrreason?, (mrgenmod|(mrinstr?, mrchgtxt)))

Parents: modreq

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mrpara

Modification Request Paragraph (Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None

Content Model: ((#PCDATA | change | tabmat | ftref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Parents: mrgenmod, mrinstr, mrreason, mrrespns

Entities used in this element: chgatt, delstat, status, text, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mrreason

Modification Request Reason (Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. This element is used only in the review process and will not be used during document composition.

Source paragraph: None

Content Model: ([mrpara](#) | [mrlist](#))+

Parents: [mrmod](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

mrrespns

Modification Request Response(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. This element is used only in the review process and will not be used during document composition.

Source paragraph: None

Content Model: ([mrpara](#) | [mrlist](#))*

Parents: [modreq](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
disposn	NMTOKEN	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.
status	NMTOKEN	#IMPLIED	This attribute is used to specify information about the modification request. This attribute is not currently supported by the FOSI.

nameloc

Name Location - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a locator for external references and contains several nmlist elements. Useful for referencing objects that do not have the traditional SGML id.

Source paragraph: None

Content Model: (nmlist)*

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [fnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersd](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
HyBase	NAME	#FIXED nameloc	Assigns nameloc as the HyBase attribute.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

nmlist

Name List - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a description of the location of the entity or element reference in the nameloc element. Useful for referencing objects that do not have the traditional SGML id and/or entities that reside in external documents.

Source paragraph: None

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hpc](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [nameloc](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
HyBase	NAME	#FIXED nmsploc	Used in conjunction with HyTime to set up independent and contextual links.
impsrc	NAME	#FIXED grovert	Used in conjunction with HyTime to set up independent and contextual links.
HyBnames	CDATA	#FIXED "locsrc docorsub namespc nametype #MAPTOKEN elements element #MAPTOKEN entities entity"	Used in conjunction with HyTime to set up independent and contextual links.
nametype	(entity element)	entity	Identifies whether the external reference is an element or entity.
docorsub	ENTITY	#IMPLIED	Defines the entity name of the external document as declared in the entity declarations at the top of the tagged instance. Other attributes are not included because at this time as they are not applicable during alpha testing and will be added to the TDT as the options are explored and implemented.
notspace	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
notname	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
notprop	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
direct	(direct indirect)	indirect	Used in conjunction with HyTime to set up independent and contextual links.
locsrc	CDATA	#IMPLIED	Used in conjunction with HyTime to set up independent and contextual links.
cantcnst	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

nomen

Nomenclature

Description: Identifies the nomenclature of the equipment on the title page and on the difference data sheet.

Source paragraph: 4.5.1.3.4 and 4.7.3.3 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+ -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ddsheets](#), [ipbdesc](#), [ipbserrow](#), [ipbsertable](#), [prtitle](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltypes	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

none

None

<i>Description:</i>	Allows the author to opt for none instead of having the technical publications deficiency report table.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	tpdr

note

Note

<i>Description:</i>	Identifies a NOTE in the manual.
<i>Source paragraph:</i>	4.3.10 (MIL-STD-38784)
<i>Content Model:</i>	(para*) -(randlist deflist seqlist figure table foldout objmedia warning caution)
<i>Parents:</i>	abbrsect , abbrsect , applicdef , applicdef , chapter , dddesc , dddesc , ddindex , ddindex , entry , ipbesdsdesc , ipbesdsdesc , ipbfinding , ipbfinding , ipbhcidesc , ipbhcidesc , ipbmfrlist , ipbmfrlist , ipbmodelcover , ipbmodelcover , ipbpartstd , ipbpartstd , ipbquickchgexpl , ipbquickchgexpl , ipbserialization , ipbserialization , ipbshtnoexpl , ipbshtnoexpl , ipbsimassem , ipbsimassem , ipbsmrexpl , ipbsmrexpl , ipbuseonexpl , ipbuseonexpl , lrp , lrp , para0 , para0 , ratddesc , ratddesc , step1 , step1 , step2 , step2 , step3 , step3 , step4 , step4 , subpara1 , subpara1 , subpara2 , subpara2 , subpara3 , subpara3 , subpara4 , subpara4 , subpara5 , subpara5 , subpara6 , subpara6 , subpara7 , subpara7 , subpara8 , subpara8 , symsect , symsect , tctolist , tctolist , tmimprep , tmimprep
<i>Included in:</i>	doc , ipbpl0tbl , ipbuseoncodelist , para0 , section

Excluded in: [contents](#), [foldsect](#), [glossary](#), [illuslist](#), [index](#), [ipbnumindx](#), [ipbplgrp](#), [ipbrfdsindx](#), [lep](#), [tablelist](#), [title](#), [volcontents](#), [volilluslist](#), [vollep](#), [voltablelist](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [list](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

nsn

National Stock Number

Description: Identifies the national stock number of the equipment on the title page.

Source paragraph: 4.5.1.3.4 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [prtitle](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

nsp

Nuclear Surety Procedures

<i>Description:</i>	Identifies the nuclear surety procedures. Use of this element will cause the **NSP** symbol to appear at that point in the running text. This element should only be used in running text, e.g. to display the **NSP** symbol in a paragraph. The nsp attribute should be used to place the **NSP** symbol between a paragraph/step number and text.
<i>Source paragraph:</i>	4.3.10.2 (MIL-STD-38784)
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	abrtitle , activity , address , applicabil , appltile , authnot , change , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , figno , ftnote , hazmat , ilink , insertpg , internatlst , ipbcage , ipbfigindex , ipbfigureno , ipbpartnosym , ipbrefdes , ipbsmrcoe , ipbsssn , ipbunits , ipbuseoncode , item , label , lepchg , leppage , letter , line , maintlvl , mfr , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , phrase , pretmidno , prindex , pubdate , remarks , removepg , revnum , secindex , seqno , serno , sigblock , subject , subtitle , supersed , suppl , syntitle , tabno , tctono , term , tfid , title , tmidno , topic , tpdrlocation , tpdrno , typedes , typeno , underline , vollepgchg , volleppage , volnot , volnum
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

oadr

Official Authority Downgrade Review Notice

<i>Description:</i>	Identifies the official authority downgrade review notice on the title page. This notice is used only on classified manuals.
<i>Source paragraph:</i>	4.4 and 4.5.1.10 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+)
<i>Parents:</i>	downgrd
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

object

Multimedia Object

Description: Developed for use in interactive manuals to evoke multimedia applications.

Source paragraph: None

Content Model: (param*)

Parents: abbrtitle, activity, address, applicabil, apptitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, objmedia, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subobjmed, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrllocation, tpdarno, typedes, typeno, underline, vollepchg, volleppage, volnot, volnum

Entities used in this element: chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
objectno	ENTITY	#REQUIRED	References the object number of the application being referenced.
reprowid	NUTOKEN	#IMPLIED	Provides the width of the object being invoked, especially if it is a graphic or foldout from an external document.
reprodep	NUTOKEN	#IMPLIED	Provides the depth (height) of the object being invoked, especially if it is a graphic or foldout from an external document.
type	CDATA	#IMPLIED	Provides details about the type of applications being referenced.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

objmedia

Object Media

Description: Developed for use in interactive manuals to evoke multimedia applications. Defines details about the external application being invoked.

Source paragraph: None

Content Model: (title, ((subobjmed, subobjmed+) | object)) -(figure | table | foldout | objmedia)

Included in: appendix, chapter, ddchapter

Excluded in: abbrtitle, acronym, acronymlist, applicabil, appltitle, caution, change, dataiden, date, dateinc, def, ecpno, emphasis, extapplicabil, figure, foldout, ftnote, item, modelno, nomen, note, objmedia, partno, prentry, remarks, secentry, serno, symtitle, tabdisplay, table, tabmat, tctono, term, title, tmidno, topic, typedes, typeno, underline, warning

Entities used in this element: bodyatt, chgatt, delstat, exclus, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

oci

Observable Critical Item

Description: Identifies the observable critical items. Use of this element will cause the ****OCI**** symbol to appear at that point in the running text. This element should only be used in running text, e.g. to display the ****OCI**** symbol in a paragraph. The oci attribute should be used to place the ****OCI**** symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.6 (MIL-STD-38784)

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmllist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ocp

Observable Critical Processes

<i>Description:</i>	Identifies the observable critical processes. Use of this element will cause the **OCP** symbol to appear at that point in the running text. This element should only be used in running text, e.g. to display the **OCP** symbol in a paragraph. The ocp attribute should be used to place the **OCP** symbol between a paragraph/step number and text.
<i>Source paragraph:</i>	4.3.10.6 (MIL-STD-38784)
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	abbrtitle , activity , address , applicabil , appltitle , authnot , change , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , figno , ftnote , hazmat , ilink , insertpg , internatlstd , ipbcage , ipbfigindex , ipbfigureno , ipbpartnosym , ipbrefdes , ipbsmrcode , ipbsssn , ipbunits , ipbuseoncode , item , label , lepchg , leppage , letter , line , maintlvl , mfr , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , phrase , pretmidno , prindex , pubdate , remarks , removepg , revnum , secindex , seqno , serno , sigblock , subject , subtitle , supersed , suppl , syntitle , tabno , tctono , term , tfnid , title , tmidno , topic , tpdrlocation , tpdrno , typedes , typeno , underline , vollepgchg , volleppage , volnot , volnum
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

pageno

Page Number

<i>Description:</i>	Identifies the page number associated with each table/figure that appears in the list of tables or list of illustrations when the list is manually tagged.
<i>Source paragraph:</i>	4.5.7 and 4.5.8 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	cntentry , ddlist , illustrow , illuslist , tablelist , tbllistrow , volilluslist , voltablelist
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

para

Paragraph

<i>Description:</i>	Identifies text within a paragraph without regard to title, heading, etc. For example, a NOTE consists of a heading and one or more paragraphs.
<i>Source paragraph:</i>	4.2.9.5 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat fnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+ randlist deflist seqlist)+)
<i>Parents:</i>	abbrsect , applicdef , caution , dddesc , ddindex , ipbesdsdesc , ipbfinding , ipbhcidesc , ipbmfrlist , ipbmodelcover , ipbpartstd , ipbquickchgexpl , ipbserialization , ipbshtnoexpl , ipbsimassem , ipbsmrexpl , ipbuseonexpl , lrp , note , para0 , ratddesc , step1 , step2 , step3 , step4 , subpara1 , subpara2 , subpara3 , subpara4 , subpara5 , subpara6 , subpara7 , subpara8 , symsect , tctolist , tmimprep , warning , wpgentry
<i>Entities used in this element:</i>	chgatt , delstat , list , paracon , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
xrefid	IDREF	#IMPLIED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

para0

Primary Paragraph

Description: Identifies a primary paragraph within the manual.

Source paragraph: 4.2.9.5.1.1 (MIL-STD-38784)

Content Model: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*) +(note)

Parents: [appendix](#), [chapter](#), [ddsheets](#), [foreword](#), [foreword](#), [intro](#), [intro](#), [ipbwordchap](#), [ipbwordchap](#), [preface](#), [preface](#), [safesum](#), [section](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcp	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

param

Parameter

<i>Description:</i>	Used with Object Media to provide textual information about the application being invoked.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	object
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

partno

Part Number

<i>Description:</i>	Identifies the part number of the equipment on the title page and on the difference data sheet.
<i>Source paragraph:</i>	4.5.1.3.4 and 4.7.3.3 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+ -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ddlist](#), [ddsheets](#), [ipbnumgrp](#), [ipbnumgrprow](#), [ipbpl0](#), [ipbpl1](#), [ipbpl2](#), [ipbpl3](#), [ipbpl4](#), [ipbpl5](#), [ipbpl6](#), [ipbpl7](#), [lrpentry](#), [prttitle](#), [pslist](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

pgbrk

Page Break

Description: Identifies where a page will begin. Page breaks can be placed at the top of each logical page to identify where the page should start.

Source paragraph: 4.2.1.1 (MIL-STD-38784)

Content Model: EMPTY

Included in: [doc](#)

Entities used in this element: [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
pgnum	CDATA	#IMPLIED	Page number generated by the FOSI during a recomposition. Provides data for OmniMark and DataLogics Composer in the script and change package processing.
pgnumber	CDATA	#IMPLIED	Allows the author to assign the page number.
pgdesc	CDATA	#IMPLIED	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
nxtpgnum	CDATA	#IMPLIED	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
nxtpgdesc	CDATA	#IMPLIED	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.

Attribute	Type	Default	Description
seqnum	CDATA	#IMPLIED	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
prefix	CDATA	#IMPLIED	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
paraflag	NUMBER	0	Setting this attribute equal to "1" will allow the last paragraph on the page to split.
hyphflag	NUMBER	#IMPLIED	Setting this attribute equal to "1" will allow the last word on a page to be hyphenated.
shrink	NUMBER	100	Used to shrink vertical space so that overflowed text will pull back to the desired page.
rectover	NUMBER	#IMPLIED	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
chglevel	CDATA	#IMPLIED	Specifies the change level of the page.
security	CDATA	#IMPLIED	Identifies the security level of the document
empty	NUMBER	0	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
ignore	CDATA	#IMPLIED	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
chgstatus	CDATA	#IMPLIED	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
prevchgstatus	CDATA	#IMPLIED	This attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
emergency	(0 1)	#IMPLIED	Indicates that this element will produce an emergency border on the page when set equal to "1".
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.

phrase

Downgrade Phrase

Description: Identifies the text of the downgrade notice on the title page.

Source paragraph: 4.4 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [downgrd](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

preface

Preface

Description: Identifies the preface of the manual. This element is identical to the foreword and introduction elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: (para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp | tctolist | ratddesc | tmimprep)*) +(figure | table)

Parents: auxfront, front

Entities used in this element: chgatt, delstat, fpi, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltypes	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

preentry

Primary Index Entry

Description: Identifies the primary entries that will be included in the index when the index is tagged manually.

Source paragraph: 4.2.9.8 (MIL-STD-38784)

Content Model: (topic) -(figure | table | foldout | objmedia)

Parents: index, indexrow

Entities used in this element: chgatt, delstat, exclus, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

Attribute	Type	Default	Description
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

pretmidno

Previous Technical Manual Identification Number

<i>Description:</i>	Identifies the previous technical manual identification number of the manual on the title page. This element is used only when the manual number has been changed. The FOSI will automatically generate the "Formerly" prefix preceding the former manual number.
<i>Source paragraph:</i>	4.5.1 and Figure 1 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+)
<i>Parents:</i>	idinfo
<i>Entities used in this element:</i>	chgatt , delstat , secur , service , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
service	(AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD FRN)	#IMPLIED	Identifies which branch of service.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

prindex

Primary Index

<i>Description:</i>	Identifies a primary alphabetical index topic in the manual when the index is set to be automatically generated.
<i>Source paragraph:</i>	4.2.9.8 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(prindex)
<i>Parents:</i>	abbrtitle , activity , address , applicabil , apptitle , authnot , change , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , figno , ftnote , hazmat , ilink , insertpg , internatlstd , ipbcage , ipbfigindex , ipbfigureno , ipbpartnosym , ipbrefdes , ipbsmrcode , ipbsssn , ipbunits , ipbuseoncode , item , label , lepchg , leppage , letter , line , maintlvl , mfr , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , phrase , pretmidno , prindex , pubdate , remarks , removepg , revnum , secindex , seqno , serno , sigblock , subject , subtitle , supersed , suppl , symtitle , tabno , tctono , term , tfnid , title , tmidno , topic , tpdrlocation , tpdrno , typedes , typeno , underline , vollepgchg , volleppage , volnot , volnum
<i>Excluded in:</i>	prindex
<i>Entities used in this element:</i>	chgatt , delstat , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
pridnbr	CDATA	#IMPLIED	Defines a unique identification number that allows an association between items tagged as primary index topics and those tagged as secondary index topics.
display	NUMBER	1	Setting this attribute equal to "1" will display the contents of this element in the text where tagged and in the index. Setting this attribute equal to "0" will display the contents of this element in the index only.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

prtitle

Prime Title

Description: Identifies the title of the manual on the title page.

Source paragraph: 4.5.1.3.4 (MIL-STD-38784)

Content Model: (([nomen](#), ([modelno](#) | [partno](#) | [typesdes](#) | [pslist](#) | [nsn](#))⁺, [serno](#)*) | [subject](#))

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

pslist

Part/Serial Number List

Description: Identifies a listing on the title page that corresponds a particular part number with associated serial numbers. This element could also be used to correspond model numbers with serial numbers.

Source paragraph: 4.5.1.3.4 (MIL-STD-38784)

Content Model: ([partno](#), [serno](#))⁺

Parents: [prtitle](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

pubdate

Publication Date

Description: Identifies the basic date of the manual on the title page.

Source paragraph: 4.5.1.16 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

randlist

Random List

Description: Identifies a random list. All items within the random list will appear unnumbered but with bullets, on separate lines, in the order they were entered by the author.

Source paragraph: None

Content Model: ([title](#)?, [item](#)*)

Parents: [entry](#), [fnote](#), [para](#)

Excluded in: [caution](#), [note](#), [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
prefix	CDATA	#IMPLIED	Used to replace the bullets that are normally created by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

ratd

Record of Applicable Technical Directives Table

Description: Identifies the record of applicable technical directives table.

Source paragraph: 4.5.9.4 (MIL-STD-38784)

Content Model: (ratdentry+)

Parents: ratddesc

Entities used in this element: bodyatt, chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

ratddesc

Record of Applicable Technical Directives Description

Description: Identifies the description of the record of applicable technical directives paragraph(s) and the associated table.

Source paragraph: 4.5.9.4 (MIL-STD-38784)

Content Model: ((*title*, *warning**, *caution?*, *note?*, (*para*, *note?*)?), (*step1*, *step1+*)?, *subpara1**)?, *ratd?*)

Parents: *foreword*, *intro*, *preface*

Entities used in this element: *bodyatt*, *chgatt*, *delstat*, *para0att*, *parazero*, *secur*, *status*, *verified*, *wcn*, *yesorno*

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcp	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

Attribute	Type	Default	Description
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

ratdentry

Record of Applicable Technical Directives Table Entry

Description: Identifies each entry of the record of applicable technical directives table.

Source paragraph: 4.5.9.4 (MIL-STD-38784)

Content Model: (typeno, date?, title, ecjno?, dateinc?, remarks?)

Parents: ratd

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

rear

Rear Matter

Description: Identifies the rear matter of the manual.

Source paragraph: 4.2.4.1, 4.2.9.6, 4.2.9.7, and 4.2.9.8 (MIL-STD-38784)

Content Model: ([appendix*](#), [glossary?](#), [index?](#), [foldsect?](#))

Parents: [doc](#), [volume](#)

Entities used in this element: [chgatt](#), [delstat](#), [rr](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
numcols	(1 2)	#REQUIRED	Allows the author to define the page format as one or two columns for this section of the manual.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

remarks

Remarks Entry

Description: Identifies an entry in the remarks column of the record of applicable technical directives or a remark in the illustrated parts breakdown parts list.

Source paragraph: 4.5.9.4e (MIL-STD-38784) and 3.6.7.4 (MIL-PRF-38807)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ipbdesc](#), [ratdentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.

Attribute	Type	Default	Description
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

removepg

Remove Page Column Entry

<i>Description:</i>	Identifies an entry within the Remove Page column on the change instruction sheet.
<i>Source paragraph:</i>	4.7.3.10.2 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	chglist
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

revnum

Revision Number

<i>Description:</i>	Identifies the revision number of the manual on the title page.
<i>Source paragraph:</i>	4.8 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

row

Row

Description: Identifies a row in a table.

Source paragraph: 4.2.7 (MIL-STD-38784)

Content Model: ([entry](#) | [entrytbl](#))⁺

Parents: [tbody](#), [tfoot](#), [thead](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
rowsep	NUMBER	#IMPLIED	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
valign	(top bottom middle)	#IMPLIED	Defines the vertical alignment for cell contents.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

safesum

Safety Summary

Description: Identifies the safety summary of the manual. The title is automatically generated by the FOSI.

Source paragraph: 4.5.10 (MIL-STD-38784)

Content Model: (para0+) +(figure | table | warning | caution)

Parents: auxfront, front

Entities used in this element: bodyatt, chgatt, delstat, para0att, safesum, secur, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

seal

Seal

Description: Identifies the Department of the Navy Seal, with command identifier, which appears below the contract number on the title page.

Source paragraph: 4.5.1.5 (MIL-STD-38784)

Content Model: EMPTY

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

secentry

Secondary Index Entry

Description: Identifies the secondary entries that will be included in the index when the index is tagged manually.

Source paragraph: 4.2.9.8 (MIL-STD-38784)

Content Model: (topic) -(figure | table | foldout | objmedia)

Parents: [index](#), [indexrow](#)

Entities used in this element: [chgtatt](#), [delstat](#), [exclus](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

secindex

Secondary Index

Description: Identifies a secondary alphabetical index topic in the manual when the index is set to be automatically generated.

Source paragraph: 4.2.9.8 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hpc](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([secindex](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcode](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvl](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [vollepgchg](#), [volleppage](#), [volnot](#), [volnum](#)

Excluded in: [secindex](#)

Entities used in this element: [chgtatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
pridnbr	CDATA	#REQUIRED	Defines a unique identification number that allows an association between items tagged as primary index topics and those tagged as secondary index topics.
display	NUMBER	1	Setting this attribute equal to "1" will display the contents of this element in the text where tagged and in the index. Setting this attribute equal to "0" will display the contents of this element in the index only.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

section

Section

Description: Identifies a section of the manual.

Source paragraph: 4.2.9.4 (MIL-STD-38784)

Content Model: (title, para0+) +(note)

Parents: chapter, chapter

Entities used in this element: bodyatt, chapatt, chgatt, delstat, sect, sectatt, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

seqlist

Sequential List

Description: Identifies a sequential list. All items within the sequential list will appear numbered, on separate lines, in the order they were entered by the author.

Source paragraph: None

Content Model: (title?, item+)

Parents: entry, footnote, para

Excluded in: caution, note, warning

Entities used in this element: chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
numstyle	(alphauc alphalc arabic romanuc romanlc)	arabic	Defines the type of enumeration on the sequential list. Set this attribute to "alphauc" for uppercase letters (e.g., A., B., C., etc.), "alphalc" for lowercase letters (e.g., a., b., c., etc.), "arabic" for numbers (e.g., 1., 2., 3., etc.), "romanuc" for uppercase roman numerals (e.g., I., II., III., etc.), "romanlc" for lowercase roman numerals (e.g., i., ii., iii., etc.).
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

seqno

Sequence Number

Description: Identifies the sequence number for a hazard warning.

Source paragraph: 4.3.10.1 (MIL-STD-38784)

Content Model: ((#PCDATA | change | tabmat | fnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Parents: icon

Entities used in this element: chgatt, delstat, status, text, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

serno

Serial Number

Description: Identifies serial numbers of the equipment on the title page and on the difference data sheet.

Source paragraph: 4.5.1.3.4 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ipbserrow](#), [ipbsertable](#), [prtitle](#), [pslist](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

sigblock

Signature Block

Description: Identifies a signature block on the change instruction sheet.

Source paragraph: 4.7.3.10.2 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginsst](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

spanspec

Span Specification

Description: Used to join two or more columns in a table. Span specifications are similar to column specifications (<colspec>) except that they describe areas of the table that can be spanned (joined) using a table entry (<entry>). For example, a three-column table may have columns named 1, 2, and 3 respectively. A span named 23 may be declared using spanspec. When spanname=23 is used on an entry, that entry would occupy the space in both columns 2 and 3.

Source paragraph: 4.2.7 (MIL-STD-38784)

Content Model: EMPTY

Parents: [entrytbl](#), [tfoot](#), [tgroup](#), [thead](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
namest	NMTOKEN	#REQUIRED	This should be set to the name of the first column of the set of columns that the author wants to span.
nameend	NMTOKEN	#REQUIRED	This should be set to the name of the last column of the set of columns that the author wants to span.
spanname	NMTOKEN	#IMPLIED	Defines a unique name for the span.
align	(left right center justify char)	center	Defines the horizontal alignment of text within a cell.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column. This attribute should be used when the align attribute is set to "char".
colsep	NUMBER	#IMPLIED	Allows the author to include a vertical line to separate columns. Setting this attribute equal to "1" will generate column separators.
rowsep	NUMBER	#IMPLIED	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

step1

First Level Procedural Step

Description: Identifies a first level procedural step.

Source paragraph: 4.2.9.5.3 (MIL-STD-38784)

Content Model: (warning*, caution?, note?, para, note?, (step2, step2+)?)

Parents: abbrsect, abbrsect, applicdef, applicdef, dddesc, dddesc, ddindex, ddindex, ipbesdsdesc, ipbesdsdesc, ipbfinding, ipbfinding, ipbhcidesc, ipbhcidesc, ipbmfrlist, ipbmfrlist, ipbmodelcover, ipbmodelcover, ipbpartstd, ipbpartstd, ipbquickchgexpl, ipbquickchgexpl, ipbserialization, ipbserialization, ipbshtnoexpl, ipbshtnoexpl, ipbsimassem, ipbsimassem, ipbsmrexpl, ipbsmrexpl, ipbuseonexpl, ipbuseonexpl, lrp, lrp, para0, para0, ratddesc, ratddesc, subpara1, subpara1, subpara2, subpara2, subpara3, subpara3, subpara4, subpara4, subpara5, subpara5, subpara6, subpara6, subpara7, subpara7, subpara8, subpara8, symsect, symsect, tctolist, tctolist, tmimprep, tmimprep

Entities used in this element: chgatt, delstat, status, step1.mdl, stepatt, stepcon, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.

step2

Second Level Procedural Step

Description: Identifies a second level procedural step.
Source paragraph: 4.2.9.5.3 (MIL-STD-38784)
Content Model: (warning*, caution?, note?, para, note?, (step3, step3+)?)
Parents: step1, step1
Entities used in this element: chgatt, delstat, status, step2.mdl, stepatt, stepcon, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcg	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.

step3

Third Level Procedural Step

Description: Identifies a third level procedural step.

Source paragraph: 4.2.9.5.3 (MIL-STD-38784)

Content Model: (warning*, caution?, note?, para, note?, (step4, step4+)?)

Parents: step2, step2

Entities used in this element: chgatt, delstat, status, step3.mdl, stepatt, stepcon, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.

step4

Fourth Level Procedural Step

Description: Identifies a fourth level procedural step.

Source paragraph: 4.2.9.5.3 (MIL-STD-38784)

Content Model: ([warning*](#), [caution?](#), [note?](#), [para](#), [note?](#))

Parents: [step3](#), [step3](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [stepatt](#), [stepcon](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcg	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.

subfig

Subfigure

Description: Identifies a subfigure. This element is used for multisheet illustrations with each sheet being a subfigure. The FOSI will automatically generate the sheet count (e.g. Sheet 1 of 10, Sheet 2, etc.).

Source paragraph: 4.2.4.2 (MIL-STD-38784)

Content Model: ((([graphic](#), [legend](#)?)) | [tabdisplay](#))

Parents: [figure](#), [figure](#), [foldout](#), [foldout](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [subfig](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
orient	(port land1)	port	Defines the orientation of the figure, either portrait or landscape.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

subfigfo

Subfigure Foldout

Description: Identifies a subfigure used in a foldout.

Source paragraph: 4.2.4.1 (MIL-STD-38784)

Content Model: (([graphic](#), [legend?](#)) | [tabdisplay](#))

Parents: [figure](#), [figure](#), [foldout](#), [foldout](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
orient	(port land1)	port	Defines the orientation of the figure, either portrait or landscape.
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
pgstyle	(11x17 11x20.5 11x24 11x27.5 11x31 11x34.5 11x38 11x41.5 11x45)	#IMPLIED	Defines the page size for the foldout.
blankapron	NUMBER	1	Set this attribute to "1" to indicate that the foldout will have a blank apron, and to "0" to indicate that the foldout will not have a blank apron.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

subject

Subject

Description: Identifies the prime title of the manual on the title page.

Source paragraph: 4.5.1.3.4 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [prtitle](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

subjinfo

Subject Information (Not Used; Under Review)

Description: Identifies subject information that appears at the top of every column in a chapter. The first subjinfo tag in a chapter should be placed after the chapter element or the first section element (if used). Additional subjinfo elements have no restrictions on placement and should be used wherever the information changes.

Source paragraph: None

Content Model: EMPTY

Included in: [doc](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
subjup	CDATA	#REQUIRED	This attribute is not currently supported by the FOSI. Element and attributes are under review.
subjlwr	CDATA	#REQUIRED	This attribute is not currently supported by the FOSI. Element and attributes are under review.
infoup	CDATA	#REQUIRED	This attribute is not currently supported by the FOSI. Element and attributes are under review.
infolwr	CDATA	#REQUIRED	This attribute is not currently supported by the FOSI. Element and attributes are under review.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

subobjmed

Sub-Object Media

Description: Developed for use in interactive manuals to evoke multimedia applications. Defines details about the external application being invoked.

Source paragraph: None

Content Model: ([object](#))

Parents: [objmedia](#), [objmedia](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.

Attribute	Type	Default	Description
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

subpara1

First Subordinate Paragraph

Description: Identifies a first subordinate paragraph.

Source paragraph: 4.2.9.5.1.2 (MIL-STD-38784)

Content Model: (title, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara2*)

Parents: abbrsect, applicdef, dddesc, ddindex, ipbesdsdesc, ipbfinding, ipbhcidesc, ipbmfrlist, ipbmodelcover, ipbpartstd, ipbquickchgexpl, ipbserialization, ipbshtnoexpl, ipbsimassem, ipbsmrexpl, ipbuseonexpl, lrp, para0, ratddesc, symsect, tctolist, tmimprep

Entities used in this element: bodyatt, chgatt, delstat, nparcon, para0att, secur, status, sub1att, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

Attribute	Type	Default	Description
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

subpara2

Second Subordinate Paragraph

Description: Identifies a second subordinate paragraph.

Source paragraph: 4.2.9.5.1.2 (MIL-STD-38784)

Content Model: ((*title*)?, *warning**, *caution*?, *note*?, *para*, *note*?, (*step1*, *step1*+)?, *subpara3**)

Parents: [subpara1](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [nparcon1](#), [para0att](#), [secur](#), [status](#), [sub2att](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcp	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".

Attribute	Type	Default	Description
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

subpara3

Third Subordinate Paragraph

Description: Identifies a third subordinate paragraph.

Source paragraph: 4.2.9.5.1.2 (MIL-STD-38784)

Content Model: (([title](#))?, [warning](#)*, [caution](#)?, [note](#)?, [para](#), [note](#)?, ([step1](#), [step1](#)+)?, [subpara4](#)*)

Parents: [subpara2](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [nparcon1](#), [para0att](#), [secur](#), [status](#), [sub3att](#), [subpara3.mdl](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".

Attribute	Type	Default	Description
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

subpara4

Fourth Subordinate Paragraph

<i>Description:</i>	Identifies a fourth subordinate paragraph.
<i>Source paragraph:</i>	4.2.9.5.1.2 (MIL-STD-38784)
<i>Content Model:</i>	((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara5*)
<i>Parents:</i>	subpara3

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [nparcon1](#), [para0att](#), [secur](#), [status](#), [subatts](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
moretocspc	NUMBER	0	Setting this attribute equal to "1" will create more space between the subpara number and the subpara title in the table of contents.

subpara5

Fifth Subordinate Paragraph

Description: Identifies a fifth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2 (MIL-STD-38784)

Content Model: ((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara6*)

Parents: subpara4

Entities used in this element: bodyatt, chgatt, delstat, nparcon1, para0att, secur, status, subatts, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

subpara6

Sixth Subordinate Paragraph

Description: Identifies a sixth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2 (MIL-STD-38784)

Content Model: ((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara7*)

Parents: subpara5

Entities used in this element: bodyatt, chgatt, delstat, nparcon1, para0att, secur, status, subatts, verified, wcn, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

subpara7

Seventh Subordinate Paragraph

Description: Identifies a seventh subordinate paragraph.

Source paragraph: 4.2.9.5.1.2 (MIL-STD-38784)

Content Model: ((*title*)?, *warning**, *caution*?, *note*?, *para*, *note*?, (*step1*, *step1*+)?, *subpara8**)

Parents: [subpara6](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [nparcon1](#), [para0att](#), [secur](#), [status](#), [subatts](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcp	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".

Attribute	Type	Default	Description
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

subpara8

Eighth Subordinate Paragraph

Description: Identifies an eighth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2 (MIL-STD-38784)

Content Model: (([title](#))?, [warning](#)*, [caution](#)?, [note](#)?, [para](#), [note](#)?, ([step1](#), [step1](#)+)?)

Parents: [subpara7](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [nparcon1](#), [para0att](#), [secur](#), [status](#), [subatts](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

subtitle

Subtitle

<i>Description:</i>	Identifies the subtitle of the manual on the title page. This element is only used with multivolume manuals to indicate the contents of the specific volume as the prime title is shared amongst all the volumes.
<i>Source paragraph:</i>	4.5.1.3.5 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	idinfo
<i>Entities used in this element:</i>	chgatt , delstat , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

superseded

Supersedure Notice

<i>Description:</i>	Identifies the supersedure notice on the title page.
<i>Source paragraph:</i>	4.5.1.6 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	idinfo
<i>Entities used in this element:</i>	text

suppl

Supplement Notice

Description: Identifies the supplement notice on the title page.

Source paragraph: 4.5.1.7 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

symrow

Symbol Row

Description: Identifies a row which contains a term and definition for describing symbols used in the manual.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: ([term](#), [def](#))

Parents: [symsect](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

symsect

Symbol Paragraph

Description: Identifies the paragraph(s) used to define symbols (e.g., ESDS symbol) and the associated list.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: (([title](#), [warning*](#), [caution?](#), [note?](#), ([para](#), [note?](#))?), ([step1](#), [step1+](#))?, [subpara1*](#))?, ([symtitle?](#), ([symrow+](#) | ([term](#), [def](#))⁺)))

Parents: [foreword](#), [intro](#), [preface](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [symsect](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	2.75in	Allows the author to define the width of the right column.
ltermwidth	NUTOKEN	0.75in	Allows the author to define the width of the left column.
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

Attribute	Type	Default	Description
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

symtitle

Symbol Paragraph Title

Description: Identifies the title of the list that is used to define symbols (e.g., ESDS symbol).

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [symsect](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tabdisplay

Table Display

Description: Identifies table data contained within an illustration.

Source paragraph: 4.3.9 (MIL-STD-38784)

Content Model: (tgroup+) -(figure | table | foldout | objmedia) +(tfoot | tfnref | tfndisplay)

Parents: figure, foldout, subfig, subfigfo

Entities used in this element: chgatt, delstat, exclus, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
frame	(top bottom topbot all sides none)	all	Defines the frame for the table.
colsep	NUMBER	1	Allows the author to include a vertical line to separate columns. Setting this attribute equal to "1" will generate column separators.
rowsep	NUMBER	0	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
tbwidth	NUTOKEN	#IMPLIED	Defines the width of the table.
tbdepth	NUTOKEN	#IMPLIED	Defines the depth (height) of the table.
horrefpt	(left right)	left	Defines the horizontal reference point for the table.
verrefpt	(vtop vbottom)	vtop	Defines the vertical reference point for the table.
coordst	CDATA	0,10000	Defines the coordinates to start the table.
assocfig	IDREF	#IMPLIED	Used to associate the table with an illustration.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

table

Table

<i>Description:</i>	Identifies a table.
<i>Source paragraph:</i>	4.2.7 (MIL-STD-38784)
<i>Content Model:</i>	(title , tgroup +) -(figure table foldout objmedia) +(tfhref tfoot tfndisplay tfnid)
<i>Included in:</i>	appendix , chapter , ddchapter , foreword , intro , ipbfwordchap , preface , safesum
<i>Excluded in:</i>	abbrtitle , acronym , acronymlist , applicabil , apptitle , caution , change , dataiden , date , dateinc , def , ecpno , emphasis , extapplicabil , figure , foldout , ftnote , item , modelno , nomen , note , objmedia , partno , preentry , remarks , secentry , serno , symtitle , tabdisplay , table , tabmat , tctono , term , title , tmidno , topic , typedes , typeno , underline , warning
<i>Entities used in this element:</i>	bodyatt , chgatt , delstat , exclus , secur , status , tabatts , tabl , verified , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
tabstyle	NMTOKEN	#IMPLIED	Describes the type of table.
frame	(top bottom topbot all sides none)	all	Defines the frame for the table.
colsep	NUMBER	1	Allows the author to include a vertical line to separate columns. Setting this attribute equal to "1" will generate column separators.
rowsep	NUMBER	0	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
orient	(port land1)	port	Defines the orientation of the table on the page, either portrait or landscape.
pgwide	NUMBER	1	Set this attribute equal to "1" to have the table fill the entire width of the page.
cellcont	(Continued Cont)	Continued	Specifies whether the table will display "Continued" or "Cont." when it continues on more than one page.
id	ID	#IMPLIED	Provides means to specify an ID number for the table.
footnotes	(page end)	#IMPLIED	Allows the author to specify whether table footnotes appear at the end of the table or at the end of the page.
leftind	CDATA	#IMPLIED	Specifies the left indent of the table in relationship to the page.
rightind	CDATA	#IMPLIED	Specifies the right indent of the table in relationship to the page.
leftmar	NUTOKEN	#IMPLIED	Specifies the left margin of the table.
rightmar	NUTOKEN	#IMPLIED	Specifies the right margin of the table.
topmar	NUTOKEN	#IMPLIED	Specifies the top margin of the table.
botmar	NUTOKEN	#IMPLIED	Specifies the bottom margin of the table.
mindepth	NUTOKEN	#IMPLIED	Specifies the minimum depth (height) of the table.
pgdeep	NUMBER	0	Setting this attribute equal to "1" will set the depth (height) of the table equal to the depth (height) of the page.
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
continued	NUMBER	0	Setting this attribute equal to "1" allows the table to be continued from the previous page. This tag was only added to allow for proper formatting of table footnotes. It is to be used in conjunction with the 38784 Table Footnotes script.

tablelist

List of Tables

<i>Description:</i>	Identifies the list of tables in the manual. This information is automatically generated by the FOSI. If this element is not used, the list of tables will not appear in the manual.
<i>Source paragraph:</i>	4.5.8 (MIL-STD-38784)
<i>Content Model:</i>	(tbllistrow* (tabno, title, pageno)*) -(note)
<i>Parents:</i>	auxfront, front
<i>Entities used in this element:</i>	chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tabmat

Tabular Material

<i>Description:</i>	Identifies tabular material that is to be displayed without the table title or headers.
<i>Source paragraph:</i>	4.3.9.1 (MIL-STD-38784)
<i>Content Model:</i>	(tgroup+) -(figure table foldout objmedia)
<i>Parents:</i>	abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chglist, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, legend, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrllocation, tpdarno, typedes, typeno, underline, verstat, vollepage, volnot, volnum
<i>Entities used in this element:</i>	bodyatt, chgatt, delstat, exclus, secur, status, tabatts, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
tabstyle	NMTOKEN	#IMPLIED	Describes the type of table.
frame	(top bottom topbot all sides none)	all	Defines the frame for the table.
colsep	NUMBER	1	Allows the author to include a vertical line to separate columns. Setting this attribute equal to "1" will generate column separators.
rowsep	NUMBER	0	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
orient	(port land1)	port	Defines the orientation of the table on the page, either portrait or landscape.
pgwide	NUMBER	1	Set this attribute equal to "1" to have the table fill the entire width of the page.
cellcont	(Continued Cont)	Continued	Specifies whether the table will display "Continued" or "Cont." when it continues on more than one page.
id	ID	#IMPLIED	Provides means to specify an ID number for the table.
footnotes	(page end)	#IMPLIED	Allows the author to specify whether table footnotes appear at the end of the table or at the end of the page.
leftind	CDATA	#IMPLIED	Specifies the left indent of the table in relationship to the page.
rightind	CDATA	#IMPLIED	Specifies the right indent of the table in relationship to the page.
leftmar	NUTOKEN	#IMPLIED	Specifies the left margin of the table.
rightmar	NUTOKEN	#IMPLIED	Specifies the right margin of the table.
topmar	NUTOKEN	#IMPLIED	Specifies the top margin of the table.
botmar	NUTOKEN	#IMPLIED	Specifies the bottom margin of the table.
mindepth	NUTOKEN	#IMPLIED	Specifies the minimum depth (height) of the table.
pgdeep	NUMBER	0	Setting this attribute equal to "1" will set the depth (height) of the table equal to the depth (height) of the page.
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

tabno

Table Number

<i>Description:</i>	Identifies the table number within the list of tables when the list of tables is manually tagged.
<i>Source paragraph:</i>	4.5.8 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	tablelist , tblistrow , votablelist
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tbllistrow

List of Tables Row

Description: Identifies a row in the list of tables when the list of tables is manually tagged.

Source paragraph: 4.5.8 (MIL-STD-38784)

Content Model: ([tabno](#), [title](#), [pageno](#))

Parents: [tablelist](#), [voltablelist](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tbody

Table Body

Description: Identifies the body of a table (e.g., material below the boxheads).

Source paragraph: 4.2.7 (MIL-STD-38784)

Content Model: ([row+](#))

Parents: [entrytbl](#), [tgroup](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
valign	(top middle bottom)	top	Defines the vertical alignment of text within the cells of the table body.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tctolist

List of Time Compliance Technical Orders

Description: Identifies the time compliance technical orders paragraph(s) and the associated table.

Source paragraph: 4.5.9.3 (MIL-STD-38784)

Content Model: (([title](#), [warning*](#), [caution?](#), [note?](#), ([para](#), [note?](#))?), ([step1](#), [step1+](#))?, [subpara1*](#))?, [tctotbl](#)?)

Parents: [foreword](#), [intro](#), [preface](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcp	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hci	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tctono

Time Compliance Technical Order (TCTO) Number

Description: Identifies an entry in the TCTO Number column in the TCTO table.

Source paragraph: 4.5.9.3 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [tctorow](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

tctorow

Time Compliance Technical Orders Row

Description: Identifies a row in the time compliance technical orders table.

Source paragraph: 4.5.9.3 (MIL-STD-38784)

Content Model: (tctono, title, date)

Parents: tctotbl

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tctotbl

Time Compliance Technical Order (TCTO) Table

Description: Identifies the table that lists all TCTOs applicable to the manual. The FOSI will automatically generate the table title and the column headings (boxheads).

Source paragraph: 4.5.9.3 (MIL-STD-38784)

Content Model: (tctorow+)

Parents: tctolist

Entities used in this element: bodyatt, chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.

Attribute	Type	Default	Description
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

term

Term

<i>Description:</i>	Identifies an entry in the term portion of a list. Each term has an associated definition.
<i>Source paragraph:</i>	4.3.4 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(figure table foldout objmedia)
<i>Parents:</i>	acronym , acronymlist , acronymrow , applic , applichd , defhd , deflist , glosslist , glossrow , ipbuseoncodelist , symrow , symsect
<i>Entities used in this element:</i>	chgatt , delstat , exclus , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tfndisplay

Table Footnote Display

Description: This element is for displaying footnotes in a table. Footnotes to tables will be displayed at the end of the table. This element should be placed in a span in the last row of the table.

Source paragraph: 4.2.7.5 (MIL-STD-38784)

Content Model: EMPTY

Included in: [ipbpl0tbl](#), [tabdisplay](#), [table](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tfnid

Table Footnote ID

Description: This element is for placing a footnote in a table. A superscript character will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display element is used.

Source paragraph: 4.2.7.5 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [tfoot](#)

Included in: [table](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#REQUIRED	Allows the author to generate a unique ID for use when referencing this element.
tfntype	(num alpha sym)	num	Defines the type of symbol used to indicate a table footnote.
tfnsymbol	CDATA	#IMPLIED	Allows the author to define the actual symbol to serve as a table footnote reference.
tfnval	CDATA	#IMPLIED	Defines the text value of the reference. The actual data to be generated at the bottom of the table should be placed with this attribute.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tfnref

Table Footnote Reference

<i>Description:</i>	This element is for referencing a footnote in a table that was created with a table footnote ID. The superscript character that was generated from the table footnote ID will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display element is used.
<i>Source paragraph:</i>	4.2.7.5 (MIL-STD-38784)
<i>Content Model:</i>	EMPTY
<i>Included in:</i>	ipbcagecodes , tabdisplay , table
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tfoot

Table Footer

Description: The footer of the table.

Source paragraph: 4.2.7.5 (MIL-STD-38784)

Content Model: (([colspec*](#), [spanspec*](#), [row+](#)) | [tfnid+](#)) -([entrytbl](#))

Parents: [tgroup](#)

Included in: [ipbcagecodes](#), [tabdisplay](#), [table](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tgroup

Table Group

Description: Identifies a table group which consists of a table heading (boxheads) and a table body.

Source paragraph: 4.2.7 (MIL-STD-38784)

Content Model: ([colspec*](#), [spanspec*](#), ([thead?](#), [tfoot?](#), [tbody](#)))

Parents: [tabdisplay](#), [table](#), [tabmat](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
cols	NUMBER	#REQUIRED	Defines the number of columns within the table.
colsep	NUMBER	#IMPLIED	Allows the author to include a vertical line to separate columns. Setting this attribute equal to "1" will generate column separators.
rowsep	NUMBER	#IMPLIED	Allows the author to include a horizontal line to separate rows. Setting this attribute equal to "1" will generate row separators.
align	(left right center justify char)	left	Defines the horizontal alignment of text within a cell.

Attribute	Type	Default	Description
leftind	CDATA	#IMPLIED	Defines the left indent of text within the cell.
rightind	CDATA	#IMPLIED	Defines the right indent of the text within the cell.
leftmar	NUTOKEN	#IMPLIED	Defines the left margin of the cell.
rightmar	NUTOKEN	#IMPLIED	Defines the right margin of the cell.
topmar	NUTOKEN	#IMPLIED	Defines the top margin of the cell.
botmar	NUTOKEN	#IMPLIED	Defines the bottom margin of the cell.
mindepth	NUTOKEN	#IMPLIED	Defines the minimum depth (height) of the table.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column. This attribute should be used when the align attribute is set to "char".
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

thead

Table Heading (Boxheads)

<i>Description:</i>	Identifies a table heading (boxheads). The table heading (boxheads) repeat when the table breaks across a column or page.
<i>Source paragraph:</i>	4.2.7.3 (MIL-STD-38784)
<i>Content Model:</i>	(colspec*, spanspec*, row+) -(entrytbl)
<i>Parents:</i>	entrytbl, tgroup
<i>Entities used in this element:</i>	chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
valign	(top middle bottom)	bottom	Defines the vertical alignment of text within a cell.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

title

Title

Description:	Identifies a title (e.g., chapter, paragraph, table, etc.). The title should be tagged exactly as it is to appear in the table of contents. Titles that are placed on tables will appear in the List of Tables, and titles that are placed on figures and figure tables will be placed in the List of Illustrations.
Source paragraph:	4.2.7.2, 4.2.8.2, 4.2.9.3, 4.2.9.4, 4.2.9.5.1, and 4.2.9.5.1.1 (MIL-STD-38784)
Content Model:	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(figure table foldout objmedia note)
Parents:	abbrsect , appendix , applicdef , chapter , cntentry , dddesc , ddindex , deflist , figure , foldout , illistrow , illuslist , ipbesdsdesc , ipbfinding , ipbhcidesc , ipbmfriest , ipbmodelcover , ipbpartstd , ipbquickchgexpl , ipbserialization , ipbsertable , ipbshtnoexpl , ipbsimassem , ipbsmrexpl , ipbuseonexpl , lrp , lrpentry , objmedia , para0 , randlist , ratddesc , ratdentry , section , seqlist , subpara1 , subpara2 , subpara3 , subpara4 , subpara5 , subpara6 , subpara7 , subpara8 , symsect , table , tablelist , tblistrow , tctolist , tctorow , tmimprep , volilluslist , votablelist , wpgentry
Entities used in this element:	chgatt , delstat , exclus , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tmidno

Technical Manual Identification Number

Description:	Identifies the technical manual identification number. When used on the title page (<idinfo>), it will cause the technical manual number to appear on the title page and at the top of each page in the manual. When used in the list of related publications (<lrp>), it will cause the technical manual number to be placed in the Publication Number column.
--------------	---

Source paragraph: 4.2.1.5 and 4.5.9.2 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [idinfo](#), [lrpentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [service](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
service	(AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD FRN)	#IMPLIED	Defines the branch of service.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

tmimprep

Technical Manual Improvement Report

Description: Identifies the paragraph(s) which describe the technical manual improvement report process.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: ([title](#), [warning](#)*, [caution](#)?, [note](#)?, ([para](#), [note](#)?)?, ([step1](#), [step1](#)+)?, [subpara1](#)*)

Parents: [foreword](#), [intro](#), [preface](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [wcn](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that this element will produce an emergency border on the page when set equal to "1".
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
esds	NUMBER	0	Electrostatic Discharge Sensitive (ESDS). All paragraphs which address handling or maintenance which could damage ESDS parts shall be identified by the **ESD** symbol by setting this attribute equal to "1".

Attribute	Type	Default	Description
nsp	NUMBER	0	Nuclear Surety Procedures (NSP). All nuclear surety procedures shall be identified by the **NSP** symbol by setting this attribute equal to "1".
fcf	NUMBER	0	Fracture Critical Parts (FCP). All fatigue and fracture critical parts shall be identified by the **FCP** symbol by setting this attribute equal to "1".
hcp	NUMBER	0	Hardness Critical Processes (HCP). All hardness critical processes shall be identified by the **HCP** symbol by setting this attribute equal to "1".
hcl	NUMBER	0	Hardness Critical Items (HCI). All hardness critical items shall be identified by the **HCI** symbol by setting this attribute equal to "1".
ocp	NUMBER	0	Observable Critical Processes (OCP). All observable critical processes shall be identified by the **OCP** symbol by setting this attribute equal to "1".
oci	NUMBER	0	Observable Critical Items (OCI). All observable critical items shall be identified by the **OCI** symbol by setting this attribute equal to "1".
applicref	IDREFS	#IMPLIED	Allows the author to assign an applicability/effectivity reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver notapplicable)	unver	Identifies the verification status of the element.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

topic

Index topic

Description: Identifies topics that will be appear in the index when the index is manually tagged.

Source paragraph: 4.2.9.8 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcf](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [prentry](#), [secentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
page	CDATA	#IMPLIED	Defines the page where the index topic occurs in the manual.
para	CDATA	#IMPLIED	Defines the paragraph where the index topic occurs in the manual. If this attribute is specified, the page attribute should be ignored.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tpdr

Technical Publications Deficiency Report

Description: Identifies the technical publications deficiency report list.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: ([tpdrtbl](#) | [none](#))

Parents: [auxfront](#), [front](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tpdrlocation

Technical Publications Deficiency Report Location

Description: Identifies an entry in the Location column of the technical publications deficiency report table.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [tpdrrow](#), [tpdrtbl](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tpdrno

Technical Publications Deficiency Report Number

Description: Identifies an entry in the Report Control Number column of the technical publications deficiency report table.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [tpdrrow](#), [tpdrtbl](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

Attribute	Type	Default	Description
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tpdrrow

Technical Publications Deficiency Report Row

Description: Identifies a row in the technical publications deficiency report table.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: (activity, tpdarno, tpdlocation)

Parents: tpdrtbl

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

tpdrtbl

Technical Publications Deficiency Report Table

Description: Identifies the technical publications deficiency report table.

Source paragraph: 4.5.9 (MIL-STD-38784)

Content Model: (tpdrrow+ | (activity, tpdarno, tpdlocation)+)

Parents: tpd

Entities used in this element: [bodyatt](#), [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows the author to generate a unique ID for use when referencing this element.
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltypes	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.

typedes

Type Designation

Description: Identifies a type designation on the title page and on the difference data sheet.

Source paragraph: 4.5.1.3.4 and 4.7.3.3.1b (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+ -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ddsheets](#), [lrpentry](#), [prttitle](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

Attribute	Type	Default	Description
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

typeno

Directive Type and Number

Description: Identifies an entry in the Type/No column of the record of applicable technical directives table.

Source paragraph: 4.5.9.4a (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ratdentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

underline

Underline

<i>Description:</i>	Allows for the underlining of certain parts of the export control notice.
<i>Source paragraph:</i>	4.5.1.12 (MIL-STD-38784)
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(figure table foldout objmedia)
<i>Included in:</i>	expcont
<i>Entities used in this element:</i>	exclus , text

verbatim

Verbatim Text

<i>Description:</i>	A verbatim element is used to format computer examples or similar text in a typewritten emulation mode. Formatting follows "asis" quadding with monospaced font.
<i>Source paragraph:</i>	None
<i>Content Model:</i>	(#PCDATA)
<i>Parents:</i>	abbrtitle , activity , address , applicabil , applttitle , authnot , change , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , figno , fnote , hazmat , ilink , insertpg , internatlstd , ipbcage , ipbfigindex , ipbfigureno , ipbpartnosym , ipbrefdes , ipbsmrcode , ipbsssn , ipbunits , ipbuseoncode , item , label , lepchg , leppage , letter , line , maintlvl , mfr , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , phrase , pretmidno , prindex , pubdate , remarks , removepg , revnum , secindex , seqno , serno , sigblock , subject , subtitle , supersed , suppl , symtitle , tabno , tctono , term , tfnid , title , tmidno , topic , tpdrlocation , tpdrno , typedes , typeno , underline , volleppchg , volleppage , volnot , volnum
<i>Entities used in this element:</i>	chgatt , delstat , secur , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
allowbrk	NUMBER	1	Setting this attribute equal to "1" allows breaks to be inserted into verbatim text.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

verstat

Verification Status Page

<i>Description:</i>	Identifies the verification status page in the manual. This information is automatically generated by the FOSI. This element should not be used if a verification status page is not desired.
<i>Source paragraph:</i>	4.5.4 (MIL-STD-38784)
<i>Content Model:</i>	(tabmat?)
<i>Parents:</i>	auxfront , front
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	NUMBER	1	Set this attribute equal to "1" when the output of this element should be autogenerated.
agency	CDATA	#IMPLIED	Identifies the technical order management agency.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

volcontents

Volume Table of Contents

<i>Description:</i>	Identifies a table of contents for a volume.
<i>Source paragraph:</i>	4.5.6 (MIL-STD-38784)
<i>Content Model:</i>	((cntentry* #PCDATA)*) -(note)
<i>Parents:</i>	auxfront , front

Entities used in this element: [cntnt](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.

volilluslist

Volume List of Illustrations

Description: Identifies a list of illustrations for a volume.

Source paragraph: 4.5.7 (MIL-STD-38784)

Content Model: ([illistrow*](#) | ([figno](#), [title](#), [pageno](#))*) -([note](#))

Parents: [auxfront](#), [front](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.

vollep

Volume List of Effective Pages

Description: Identifies the list of effective pages for a volume.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ([vollepcontents](#)) -([note](#))

Parents: [auxfront](#), [front](#)

vollepchg

Volume List of Effective Pages (LEP) Change Number

Description: Identifies the change number that appears in the change number column in a manually tagged LEP entry for a volume.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [volleptentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

volleppcontents

Volume List of Effective Pages (LEP) Contents

Description: Identifies the contents of a manually tagged LEP for a volume.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ([volleptentry](#))⁺

Parents: [vollep](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.
lepcount	CDATA	#IMPLIED	Identifies the number of pages in the volume for a manually tagged LEP.

volleptentry

Volume List of Effective Pages (LEP) Entry

Description: Identifies a LEP entry in a manually tagged LEP for a volume.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ([volleppage](#), [volleppchg](#))

Parents: [volleppcontents](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

volleppage

Volume List of Effective Pages (LEP) Page Number

Description: Identifies the page number that appears in the page number column in a manually tagged LEP entry for a volume.

Source paragraph: 4.5.3 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [volleppentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

volnot

Volume Notice

Description: Identifies the volume notice on the title page.

Source paragraph: 4.2.9.1 and Figure 1 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

volnum

Volume Number

Description: Identifies the volume number on the title page.

Source paragraph: 4.2.9.1 and Figure 1 (MIL-STD-38784)

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

voltablelist

Volume List of Tables

Description: Identifies the list of tables for a volume.

Source paragraph: 4.5.8 (MIL-STD-38784)

Content Model: (tblistrow* | (tabno, title, pageno)*) -(note)

Parents: auxfront, front

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	Set this attribute equal to "1" when the output of this element should be autogenerated.

volume

Volume

Description: Identifies a volume.

Source paragraph: 4.2.9.1 (MIL-STD-38784)

Content Model: ((front | auxfront), body, rear?)

Parents: doc, doc

Entities used in this element: bodyatt, chgatt, delstat, docatt, secur, service, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows the author to label this element manually. The FOSI automatically generates labels, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, Sub-subsystem Number (SSSN). Allows the author to assign a SSSN to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. This attribute is not currently supported by the FOSI.
deltype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
security	(u c s n)	n	Identifies the security level of the element. Set this attribute to "u" for UNCLASSIFIED, "c" for CONFIDENTIAL, "s" for SECRET, or "n" for no security level.
caveat	CDATA	#IMPLIED	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	CDATA	#IMPLIED	Foreign Government Identification (FGI). Provides a place for inline FGI portion marking. This is typically only used in Foreign Military Sales (FMS) manuals.
docid	CDATA	#IMPLIED	Allows the author to define an identification number for the document.
docstat	(revision change prelim draft formal)	prelim	Allows the author to stipulate what form the manual is in.

Attribute	Type	Default	Description
verstatpg	(ver unver)	unver	Allows the author to stipulate a verified or unverified manual. Use of this attribute will trigger the generation of the verification status page and the temporary file - vsmatter.dat. See the accompanying readme.txt file on verification status for more details.
index	NUMBER	0	Indicates whether an index is included in the manual. This attribute should be set to "1" when an index is present. Use of this attribute will affect the level of detail in the table of contents.
service	(AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD FRN)	#REQUIRED	Defines the branch of service.
volpages	NUMBER	0	Setting this attribute equal to "1" will cause the page numbers to use the volume number prefix.
resetnbrs	NUMBER	1	Setting this attribute equal to "1" will cause the chapter and section numbers to reset for this volume.

warning

Warning

<i>Description:</i>	Identifies a WARNING in the manual. Multiple warning tags may be used only when it is desired to change the warning icon (standard or hazardous warning graphic).
<i>Source paragraph:</i>	4.3.10 (MIL-STD-38784)
<i>Content Model:</i>	(icon? , para*) -(randlist deflist seqlist figure table foldout objmedia warning caution)
<i>Parents:</i>	abbrsect , applicdef , dddesc , ddindex , entry , ipbesdsdesc , ipbfinding , ipbhcidesc , ipbmfrlist , ipbmodelcover , ipbpartstd , ipbquickchgexpl , ipbserialization , ipbshtnoexpl , ipbsimassem , ipbsmrexpl , ipbuseonexpl , lrp , para0 , ratddesc , step1 , step2 , step3 , step4 , subpara1 , subpara2 , subpara3 , subpara4 , subpara5 , subpara6 , subpara7 , subpara8 , symsect , tctolist , tmimprep
<i>Included in:</i>	safesum
<i>Excluded in:</i>	caution , note , warning
<i>Entities used in this element:</i>	chgatt , delstat , exclus , list , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

warnpage

Warning Page

Description: Identifies the warning page(s) of the manual.

Source paragraph: 4.5.2 (MIL-STD-38784)

Content Model: ([wpgentry+](#))

Parents: [auxfront](#), [front](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

wpgentry

Warning Page Entry

Description: Identifies an individual warning on the warning page(s). The FOSI does not currently fully support this element.

Source paragraph: 4.5.2 (MIL-STD-38784)

Content Model: ([title](#), [para](#)+)

Parents: [warnpage](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
warnbox	NUMBER	#IMPLIED	Allows you to specify the appearance and size of the warning box.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.
titlefont	(10pt 14pt)	14pt	Specifies the font size choices available for a warning page entry.
line	NUMBER	#IMPLIED	Specifies whether a line should appear between warning page entries.

xref

Cross-reference

Description: Identifies a cross-reference to a paragraph, figure, table, etc.

Source paragraph: 4.3.1 (MIL-STD-38784)

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [bindByCoords](#), [bindById](#), [bindByName](#), [change](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [figno](#), [ftnote](#), [hazmat](#), [ilink](#), [insertpg](#), [internattstd](#), [ipbcage](#), [ipbfigindex](#), [ipbfigureno](#), [ipbpartnosym](#), [ipbrefdes](#), [ipbsmrcline](#), [ipbsssn](#), [ipbunits](#), [ipbuseoncode](#), [item](#), [label](#), [lepchg](#), [leppage](#), [letter](#), [line](#), [maintlvi](#), [mfr](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [phrase](#), [pretnidno](#), [prindex](#), [pubdate](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [tabno](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [topic](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [volleppchg](#), [volleppage](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
xrefid	IDREF	#IMPLIED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
displayvalue	CDATA	#IMPLIED	Allows the author to add additional, unique information for purposes of referencing an external document. This attribute should be used for providing paragraph titles, system numbers, task numbers and for author-generated TO numbers where applicable.
HyTime	NAME	#FIXED "clink"	Used in combination with HyTime to establish a contextual link.
HyNames	NAMES	#FIXED "linkend xrefid"	Used in combination with HyTime to establish a contextual link.
delttype	(delete real reserve NA)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the deletion type of this element.
inschlvi	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvi	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was deleted at the change level indicated.
status	(empty deleted reserved notapp)	#IMPLIED	Allows for additional processing during the change package process and is used to indicate the status of this element.
revchg	NUMBER	0	Used to mark changes in a revision. Setting this attribute equal to "1" indicates a revision change.

% append

Unexpanded:
title, para0+

Expanded:
title, para0+

% auxfrnt

Unexpanded:
warnpage?, idinfo, chginssht?, (lep | vollep), verstat?, tpd?, chgrec?, (contents | volcontents), (illuslist| volilluslist)?, (tablelist | vtablelist)?, (foreword | preface | intro)?, safesum?

Expanded:
warnpage?, idinfo, chginssht?, (lep | vollep), verstat?, tpd?, chgrec?, (contents | volcontents), (illuslist| volilluslist)?, (tablelist | vtablelist)?, (foreword | preface | intro)?, safesum?

% bodyatt

Unexpanded:
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
%chgatt;

Expanded:
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% bodyele

Unexpanded:
chapter, ((chapter+, ipbchap?) | ipbchap), ddchapter?

Expanded:
chapter, ((chapter+, ipbchap?) | ipbchap), ddchapter?

% cgmatts

Unexpanded:

id ID #IMPLIED
title CDATA #IMPLIED
descript CDATA #IMPLIED
visibility (visible | hidden) 'visible'
interactivity (interactive | none) 'none'
%[chgatt](#);

Expanded:

id ID #IMPLIED
title CDATA #IMPLIED
descript CDATA #IMPLIED
visibility (visible | hidden) 'visible'
interactivity (interactive | none) 'none'
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% chap

Unexpanded:

[title](#), (([section](#), ([note](#)?, [section](#))⁺) | [para0](#)⁺)

Expanded:

[title](#), (([section](#), ([note](#)?, [section](#))⁺) | [para0](#)⁺)

% chapatt

Unexpanded:

id ID #IMPLIED
%[secur](#);
%[bodyatt](#);

Expanded:

id ID #IMPLIED
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% chgatt

Unexpanded:

delttype (%[delstat](#);) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (%[status](#);) #IMPLIED
revchg %[yesorno](#); '0'

Expanded:

delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% chgsht

Unexpanded:

[chgnum](#), [address](#), [date](#), [pritle](#), [effdatenot?](#), [discl?](#), [distrib](#), [expcont?](#), [destr?](#), [chgpara+](#), [chglist](#), [sigblock?](#)

Expanded:

[chgnum](#), [address](#), [date](#), [pritle](#), [effdatenot?](#), [discl?](#), [distrib](#), [expcont?](#), [destr?](#), [chgpara+](#), [chglist](#), [sigblock?](#)

% cntnt

Unexpanded:

([cntentry](#)* | #PCDATA)*

Expanded:

([cntentry](#)* | #PCDATA)*

% ddchap

Unexpanded:

[dddesc](#), ([ddindex](#), [ddsheets+](#))?

Expanded:

[dddesc](#), ([ddindex](#), [ddsheets+](#))?

% delstat

Unexpanded:

delete | real | reserve | NA

Expanded:

delete | real | reserve | NA

% descatts

Unexpanded:

```
attachpart %yesorno; '0'  
kit %yesorno; '0'  
quickchgexpl %yesorno; '0'  
%chgatt;
```

Expanded:

```
attachpart NUMBER '0'  
kit NUMBER '0'  
quickchgexpl NUMBER '0'  
delttype (delete | real | reserve | NA) #IMPLIED  
inschlvl NMTOKEN #IMPLIED  
delchlvl NMTOKEN #IMPLIED  
status (empty | deleted | reserved | notapp) #IMPLIED  
revchg NUMBER '0'
```

% doc

Unexpanded:

```
(volume, volume+) | (front, body, rear?)
```

Expanded:

```
(volume, volume+) | (front, body, rear?)
```

% docatt

Unexpanded:

```
docid CDATA #IMPLIED  
docstat (revision | change | prelim | draft | formal) 'prelim'  
verstatpg (ver | unver) 'unver'  
index %yesorno; '0'
```

Expanded:

```
docid CDATA #IMPLIED  
docstat (revision | change | prelim | draft | formal) 'prelim'  
verstatpg (ver | unver) 'unver'  
index NUMBER '0'
```

% entry

Unexpanded:

```
(%text; | %list; | warning | caution | note )+
```

Expanded:

```
((#PCDATA | change | tabmat | ftref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci |  
ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+ | randlist | deflist | seqlist | warning | caution | note )+
```

% entryatt

Unexpanded:

colname NMTOKEN #IMPLIED
spanname NMTOKEN #IMPLIED
id ID #IMPLIED
morerows NUMBER '0'
colsep %yesorno; #IMPLIED
rowsep %yesorno; #IMPLIED
rotate %yesorno; '0'
valign (top | middle | bottom) #IMPLIED
align (left | right | center | justify | char) #IMPLIED
charoff NUTOKEN #IMPLIED
char CDATA #IMPLIED
%chgatt;

Expanded:

colname NMTOKEN #IMPLIED
spanname NMTOKEN #IMPLIED
id ID #IMPLIED
morerows NUMBER '0'
colsep NUMBER #IMPLIED
rowsep NUMBER #IMPLIED
rotate NUMBER '0'
valign (top | middle | bottom) #IMPLIED
align (left | right | center | justify | char) #IMPLIED
charoff NUTOKEN #IMPLIED
char CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% exclus

Unexpanded:

[figure](#) | [table](#) | [foldout](#) | [objmedia](#)

Expanded:

[figure](#) | [table](#) | [foldout](#) | [objmedia](#)

expcontnot

Unexpanded:

This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C. SEC 2751, <underline>et</underline> <underline>seq</underline>.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App 2401 <underline>et</underline> <underline>seq</underline>. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

Expanded:

This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C. SEC 2751, <underline>et</underline> <underline>seq</underline>.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App 2401 <underline>et</underline>

<underline> seq</underline>. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

% fig

Unexpanded:

[title](#), ((([subfig](#) | [subfigfo](#)), ([subfig](#) | [subfigfo](#))⁺) | (([graphic](#), [legend?](#)) | [tabdisplay](#))⁺)

Expanded:

[title](#), ((([subfig](#) | [subfigfo](#)), ([subfig](#) | [subfigfo](#))⁺) | (([graphic](#), [legend?](#)) | [tabdisplay](#))⁺)

% figatts

Unexpanded:

[pgwide](#) %[yesorno](#); '1'
[orient](#) (port | land | land2) 'port'
[id](#) ID #IMPLIED
[applicref](#) IDREFS #IMPLIED
[legend](#) %[yesorno](#); '0'
[nextpg](#) %[yesorno](#); '0'
%[verified](#);
%[bodyatt](#);
%[secur](#);

Expanded:

[pgwide](#) NUMBER '1'
[orient](#) (port | land | land2) 'port'
[id](#) ID #IMPLIED
[applicref](#) IDREFS #IMPLIED
[legend](#) NUMBER '0'
[nextpg](#) NUMBER '0'
[verdate](#) CDATA #IMPLIED
[verrem](#) CDATA #IMPLIED
[verstatus](#) (unver | ver | notapplicable) 'unver'
[label](#) CDATA #IMPLIED
[sssn](#) CDATA #IMPLIED
[indexid](#) CDATA #IMPLIED
[delttype](#) (delete | real | reserve | NA) #IMPLIED
[inschlvl](#) NMTOKEN #IMPLIED
[delchlvl](#) NMTOKEN #IMPLIED
[status](#) (empty | deleted | reserved | notapp) #IMPLIED
[revchg](#) NUMBER '0'
[security](#) (u | c | s | n) 'n'
[caveat](#) CDATA #IMPLIED
[fgi](#) CDATA #IMPLIED

% fpi

Unexpanded:

[para0](#), ([para0](#) | [applicdef](#) | [symsect](#) | [abbrsect](#) | [internatlst](#) | [lrp](#) | [tctolist](#) | [ratddesc](#) | [tmimprep](#))*

Expanded:

[para0](#), ([para0](#) | [applicdef](#) | [symsect](#) | [abbrsect](#) | [internatlst](#) | [lrp](#) | [tctolist](#) | [ratddesc](#) | [tmimprep](#))*

% frnt

Unexpanded:

[warnpage?](#), [idinfo](#), [chginssht?](#), ([lep](#) | [vollep](#)), [verstat?](#), [tpdr?](#), [chgrec?](#), ([contents](#) | [volcontents](#)), ([illuslist](#)| [volilluslist](#))?, ([tablelist](#) | [votablelist](#))?, ([foreword](#) | [preface](#) | [intro](#)), [safesum?](#)

Expanded:

[warnpage?](#), [idinfo](#), [chginssht?](#), ([lep](#) | [vollep](#)), [verstat?](#), [tpdr?](#), [chgrec?](#), ([contents](#) | [volcontents](#)), ([illuslist](#)| [volilluslist](#))?, ([tablelist](#) | [votablelist](#))?, ([foreword](#) | [preface](#) | [intro](#)), [safesum?](#)

% glossry

Unexpanded:

([letter?](#), [glosslist](#))⁺

Expanded:

([letter?](#), [glosslist](#))⁺

% graphatt

Unexpanded:

id ID #IMPLIED
boardno ENTITY #REQUIRED
graphsty NMTOKEN #IMPLIED
llcordra CDATA #IMPLIED
rucordra CDATA #IMPLIED
reprowid NUTOKEN #IMPLIED
reprodep NUTOKEN #IMPLIED
hscale NUMBER #IMPLIED
vscale NUMBER #IMPLIED
scalefit %[yesorno](#); #IMPLIED
hplace (left | right | center) #IMPLIED
vplace (top | middle | bottom) #IMPLIED
coordst CDATA #IMPLIED
coordend CDATA #IMPLIED
color %[yesorno](#); '0'
icon (yes|no) 'no'
%[chgatt](#);

Expanded:

id ID #IMPLIED
boardno ENTITY #REQUIRED
graphsty NMTOKEN #IMPLIED
llcordra CDATA #IMPLIED
rucordra CDATA #IMPLIED
reprowid NUTOKEN #IMPLIED
reprodep NUTOKEN #IMPLIED
hscale NUMBER #IMPLIED
vscale NUMBER #IMPLIED
scalefit NUMBER #IMPLIED
hplace (left | right | center) #IMPLIED
vplace (top | middle | bottom) #IMPLIED
coordst CDATA #IMPLIED
coordend CDATA #IMPLIED

color NUMBER '0'
icon (yes|no) 'no'
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% icon

Unexpanded:

[graphic+](#), [hazmat+](#), [seqno](#)

Expanded:

[graphic+](#), [hazmat+](#), [seqno](#)

% idinf

Unexpanded:

[tmidno+](#), ([chgnum](#), [chgdate](#))?, [chghistory](#), [pretmidno*](#), [volnum?](#), [revnum?](#), [doctype](#), [maintlvl?](#), [prttitle](#), [subtitle?](#), ([mfr+](#), [contractno+](#))?, [seal?](#), [superseded?](#), [suppl*](#), [effdatenot?](#), [volnot?](#), [discl?](#), [distrib](#), [expcont?](#), [destr?](#), [copyright*](#), [cogact?](#), [moveddata?](#), [authnot](#), [downgrd?](#), [pubdate](#)

Expanded:

[tmidno+](#), ([chgnum](#), [chgdate](#))?, [chghistory](#), [pretmidno*](#), [volnum?](#), [revnum?](#), [doctype](#), [maintlvl?](#), [prttitle](#), [subtitle?](#), ([mfr+](#), [contractno+](#))?, [seal?](#), [superseded?](#), [suppl*](#), [effdatenot?](#), [volnot?](#), [discl?](#), [distrib](#), [expcont?](#), [destr?](#), [copyright*](#), [cogact?](#), [moveddata?](#), [authnot](#), [downgrd?](#), [pubdate](#)

% inclus

Unexpanded:

[figure](#) | [table](#) | [foldout](#) | [objmedia](#)

Expanded:

[figure](#) | [table](#) | [foldout](#) | [objmedia](#)

% ipbforwd

Unexpanded:

([para0+](#), [ipbmodelcover](#), [ipbserialization?](#), [ipbfinding?](#), [ipbsimassem?](#), [ipbquickchgexpl?](#), [ipbshtnoexpl?](#), [ipbuseonexpl](#), [ipbsmrexpl](#), [ipbhcidesc?](#), [ipbesdsdesc?](#), [ipbpartstd](#), [ipbmfrlist?](#), [para0*](#))

Expanded:

([para0+](#), [ipbmodelcover](#), [ipbserialization?](#), [ipbfinding?](#), [ipbsimassem?](#), [ipbquickchgexpl?](#), [ipbshtnoexpl?](#), [ipbuseonexpl](#), [ipbsmrexpl](#), [ipbhcidesc?](#), [ipbesdsdesc?](#), [ipbpartstd](#), [ipbmfrlist?](#), [para0*](#))

% lepcontents

Unexpanded:

[lepentry+](#)

Expanded:
[lepretry](#)+

% lineatt

Unexpanded:
quad (left | center | right | justify) left
indent CDATA #IMPLIED

Expanded:
quad (left | center | right | justify) left
indent CDATA #IMPLIED

% list

Unexpanded:
[randlist](#) | [deflist](#) | [seqlist](#)

Expanded:
[randlist](#) | [deflist](#) | [seqlist](#)

% lrp

Unexpanded:
(%[parazero](#);; [subpara1](#)*)?, [lrptable](#)?

Expanded:
([title](#), [warning](#)*, [caution](#)?, [note](#)?, ([para](#), [note](#)?)?, ([step1](#), [step1](#)+)?, [subpara1](#)*)?, [lrptable](#)?

% mpl

Unexpanded:
([ipbfigureno](#)?, [ipbfigindex](#), ([partno](#), [ipbpartnosym](#)?, ([ipbcagecodes](#) | [ipbcage](#)), [ipbdesc](#), [ipbunits](#), [ipbuseoncode](#)?, [ipbsmrcodes](#))++)

Expanded:
([ipbfigureno](#)?, [ipbfigindex](#), ([partno](#), [ipbpartnosym](#)?, ([ipbcagecodes](#) | [ipbcage](#)), [ipbdesc](#), [ipbunits](#), [ipbuseoncode](#)?, [ipbsmrcodes](#))++)

% mplatts

Unexpanded:
sepmanual %[yesorno](#); '0'
id ID #IMPLIED
shown %[yesorno](#); '1'
attachpart %[yesorno](#); '0'
marking %[yesorno](#); '0'
kit %[yesorno](#); '0'
quickchgexpl %[yesorno](#); '0'

Expanded:

sepmanual NUMBER '0'
id ID #IMPLIED
shown NUMBER '1'
attachpart NUMBER '0'
marking NUMBER '0'
kit NUMBER '0'
quickchgexpl NUMBER '0'

% nparcon

Unexpanded:

[title](#), [%wcn](#);, [para](#), [note?](#), ([step1](#), [step1+](#))?

Expanded:

[title](#), [warning*](#), [caution?](#), [note?](#), [para](#), [note?](#), ([step1](#), [step1+](#))?

% nparcon1

Unexpanded:

([title](#))?, [%wcn](#);, [para](#), [note?](#), ([step1](#), [step1+](#))?

Expanded:

([title](#))?, [warning*](#), [caution?](#), [note?](#), [para](#), [note?](#), ([step1](#), [step1+](#))?

% para0att

Unexpanded:

emergency [%yesorno](#); '0'
id ID #IMPLIED
esds [%yesorno](#); '0'
nsp [%yesorno](#); '0'
fcp [%yesorno](#); '0'
hcp [%yesorno](#); '0'
hci [%yesorno](#); '0'
ocp [%yesorno](#); '0'
oci [%yesorno](#); '0'
applicref IDREFS #IMPLIED
[%verified](#);
[%secur](#);
[%bodyatt](#);

Expanded:

emergency NUMBER '0'
id ID #IMPLIED
esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED

verstatus (unver | ver | notapplicable) 'unver'
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% paracon

Unexpanded:

(%[text](#); | %[list](#);) +

Expanded:

((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#)) + | [randlist](#) | [deflist](#) | [seqlist](#)) +

% parazero

Unexpanded:

[title](#), %[wcn](#);; (para, [note](#)?)?, (step1, [step1](#)+)?

Expanded:

[title](#), [warning](#)*, [caution](#)?, [note](#)?, (para, [note](#)?)?, (step1, [step1](#)+)?

% pubatts

Unexpanded:

controlno CDATA '00000000'
cycle CDATA 'new'
chglevel NUMBER #IMPLIED
initlabel NUMBER #IMPLIED
initpage NUMBER '1'
docno CDATA #IMPLIED
highguid NUMBER '0'
labelstyle CDATA 'FAN'

Expanded:

controlno CDATA '00000000'
cycle CDATA 'new'
chglevel NUMBER #IMPLIED
initlabel NUMBER #IMPLIED
initpage NUMBER '1'
docno CDATA #IMPLIED
highguid NUMBER '0'
labelstyle CDATA 'FAN'

% rr

Unexpanded:

[appendix*](#), [glossary?](#), [index?](#), [foldsect?](#)

Expanded:

[appendix*](#), [glossary?](#), [index?](#), [foldsect?](#)

% safesum

Unexpanded:

[para0+](#)

Expanded:

[para0+](#)

% sect

Unexpanded:

[title](#), [para0+](#)

Expanded:

[title](#), [para0+](#)

% sectatt

Unexpanded:

[%chapatt](#);

Expanded:

id ID #IMPLIED
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% secur

Unexpanded:

security (u | c | s | n) 'n'

caveat CDATA #IMPLIED
fgi CDATA #IMPLIED

Expanded:

security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED

% service

Unexpanded:

(AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)

Expanded:

(AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)

% status

Unexpanded:

empty | deleted | reserved | notapp

Expanded:

empty | deleted | reserved | notapp

% step1.mdl

Unexpanded:

(%stepcon;,, (step2, step2+)?)

Expanded:

(warning*, caution?, note?, para, note?, (step2, step2+)?)

% step2.mdl

Unexpanded:

(%stepcon;,, (step3, step3+)?)

Expanded:

(warning*, caution?, note?, para, note?, (step3, step3+)?)

% step3.mdl

Unexpanded:

(%stepcon;,, (step4, step4+)?)

Expanded:

(warning*, caution?, note?, para, note?, (step4, step4+)?)

% stepatt

Unexpanded:

```
label CDATA #IMPLIED
sssn CDATA #IMPLIED
id ID #IMPLIED
esds %yesorno; '0'
nsp %yesorno; '0'
fcp %yesorno; '0'
hcp %yesorno; '0'
hci %yesorno; '0'
ocp %yesorno; '0'
oci %yesorno; '0'
applicref IDREFS #IMPLIED
%chgatt;
%verified;
```

Expanded:

```
label CDATA #IMPLIED
sssn CDATA #IMPLIED
id ID #IMPLIED
esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'
```

% stepcon

Unexpanded:

```
%wcn;, para, note?
```

Expanded:

```
warning*, caution?, note?, para, note?
```

% sub1att

Unexpanded:

```
%para0att;
```

Expanded:

```
emergency NUMBER '0'
id ID #IMPLIED
```

esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% sub2att

Unexpanded:
%para0att;

Expanded:

emergency NUMBER '0'
id ID #IMPLIED
esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% sub3att

Unexpanded:
%para0att;

Expanded:

emergency NUMBER '0'
id ID #IMPLIED
esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% subatts

Unexpanded:

%[para0att](#);

Expanded:

emergency NUMBER '0'
id ID #IMPLIED
esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% subfig

Unexpanded:
([graphic](#), [legend?](#))

Expanded:
([graphic](#), [legend?](#))

% subpara3.mdl

Unexpanded:
(%[nparcon1](#);; [subpara4](#)*)

Expanded:
(([title](#))?, [warning](#)*, [caution](#)?, [note](#)?, [para](#), [note](#)?, ([step1](#), [step1](#)+)?, [subpara4](#)*)

suppnotice

Unexpanded:
A suitable reference to this supplement will be made on the title page of the basic publication.

Expanded:
A suitable reference to this supplement will be made on the title page of the basic publication.

% symsect

Unexpanded:
(%[parazero](#);; [subpara1](#)*)?, ([symtitle](#)?, ([symrow](#)+ | ([term](#), [def](#))+))

Expanded:
([title](#), [warning](#)*, [caution](#)?, [note](#)?, ([para](#), [note](#)?)?, ([step1](#), [step1](#)+)?, [subpara1](#)*)?, ([symtitle](#)?, ([symrow](#)+ | ([term](#), [def](#))+))

% tabatts

Unexpanded:
tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) 'all'
colsep %[yesorno](#); '1'
rowsep %[yesorno](#); '0'
orient (port | land1) 'port'
pgwide %[yesorno](#); '1'
cellcont (Continued | Cont) 'Continued'
id ID #IMPLIED
footnotes (page | end) #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NMTOKEN #IMPLIED

rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep %yesorno; '0'
applicref IDREFS #IMPLIED
%verified;
%bodyatt;
%secur;

Expanded:

tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) 'all'
colsep NUMBER '1'
rowsep NUMBER '0'
orient (port | land1) 'port'
pgwide NUMBER '1'
cellcont (Continued | Cont) 'Continued'
id ID #IMPLIED
footnotes (page | end) #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NUTOKEN #IMPLIED
rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED

% tabl

Unexpanded:

[title](#), [tgroup](#)+

Expanded:

[title](#), [tgroup](#)+

% text

Unexpanded:

(#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+

Expanded:

(#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺

% verified

Unexpanded:

verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'

Expanded:

verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'

% wcn

Unexpanded:

[warning](#)^{*}, [caution](#)[?], [note](#)[?]

Expanded:

[warning](#)^{*}, [caution](#)[?], [note](#)[?]

% xtabatts

Unexpanded:

tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) 'all'
colsep [%yesorno](#); '1'
rowsep [%yesorno](#); '0'
orient (port | land1) 'port'
pgwide [%yesorno](#); '1'
cellcont (Continued | Cont) 'Continued'
id ID #IMPLIED
footnotes (page | end) #IMPLIED
applicref IDREFS #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NUTOKEN #IMPLIED
rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep [%yesorno](#); '0'
[%verified](#);
[%bodyatt](#);
[%secur](#);

Expanded:

tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) 'all'
colsep NUMBER '1'
rowsep NUMBER '0'
orient (port | land1) 'port'

pgwide NUMBER '1'
cellcont (Continued | Cont) 'Continued'
id ID #IMPLIED
footnotes (page | end) #IMPLIED
applicref IDREFS #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NUTOKEN #IMPLIED
rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep NUMBER '0'
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED

% yesorno

Unexpanded:
NUMBER

Expanded:
NUMBER