

Attention: Please obey all notices about operation. Safety and repair to avoid getting an electric shock and keep the excellent effect.

1. Keep clean.
2. Use in door.
3. The power must same as located.
4. Power off before adding fog liquid.
5. Power off or pull out plug after use.
6. Non waterproof, if there are some humidity please switch off power and contact distributor.
7. There are no spare parts with machine, please contact distributor or professional.

Avoid fire:

1. Only for adults operate. Equip it over the more attention during operation.
2. Don't spray it to people directly and far away fire.
3. The temperature of smoke is very high so that keep the space between machine and other material things more than 100cm.(surface temperature of machine is 40-80°C, don't touch)
4. Put the machine at a drafty place and don't cover the cool holes to keep the best cool effect. Keep the space between the smoke machine and around things more than 20cm and between smoke machine and tinder more than 20cm. And without easily burnt things within 300cm (far away carpet, board & inflammable) .

Avoid explode:

1. Don't add tinder liquid such as oil, gas, perfume and etc. in fog machine.
2. Pay more attention to all notices sign and operation instructions on all machines.
3. Please use the high quality fog liquid recommended by distributor. Bad quality fog liquid may get blast or spray oil.
4. Often check whether there has enough fog liquid.
5. Get out all fog liquid before transport or post.
6. Don't eat fog liquid otherwise to see the doctor immediately. Use clean water to wash skin and eyes once fog liquid touches them.

Remove package and check:

1. If you check whether all necessary accessories are included in the list. Please contact distributor if there are

2. If you machine and power line to see whether they are correct. Please contact distributor once you find the machine.

3. If you specially the spray mouth.

4. If you and open the cover of liquid can. Please contact distributor once you find the machine and screw the cover of the machine will damage fog machine

5. If you take out the socket of the back of machine.

6. If you take out the liquid can and fix it on the opposite, ask distributor to offer video if don't know how to fix it.

DMX Control:

CH	Function	Value	Description
1	Fogging	0-255	0-100% spray the fog
2	Dimming	0-255	Total dimming
3	LED Red	0-255	LED red dimming
4	LED Green	0-255	LED green dimming
5	LED Blue	0-255	LED blue dimming
6	LED Strobe	0-255	LED strobe from slow to fast, work together with CH2-CH5.
7	LED change	0-255	LED color gradual change, from slow to fast.

The machine has DMX priority function, other functions invalid when there is DMX in.

Wireless remote control:

1. Press FOG button, the machine spray the fog.
2. Press "R" button, red LED light and spray the fog.
3. Press "G" button, green LED light and spray the fog.
4. Press "B" button, blue LED light and spray the fog.