TECHNICAL · PROCEDURE · TAKE-HOME SHEET

Replace the head gasket

A printed reference, not a substitute for the manufacturer's manual.

Before you start

Tools	Torque wrench 5–25 Nm; Plastic scraper; Lint-free cloth; Drain pan
Parts	Head gasket; Head bolts (10); Coolant (5 L)

Hazards

- Coolant is toxic and stays hot for hours after the engine stops.
- A dropped bolt or washer can fall into an oil gallery.

> STOP CONDITION
>
> Stop and do not proceed if any bolt will not reach the specified torque, if a thread is damaged, or if the deck shows a crack or deep score.

Procedure

1. Before you lift the head

Drain coolant; engine cold; photograph the routing.

2. Loosen in reverse sequence

Loosen outside-in, a quarter turn at a time, reverse sequence.

3. Clean the deck and fit the gasket

Clean the deck; fit the gasket dry, tab to the front.

Check: Gasket tab faces the front of the engine.

4. Torque the head bolts

Oil threads; three passes in the numbered sequence.

Check: Wrench clicks at the specified torque on every bolt.

5. Verify before the first start

Re-check sequence, connectors, coolant; run to temperature.

Torque rows and source

Keep this page with page one. The manual remains the authority for the final value.

Deterministic schematic

Head bolt torque sequence

Fastener	Value	Order
Bolt 1	20 Nm	1
Bolt 2	20 Nm	2
Bolt 3	40 Nm	3
Bolt 4	40 Nm	4

This table is rendered from the lesson's structured rows. It is not an illustration and no generated image appears on this page. The manual page remains the authority for the final value.

Schematic text equivalent: Four-row torque table: bolts 1 and 2 at 20 Nm, bolts 3 and 4 at 40 Nm, in the order the manual prints.

Source: `src_gasket_manual` · permission: licensed

Before the first start

Re-check the sequence, confirm every connector is seated, refill coolant, and run the engine to temperature while watching for leaks. If any step was skipped, stop and do not start the engine.