Read encoder targeting status

Reads status register on the GoPiGo and returns the status of the encoder targeting

Syntax

```
read_enc_status()
```

Parameter:

None

Return:

0 if encoder target is reached, else 1

Example

```
from gopigo import *
print read_enc_status()
```